


SECTION 11: PARTS LIST FOR MODEL 998Q




IMPORTANT: For a proper working machine, use Factory Approved Parts. **V-BELTS** are specially designed to engage and disengage safely. A substitute (non OEM) V-Belt can be dangerous by not disengaging completely.

Model 998Q

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	647-0004	Control Handle	55.	736-0270	Bell Washer.265 ID x.75 OD
2.	731-0904A	Upper Control Housing	56.	710-0751	Hex Cap Screw 1/4-20 x.620
3.	16864	6 Spd. Rack Cable Bracket	57.	737-3000	Grease Fitting
4.	731-0620	Control Lever	58.	736-0931	Flat Washer.203 ID x.403 OD
5.	713-0397	Gear Insert	59.	747-0924	Wheel Pin Lock
6.	732-0627	Shift Lever Spring	60.	682-9020A	Caster Assembly RH
7.	731-0924	6 Speed Shift Lever		682-9021A	Caster Assembly LH
8.	731-0905A	Lower Control Housing	61.	682-9024	Caster Bracket Assembly RH
9.	710-1667A	C Sunk Tap Screw #10 x.75 Lg		682-9026	Caster Bracket Assembly LH
10.	731-0906	Cable Mounting Cap	62.	710-1348	Screw 1/4-14 x.500
11.	746-0711B	Drive Cable 51.0	63.	710-1652	Screw 1/4-20 x.625
12.	712-0324	Top Lock Nut 1/4-20	64.	710-0654A	Hex Washer Screw 3/8-16 x 1.0
13.	746-0883	Control Housing	65.	711-1146	Caster Axle
14.	710-1270	Oval C-Sunk Screw	66.	726-0233	Push Nut.25ID x.50OD
15.	746-0557	Control Cable 47"	67.	710-0703	Carriage Screw 1/4-20 x.75
16.	749-0439D	Upper Handle	68.	710-0969	Screw #12-16 x 1.00
17.	720-0284	Wing Nut	69.	736-0232	Wave Washer.531 ID x.781 OD
18.	736-0451	Saddle Washer.320 ID x.830 OD	70.	712-0397	Wing Nut
19.	710-1174	Carriage Bolt 5/16-18 x 2.0	71.	710-0260	Carriage Bolt 5/16-18 x.62
20.	726-0240	Cable Tie	72.	754-0460	Belt 3/8 x 39.24
21.	749-0907B	Lower Handle	73.	656-0613	Pulley Assembly
27.	731-1901	Trail Shield	74.	750-1071	Sleeve Spacer.88 ID x 1.13 OD
28.	732-0842	Trail Shield Wire	75.	750-1070	Sleeve Spacer.88 ID x 1.00 OD
29.	631-0066	Chute Assembly	76.	782-7597	Pivot Bracket
30.	731-1832	Side-Discharge Chute	77.	725-0157	Cable Tie
31.	731-1833A	Mulch Cover	78.	782-7596	Control Arm
32.	782-0078B	Deck 21"	79.	732-0807	Torsion Spring
33.	712-0397	Wing Nut	80.	711-1114	Pivot Shaft
34.	710-0703	Carriage Bolt 1/4-20 x.75	81.	736-0526	Wave Washer 1.38 ID x.88 OD
35.	746-0939A	6 Speed Cable	82.	731-1828	Baffle
36.	782-7574A	Cable Adjustment Bracket	83.	710-0653	Screw 1/4-20 x 3.75
37.	736-0270	Bell Washer.265 ID x.75 OD	84.	748-0377C	Blade Adapter
38.	712-3006	Hex Nut 1/4-20	85.	742-0741	21" Mulching Blade
39.	710-0167	Carriage Screw 1/4-20 x.50	86.	736-0524A	Blade Bell Support
40.	712-0138	Hex Nut 1/4-28	87.	710-1257	Hex Bolt 3/8-24 x 2.5
41.	782-7575A	Cable Mounting Bracket	88.	731-1874	Chute Door
42.	736-0329	Lock Washer 1/4	89.	732-0819	Torsion Spring
43.	756-0625	Cable Roller	90.	726-0111	Push Cap
44.	738-0924	Shoulder Screw.375 ID x 1/4-14	91.	747-0965	Pivot Rod
45.	736-0264	Flat Washer.330 ID x.630 OD	92.	731-1713B	Discharge Chute
46.	714-0104	Cotter Pin	94.	726-0214	Push Cap
47.	732-0306	Compression Spring	95.	736-0366	Flat Washer.640 ID x 1.12 OD
48.	734-1981A	Wheel 9 x 2	96.	741-0685	Flange Bearing
49.	712-0414	Top Lock Tab Weld Nut 1/4-20	97.	712-3004A	Flange Lock Nut 5/16-18
50.	16855	Ratchet Pawl Plate	98.	734-1857	Wheel 7 x 2
51.	10622B	Plastic Spring Ratchet	99.	731-1887	Hubcap - Spoke w/ Hole
52.	748-0381	Pawl RH	100.	731-0981A	Hubcap - Radial Spoke
	748-0188B	Pawl LH	101.	682-3052	Handle Bracket Assembly - RH
53.	738-0137A	Shld Screw.340 ID x.285 OD		682-3053	Handle Bracket Assembly - LH
54.	748-0318	Wheel Ratchet	102.	710-0134	Carriage Screw 1/4-20 x.62

Model 998Q



Model 998Q

Ref. No.	Part No.	Part Description	Ref. No.	Part No.	Part Description
1.	720-0223	Grip	33.	712-0896	Hex Jam Nut 1/4-28
2.	732-0803A	Spring Lever	34.	782-7598	Belt Keeper
3.	738-0529	Shoulder Nut.825 x.165 Lg.	35.	741-0124	Bearing
4.	710-0751	Cap Screw 1/4-20 x.620	36.	732-0849A	Extension Spring
5.	736-0270	Bell Washer.285 ID x.75 OD	37.	750-1050	Flange Spacer
6.	748-0318	Wheel Ratchet	38.	682-0027A	Idler Bracket Assembly
7.	736-0369	Flat Washer.508 ID x 1.0 OD	39.	710-0299	Hex Cap Screw 1/4-28 x 1.0
8.	682-0531	Pivot Arm Assembly	40.	741-0682A	Bearing Sleeve
9.	750-0515	Spacer.510 ID x.70 OD	41.	736-0570	Flat Washer.885 ID x 1.45 OD
10.	741-0978	Sleeve Bearing.504 ID x.830 OD	42.	721-0329	Oil Seal
11.	750-1056	Shoulder	44.	618-0253	Upper Housing Assembly
12.	710-0653	Tap Screw 1/4-20 x.375	45.	782-7601A	Cable Bracket
13.	682-7528	Chain Cover Assembly	46.	741-0690	Bearing
14.	741-0324A	Flange Bearing.506 ID x.590 Lg	47.	736-0616	Thrust Washer.504 ID x.70 OD
15.	682-7526	Transmission Axle Assembly	48.	782-7595	Pivot Bracket
16.	618-0263A	Transmission Assembly	49.	712-0429	Hex Nut 5/16-18
17.	710-0604A	Hex Screw 5/16-18	50.	711-1168	Output Shaft 6T
18.	713-0453	Chain	51.	717-1469	Gear 34T
19.	638-0012	Rear Axle Assembly	52.	741-0674	Bearing
20.	741-0522	Flange Bearing.506 ID x.715 Lg	53.	717-1487	Pinion Shaft 10T
21.	732-0832	Torsion Spring	54.	736-0314	Thrust Washer 3/8 x.70
22.	750-0151	Spacer.550 ID x.750 OD	55.	736-0569	Thrust Washer.388 x.625
23.	710-1315	Screw 3/8-16 x.25	56.	618-0252	Lower Housing Assembly
24.	711-0835	Clevis Pin.50 Dia x 4.82 Lg.	57.	710-0642	Hex Screw 1/2-20 x.75
25.	750-0807	Spacer.385 ID x.624 OD	58.	611-0066	Shaft Assembly
26.	782-0568	Height Adjustment Spring Bracket	59.	664-0076	Grass Bag
27.	710-1652	Screw 1/4-20 x.625	60.	747-0940A	Support Rod w/ Rope Guide
28.	714-0474	Cotter Pin	61.	747-0939	Pivot Rod
29.	712-3025	Hex Jam Nut 5/16-24	62.	747-0937	Grass Bag Frame
30.	736-0425	Bell Washer.325 ID x.930 OD	63.	631-0071	Grass Bag Cover
31.	756-0656	Pulley	64.	726-0106	Cap Nut
32.	736-3084	Flat Washer.510 ID x 1.120 OD	65.	741-0673	Bearing