


REPAIR PARTS
ENGINE, LCT

SNOW THROWER - - MODEL NUMBER 944.520640
COMPLETE ENGINE-428169



REPAIR PARTS

ENGINE, LCT

SNOW THROWER - - MODEL NUMBER 944.520640

COMPLETE ENGINE-428169

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	424932	Heater Box Assy	26a	429236	Manual Start Flywheel Assy (If Equipped)
2	424934	Shield, Heater Box	27	424969	High Oil Fill Tube Assy
3	424937	Snow Muffler Assy	28	420586	Flywheel Fan
4	424938	Snow Fuel Tank Assy	29	420595	Ignition Coil Assy
5	424942	Oversized Fuel Tank Cap	30	420606	Crankcase Cover Assy
6	424944	Snow Carburetor Assy	31	429598	Non Removable Plug
8	424949	Fuel Primer Bulb With Hose	32	424959	Charging Coil DC (If Equipped)
10	424953	Electric Starter Assy (If Equipped)	33	429244	Electric Starter Bracket (If Equipped)
11	424954	Key Switch Assy	34	429246	Spark Plug Boot
12	424955	CDI Box	36	420601	Governor Arm Assy
13	424957	Run/Stop Switch	37	420602	Governor Shaft
15	424958	Choke Lever/Choke Handle (Red)	38	429646	Governor Gear Assy
16	424960	Governor Linkage Shield Plate	39	420584	Camshaft
17	424962	Snow Recoil Starter Assy (Hex Style - Black)	40	420578	Cylinder Head Assy
18	424966	Starter Cup Small	41	424939	Spark Plug
19	424968	Snow Starter Grip	42	424936	CDI Box Bracket
20	424971	Blower Housing Assembly	44	420582	Piston And Rod Assy
		Electric Start -Snow (Black) (If Equipped)	45	429259	Speed Control Bracket
20a	429230	Blower Housing Assembly	46	429260	Vapor Shield
		Manual Start -Snow (Black) (If Equipped)	47	429599	Seal Kit
21	424973	Shield, Cylinder	48	429262	Wire Harness
22	424975	Shield, Flywheel-Electric Start (If Equipped)	49	429600	Crankshaft
22a	429596	Shield, Flywheel-Manual Start (If Equipped)	50	429601	Gasket Kit
23	420580	Valve Cover	51	429602	Crankcase Cover Gasket
25	429597	Fuel Petcock	52	429603	Cylinder Head Gasket
26	429235	Electric Start Flywheel Assy (If Equipped)	53	429604	Valve Cover Gasket
			54	429647	208cc Short Block
			55	429691	Rocker Arm Kit
			56	420579	Push Rod Kit

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm
IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts.
 Failure to do so could be hazardous, damage your snow thrower and void your warranty.