






BELT GUARD AND PULLEY ASSEMBLY

Ref #	Part Number	Qty	Description
1	23230506		SET SCREW
2	130812		ENGINE PULLEY
4	74610812		BOLT.HEX.HEAD
5	17490440		BOLT.ROLLER.1/4-20X2 1/2
6	165770		SHEILD.INNER.GUARD
7	165503		SCREW HX WSH.HD#8-18X1/2
8	139155		SPACER.SPLIT
9	165768X505		GUARD.PNT.BELT
10	109227X		PAD IDLER TI
12	9180R		V BELT STD
13	12000028		SUB= 2267J
14	151223		SHEAVE.TRANS
15	165504		NUT J CLIP #8
16	12000036		KLIP RING TI
17	73350600		NUT
18	161806		"PULLEY, IDLER"
19	162290		"ARM, IDLER"
20	74760620		SUB= 74780620
21	106968X		SHAFT IDLER TI
25	73350500		JAM NUT TI


TILLER - - MODEL NUMBER AYP3352B99

DECALS



Ref #	Part Number	Qty	Description
1	146348		DECAL.CNTRL.PNL.5
2	166629		DECAL, LOGO
3	127521		NLA
4	110594X		DECAL TI
5	120431X		DECAL TI
6	162215		DECAL.TINE.SHIELD
7	165266		SUB= 271948
8	120075X		DECAL TI
9	165278		SUB= 273721
	169768		MANUAL.O.

TILLER - - MODEL NUMBER AYP3352B99
ENGINE, BRIGGS & STRATTON - - MODEL NUMBER 134202, TYPE NO. 1118-E1




Ref #	Part Number	Qty	Description
1	495133		CYLINDER ASSEMBLY
2	399268		BUSHING, CYLINDER
3	299819		SEAL, OIL
5	214040		HEAD, CYLINDER
7	272157		GASKET, CYLINDER HEAD
8	495774		BREATHER ASSEMBLY
9	27549		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	66578		GROMMET, BREATHER TUBE
12	270080		GASKET CRANKCASE STANDARD .015"
12	270125		GASKET, CRANKCASE .005" THICK
12	270126		GASKET, CRANKCASE .009" THICK
13	94221		SCREW, CYLINDER HEAD 2-3/32"
14	94679		SCREW, CYLINDER HEAD 2-15/32"
15	94916		PLUG, PIPE, HEX SOCKET
16	492088		CRANKSHAFT
18	494044		COVER ASSEMBLY, CRANKCASE
19	495660		BUSHING, CRANKCASE COVER
20	294606		SEAL, OIL
21	281658		PLUG-OIL FILLER
21A	399195		SEAL ASSEMBLY, CYLINDER PLUG
22	94682		SCREW
23	399673		FLYWHEEL, MAGNETO
24	222698		KEY, FLYWHEEL
25	399819		PISTON ASSEMBLY
25	393820		PISTON ASSEMBLY-.010 OVERSIZE
25	393821		PISTON ASSEMBLY-.020 OVERSIZE
25	393822		PISTON ASSEMBLY-.030 OVERSIZE
26	393067		RING SET, PISTON
26	399014		RING SET-PISTON-.010 OVERSIZE
26	399015		RING SET-PISTON.020 OVERSIZE
26	399016		RING SET-PISTON-.030 OVERSIZE
27	26026		LOCK, PISTON PIN
28	298909		PIN ASSY, PISTON, STD
28	298908		PIN ASSEMBLY, PISTON .005" OVERSIZE
29	299430		ROD ASSEMBLY, CONNECTING
29	390459		ROD ASSEMBLY, CONNECTING
30	225183		DIPPER-CONNECTING ROD
32	94699		SCREW
33	211119		VALVE, EXHAUST
34	261044		VALVE, INTAKE
35	260552		SPRING, INTAKE VALVE
36	26478		SPRING, EXHAUST VALVE
37	222443		GUARD, FLYWHEEL
40	93312		RETAINER, VALVE SPRING
45	260642		TAPPET, VALVE
46	212733		GEAR, CAM
51	273113		GASKET, CARBURETOR MOUNTING
55	497442		HOUSING, REWIND STARTER
56	498144		PULLEY, REWIND STARTER
58	280399		ROPE, REWIND STARTER (CUT TO 88-5/8)
59	396892		INSERT, HANDLE
60	393152		HANDLE, REWIND STARTER
65	94686		SCREW, HOUSING MOUNTING
73	225176		SCREEN, ROTATING
81	222263		LOCK, SCREW
90	498298		CARBURETOR ASSEMBLY
95	93499		SCREW

Ref #	Part Number	Qty	Description
96	223793		THROTTLE, CARBURETOR
97	497600		SHAFT & LEVER, THROTTLE
109	497230		VALVE & SHAFT GROUP, CHOKE
111	262715		SPRING, CHOKE
121	495606		CARBURETOR OVERHAUL KIT
124	94913		SCREW, TORX HEX
127	220352		PLUG, WELCH
127A	223789		PLUG, WELCH
146	94388		TIMING GEAR KEY
152	260575		SPRING, THROTTLE ADJUSTMENT
154	93527		SCREW, MACHINE, ROUND HEAD
162	490589		SCREW AND COLLAR
163	271935		GASKET, AIR CLEANER MOUNTING
180	495405		TANK ASSEMBLY, FUEL
181	494559		CAP, FUEL TANK
187	231068		PIPE FUEL
190	94924		SCREW, TORX
190A	94919		SCREW, TORX
191	272489		GASKET, FUEL TANK TO CARBURETOR
200	223886		GUIDE, AIR
201	262280		LINK, GOVERNOR
202	262270		LINK, THROTTLE
203	280720		BELL CRANK
205	231520		SCREW, SHOULDER
208	262279		ROD, SPEED CONTROL
209	262948		SPRING-GOVERNOR
216	262359		LINK, CHOKE
219	494845		GEAR, GOVERNOR
220	221551		WASHER THRUST
222	490649		PANEL, CONTROL
227	490374		LEVER ASSEMBLY, GOVERNOR
230	94927		WASHER, GOVERNOR LEVER
256	223813		CRANK, BELL
300	494585		MUFFLER-EXHAUST
304	495759		HOUSING, BLOWER
305	94786		SCREW
306	224820		SHIELD, CYLINDER
307	94680		SCREW, CYLINDER SHIELD
308	224738		COVER, CYLINDER HEAD
332	94877		NUT, FLYWHEEL
333	397358		ARMATURE GROUP
334	93414		SCREW, ARMATURE MOUNTING
337	802592		PLUG, SPARK
346	94896		SCREW, SEMS
356	497833		WIRE GROUND
358	495603		GASKET SET
363	19069		PULLEY, FLYWHEEL
369	263074		SPRING, REWIND STARTER
373	94908		NUT, HEX
383	89838		WRENCH SPARK PLUG
392	262328		SPRING, FUEL PUMP DIAPHRAGM
393	225058		SCREEN-CARBURETOR
394	272538		DIAPHRAGM
414	220982		WASHER
432	221377		CAP, SPRING
433	93265		PIN, DIAPHRAGM COVER
434	213963		COVER, DIAPHRAGM
435	93141		SCREW, DIAPHRAGM

Ref #	Part Number	Qty	Description
455	225121		CUP, STARTER
456	225257		RETAINER SPRING
456A	281503		RETAINER, STARTER
459	281505		PAWL, RATCHET
467	280715		KNOB, CONTROL
524	271485		SEAL, FILLER TUBE
526	94914		SCREW, SEMS, TANK BRACKET MOUNT
527	223786		CLAMP BREATHER TUBE
528	231550		TUBE, BREATHER
529	67838		GROMMET, BREATHER TUBE
535	491435		FILTER, AIR
536	494279		AIR CLEANER KIT
542	94897		SCREW
552	231079		BUSHING, GOVERNOR CRANK
562	94907		BOLT, GOVENOR LEVEL
952	231978		NUT, HEX
608	497830		STARTER ASSEMBLY, REWIND
611	391813		FUEL PIPE AND CLIP ASSEMBLY
613	93935		SCREW, HEX HEAD
614	93306		COTTER, HAIR PIN
616	495243		CRANK, GOVERNOR
621	396847		SWITCH, STOP
623	94943		P/N CONFLICT - CHECK WITH SUPPLIER
634	271853		WASHER, THROTTLE SHAFT, FOAM
635	66538		ELBOW, SPARK PLUG
676	393757		DEFLECTOR, EXHAUST, SIDE OUTLET
679	270382		WASHER, FOAM
680	221839		WASHER, BRASS
741	262992		GEAR, TIMING
779	262570		LINK, SPEED CONTROL
851	493880		TERMINAL, IGNITION CABLE
869	211787		SEAT, INTAKE VALVE, STANDARD
870	263094		SEAT-EXHAUST VALVE-STD
871	262001		GUIDE, EXHAUST VALVE
871	63709		GUIDE, INTAKE VALVE
883	272228		GASKET-EXHAUST
916	280321		RACK, GEAR CONTROL
966	492797		BASE, AIR CLEANER
967	491588		SUB= 3364
968	495872		COVER, AIR CLEANER
969	490073		SCREW, COVER MOUNTING
971	94902		SCREW, HEX HEAD
978	273326		GASKET-COVER
979	494807		COVER-OIL GUARD
982	94658		SCREW-HEX HEAD
987	398970		SEAL, THROTTLE SHAFT
995	225057		LEVER, BRACKET ASSY
1012	490507		RETAINER, LINK
1036	499345		LABEL KIT-EMISSIONS
1095	498529		VALVE OVERHAUL GASKET KIT
2500	134202-1114		REPLACEMENT ENGINE
	495952		SHORTBLOCK


TILLER - - MODEL NUMBER AYP3352B99
ENGINE, BRIGGS & STRATTON - - MODEL NUMBER 134202, TYPE NO. 1118-E1



Ref #	Part Number	Qty	Description
1	495133		CYLINDER ASSEMBLY
2	399268		BUSHING, CYLINDER
3	299819		SEAL, OIL
5	214040		HEAD, CYLINDER
7	272157		GASKET, CYLINDER HEAD
8	495774		BREATHER ASSEMBLY
9	27549		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	66578		GROMMET, BREATHER TUBE
12	270080		GASKET CRANKCASE STANDARD .015"
12	270125		GASKET, CRANKCASE .005" THICK
12	270126		GASKET, CRANKCASE .009" THICK
13	94221		SCREW, CYLINDER HEAD 2-3/32"
14	94679		SCREW, CYLINDER HEAD 2-15/32"
15	94916		PLUG, PIPE, HEX SOCKET
16	492088		CRANKSHAFT
18	494044		COVER ASSEMBLY, CRANKCASE
19	495660		BUSHING, CRANKCASE COVER
20	294606		SEAL, OIL
21	281658		PLUG-OIL FILLER
21A	399195		SEAL ASSEMBLY, CYLINDER PLUG
22	94682		SCREW
23	399673		FLYWHEEL, MAGNETO
24	222698		KEY, FLYWHEEL
25	399819		PISTON ASSEMBLY
25	393820		PISTON ASSEMBLY-.010 OVERSIZE
25	393821		PISTON ASSEMBLY-.020 OVERSIZE
25	393822		PISTON ASSEMBLY-.030 OVERSIZE
26	393067		RING SET, PISTON
26	399014		RING SET-PISTON-.010 OVERSIZE
26	399015		RING SET-PISTON.020 OVERSIZE
26	399016		RING SET-PISTON-.030 OVERSIZE
27	26026		LOCK, PISTON PIN
28	298909		PIN ASSY, PISTON, STD
28	298908		PIN ASSEMBLY, PISTON .005" OVERSIZE
29	299430		ROD ASSEMBLY, CONNECTING
29	390459		ROD ASSEMBLY, CONNECTING
30	225183		DIPPER-CONNECTING ROD
32	94699		SCREW
33	211119		VALVE, EXHAUST
34	261044		VALVE, INTAKE
35	260552		SPRING, INTAKE VALVE
36	26478		SPRING, EXHAUST VALVE
37	222443		GUARD, FLYWHEEL
40	93312		RETAINER, VALVE SPRING
45	260642		TAPPET, VALVE
46	212733		GEAR, CAM
51	273113		GASKET, CARBURETOR MOUNTING
55	497442		HOUSING, REWIND STARTER
56	498144		PULLEY, REWIND STARTER
58	280399		ROPE, REWIND STARTER (CUT TO 88-5/8)
59	396892		INSERT, HANDLE
60	393152		HANDLE, REWIND STARTER
65	94686		SCREW, HOUSING MOUNTING
73	225176		SCREEN, ROTATING
81	222263		LOCK, SCREW
90	498298		CARBURETOR ASSEMBLY
95	93499		SCREW

Ref #	Part Number	Qty	Description
96	223793		THROTTLE, CARBURETOR
97	497600		SHAFT & LEVER, THROTTLE
109	497230		VALVE & SHAFT GROUP, CHOKE
111	262715		SPRING, CHOKE
121	495606		CARBURETOR OVERHAUL KIT
124	94913		SCREW, TORX HEX
127	220352		PLUG, WELCH
127A	223789		PLUG, WELCH
146	94388		TIMING GEAR KEY
152	260575		SPRING, THROTTLE ADJUSTMENT
154	93527		SCREW, MACHINE, ROUND HEAD
162	490589		SCREW AND COLLAR
163	271935		GASKET, AIR CLEANER MOUNTING
180	495405		TANK ASSEMBLY, FUEL
181	494559		CAP, FUEL TANK
187	231068		PIPE FUEL
190	94924		SCREW, TORX
190A	94919		SCREW, TORX
191	272489		GASKET, FUEL TANK TO CARBURETOR
200	223886		GUIDE, AIR
201	262280		LINK, GOVERNOR
202	262270		LINK, THROTTLE
203	280720		BELL CRANK
205	231520		SCREW, SHOULDER
208	262279		ROD, SPEED CONTROL
209	262948		SPRING-GOVERNOR
216	262359		LINK, CHOKE
219	494845		GEAR, GOVERNOR
220	221551		WASHER THRUST
222	490649		PANEL, CONTROL
227	490374		LEVER ASSEMBLY, GOVERNOR
230	94927		WASHER, GOVERNOR LEVER
256	223813		CRANK, BELL
300	494585		MUFFLER-EXHAUST
304	495759		HOUSING, BLOWER
305	94786		SCREW
306	224820		SHIELD, CYLINDER
307	94680		SCREW, CYLINDER SHIELD
308	224738		COVER, CYLINDER HEAD
332	94877		NUT, FLYWHEEL
333	397358		ARMATURE GROUP
334	93414		SCREW, ARMATURE MOUNTING
337	802592		PLUG, SPARK
346	94896		SCREW, SEMS
356	497833		WIRE GROUND
358	495603		GASKET SET
363	19069		PULLEY, FLYWHEEL
369	263074		SPRING, REWIND STARTER
373	94908		NUT, HEX
383	89838		WRENCH SPARK PLUG
392	262328		SPRING, FUEL PUMP DIAPHRAGM
393	225058		SCREEN-CARBURETOR
394	272538		DIAPHRAGM
414	220982		WASHER
432	221377		CAP, SPRING
433	93265		PIN, DIAPHRAGM COVER
434	213963		COVER, DIAPHRAGM
435	93141		SCREW, DIAPHRAGM

Ref #	Part Number	Qty	Description
455	225121		CUP, STARTER
456	225257		RETAINER SPRING
456A	281503		RETAINER, STARTER
459	281505		PAWL, RATCHET
467	280715		KNOB, CONTROL
524	271485		SEAL, FILLER TUBE
526	94914		SCREW, SEMS, TANK BRACKET MOUNT
527	223786		CLAMP BREATHER TUBE
528	231550		TUBE, BREATHER
529	67838		GROMMET, BREATHER TUBE
535	491435		FILTER, AIR
536	494279		AIR CLEANER KIT
542	94897		SCREW
552	231079		BUSHING, GOVERNOR CRANK
562	94907		BOLT, GOVENOR LEVEL
952	231978		NUT, HEX
608	497830		STARTER ASSEMBLY, REWIND
611	391813		FUEL PIPE AND CLIP ASSEMBLY
613	93935		SCREW, HEX HEAD
614	93306		COTTER, HAIR PIN
616	495243		CRANK, GOVERNOR
621	396847		SWITCH, STOP
623	94943		P/N CONFLICT - CHECK WITH SUPPLIER
634	271853		WASHER, THROTTLE SHAFT, FOAM
635	66538		ELBOW, SPARK PLUG
676	393757		DEFLECTOR, EXHAUST, SIDE OUTLET
679	270382		WASHER, FOAM
680	221839		WASHER, BRASS
741	262992		GEAR, TIMING
779	262570		LINK, SPEED CONTROL
851	493880		TERMINAL, IGNITION CABLE
869	211787		SEAT, INTAKE VALVE, STANDARD
870	263094		SEAT-EXHAUST VALVE-STD
871	262001		GUIDE, EXHAUST VALVE
871	63709		GUIDE, INTAKE VALVE
883	272228		GASKET-EXHAUST
916	280321		RACK, GEAR CONTROL
966	492797		BASE, AIR CLEANER
967	491588		SUB= 3364
968	495872		COVER, AIR CLEANER
969	490073		SCREW, COVER MOUNTING
971	94902		SCREW, HEX HEAD
978	273326		GASKET-COVER
979	494807		COVER-OIL GUARD
982	94658		SCREW-HEX HEAD
987	398970		SEAL, THROTTLE SHAFT
995	225057		LEVER, BRACKET ASSY
1012	490507		RETAINER, LINK
1036	499345		LABEL KIT-EMISSIONS
1095	498529		VALVE OVERHAUL GASKET KIT
2500	134202-1114		REPLACEMENT ENGINE
	495952		SHORTBLOCK




Ref #	Part Number	Qty	Description
1	495133		CYLINDER ASSEMBLY
2	399268		BUSHING, CYLINDER
3	299819		SEAL, OIL
5	214040		HEAD, CYLINDER
7	272157		GASKET, CYLINDER HEAD
8	495774		BREATHER ASSEMBLY
9	27549		GASKET, VALVE COVER
10	94621		SCREW, STEMS
11	66578		GROMMET, BREATHER TUBE
12	270080		GASKET CRANKCASE STANDARD .015"
12	270125		GASKET, CRANKCASE .005" THICK
12	270126		GASKET, CRANKCASE .009" THICK
13	94221		SCREW, CYLINDER HEAD 2-3/32"
14	94679		SCREW, CYLINDER HEAD 2-15/32"
15	94916		PLUG, PIPE, HEX SOCKET
16	492088		CRANKSHAFT
18	494044		COVER ASSEMBLY, CRANKCASE
19	495660		BUSHING, CRANKCASE COVER
20	294606		SEAL, OIL
21	281658		PLUG-OIL FILLER
21A	399195		SEAL ASSEMBLY, CYLINDER PLUG
22	94682		SCREW
23	399673		FLYWHEEL, MAGNETO
24	222698		KEY, FLYWHEEL
25	399819		PISTON ASSEMBLY
25	393820		PISTON ASSEMBLY-.010 OVERSIZE
25	393821		PISTON ASSEMBLY-.020 OVERSIZE
25	393822		PISTON ASSEMBLY-.030 OVERSIZE
26	393067		RING SET, PISTON
26	399014		RING SET-PISTON-.010 OVERSIZE
26	399015		RING SET-PISTON.020 OVERSIZE
26	399016		RING SET-PISTON-.030 OVERSIZE
27	26026		LOCK, PISTON PIN
28	298909		PIN ASSY, PISTON, STD
28	298908		PIN ASSEMBLY, PISTON .005" OVERSIZE
29	299430		ROD ASSEMBLY, CONNECTING
29	390459		ROD ASSEMBLY, CONNECTING
30	225183		DIPPER-CONNECTING ROD
32	94699		SCREW
33	211119		VALVE, EXHAUST
34	261044		VALVE, INTAKE
35	260552		SPRING, INTAKE VALVE
36	26478		SPRING, EXHAUST VALVE
37	222443		GUARD, FLYWHEEL
40	93312		RETAINER, VALVE SPRING
45	260642		TAPPET, VALVE
46	212733		GEAR, CAM
51	273113		GASKET, CARBURETOR MOUNTING
55	497442		HOUSING, REWIND STARTER
56	498144		PULLEY, REWIND STARTER
58	280399		ROPE, REWIND STARTER (CUT TO 88-5/8)
59	396892		INSERT, HANDLE
60	393152		HANDLE, REWIND STARTER
65	94686		SCREW, HOUSING MOUNTING
73	225176		SCREEN, ROTATING
81	222263		LOCK, SCREW
90	498298		CARBURETOR ASSEMBLY
95	93499		SCREW

Ref #	Part Number	Qty	Description
96	223793		THROTTLE, CARBURETOR
97	497600		SHAFT & LEVER, THROTTLE
109	497230		VALVE & SHAFT GROUP, CHOKE
111	262715		SPRING, CHOKE
121	495606		CARBURETOR OVERHAUL KIT
124	94913		SCREW, TORX HEX
127	220352		PLUG, WELCH
127A	223789		PLUG, WELCH
146	94388		TIMING GEAR KEY
152	260575		SPRING, THROTTLE ADJUSTMENT
154	93527		SCREW, MACHINE, ROUND HEAD
162	490589		SCREW AND COLLAR
163	271935		GASKET, AIR CLEANER MOUNTING
180	495405		TANK ASSEMBLY, FUEL
181	494559		CAP, FUEL TANK
187	231068		PIPE FUEL
190	94924		SCREW, TORX
190A	94919		SCREW, TORX
191	272489		GASKET, FUEL TANK TO CARBURETOR
200	223886		GUIDE, AIR
201	262280		LINK, GOVERNOR
202	262270		LINK, THROTTLE
203	280720		BELL CRANK
205	231520		SCREW, SHOULDER
208	262279		ROD, SPEED CONTROL
209	262948		SPRING-GOVERNOR
216	262359		LINK, CHOKE
219	494845		GEAR, GOVERNOR
220	221551		WASHER THRUST
222	490649		PANEL, CONTROL
227	490374		LEVER ASSEMBLY, GOVERNOR
230	94927		WASHER, GOVERNOR LEVER
256	223813		CRANK, BELL
300	494585		MUFFLER-EXHAUST
304	495759		HOUSING, BLOWER
305	94786		SCREW
306	224820		SHIELD, CYLINDER
307	94680		SCREW, CYLINDER SHIELD
308	224738		COVER, CYLINDER HEAD
332	94877		NUT, FLYWHEEL
333	397358		ARMATURE GROUP
334	93414		SCREW, ARMATURE MOUNTING
337	802592		PLUG, SPARK
346	94896		SCREW, SEMS
356	497833		WIRE GROUND
358	495603		GASKET SET
363	19069		PULLEY, FLYWHEEL
369	263074		SPRING, REWIND STARTER
373	94908		NUT, HEX
383	89838		WRENCH SPARK PLUG
392	262328		SPRING, FUEL PUMP DIAPHRAGM
393	225058		SCREEN-CARBURETOR
394	272538		DIAPHRAGM
414	220982		WASHER
432	221377		CAP, SPRING
433	93265		PIN, DIAPHRAGM COVER
434	213963		COVER, DIAPHRAGM
435	93141		SCREW, DIAPHRAGM

Ref #	Part Number	Qty	Description
455	225121		CUP, STARTER
456	225257		RETAINER SPRING
456A	281503		RETAINER, STARTER
459	281505		PAWL, RATCHET
467	280715		KNOB, CONTROL
524	271485		SEAL, FILLER TUBE
526	94914		SCREW, SEMS, TANK BRACKET MOUNT
527	223786		CLAMP BREATHER TUBE
528	231550		TUBE, BREATHER
529	67838		GROMMET, BREATHER TUBE
535	491435		FILTER, AIR
536	494279		AIR CLEANER KIT
542	94897		SCREW
552	231079		BUSHING, GOVERNOR CRANK
562	94907		BOLT, GOVENOR LEVEL
952	231978		NUT, HEX
608	497830		STARTER ASSEMBLY, REWIND
611	391813		FUEL PIPE AND CLIP ASSEMBLY
613	93935		SCREW, HEX HEAD
614	93306		COTTER, HAIR PIN
616	495243		CRANK, GOVERNOR
621	396847		SWITCH, STOP
623	94943		P/N CONFLICT - CHECK WITH SUPPLIER
634	271853		WASHER, THROTTLE SHAFT, FOAM
635	66538		ELBOW, SPARK PLUG
676	393757		DEFLECTOR, EXHAUST, SIDE OUTLET
679	270382		WASHER, FOAM
680	221839		WASHER, BRASS
741	262992		GEAR, TIMING
779	262570		LINK, SPEED CONTROL
851	493880		TERMINAL, IGNITION CABLE
869	211787		SEAT, INTAKE VALVE, STANDARD
870	263094		SEAT-EXHAUST VALVE-STD
871	262001		GUIDE, EXHAUST VALVE
871	63709		GUIDE, INTAKE VALVE
883	272228		GASKET-EXHAUST
916	280321		RACK, GEAR CONTROL
966	492797		BASE, AIR CLEANER
967	491588		SUB= 3364
968	495872		COVER, AIR CLEANER
969	490073		SCREW, COVER MOUNTING
971	94902		SCREW, HEX HEAD
978	273326		GASKET-COVER
979	494807		COVER-OIL GUARD
982	94658		SCREW-HEX HEAD
987	398970		SEAL, THROTTLE SHAFT
995	225057		LEVER, BRACKET ASSY
1012	490507		RETAINER, LINK
1036	499345		LABEL KIT-EMISSIONS
1095	498529		VALVE OVERHAUL GASKET KIT
2500	134202-1114		REPLACEMENT ENGINE
	495952		SHORTBLOCK

TILLER - - MODEL NUMBER AYP3352B99


HANDLE ASSEMBLY



Ref #	Part Number	Qty	Description
1	137176X505		HANDLE BRKT
2	72140512		BOLT
3	9266R		SUB= 624A78
4	151473		HANDLE LH
5	73680500		SUB= 73690500
6	19111116		WASHER
7	19121414		WASHER
8	74760516		SUB= 77394
9	74760512		BOLT
10	10040500		LOCKWASHER
11	73220500		NUT.HEX.5/16-18
12	98000129		NUT
13	72140506		BOLT
14	9209R505		PANEL. HANDLE
15	74760524		BOLT.HEX.5/16-1.5
16	151474		HANDLE RH
18	3067J		SUB= 100382K
19	164937		LEVER.CONTROL.TINE
28	19131312		WASHER
33	8206H		GRIP T
34	3070J		SPRING EXT TI

TILLER - - MODEL NUMBER AYP3352B99


TINE ASSEMBLY



Ref #	Part Number	Qty	Description
1	156926		"TINE ASM OUTER,RH"
2	3146R		RETAINER.SPRING
3	156924		"TINE ASM INNER,RH"
4	156923		TINE ASM INNER LH
5	156925		"TINE ASM OUTER,LH"
6	4929H		RIVET.PAN HD.1.75


TILLER - - MODEL NUMBER AYP3352B99

TRANSMISSION



Ref #	Part Number	Qty	Description
1	74760524		BOLT.HEX.5/16-1.5
2	74780652		BOLT HEX 3/8-16
3	19131311		WASHER
5	73800600		NUT
6	9056R505		"SHIELD, TINE"
7	165835		BRACKET.ENGINE.RH
8	165834		BRKT.ENGINE.LH
9	10040500		LOCKWASHER
10	73220500		NUT.HEX.5/16-18
11	74760544		SUB= 74780544
12	151222		SUB= 165808
14	9173R		SPLIT SPACER RT
15	73510500		NUT
16	19091412		WASHER
17	19092016		WASHER
18	10040400		LOCKWASHER
19	74610412		BOLT
20	PARTSIMAGE		REFER TO PARTS IMAGE
20	SUPPLIER		CHECK WITH SUPPLIER

TILLER - - MODEL NUMBER AYP3352B99
WHEEL AND DEPTH STAKE ASSEMBLY



WHEEL AND DEPTH STAKE ASSEMBLY

Ref #	Part Number	Qty	Description
1	9194R		DRILLED RIVET RT
2	74760520		BOLT
3	74760512		BOLT
4	73220500		NUT.HEX.5/16-18
5	10040500		LOCKWASHER
6	73800600		NUT
7	4921H		SPRING.RETAINER
8	1952J		SUB= 1952J500
9	122233X		SUB= 2582J
10	326J		SUB= 4929H
11	74780628		BOLT
13	1951J		SUB= 1951J500
15	5388J		STAKE SPRING TI
16	121117X		BOLT SHOULDER
17	9188R		SUB= 107644X
18	19131311		WASHER
19	9190R		SUB= 9190R500
20	73680600		SUB= 73690600
21	74760516		SUB= 77394
22	73800500		NUT