


16 H.P. HYDROSTATIC YARD TRACTOR

ENGINE MODEL NUMBER 402707, TYPE NUMBER 1211-01

AIR CLEANER AND CARBURETOR

ALL ENGINE PARTS MUST BE PURCHASED THROUGH AND WARRANTY SERVICE PERFORMED BY YOUR LOCAL BRIGGS AND STRATTON DEALER





31

58 GASKET SET

74 PUMP REPAIR KIT

75 CARBURETOR OVERHAUL KIT



Assemblies include all parts shown in frames.

Ref #	Part Number	Qty	Description
1	212706		
2	94289		NUT, WING
3	223579		COVER, AIR CLEANER
4	271271		ELEMENT, AIR CLEANER
5	223472		PLUG, WELCH
6	94166		SCREW
7	398826		BODY, AIR CLEANER
8	491535		CARBURETOR ASSY
9	399535		BODY ASSY - UPPER CARBURETOR
10	271411		GASKET AIR CLEANER
11	93499		SCREW
12	223534		VALVE, CHOKE
14	392673		SHAFT AND LEVER, CHOKE
15	271607		GASKET, CARBURETOR BODY
16	298514		FLOAT, CARBURETOR
17	94152		SCREW, SEMS, HEX HEAD
18	491543		BODY, LOWER CARBURETOR
19	231209		BUSHING, THROTTLE SHAFT
20	221939		VALVE, THROTTLE
21	271412		GASKET, CARBURETOR & INTAKE ELBOE
22	93897		SCREW, SEMS
23	93971		SCREW, SHOULDER
24	280818		CRANK - BELL
25	270884		GASKET, INTAKE MANIFOLD MOUNTING
26	93208		SCREW, SEMS INTAKE MANIFOLDING MOUNTING
27	93970		SCREW, SEMS, CARBURETOR MOUNTING
28	261587		LINK - THROTTLE
29	280319		SPACER, CARBURETOR
30	213290		MANIFOLD, INTAKE
31	93949		SCREW, SEMS
32	262351		SPRING, GOVERNOR
33	491297		LEVER ASSEMBLY, GOVERNOR
34	92278		NUT, HEX
35	222289		WASHER
36	261563		SPRING, GOVERNOR IDLE
37	93853		BOLT, GOVERNOR LEVER
38	261586		LINK - GOVERNOR
39	394538		PLATE ASSY - GOVERNOR CONTROL
40	393815		HOSE (CUT TO SUIT)
41	93053		CLAMP, HOSE, GREEN
44	491538		VALVE ASSEMBLY, CARBURETOR IDLE
45	392672		SHAFT AND LEVER, THROTTLE
46	271013		WASHER, THROTTLE SHAFT
47	26157		SPRING, THROTTLE ADJUSTMENT
48	91920		SCREW, MACHINE, FILLISTER HEAD
49	270988		DIAPHRAGM
50	261358		SPRING, DIAPHRAGM
51	221377		CAP, SPRING
52	261395		SPRING, PUMP
53	223688		COVER, DIAPHRAGM
54	93829		SCREW, DIAPHRAGM COVER
55	271025		GASKET, CARBURETOR
56	270989		DIAPHRAGM, DAMPING
57	280197		BODY, PUMP
58	394501		GASKET SET
59	394019		CARTRIDGE AIR CLEANER
60	224039		SHIELD, SPITBACK
61	223714		CARTRIDGE PLATE, AIR CLEANER


Ref #	Part Number	Qty	Description
62	230896		PIN, FLOAT HINGE
63	394681		VALVE, FUEL INLET
65	231338		JET, NEEDLE VALVE
66	397882		PLUG & SEAL, SOLENOID
67	280474		O-RING
68	490207		CRANK, BELL
69	262375		LINK
73	221535		CLAMP
74	393397		PUMP REPAIR KIT
75	491539		CARBURETOR OVERHAUL KIT
76	223882		WASHER, GOVERNOR CRANK, INSIDE
77	262337		SPRING, COMPRESSION
78	94297		SCREW, PAN HEAD
79	491282		PLATE ASSEMBLY, GOVERNOR CONTROL
80	94298		NUT, SQUARE

16 H.P. HYDROSTATIC YARD TRACTOR

ENGINE MODEL NUMBER 402707, TYPE NUMBER 1211-01

ALTERNATOR AND STARTER MOTOR GROUP

ALL ENGINE PARTS MUST BE PURCHASED
THROUGH AND WARRANTY SERVICE PER-
FORMED BY YOUR LOCAL BRIGGS AND
STRATTON DEALER



Ref #	Part Number	Qty	Description
1	94326		SCREW, AIR CLEANER
2	222673		SCREEN, FLUSH ROTATING
3	230674		NUT, HEX
4	222511		WASHER SPRING
5	222674		CUP - SCREEN MOUNTING
6	491180		FLYWHEEL & RING GEAR ASSY, MAGNETO
7	93535		SCREW, HEX HEAD
8	393537		CONNECTOR ASSEMBLY, TRI-CIRCUIT
9	392595		STATOR, ALTERNATOR
10	93621		SCREW, SEMS
11	391362		GEAR, RING
12	19203		PULLER, FLYWHEEL
13	394891		ARMATURE GROUP MAGNETRON IGNITION
14	93381		SCREW, SEM, ARMATURE MOUNTING
15	221798		TERMINAL, IGNITION CABLE
16	394970		TRIGGER COIL ASSY MAGNATRON
17	93163		SCREW
18	222848		COVER, AIR GUIDE
19	222849		COVER, AIR GUIDE
20	222846		SHIELD, CYLINDER
21	222847		SHIELD, CYLINDER
24	394808		MOTOR, STARTING
25	395537		END CAP ASSY. COMMUTATOR
26	395538		BRUSH ASSEMBLY
27	393825		HOUSING ASSEMBLY
28	94003		BOLT
29	390837		ARRMATURE ASSEMBLY
30	394860		CAP, DRIVE
31	90366		LOCKWASHER
32	91162		SCREW
33	280104		GEAR, STARTER
34	398003		CLUTCH ASSEMBLY
35	393254		RETAINER & PIN
36	94192		ROLL PIN
40	394988		ARMATURE ASSEMBLY
42	396865		DRIVE ASSY
43	223726		RETAINER FAN
44	280815		FAN, FLYWHEEL

Exploded view diagram of a mechanical assembly, likely a camera or projector. The diagram shows various components and their assembly sequence, with parts labeled by numbers and letters.

Key components and parts shown include:

- Top Section:** Components 128, 131, 130, 132, 133, 135, 134, 123, 124, 129, 126, 127, 128, 129, 130, 131, 132, 133, 134, 135.
- Central Section:** Components 46, 49, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 114, 115, 116, 117, 118, 119, 120, 121, 122, 123, 124, 125, 126, 127, 128, 129, 130, 131, 132, 133, 134, 135.
- Bottom Section:** Components 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 114, 115, 116, 117, 118, 119, 120, 121, 122, 123, 124, 125, 126, 127, 128, 129, 130, 131, 132, 133, 134, 135.

Hardware items listed at the bottom:

- A:** 65, 66
- C:** 70
- D:** 71
- E:** 73, 70
- J:** 92, 126
- F:** 72
- G:** 74
- H:** 86, 93, 70
- J:** 75
- K:** 30, 66
- M:** 75, 80, 81
- N:** 136, 137
- O:** 82, 83
- P:** 106, 81
- Q:** 84, 85
- R:** 86, 127, 127
- S:** 87, 70
- T:** 88, 89
- V:** 79, 79, 81
- W:** 90, 91, 42
- X:** 102, 100, 101
- Y:** 79, 81
- Z:** 76, 93, 70
- AA:** 98, 70
- CC:** 30, 104, 66


Ref #	Part Number	Qty	Description
1	110840X		SUB= 140121
2	121247		PAN - SEAT
3	105513X		SUB= 140551
5	121642X392		FENDER
6	106202X		REFLECTOR-TAIL YT
7	121586X		NLA
8	121068X		SPRING T
9	105511X		SUB= 140675
10	121067X		SPRING T
11	105531X		NUT-PUSH YT
12	105509X		SUB= 137113
13	6431J		PAD-SPACER T
14	121221X		SUB= 158990
15	106020X		SUB= 151346
16	3645J		BUSHING OUTLET T
17	8710J		FUEL TANK STEM GT
18	6999R		SUB= 123487X
19	5277J		SUB= 8543R
20	19143210		SPACER WASHER YTH
21	105523X		DASH PANEL T
24	105465X392		FOOTREST LH
25	101892X		DECAL T
26	121215X		DECAL DRIVE BELT
27	108256X		PAD FOOTREST T
28	121306X		SUB= 127866
29	109219X		DEFLECTOR HYT
30	74180512		SCREW
31	121278X		CHASSIS
32	105464X392		FOOTREST RH
33	110828X		SUB= 133748
34	108105X		SUB= 133746
35	110436X		SUB= 9151R
37	121195X		SADDLE
38	1554J		SUB= 155108
40	104805X		LOWER DASH
41	121312X		DASH
42	2029J		WELDNUT
43	121723X011		PLATE DASH
44	19131316		WASHER
46	108372X392		SUB= 132638X424
47	122199X		SUB= 135062
49	122208X		DECAL - HOOD, L.H.
50	106784X		SUB= 155013
51	104618X		SUB= 155013
52	108370X392		SUB= 150301X424
53	109458X		FOAM STRIP T
54	110829X		SUB= 124130X
55	106965X		SUB= 140181
57	108371X392		SUB= 132639X424
58	122209X		DECAL- HOOD, R.H.
59	104613X		SUB= 147717
60	106395X		LENS LT
61	110855X		SUPPORT LH YTH
62	110854X		SUPPORT RH YTH
62	104634X		SUB= 105419X388
64	122100X		GRILL ASSY
65	105529X		SUB= 139888
66	73680500		SUB= 73690500

Ref #	Part Number	Qty	Description
67	74760612		SUB= 74780612
69	19131212		WASHER T
70	73680600		SUB= 73690600
71	17490608		SCREW LT
72	17490612		SCREW
73	19131614		WASHER
74	72140606		BOLT
75	17431008		SUB= 98000165
76	74760616		BOLT
77	121794X		COVER ACCESS
79	19091216		WASHER PM
80	11050400		LOCKWASHER
81	73220400		SUB= 50675
82	74780512		BOLT
83	73510500		NUT
84	17211010		SCREW LT
85	104755X		""""J"" FASTENER LT"
86	17490512		SCREW
87	74760616		BOLT
88	7605J		BOLT T
89	73680400		SUB= 73690400
90	74191008		SCREW
91	10071000		LOCKWASHER
92	17190412		SCREW
93	19131312		WASHER
96	74760612		SUB= 74780612
98	109808X		HOOD LATCH T
99	73731000		NUT
100	7206J		SPACER LT
101	19070818		WASHER
102	74981020		SCREW
104	19111116		WASHER
106	10090400		SUB= 10040400
108	17490616		SCREW GTV
109	2751R		CLIP T
110	108885X		GUARD MUFFLER HYT
111	19131616		WASHER HYT
112	109459X		STRIP - FOAM
113	121144X		SUB= 127018X
115	71616		NLA
116	121236X		SPACER
117	105751X		SUB= 123650X
118	105838X		RETAINER LT
119	105839X		RECEPTACLE LT
120	110853X		SUPPORT RH YTH
121	110852X		SUPPORT LH YTH
112	105419X392		STRAP GRILL
123	120068X		"KNOB 1/2"" YT"
124	19171912		WASHER
125	11050600		LOCKWASHER
126	11030400		LOCKWASHER GT
127	19111216		WASHER M
128	72170410		BOLT
129	121251X		STRIP FORM
130	121250X		SPRING
131	121249X		SPACER SPLIT
132	121246X		BRKT SWITCH
133	121248X		BUSHING

Ref #	Part Number	Qty	Description
134	4171R		CLIP T
135	73900400		NUT T
136	71031012		SCREW
137	73951000		"NUT,KEPS"

16 H.P. HYDROSTATIC YARD TRACTOR
ENGINE MODEL NUMBER 402707, TYPE NUMBER 1211-01
CYLINDER, CRANKSHAFT AND ENGINE BASE GROUP


ALL ENGINE PARTS MUST BE PURCHASED THROUGH AND WARRANTY SERVICE PERFORMED BY YOUR LOCAL BRIGGS AND STRATTON DEALER.



Ref #	Part Number	Qty	Description
1	90576		NUT, HEX
4	27803		GASKET, VALVE COVER
5	92791		WASHERLOCK
6	222892		COVER, BREATHER CYLINDER #2
7	93722		TERMINAL, SPADE
8	93394		SCREW, SEMS, BREATHER, MOUNTING
9	222912		BAFFLE - AIR
10	93777		SCREW, HEX HEAD BACK PLATE TO CYLINDER
11	93158		SCREW, SEMS
12	491247		HOUSING, BLOWER
13	93882		SCREW, SEMS
14	270981		GASKET, CRANKCASE
15	222860		COVER PLATE, CRANKCASE
16	261463		SEAT, INTAKE VALVE, STANDARD
17	210940		SEAT]
18	212462		HEAD - CYLINDER
19	93211		SCREW
21	93686		SCREW, HEX HEAD
22	92290		WASHER, LOCK
23	393415		OIL SLINGER ASSEMBLY
24	260924		LOCK, PISTON PIN
25	394959		RING SET, PISTON, STANDARD SIZE
25	394960		RING SET, PISTON,.010" OVERSIZE
25	394961		RING SET, PISTON,.020" OVERSIZE
25	394962		RING SET, PISTON,.030" OVERSIZE
26	394955		PISTON ASSEMBLY, STANDARD SIZE
26	394956		PISTON ASSEMBLY,.010" OVERSIZE
26	394957		PISTON ASSEMBLY,.020" OVERSIZE
26	394958		PISION ASSEMBLY,.030" OVERSIZE
27	299691		PIN ASSEMBLY, PISTON, STANDARD
27	391286		PIN ASSEMBLY, PISTON .005" OVER
28	394348		GEAR, GOVERNOR
29	222773		WASHER, THRUST
30	393270		ROD ASSEMBLY, CONNECTING
31	92909		SCREW, CONNECTING ROD
32	220863		WASHER
33	291675		SEAL, OIL
34	91084		PLUG OIL DRAIN
35	393552		BASE ASSY - CRANKCASE
36	271868		GASKET, CYLINDER HEAD #2
37	271142		GASKET, CRANKCASE COVER 1/64"
37	271188		GASKET, CRANKCASE COVER,.005"
37	271189		GASKET, CRANKCASE COVER,.009"
38	222698		KEY, FLYWHEEL
39	93585		SCREW, HEX HEAD
40	94296		RETAINER, E-RING
41	491287		SEAL, GOVERNOR SHAFT
42	261560		UPPER BUSHING - GOVERNOR
43	262332		LOWER BUSHING, GOVERNOR
44	491530		CRANK, GOVERNOR
45	223882		WASHER, GOVERNOR CRANK, INSIDE
46	394501		GASKET SET
47	271157		SEAL, FILLER TUBE
48	93469		SCREW, HEX HEAD
49	212337		GEAR, CAM
50	222875		CLAMP, OIL FILLER
51	280224		TUBE, OIL FILLER
52	271170		SEAL, OIL FILLER CAP

Ref #	Part Number	Qty	Description
53	394020		CAP AND DIPSTICK, OIL FILLER
54	394394		DIPSTICK AND TUBE ASSEMBLY
55	390420		VALVE, EXHAUST
56	261528		VALVE, INTAKE
57	231445		GEAR - TIMING
58	393606		SEAL ASSEMBLY AND RETAINER
59	26828		SPRING, EXHAUST VALVE
60	292260		RETAINER, EXHAUST VALVE
61	93630		RETAINER, EXHAUST VALVE ROTOCOIL(2)
62	221596		RETAINER, INTAKE VALVE
63	65906		SPRING, INTAKE VALVE
64	261368		TAPPET, VALVE
65	393382		CRANKSHAFT
66	261961		GUIDE, EXHAUST VALVE
67	394941		CYLINDER ASSY
68	230318		CONNECTOR, IMPULSE PUMP
69	394539		RESISTOR SPARK PLUG
70	66538		ELBOW, SPARK PLUG
71	89838		WRENCH SPARK PLUG
72	280225		TUBE, BREATHER
73	394358		FILTER, FUEL
74	212461		HEAD, CYLINDER
75	271867		GASKET, CYLINDER HEAD #1
76	491304		BACK PLATE ASSEMBLY
77	399265		P/N CONFLICT - CHECK WITH SUPPLIER
78	391086		SEAL, OIL
79	391115		WIRE - GROUND
80	299146		LINE, FUEL, 28"(CUT TO SUIT)
81	93053		CLAMP, HOSE, GREEN
82	393370		BREATHER ASSEMBLY
83	223167		CLAMP, FUEL PUMP
84	221535		CLAMP
85	223890		BRACKET, CABLE
86	93496		SCREW, SEMS


16 H.P. HYDROSTATIC YARD TRACTOR
DIFFERENTIAL AND PUMP ASSEMBLY



Ref #	Part Number	Qty	Description
1	121192X		SUB= 123634X
2	76020312		SUB= 3145
3	121193X		SUB= 123634X
4	121188X		BRACKET
5	74780412		SUB= 74780414
6	121186X		FAN
7	121180X		PULLEY TRANSAXLE
8	121211X		STANDOFF
9	121182X		GUARD ASSY
10			REFER TO IMAGE
11			REFER TO IMAGE
12	74760572		BOLT
13	121323X		PUMP.2003081.
14	73680500		SUB= 73690500
15	121250X		SPRING
16	STD523707		BOLT, 3/8 - 16 X 3/4
17	73680600		SUB= 73690600
18	10040500		LOCKWASHER
19	71673		PLUNGER CAP T
20	7605J		BOLT T
21	120529X		WASHER T
22	73680400		SUB= 73690400
23	19092016		WASHER
24	10040400		LOCKWASHER

18 H.P. HYDROSTATIC YARD TRACTOR


DRIVE



Ref #	Part Number	Qty	Description
1	110012X		BAFFLE - VERTICAL
2	9151R		SNAP BUSHING T
3	110562X		ENGINE 16 H.P. MODEL #402707 TYPE #1211 - 01
4	8545J		SUB= 272250
5	108373X		MUFFLER HYT
6	4497H		RETAINER M
7	10040400		LOCKWASHER
8	17210806		SCREW
9	13200300		ELBOW
10	13280336		PIPE NIPPLE LT
11	91084		PLUG OIL DRAIN
12	121524X		CONTROL THROTTLE
14	108103X		SUB= 120418X
15	2751R		CLIP T
16	121187X		PLATE TRANS SUPT
17	121191X		SUB= 126649X
18	2703J		SUB= 123583X
19	73510600		NUT
20	121189X		U BOLT
21	121199X		SPACER SPLIT
22	121748X		WASHER
23	106108X		SUB= 106108X417
24	12000001		E-RING LT
25	104757X		HUB CAP
27	65139		VALVE STEM LT
28	59192		VALVE CAP
29	74610764		SUB= 71130768
30	19152405		WASHER LT
31	10040700		LOCKWASHER
32	108218X		SUB= 142600
33	109841X		SUB= 136905
35	74760644		BOLT
36	4859J		SUB= 123674X
37	4470J		SPACER T
38	19131312		WASHER
39	105730X		"KEEPER,BLT ENG LT"
40	121218X		KEEPER BELT ENGLH
41	109169X		SUB= 109172X
42	76020412		COTTER PIN
44	106888X		SPRING ROD LT
45	121200X		ROD BRAKE
46	8883R		PEDAL COVER T
47	106918X		ARM BRAKE LT
48	109037X		FOOT SHAFT PEDAL
49	1572H		SUB= 2882J
50	71673		PLUNGER CAP T
51	105844X		SUB= 125637X
52	105710X		"LINK, CLUTCH T"
53	73680600		SUB= 73690600
54	106499X		SUB= 123205X
55	12000039		KLIP RING
56	110812X		WASHER LT
57	105707X		"ASS T, BELLCRAN"
58	105709X		"SPRING, RETURN LT"
59	105724X		SUB= 123102X
60	74760624		SUB= 74930624
61	106298X		SUB= 139245
62	105706X		"LY, BEARING"


Ref #	Part Number	Qty	Description
63	121749X		WASHER
64	228M		KEY WOODRUFF #9
65	17080408		SCREW
66	17490624		SCREW LT
67	11050600		LOCKWASHER
68	74760612		SUB= 74780612
69	74760616		BOLT
70	72140606		BOLT
71	76020412		COTTER PIN
79	10040600		LOCKWASHER
80	122082X		SUB= 918122082X
80A	7152J		TUBE.18X9.5-8
82	108236X		BRACKET LT
83	17021008		SCREW
84	110442X		SUB= 146682
88	19091016		WASHER
89	72140506		BOLT
90	73680500		SUB= 73690500
91	4921H		SPRING.RETAINER
92	17490508		SCREW LT
93	74780412		SUB= 74780414
94	100229L		EXHAUST TUBE T
95	104917X		BAFFLE YT
96	110013X		BRACKET HEAT SHIELD
97	17490508		SCREW LT
98	100091M		SUB= 132922
99	73350600		NUT

16 H.P. HYDROSTATIC YARD TRACTOR
ELECTRICAL




Ref #	Part Number	Qty	Description
1	123198X		SUB= 146525
2	19091016		WASHER
3	102476X		SUB= 150109
4	72240460		BOLT
5	121537X		SUB= 123899X
6	7603J		"TRAY T, BATTERY"
7	121534X		NLA
8	121264X		"CAP,BATTERY "
9	4171R		CLIP T
10	110859X		HARNESS T
11	7662J		SUB= 4152J
12	100541K		SUB= 7697J
13	7192J		WIRE TIE
14	104445X		SWITCH-INTER. GT
15	4206J		CABLE-BATTERY T
16	4406R		SUB= STD365402
18	109788X		SUB= 124211X
19	122147X		KEY
20	109081X		SUB= 146154
21	110712X		SWITCH LT
22	73680400		SUB= 73690400
24	4799J		"CABLE T, BATTERY"
26	719J		SUB= 154336
27	4207J		CABLE T
30	17021008		SCREW
30A	109748X		RELAY ASSY T
31	2751R		CLIP T
32	109596X		HOSE CLAMP T
33	10090400		SUB= 10040400
34	73350400		NUT
35	74780408		BOLT
36	73510400		NUT
37	74760412		BOLT LT
39	73220400		SUB= 50675
40	11050400		LOCKWASHER
43	10040400		LOCKWASHER
45	108824X		FUSE HYT
46	9433R		AMMETER T
47	6009J		SUB= 532131708
48	10101000		SUB= 10071000
49	73911000		NUT
50	19070818		WASHER
51	102501X		SUB= 141940
52	235R		CLIPT
54	106315X		SUB= 135665
55	4021J		SWITCH.PTO.T
56	4022J		HEX NUT T
57	109787X		SUB= 147626
58	121305X		SWITCH SEAT
59	74641008		SUB= 71031008
60	73951000		"NUT,KEPS"
	101539X		SHEET INSTR LT
	101572X		SHEET-INSTRUCTION (FRENCH)
	122316X		NLA
	120663X		SHEET - INSTRUCTION (GERMAN)

16 H.P. HYDROSTATIC YARD TRACTOR




Ref #	Part Number	Qty	Description
70	73680600		SUB= 73690600
87	74760616		BOLT
96	74760612		SUB= 74780612
111	19131616		WASHER HYT
125	11050600		LOCKWASHER

16 H.P. HYDROSTATIC YARD TRACTOR




Ref #	Part Number	Qty	Description
8	17210806		SCREW
19	73510600		NUT
38	19131312		WASHER
53	73680600		SUB= 73690600
65	17080408		SCREW
66	17490624		SCREW LT
67	11050600		LOCKWASHER
68	74760612		SUB= 74780612
69	74760616		BOLT
70	72140606		BOLT
79	10040600		LOCKWASHER
83	17021008		SCREW
88	19091016		WASHER
89	72140506		BOLT
90	73680500		SUB= 73690500

16 H.P. HYDROSTATIC YARD TRACTOR




Ref #	Part Number	Qty	Description
7	73680600		SUB= 73690600
10	105848X		"BOLT, SHOULDER LT"
14	110739X		WASHER T
15	73980600		NUT SPECIAL T
35	72140608		SUB= 72110608
36	72140606		BOLT
40	74780624		"BOLT,HEX"

16 H.P. HYDROSTATIC YARD TRACTOR



Ref #	Part Number	Qty	Description
1	73680600		SUB= 73690600
55	72140506		BOLT
56	19111116		WASHER
57	73680500		SUB= 73690500
58	74760648		BOLT - HEX 3/8 - 16 X 3
59	74110632		SCREW YT
61	19111216		WASHER M
62	74760580		BOLT
65	72140506		BOLT
66	17490612		SCREW
67	72140606		BOLT
70	72110506		SUB= 72270506


16 H.P. HYDROSTATIC YARD TRACTOR



Ref #	Part Number	Qty	Description
31	73680600		SUB= 73690600
33	19131312		WASHER
71	17490508		SCREW LT
89	17490512		SCREW
92	71011012		SCREW.HXHD.10-2
93	73661000		NUT.FLANGE
96	730536K		SUB= 100536K
97	74760612		SUB= 74780612
98	73680500		SUB= 73690500
101	100536K		SHOULDER BOLT LT

16 H.P. HYDROSTATIC YARD TRACTOR

LIFT ADJUSTMENT




Ref #	Part Number	Qty	Description
1	121891X		HDLE ADJ LIFT
2	110807X		NUT T
3	110729X		ROD LIFT LT
4	76020308		SUB= 3145
5	2876H		SPRING T
6	19131016		WASHER
7	73680600		SUB= 73690600
8	19151216		WASHER
9	110810X		TRUNION LT
10	105848X		"BOLT, SHOULDER LT"
11	109413X		GRIP
12	105723X		SUB= 125925X
13	121004X		SUB= 123096X
14	110739X		WASHER T
15	73980600		NUT SPECIAL T
16	4939M		SUB= 85902
17	121006X		LEVER ROD LT
18	4921H		SPRING.RETAINER
19	19171516		WASHER T
20	110029X		LIFT LINK LT
21	121001X		SHAFT LIFT
22	110448X		PIVOT PIN T
23	110447X		SUB= 132793
24	73710700		NUT LOCK YTH
25	12000037		KLIP RING
26	105864X		"BRACKET, SUSPE T"
27	121252X		UPSTOP
28	121600X		SUB= 121598X
29	9135R		SPRING H
30	106308X		SUB= 130171
32	73220800		NUT
33	121601X		SUB= 121599X
34	12000022		E-RING
35	72140608		SUB= 72110608
36	72140606		BOLT
37	19292016		WASHER
38	73350600		NUT
39	73360700		NUT
40	74780624		"BOLT,HEX"

Ref #	Part Number	Qty	Description
1	73680600		SUB= 73690600
2	19131614		WASHER
3	102403X		IDLER-FLAT T
5	106902X		SPACER RETAINER
6	677A451		IDLER-INSIDE T
7	106513X		"WASHER, WEAR LT"
8	121425X		ARM IDLER
9	109776X		PIVOT PIN T
10	106523X		"SUPPORT YT, BAR"
11	106522X		BRACE-IDLER YT
14	121658X		SUB= 136819
15	106214X		GUARD YT
16	106085X		BELT-V.79.1.MWR
17	73220600		NUT.HEX.3/8-16UNC
18	10040600		LOCKWASHER
19	102932X		IDLER.FLAT.GTV
20	106526X		ARM-IDLER YT
21	7644J		SPRING T
22	121705X		JACKSHAFT
24	109599X		BRACKET LH YTH
25	105662X		LINK.PARALLEL
26	4921H		SPRING.RETAINER
27	105744X		"ROD, FRT. PARAL T"
28	109835X		HINGE PIN T
29	109600X		BRACKET RH YTH
30	108119X		GUARD BELT HYT
32	8418J		SUB= 136321
33	121423X		SUB= 144729
34	105304X		CAP-SLEEVE LT
35	106734X		SUB= 123713X
36	110452X		NUT PUSH M
37	109743X		SUB= 137607
38	109785X		DEFLECTOR SHIELD
39	121349X		DECAL WARNING
40	19111016		WASHER
41	109984X		NLA
42	106735X		ROD-HINGE T
43	106635X		SUB= 25034
44	74610624		BOLT.3/8-24X1-1/2
45	19132012		WASHER
46	7631J		RUNNER-LH M
47	109278X		SUB= 123807X
48	108359X		SUB= 123808X
49	108592X		DECAL HYT
50	105185X		DECAL-INST YT
51	72140614		BOLT
52	72140608		SUB= 72110608
53	72140612		BOLT
54	74760620		SUB= 74780620
55	72140506		BOLT
56	19111116		WASHER
57	73680500		SUB= 73690500
58	74760648		BOLT - HEX 3/8 - 16 X 3
59	74110632		SCREW YT
61	19111216		WASHER M
62	74760580		BOLT
65	72140506		BOLT
66	17490612		SCREW

Ref #	Part Number	Qty	Description
67	72140606		BOLT
68	102727X		"SPRING.EXT.8.5""
69	73930600		LOCKNUT
70	72110506		SUB= 72270506
71	72110505		BOLT
72	1685H		SUB= 68478
73	109729X		ROLLER T
74	19151610		WASHER T
75	19151616		SUB= 19171616


16 H.P. HYDROSTATIC YARD TRACTOR

PUMP




Ref #	Part Number	Qty	Description
1	122756X		SHAFT.PU.2003022
2	122716X		RETAINIANG RING-(2003016)
3	122745X		BALL BEARING
4	122715X		SPACER
5	122700X		SEAL LIP
6	122699X		RING.RET.2003052
8	122767X		CRADLE BEARING (2003023)
9	122729X		PLUG
10	122746X		O RING
11	122747X		BEARING
12	122717X		SEAL.9008000-0126
13	122748X		TRUNION ARM (2003005)
14	122749X		GUIDE.2000015.HYD
15	122768X		SUB= 121430X
16	122769X		JOURNAL BRG(2003071)
17	122770X		SUB= 142936
18	122771		SUB= 122771X
19	122772X		CENTER SECTION
20	122773X		NEEDLE BEARING
21	122722X		LIP SEAL-9008000-0127
22	122750X		SHAFT
23	122774X		WASHER
25	122775X		SUB= 121430X
26	122776X		SUB= 121430X
27	122777X		SUB= 121430X
28	122778X		SUB= 121430X
29	122779X		SUB= 121430X
30	122723X		SEAL LIP
31	122780X		CYLINDER BLOCK
32	122781X		CYLINDER BLOCK(70331)
33	122782X		PISTON
34	122784X		PISTON SPRING
35	122785X		WASHER.TR.2003019
37	122786X		PIN
38	122718X		GASKET.20030600
39	122731X		FILTER
40	122730X		WASHER (2000011)
41	122728X		SPRING
42	122706X		PLUG
43	122705X		O RING
44	122702X		BALL
45	122704X		SPRING.2003012.HY
46	122787X		PLUG
47	122752X		SCREW9007314-0808
48	122753X		SCREW
50	122788X		WASHER
51	122789X		PIN
52	122754X		PLUG
53	122711X		O RING
54	122708X		SPRING
55	122709X		SUB= 122712X
56	122712X		BYPAS KT 25130011
57	122710X		O RING (9004175-0027)
58	122727X		ADHESIVE LABEL
59	122790X		PLUG
60	122791X		SPRING
	121430X		PUMP.BDU-10S-114

344 LE94



Ref #	Part Number	Qty	Description
			REFER TO IMAGE


16 H.P. HYDROSTATIC YARD TRACTOR STEERING ASSEMBLY



Ref #	Part Number	Qty	Description
1	122202X		DECAL, STEERING WHEEL INSERT
2	100710L		INSERT-WHEEL LT
3	73940800		SUB= 73360800
4	100712X		SUB= 100712K
5	100713N		SUB= 150547
6	100711L		ADAPTER LT
7	106945X		TUBE YT
8	106943X		SPACER LT
9	122232X		SUB= 132778
10	102670X		SPRING GTV
11	11050600		LOCKWASHER
12	73610600		SUB= 7810H
13	104757X		HUB CAP
14	121274X		KNOB.DUCKHEAD.1/2
15	110845X		ROD.YTH
16	121631X		SPRING TORSION
17	108196X		BRKT CONTROL HYT
18	109557X		STEERING SHAFT T
19	2882J		DRIVE PIN
20	74580		SHAFT SPACER LT
21	71208		BUSHING
22	109432X		SUB= 110150X
23	19212016		WASHER D
24	12000029		RING
25	6266H		WASHER .T
26	108683X		ROD STEERING T
27	108972X		WASHER HYT
28	108684X		GEAR.SECTOR.HYT
29	106126X		KEY-WOODRUFF LT
30	76020412		COTTER PIN
31	73680600		SUB= 73690600
32	108200X		WASHER FRIC HYT
33	19131312		WASHER
34	108518X		BOLT HYT
35	19212016		WASHER D
36	108201X		SPACER HYT
37	121202X		LINK CONTROL
38	108844X		SPRING HYT
39	19132012		WASHER
40	74760648		BOLT - HEX 3/8 - 16 X 3
41	121209X		ARM ASM PUMP
42	105663X		SUPPORT-SADDL T
43	74761060		BOLT LT
44	105664X		SUPPORT.SADDLE.FT
45	105727X		LINK-DRAG LT
46	10040600		LOCKWASHER
47	10040500		LOCKWASHER
48	121334X		ROD TIE
49	73810500		NUT.LOCK.5/16-24
50	105656X		SPINDLE-LH LT
51	19272016		WASHER
52	110438X		BEARING
53	6266H		WASHER .T
54	3366R		COL. SRTG. BEAR.
55	73901000		"NUT-LOC,FLANGE LT"
56	108075X		FRONT AXLE
57	105654X		SUB= 130524
58	278H		FITTING LT

Ref #	Part Number	Qty	Description
59	65139		VALVE STEM LT
60	59192		VALVE CAP
61	9040H		"FLANGE, BEARING"
62	106732X		SUB= 106732X417
63	106222X		SUB= 122073X
63A	59904		TUBE.5.3/4.5/6
65	108212X		TRUNION HYT
66	121750X		ROD ADJ CONTROL
71	17490508		SCREW LT
73	6855M		ZERK M
74	121748X		WASHER
77	108685X		GEAR PINION T
78	109816X		NYLINER T
79	101930X		WASHER YTV
80	4921H		SPRING.RETAINER
81	19131212		WASHER T
82	121749X		WASHER
83	19111216		WASHER M
84	19151516		WASHER
85	110739X		WASHER T
86	121232X		CAP
87	121217X		GUIDE CONTROL
88	121216X		BRKT
89	17490512		SCREW
90	17021008		SCREW
91	19070816		WASHER
92	71011012		SCREW.HXHD.10-2
93	73661000		NUT.FLANGE
94	121204X		BELLCRANK
95	121206X		BRKT BELLCRANK
96	730536K		SUB= 100536K
97	74760612		SUB= 74780612
98	73680500		SUB= 73690500
99	121190X		KEEPER
100	73800600		NUT
101	100536K		SHOULDER BOLT LT
102	4497H		RETAINER M

16 H.P. HYDROSTATIC YARD TRACTOR
TRANSAXLE



Ref #	Part Number	Qty	Description
1	122614X		HSG HALF LH-44077
2	122615X		HSG HALF RH-44076
3	122616X		AXLE LH -44273
4	122620X		AXLE RH-44272
5	122621X		BEARING.44121.AGR
6	122622X		WASHER -44008
7	122623X		GEAR MITER -44096
8	122624X		GEAR MITER -44097
9	122625X		NUT -44133
10	122626X		SHAFT CROSS
11	122627X		SUB= 122688X
12	122629X		SNAP RING -44146
13	122631X		"THRUST, BEARING -44128"
14	122633X		HOUSING.ASM.DIFF.-62590
15	122634X		"FLANGE, BEARING-44129"
16	122640X		GEAR
17	122641X		BOLT -44126
18	122624X		GEAR MITER -44097
19	122643X		SNAP RING -44145
20	122644X		RET RING (44144)
21	122645X		SUB= 155892
22	122646X		"NEEDLE, BEARING 44099"
23	122647X		BEARING.NEE.44139
24	122648X		WASHER-44109
25	122649X		KEY.44136.HYDRO
26	122650X		SCREW
27	122651X		SUB= 155892
28	122652X		WASHER -44125
	122653X		WASHER -44150
	122654X		WASHER-44151
29	122656X		PIN COTTER -44101
30	122658X		NUT -44142
31	122659X		WASHER FLAT -44130
32	122660X		ARM BRAKE 23710
33	122662X		PIN BRAKE ACTUATO -44127
34	122663X		BRAKE YOKE
35	122664X		DISC BRAKE -(44090)
36	122665X		SUB= 123065X
37	122666X		SCREW -44277
38	122667X		PLATE PUCK -44134
39	122668X		SUB= 142883
40	122669X		SUB= 123066X
41	122670X		SCREW -44123
42	122671X		SCREW -44124
43	122672X		"BALL, BEARING -44147"
44	122673X		"BALL, BEARING -44232"
45	122674X		SHAFT PINION 44083
46	122675X		SHAFT DRIVE-44080
47	122676X		SUB= 123059X
48	122677X		SUB= 123060X
49	122678X		NLA
50	122679X		SUB= 122689X
51	122680X		SUB= 121839X
52	122681X		SUB= 126975X
53	122682X		NUT -43178
54	122683X		PINION-DR.44079
55	122684X		BOLT SQ HD
56	122685X		WASHER -44278

Ref #	Part Number	Qty	Description
57	122686X		WASHER -44137
58	122687X		PIN ROLL-44269
59	122688X		SCREW-STUD -44271
60	122689X		SPACER -23711
61	122690X		SUB= 123063X
62	122691X		WASHER, 1/4" STD. PLTD.
	121431X		TRANSAXLE.AGRIFAB