




22" ROTARY LAWN MOWER MODEL NO. 56sfe


PRODUCT NO. 954 05 09-01

REPAIR PARTS

Rev. 0

Ref. No.	Part No.	Part Name	Ref. No.	Part No.	Part Name
1	532 85 07-88	Trim Plate Decal	39	532 08 78-87	Axle Arm Assembly
2	532 80 07-46	Control Bar	40	532 06 23-35	Belleville Washer
3	532 85 07-24	Handle Grip	41	532 08 49-21	Shoulder Bolt 3/8-16
4	532 08 54-36	Hex Washer Head Machine Screw 1/4-20 x 1 1/2	42	532 08 69-43	Wheel & Tire Assembly 9.0 x 2.0
5	532 80 05-47	Trim Plate	43	532 05 21-60	Washer
6	532 85 10-28	Upper Handle	44	532 08 51-79	Retainer Clip
7	532 03 69-53	Self Tapping Screw 10-24 x 5/8	45	532 85 08-45	Hubcap
8	532 06 36-01	Locknut 1/4-20	46	532 80 03-68	Wheel Adjusting Bracket (LF/RR)
9	532 80 04-84	Lower Handle	47	532 85 09-98	Thread Rolling Screw 3/8-16 x 1
10	532 05 87-14	Handle Bolt	48	532 85 12-19	Engine Washer
11	532 85 14-64	Throttle Control	49	532 85 10-00	Belt Snubber
12	532 08 57-23	Washer	50	532 10 73-39	Danger Decal
13	532 06 64-26	Wire Tire	51	532 80 11-03	Lawn Mower Housing (Incl. Ref. #50)
14	532 80 03-57	Rope Guide	52	532 08 79-30	Guide Clip (Housing)
15	532 06 36-88	Handle Knob	53	532 75 00-97	Hex Washer Head Screw 10-24 x 1/2
16	532 85 11-85	Round Head Screw 1/4-20 x 2 3/4	54	532 08 75-88	Front Baffle
17	532 75 04-33	Side Baffle	55	532 85 07-95	Housing Stripe Decal
18	532 80 10-12	Discharge Baffle	56	532 85 10-84	Hex Head Screw 3/8-24 x 1 3/8 Grd. 8
19	532 08 63-44	Hex Head Screw 10-24 x 1/2	57	532 85 02-63	Helical Lockwasher 3/8
20	532 08 12-83	Self Tapping Screw 10-24 x 3/8	58	532 85 10-74	Hardened Washer
21	532 05 45-83	Hex Tapping Screw 1/4-20 x 1/2	59	532 85 09-73	22" Blade
22	532 80 11-04	Back Plate	60	532 85 09-77	Blade Adapter
23	532 04 19-45	Thread Screw 10-24 x 1/2	61	532 80 03-93	Catcher Frame Assembly
24	532 08 75-97	Rear Baffle	62	532 05 17-93	Hairpin Cotter
25	532 06 91-80	Locknut	63	532 75 03-28	Hinge Rod
26	532 75 10-83	Rear Skirt	64	532 80 10-97	Rear Door
27	532 05 51-87	Thread Cutting Screw 5/16-18 x 3/4	65	* 532 22 33-89	Muffler Deflector
28	532 06 31-24	Locknut	66	* 532 09 37-05	Screw 8-32 x 3/8
29	532 08 86-52	Hinge Screw	67	* 532 21 31-46	Cable Clamp
30	532 07 44-00	Locknut	68	532 10 74-88	Thread Rolling Screw 10-32 x 5/8
31	532 06 62-38	Carriage Bolt	69	532 08 76-77	Hi-Pro Key
32	532 85 07-84	Handle Bracket Assembly (Right)	70	532 05 97-08	Set Screw 1/4-20 x 5/16
33	532 85 07-85	Handle Bracket Assembly (Left)	71	532 08 45-96	Engine Pulley
34	532 80 03-70	Wheel Adjusting Bracket (LR)	72	532 05 17-93	Grass Bag Assembly
35	532 08 49-20	Spacer	73	532 80 05-69	Engine Decal
36	532 08 83-48	Washer	74	*	Engine - Briggs/Stratton Model No. 124707 Type No. 3120-01
37	532 85 08-63	Selector Spring			Owners Manual
38	532 07 78-65	Selector Knob			

*These Parts must be purchased through an authorized Briggs and Stratton Dealer.



22" ROTARY LAWN MOWER MODEL NO. 56sfe


PRODUCT NO. 954 05 09-01

REPAIR PARTS


Rev. 0

Ref. No.	Part No.	Part Name	Ref. No.	Part No.	Part Name
1	532 08 56-92	Machine Screw 1/4-20 x 2 1/8	19	532 05 43-38	Hex Head Bolt 1/4-20 2 3/4
2	532 06 36-01	Locknut 1/4-20	20	532 06 15-28	Flat Head Machine Screw 1/4-20 x 3/4
3	532 85 10-98	Engine Zone Control Cable	21	532 06 36-01	Locknut 1/4-20
4	532 06 36-01	Locknut 1/4-20	22	532 08 60-12	Drive Shaft Cover
5	532 85 10-97	Drive Control	23	532 75 01-08	Hex Washer Head Tapping Screw 10-24 x 3/8
6	532 08 56-92	Machine Screw 1/4-20 x 2 1/8	24	532 08 37-00	Cable Clamp
7	532 08 36-91	V-Belt	25	532 07 51-92	Spring
8	532 80 03-66	Wheel Adjuster Assembly (Right)	26	532 05 70-76	Woodruff Key #213
9	532 80 03-63	Wheel Adjuster Assembly (Left)	27	532 06 59-92	Woodruff Key #3
10	532 07 78-65	Selector Knob	28	532 04 81-84	Gear Case Assembly
11	532 07 64-01	Dust Cover	29	532 06 80-38	Locknut
12	532 07 45-07	Pinion	30	532 08 36-32	Spring
13	532 05 37-53	E-Ring	31	532 08 36-81	Drive Pulley
14	532 08 69-54	Wheel & Tire Assembly 8.0 x 2.0	32	532 07 49-76	Retaining Ring
15	532 08 69-60	Wheel Bushing	33	532 75 00-97	Hex Washer Head Screw 10-24 x 1/2
16	532 05 21-60	Washer	34	532 85 08-27	Drive Cover
17	532 08 51-79	Retainer Clip	35	532 08 76-66	Self Tapping Screw 10-24 x 2 3/4
18	532 85 08-44	Hubcap	36	532 80 05-75	Drive Cover Decal

GEAR CASE ASSEMBLY PART NUMBER 751001



Ref. No.	Part No.	Part Name	Ref. No.	Part No.	Part Name
1	532 05 38-38	Keys Locknut 1/4-20	12	532 08 78-22	Grooved Pin 1/8 x 3/4
2	532 08 51-78	Adjusting Bracket	13	532 08 64-47	Plug
3	532 08 83-86	Shifter Assembly	14	532 08 36-59	Helical Gear
4	532 05 70-72	Seal	15	532 75 04-36	Jaw Clutch
5	532 05 73-88	Grooved Pin 1/8 x 1/2	16	532 75 03-55	Grease
6	532 04 80-32	Gear Case Halves (Inc. Upper & Lower Halves) (Incl. Ref. 4, 5, 7)	17	532 05 37-53	E-Ring
7	532 07 78-81	Bearing	18	532 85 08-48	Hi-Pro Key
8	532 07 70-39	Spring Bracket	19	532 08 37-20	Worm Shaft
9	532 75 04-30	Drive Shaft	20	532 06 56-92	Woodruff Key #3
10	532 05 70-79	Hardened Washer	21	532 08 36-80	Worm
11	532 07 51-44	Yoke Clutch	22	532 05 09-50	Hex Head Mach. Screw 1/4-20 x 1 1/4
			23	532 75 10-46	Identification Tag



Ref. No.	Part No.	Part Name
1	532 80 04-10	Battery Bracket
2	532 80 04-11	Battery Cover
3	532 04 80-68	Battery Kit (Incl. Ref. #5 & 7)
4	532 75 00-97	Hex Washer Head Screw 10 - 24 x 1/2
5	532 08 63-53	Connector Mounting Clip
6	532 11 15-49	Battery Charger
7	532 08 66-49	Battery Pad