

## RIDING MOWER - -CATALOG NO. WE261 (96024000102) SCHEMATIC

SCH21



RIDING MOWER - -CATALOG NO. WE261 (96024000102) ELECTRICAL




## RIDING MOWER - -CATALOG NO. WE261 (96024000102) ELECTRICAL

KEY	PART	
NO.	NO.	DESCRIPTION
1	532 43 70-70	BATTERY
2	532 42 54-16	FOAM, POLYURETHANE
3	532 19 33-50	SWITCH, IGN, DLTA, P-IN, ROS
4	532 41 19-33	KEY, MOLDED ENGLISH/SPANISH
	532 41 19-35	KEY, MOLDED ENGLISH/FRENCH/INTERNATIONAL
5	532 43 33-30	FUSE, 5A
6	532 42 59-37	FUSE, 40A
7	532 16 07-84	SWITCH, PLUNGER, NO, OLIVE
8	532 43 15-42	RELAY, 40A
9	532 10 95-53	SWITCH, INTLK,CL, MWR, GRY
10	532 17 61-38	SWITCH, INTERLOCK, NONC, GRAY
11	532 43 18-46	MODULE, STARTING, RECOIL, LRV
12	532 19 27-49	SWITCH, SEAT, DP, ROS
13	532 42 84-77	HARNESS, IGN, ELECTSTART, LRV
14	532 10 97-48	RELAY

NOTE: All component dimensions given in U.S. inches 1 inch = 25.4 mm


CHASSIS



KEY NO.	PART NO.	DESCRIPTION
1	532 42 80-48	WELDMENT, CHASSIS
2	532 42 82-47	SUPPORT, AXEL LH
3	532 42 82-44	SUPPORT, AXEL RH
4	532 42 83-46	SHIELD, TRANSAXLE FRONT
5	532 42 81-10	BRACE, AXLE CROSS
6	532 42 81-09	COVER, FRICTION DRIVE
7	532 42 80-40	PLATE, ENGINE
8	532 42 85-76	BRACKET, CHASSIS FRONT
9 10	532 42 88-56 532 19 55-30	BRACKET, STEERING SUPPORT PAN, SEAT
11	532 17 46-48	BRACKET, SWITCH MOUNTING
12	532 42 82-48	BOOT, DUST
13	532 43 64-96	COVER, FOOT REST
14	532 42 82-50	STRUCTURE, FOOT REST
15	532 42 82-49	SUPPORT, FOOT REST
16	532 43 64-97	FENDER, CONTROL
17	532 42 83-48	GUARD, ENGINE
18		ENGINE, (NON-CALIFORNIA) 121S07-2415-F1 (438154)
		(ORDER PARTS FROM ENGINE MANUFACTURER)
		ENGINE, (CALIFORNIA) 121S07-1415-F1 (432389) (ORDER PARTS FROM ENGINE MANUFACTURER)
		ENGINE, (CANADA) 12S907-1463-B1 (435674)
		(ORDER PARTS FROM ENGINE MANUFACTURER)
19	532 42 89-86	KEEPER, BELT
20	532 42 80-46	BRACKET, BATTERY
21	532 42 98-15	LEVER, SWITCH
22	532 42 88-26	DECK CLUTCH ASM
23	532 14 98-46	KNOB
24	532 41 63-58	SCREW, NO. 10
25 26	872 14 04-24 873 51 04-00	BOLT, CARRIAGE 1/4-20 X 3 NUT, 1/4-20
20	532 43 00-87	SPACER, ENGINE
28	532 42 83-01	DISC, FRICTION ASM
29	532 43 08-17	BOLT, SCKT HD 3/8-24 X 1 .25
30	532 43 04-70	BEARING
31	532 43 73-22	SPACER, NEUTRAL
32	532 15 04-06	BOLT, 3/8-16 X .280
33	532 12 41-81	SPRING, SEAT
34	532 12 12-50	SPRING
35 36	872 05 04-12 532 12 70-18	BOLT, 1/4-20 X 1 1/2 BOLT, SHOULDER
37	819 17 19-12	WASHER, 17/32 X 1 3/16
38	532 16 63-69	KNOB, SEAT
39	532 13 43-00	SPACER
40	532 12 12-48	BUSHING, NYLON SNAP
41	532 12 39-76	NUT, LOCK
42	532 17 18-52	BOLT, 5/16-18 SHOULDER
43	873 80 05-00	NUT, 5/16-18
44 45	532 42 82-43 817 00 05-12	SEAT BOLT 5/16 19 X 3/4
45 46	817 49 05-08	BOLT, 5/16-18 X 3/4 BOLT, 5/16-18 X 1/2
40	532 08 67-77	SCREW
48	532 40 89-81	BEARING, FLANGE, BALL
49	817 06 05-16	SCREW, 5/16-18 X1
50	532 16 54-92	BOLT, SHOULDER, 5/16-18 X .561
52	532 14 50-06	CLIP PUSH-IN HINGED

NOTE: All component dimensions given in U.S. inches 1 inch = 25.4 mm


DRIVE



## DRIVE

	/ PART			PART	
NO.	NO.	DESCRIPTION	NO.	NO.	DESCRIPTION
	532 43 61-44	SERVICE KIT, TRANSAXLE	41	819 09 12-10	WASHER FLAT
1	532 43 64-98	WHEEL ASM (REAR)	42	532 16 60-02	WASHER, SERRATED
2	532 12 17-48	WASHER, 16 GA.	43	873 68 04-00	NUT. CROWN LOCK 114-20
3	812 00 00-01	E-CLIP	45	817 49 04-36	SCREW 1/4-20 X 2 114
4	532 12 35-83	KEY. SQUARE	46	819 09 10-16	WASHER
5	532 42 79-39	WELDMENT. DRIVE AXLE	47	817 49 04-20	SCREW, 1/4-20 X 1 1/2
6	532 42 80-69	CHAIN DRIVE	48	532 43 02-49	PLATE BRAKE ANTI-ROTATE
7	532 42 78-73	SPROCKET.9TOOTH SPLINED	49	532 43 02-45	SPRING, BRAKE RETURN
8	812 10 00-09	RING, SNAP	50	532 42 80-21	ARM, BRAKE
10	532 42 88-76	DIFFERENTIAL ASM	51	532 43 02-47	SPACER RETURN
11	532 00 13-70	WASHER, THRUST	52	532 42 80-78	CALIPER, BRAKE ASM
12	532 43 06-45	CHAIN, PRIMARY DRIVE	53	877 01 08-10	PIN, DOWEL 1/4
13	532 43 08-45	BUSHING	54	532 42 80-19	PLATE, BRAKE PAD
14	532 43 85-68	BRACKET, CARRIER	55	532 42 80-17	PUCK BRAKE
15	532 12 47-93	BEARING ASM	56	532 43 52-53	ROTOR, BRAKE
16	532 42 79-26	SHAFT INPUT	57	532 42 80-16	CAP, BRAKE CALIPER
17	532 43 72-81	WHEEL, FRICTION A5M	58	532 12 47-88	PIN, RETAINER
18	532 42 47-59	ARM, SHIFT	59	817 49 05-08	BOLT, 5/16-16 X 112
19	532 43 08-70	ROD, BYPASS	60	532 44 08-55	CABLE, BRAKE
20	532 42 79-97	BRACE CARRIER REAR	61	532 42 79-45	WELDMENT, PEDAL
21	532 42 80-77	SPRING, CARRIER	62	532 42 96-78	ROD, PARKING BRAKE
22	532 42 80-76	SPRING, BRAKE	63	877 10 08-12	PIN, .25 X .75 CLEVIS
23 24	532 43 13-74 532 42 79-95	SPRING, BYPASS BRACE CARRIER BOX	64 65	532 42 10-76 532 42 93-25	PIN, COTTER 5/64 X 3/4 BRACKET, BRAKE SUPPORT
24 25	532 42 79-95 532 42 83-03	LINK, SHIFT	66	532 42 93-25 532 42 96-94	COVER PEDAL
25	532 42 98-16	ARM. CLUTCH	67	532 42 96-93	COVER PEDAL COVER, BRAKE PEDAL
20	532 41 48-52	WELDMENT SHIFT LEVER	68	817 49 04-06	SCREW. 1/4-20 X 3/8
28	532 42 83-02	SUPPORT. SHIFT LEVER	69	532 42 80-70	BRAKE CABLE MOUNT
29	532 17 48-40	WASHER, NYLON	70	817 00 05-12	BOLT, 5/16-18 X 3/4
30	532 18 39-00	HUB SHIFT LEVER	71	532 43 64-99	CAP HUB AXLE
31	532 42 90-55	SPACER, NYLON	72	812 00 00-02	E RING #5133-62
32	532 42 84-64	MNTG BRKT. SHIFT ARM	73	532 42 95-19	SPROCKET II TOOTH SPLINED
33	532 42 84-61	BRACKET, SHIFTER FLEX	74	532 43 78-41	TENSION LRV CHAIN
34	532 42 84-62	TUBE SHIFT ARM	75	532 43 34-95	SPROCKET IDLER
35	532 41 15-55	GRIP, HANDLE			
36	872 11 04-06	BOLT CARRIAGE - 114-20 X 3/4			
37	873 80 04-00	NUT NYLON LOCK 114-20			
38	532 16 54-92	BOLT, SHOULDER			
39	874 78 04-12	BOLT, 1/4-20 X 3/4	NOT		t dimensions given in U.S. inches
40	810 04 04-00	WASHER, LOCK	NUT	1 inch = 25.4 i	


33



KEY PART NO. NO.	DESCRIPTION
1 532 43 65-	
2 812 00 00- 3 532 18 89-	
4 532 12 17-	
5 532 43 53-	
6 532 12 49-	,
7 532 12 49-	37 BUSHING, STEERING COLUMN
8 532 42 10-	
9 819 13 14-	
10 532 42 80-	
11 532 42 80-	
12 532 42 80- 13 874 78 05-	
14 819 13 10-	
15 873 80 05-	
16 532 42 80-	
17 532 42 82-	52 SUPPORT, UPPER STEERING
18 532 19 52-	
19 817 00 05-	
20 532 42 80-	
21 532 42 83- 22 532 42 82-	
22 532 42 82- 23 532 43 77-	
24 819 18 38-	
25 873 94 08-	
26 532 44 16-	
27 532 44 16-	
28 532 19 98-	
29 532 43 53-	
30 532 43 64-	
31 819 34 32- 45 532 16 54-	
40 032 10 54-	92 DULI SHOULDER 5/10 - 18 X .301

**NOTE:** All component dimensions given in U.S. inches 1 inch = 25.4 mm


RIDING MOWER - -CATALOG NO. WE261 (96024000102) MOWER DECK



RIDING MOWER - -CATALOG NO. WE261 (96024000102) MOWER DECK

KEY NO.	PART NO.	DESCRIPTION
	532 42 81-93	DECK, 26"
	532 19 28-70	MANDREL ASM
	532 43 25-20	KEEPER, BELT
	532 43 25-94	PULLEY, MANDREL
	532 42 85-78 532 42 82-42	BELT COVER, MANDREL
	532 42 93-95	LIFT ASM, DECK
	532 42 91-95	LINK, DECK LIFT
	532 42 93-97	LINK, ADJUSTABLE
	532 43 89-23	DEFLECTOR
	532 42 89-68	SUPPORT, DEFLECTOR
12 4	532 13 14-91 532 19 70-26	ROD, HINGE
13 :	532 19 70-26 532 41 88-63	SPRING, TORSION
14 :	232 41 88-03 873 00 05-00	ARM, MOWER SUPPORT NUT, LOCK
16 1	532 19 51-61	STUD
17 8	532 41 88-63 573 90 05-00 532 19 51-61 819 19 19-12	WASHER
17 18 19	532 19 42-09	PIN
19 (		BOLT, SHOULDER
20 5	532 19 42-08	PIN
	819 17 19-12	WASHER, 17/32 X 1 3/16
	532 42 93-50 873 90 06-00	LINK, DECK NUT, LCK 3/8-16
23 0	532 42 95-31	SPRING, DECK
	532 12 47-88	PIN
	532 18 76-90	SPACER, MANDREL
27 !	532 17 39-84	BOLT, MANDREL
28 3	532 40 02-34	NUT, LOCK
29	532 40 02-54	BLADE
30 ;	532 19 30-03 532 19 31-97	BOLT, BLADE PULLEY, IDLER
32		GUARD, IDLER
	532 19 34-14	KEEPER, BELT IDLER
	872 11 06-12	BOLT, 3/8-16 X 1 1/2
34 8 35 9	532 19 94-70	ARM, BRAKE
	532 13 77-29	SCREW, 1/4-20 X 5/8
	873 90 06-00	NUT, 3/8-16 FLANGE
	532 42 84-35	ARM, IDLER
	817 49 05-08 819 17 16-16	BOLT, 5/16-18 X 1/2 WASHER, 16 GA.
		CAP, SLEEVE
	532 11 04-52	NUT, PUSH
		GRIP, HANDLE
44 <u>4</u> 45 4	532 42 94-01	PLUNGER
	532 10 57-67	PIN
46		KEEPER, BELT
47 ±	532 12 45-20 532 10 00 02	BUTTON PLUNGER SPACER RETAINER
	817 00 06-16	SCREW 3/8-16 X 1
51 !	532 40 47-42	BUMPER
64	817 67 06-08	SCREW THDROL 3/8-16 X 1/2

**NOTE:** All component dimensions given in U.S. inches 1 inch = 25.4 mm



KEY	PART	
NO.	NO.	DESCRIPTION
1	532 43 05-88	DECAL, STEERING WHEEL
2	532 43 35-96	DECAL, V-BELT SCH 30"
3	532 42 51-13	DECAL, WARN. DEFLECT/CTFGR
4	532 44 07-79	DECAL, DECK/DEFLECTOR
6	532 43 67-55	DECAL, WARNING
7	532 43 44-57	DECAL, WARNING ENGINE
8	532 43 73-12	DECAL, STDSRRD
	532 43 24-79	DECAL, BYPASS
	532 44 39-90	MANUAL OWNER ENGLISH
	532 44 39-91	MANUAL OWNER SPANISH

**NOTE:** All component dimensions given in U.S. inches 1 inch = 25.4 mm