


ROTARY LAWN MOWER - - MODEL NUMBER 96114000200



ROTARY LAWN MOWER - - MODEL NUMBER 96114000200

KEY NO.	PART NO.	DESCRIPTION
1	189199	Lawn Mower Housing (Includes Key Number 38)
2	194177X428	Control Bar
3	179585	Rope Guide
4	194179X479	Upper Handle
5	169708X479	Lower Handle
6	87584X004	Shoulder Bolt 5/16-18 x .51
7	191574	Handle Bolt 5/16-18
8	161622	Clip, Closeout
10	132004	Locknut, Hex 1/4-20
11	158152	Engine Zone Control Cable
12	750634	Hex Washer Head Screw #10-24 x 1/2
13	86899X004	Up-Stop Bracket
15	186577X004	Axle Arm Assembly (Left Front / Right Rear)
16	189713X428	Knob
18	186578X004	Axle Arm Assembly (Right Front / Left Rear)
19	57193	Hairpin Cotter
20	750097	Screw
21	188987	Rear Skirt
22	66426	Wire Tie
23	160831	Discharge Guard
25	166785	Nut, Hex
26	---	Engine, Briggs & Stratton, Model Number 9L902 (for engine service and replacement parts, call Briggs & Stratton at 1-800-233-3723)
27	193436	Torsion Spring
28	851514	Blade Adapter

KEY NO.	PART NO.	DESCRIPTION
29	141114	22" Blade
30	851074	Hardened Washer
31	850263	Helical Lockwasher 3/8
32	851084	Screw, Hex Head 3/8-24 x 1-3/8 Grade 8
33	73930500	Nut, Hex, Flangelock 5/16-18
34	168164X479	Wheel Bracket Support, Left
35	168165X479	Wheel Bracket Support, Right
36	160835X007	Wheel Bracket Adjuster
37	160833	Hinge Rod
38	141846	Danger Decal
39	168360X004	Selector Spring
40	87877	Selector Knob
41	150406	Screw, Hex Head, Threaded, Rolled 3/8-16 x 1
43	183901	Washer
44	160828	Shoulder Bolt 5/16-18 x 33
46	83923	Locknut 1/16-18
47	193850X617	Wheel & Tire Assembly
48	17600406	Screw, Hex Head, Serrated, Type TT 1/4 x 20
53	192770	Clip, Cable
--	161058	Warning Decal (Not Shown)
--	193732	Operator's Manual, English
--	193735	Operator's Manual, Spanish
--	195041	Repair Parts Manual

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm