

This exploded view diagram illustrates the assembly of a motorized vehicle chassis. The central component is the main frame (1), which includes a motor housing (59) and a battery pack (21). The frame is shown with various mounting points and components like the front fender (31), rear fender (10), and side panels (23, 26). The diagram includes numerous numbered parts (1-75) and their corresponding assembly lines, showing the relationship between the main frame and the various sub-components such as the wheels (49), suspension (36, 37), and drivetrain (19, 28, 30, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75).

3

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	194177X428	Control Bar	30	401629	Spacer	52	412212	Kit, Lawn Mower Horizontal
2	194179X479	Upper Handle	31	165760	Deflector, Discharge			(Includes Key Number 17, 18 and 46)
3	169708X479	Lower Handle	32	401624X004	Selector Spring, Rear			
4	194788	Rope Guide	33	701037X421	Selector Knob	53	851084	Hex Head Screw, Grade 2
5	132004	Locknut, Hex 1/4-20	34	401176X004	Axle Arm Assembly, Rear, LH			3/8-24 x 1-3/8
6	191574	Handle Bolt				54	850263	Helical Lockwasher
7	66426	Wire Tie	35	166785	Locknut, Hex 5/16-18	55	851074	Hardened Washer
8	74780512	Hex Bolt 5/16-18 x 3/4	36	401638	Shoulder Bolt 5/16-18	56	406712	21" Blade
9	154132	Mounting Bracket,	37	150339	Wheel & Tire Assembly, Front, 8"	57	193707	Blade Adapter
		Mulcher Door				58	152124	Spring, Hinge Rod
10	165754	Mulcher Door	38	401638	Shoulder Bolt			Engine, Briggs & Stratton
11	183281	Engine Zone Control Cable	39	145212	Flanged Locknut	59	- - -	Model Number 120T
12	750634	Hex Washer Head Screw #10-24 x 1/2	40	401808	Frame, Grassbag			
			41	88652	Hinge Screw			
13	86899X004	Up-Stop Bracket	42	405421	Spring, Rear Door, LH			
14	189713X428	Handle Knob	43	405423	Spring, Rear Door, RH			
15	51793	Hairpin Cotter	44	184193	Bolt, Rear Door			
18	17600406	Screw	45	150406	Screw, Hex Head Thread Rolling Screw 3/8-16 x 1	61	83923	Flanged Locknut
19	401174X004	Axle Arm Assembly, Front, LH	46	404763	Danger Decal	62	73800400	Nut, Hex
20	401175X004	Axle Arm Assembly, Front, RH	47	751153	Nut, Hex	65	88348	Washer, Flat 3/8
			48	401177X004	Axle Arm Assembly, Rear, RH	66	197480	O-Ring
21	189008	Rear Skirt	49	408852X421	Wheel & Tire Assembly, Rear, 12"	67	197991	Clip, Cable
22	401621X004	Selector Spring, Front				69	407793X421	Hubcap, Front Wheel
23	401814X428	Rear Door Assembly	50	411060	Grassbag	70	407794X421	Hubcap, Rear Wheel
24	73930500	Locknut, Hex 5/16-18	51	147286	Rod, Hinge	73	401630	Washer, Curved, Cylindrical
25	400627X479	Handle Bracket, LH				74	851201X004	Washer, Special, Engine
26	400628X479	Handle Bracket, RH				- -	404764	Warning Decal (not shown)
28	407494X005	Wheel Adjusting Bracket				- -	193732	Operator's Manual, English
						- -	193734	Operator's Manual, French
						- -	412320	Repair Parts Manual, English

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm.

IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.