


ROTARY LAWN MOWER - - MODEL NUMBER 961440005 (MFG. ID. NO. 96144000500)

2



ROTARY LAWN MOWER - - MODEL NUMBER 961440005 (MFG. ID. NO. 96144000500)

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	426532	Upper Handle Assembly (Includes Foam Grip)	27	193906X460	Wheel & Tire Assembly, Rear	50	851084	Screw, Machine, Hex Head 3/8-24 x 1-3/8 Grade 8
2	424033	Cable, Operator Presence	28	174719	Bolt, Shoulder 3/8-16 x 1	51	170031	Kit, Front Baffle (Includes Key Number 53)
3	429930X004	Bracket, Upstop	29	401630	Washer, Curved, Cylindrical	52	404763	Danger Decal
4	166649	Mulcher Plug	30	401180X004	Axle Arm Assembly	53	17600406	Screw, Serrated, TT 1/4-20
5	66426	Wire Tie	31	701037	Selector Knob	54	88348	Washer, Flat
6	182398	Handle Knob	32	401626X004	Selector Spring	55	73930600	Nut, Hex 3/8-16
7	750634	Screw	33	189917X428	Mulcher Door	56	88652	Hinge Screw 1/4-20 x 1-1/4
8	426321X428	Control Bar	34	401629	Spacer	57	51793	Hairpin Cotter
9	401813X428	Rear Door Assembly	35	700325X005	Wheel Adjusting Bracket	58	151590X479	Lower Handle
10	128415	Pop Rivet	36	175735	Hinge Bracket Assembly	59	191574	Handle Bolt
11	150050	Screw, Self-Tapping #10-24 x 5/8	37	428867	Screw, Sems, Thread Cutting 5/16-18 x 3/4	60	74760612	Bolt, Hex Head 3/8-16 x 3/4
12	17060410	Screw, Hex Hex Head, Sems 1/4-20 x 5/8	38	402574X428	Discharge Deflector	64	- - -	Engine, Honda, Model Number GCV160-LAOS3A (For engine service and replacement parts, call Honda Engines at 1-800-426-7701)
14	195622X479	Back Plate	39	195915X479	Handle Bracket Assembly, LH	65	197480	O-Ring
15	410545X479	Side Baffle	40	195914X479	Handle Bracket Assembly, RH	67	182003	Clip, Packaging
16	176655X479	Discharge Baffle	41	150406	Screw, Hex Head, Threaded, Rolled 3/8-16 x 1-1/8	69	197991	Clip, Cable
17	140661X479	Rear Baffle	42	193000	Spring, Torsion	70	164265	Grip, Foam
18	132004	Keps Locknut 1/4-20	43	73800400	Nut, Hex, Nylon	71	420474X004	Belt Keeper
19	194788	Rope Guide	44	433085	Kit, Mower Housing (Includes Key Numbers 14, 15 and 51)	- -	404764	Warning Decal (not shown)
20	413160	Rear Skirt	45	175650	Rod, Hinge	- -	193733	Operator's Manual, English
21	405421	Spring, Rear Door, LH	46	421248	Blade Adapter / Pulley	- -	193736	Operator's Manual, French
24	405423	Spring, Rear Door, RH	47	406713	Blade, 22"	- -	433086	Repair Parts Manual
25	409149	Nut, Hex, Flanged	48	851074	Washer, Hardened			
26	184193	Bolt, Rear Door	49	850263	Washer, Helical			

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm.

IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.

4



KEY NO.	PART NO.	DESCRIPTION
29	409148	Locknut, Hex
32	194018	Pulley, Drive
33	196857	V-Belt
35	424201	Kit, Wheel Adjuster, LH (Includes Knob and Bearing)
36	404834	Gear Case Assembly, Complete
38	73800400	Locknut 1/4-20
40	406558	Spring
41	424200	Kit, Wheel Adjuster, RH (Includes Knob and Bearing)
54	433093	Grassbag Assembly
57	411952	Frame, Grassbag
80	421114	Water Washout Assembly
81	419735	Fitting, Hose, Water Washout
82	415585	Washer, Lock, Internal Tooth
83	415586	Locknut, Hex, with O-Ring

IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.