


REPAIR PARTS

20" ROTARY LAWN MOWER MODEL NO. A105B



REPAIR PARTS

20" ROTARY LAWN MOWER MODEL NO. A105B

KEY PART NO. NO. DESCRIPTION

1	86902	Control Bar
2	851645X479	Upper Handle
3	103672	Rope Guide
4	851646X479	Lower Handle
5	63601	Locknut 1/4-20
6	87584X004	Bracket
7	86261	Machine Screw 1/4-20 x 2-1/8
8	851712	Throttle Control
9	85723	Washer
10	851704	Engine Zone Control Cable
11	750097	Hex Washer Head Screw #10-24 x 1/2
12	850733X004	Up-Stop Bracket
13	85827	Cable Clip
14	751592	Locknut
15	53109	Hex Head Bolt 1/4-20 x 1-1/2
16	81276	Hex Washer Head Tapping Screw #10-24 x 1/2
17	751228	Rear Deflector
18	801728	Hinge Rod
19	851855	Torsion Spring
20	851981X004	Housing Bracket
21	851201X004	Engine Washer
22	752052	Discharge Guard
23	67609	Shoulder Bolt
24	130491	Wheel Assembly

KEY PART NO. NO. DESCRIPTION

25	74316	Washer
26	107339	Danger Decal
27	55912	Hex Head Bolt 3/8-16 x 3/4
28	751592	Locknut 3/8-16
29	851856	Hex Head Thread Rolling w/Sems 1/4-20
30	850998	Hex Head Thread Rolling Screw 3/8-16 x 1-1/8
31	129239X004	Blade Adapter
32	103523X	20" Blade
33	851074	Hardened Washer
34	850263	Washer, Lock, Helical 3/8
35	851084	Hex Head Screw 3/8-24 x 1-3/8 Grade 8
36	83816	Screw #10 x 5/8
37	213146	* Cable Clamp
38	128933	Lawn Mower Housing
39	61537	Washer
40	801877X479	Front Baffle
41	*	Engine - Briggs & Stratton Model No. 92502 Type No. 3124-01
42	1105600	Washer, Lock External Tooth 3/8
43	83731	Push Nut on Speed
44	74969	Key
45	129695	Engine Spacer
—	128076	Operator's Manual
—	131665	Repair Parts Manual

NOTE: All component dimensions given in U. S. inches. 1 inch = 25.4 mm

*These parts must be purchased through an authorized Briggs and Stratton Dealer.