


TRACTOR- -MODEL NO. RER155H42E


SCHEMATIC



REPAIR PARTS

TRACTOR- -MODEL NO. RER155H42E

ELECTRICAL



REPAIR PARTS

ELECTRICAL

TRACTOR- -MODEL NO. RER155H42E


KEY NO.	PART NO.	DESCRIPTION
1	163465	Battery
2	74760412	Bolt Hex Hd 1/4-20 Unc X 3/4
16	176138	Switch Interlock
21	175685	Harness Asm Light W/4152J
22	4152J	Bulb Light #1156
24	4799J	Cable Battery
25	165987	Cable Battery Crd 56" Red
26	175158	Fuse
27	73510400	Nut Keps Hex 1/4-20 Unc
28	127725X	Cable Ground 6Ga 18" Black
29	160784	Switch Plunger Normal Op Olive
30	175566	Switch Ignition
33	140401	Key Ign Molded
40	179728	Harness Ign Crd Noram
41	71110408	Bolt Flk Fin Hex 1/4-20 Unc X 1/2
42	131563	Cover Terminal Red
43	178861	Solenoid
48	140844	Adapter Ammeter Rectangular
52	141940	Protection Wire Loop
58	169419	Buzzer Crd
59	180379	Switch FBI CRD
66	17490608	Screw Thdrol 3/8-16 x 1/2 Ty-Tt
81	109748X	Relay Asm

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm.

REPAIR PARTS

TRACTOR- -MODEL NO. RER155H42E

CHASSIS AND ENCLOSURES



REPAIR PARTS

TRACTOR- -MODEL NO. RER155H42E

CHASSIS AND ENCLOSURES

KEY NO.	PART NO.	DESCRIPTION
1	174620	Chassis
2	180384	Drawbar
3	17060612	Screw 3/8-16 x 3/4
5	155272	Bumper Hood/Dash
6	155923	Saddle
8	126471X	Clip Insulator 13/32 Mtg. Hole
9	168347X011	Dash
10	72140608	Bolt, Carriage 3/8-16 x 3/4
11	155927	Panel, Dash, L.H.
12	145660	Clip Tinnerman
13	172107X010	Panel, Asm. Dash R.H.
15	74180512	Screw, Machine, Truss Head 5/16-18 UNC x 3/4
16	73510500	Nut
17	159639X505	Hood
18	126938X	Bumper Hood
20	180679	Plate Mtg Battery/Tank Fuel
24	74780616	Bolt
25	19131312	Washer 13/32 x 13/16 x 12 Gauge
26	73800600	Nut
28	179101	Grille /Lens Asm
29	140273X599	Lens, Grille
30	169962X505	Fender
31	165156	Bracket, Fender Support
33	179716X505	Footrest, L.H.
34	179717X505	Footrest, R.H.
35	72110606	Bolt
37	17490508	Screw Thdrol 5/16-18 x 1/2 TYT
38	175710	Bracket Asm Pivot Mower Rear
51	73800400	Nut Lock w/Insert 1/4-20 Unc
52	19091416	Washer 9/32 x 7/8 x 16 Ga.
53	144697	Bracket Grille LH
54	161464	Screw Hex Wshd 8-18 x 7/8
55	144696	Bracket Grille RH


KEY NO.	PART NO.	DESCRIPTION
57	74780412	Bolt fin Hex 1/4-20 Unc x .75
58	150127	Duct Air Engine
69	142432	Screw Hex Wsh
89	177287X428	Console
145	156524	Rod Pivot Chassis/Hood
162	180382	Bracket Exten Chassis Lh CRD
163	180383	Bracket Exten Chassis Rh CRD
164	165605	Support Battery CRD
165	179020X428	Cover Battery
170	178862	Backplate Asm CRD
171	72140620	Bolt Rdhd Sqnk 3/8-16 x 2-1/2 Gr. 5
172	19132016	Washer 13/32 x 1-1/4 x 16 Ga.
173	73510600	Nut, Keps Hex 3/8-16 UNC
175	180310	Guard Trap
179	180376	Rod Pivot FBI CRD
184	174662	Bracket Actuator Bagger CRD
185	179608X505	Knob Rod Brake Parking
186	160793	Latch Asm Mulch/Bagger
187	2029J	Nut Weld
188	19061216	Washer #10
189	10071000	Washer Lock #10
190	71081010	Screw Pan Hd Phillip 10-24 x 5/8
198	168937	Nut, Push
205	17490608	Screw Thdrol 3/8-16 x 1/2
207	17670508	Screw Thdrol 5/16-18 x 1/2
208	17670608	Screw Thdrol 3/8-16 x 1/2
209	17000612	Screw Hex Wsh Thdrol 3/8-16
212	156229	Insert Lens Reflective
214	4497H	Retainer Spring
215	17060508	Screw 5/16-18 x 1/2
256	180810X428	Cover Fender Rack CRD
--	5479J	Plug, Button

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm.

REPAIR PARTS

TRACTOR- -MODEL NO. RER155H42E

DRIVE



REPAIR PARTS

TRACTOR- -MODEL NO. RER155H42E

DRIVE


KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	-----	Transaxle Hydro Gear 321-0510 (Order parts from transaxle manufacturer)	95	170015	Control Asm Bypass Hydro
8	165619	Rod, Shift Fender Adjust Lt	96	4497H	Spring, Retainer 1"
9	170163	Clutch Asm	120	73900600	Nut Lock Flg. 3/8-16 Unc
10	76020416	Pin, Cotter 1/8 x 1	145	74490544	Bolt Hex FGHD 5/16-18 x Gr 5
14	10040400	Washer, Lock Hvy Helical	150	165850	Bushing, Bellcrank Grnd Dr
16	73800500	Nut, Lock Hex w/Ins 5/16-18 UNC	151	19133210	Washer 13/32 x 2 x 10 Ga.
21	106933X	Knob	156	166002	Washer Srrted 5/16ID x 1.125
22	175607	Rod, Brake	158	165589	Bracket Shift Mount
23	180302	Bracket asm Anti-Rot	159	165494	Hub Tapered Flange Shift Lt
24	73350600	Nut	160	19292016	Washer 29/32 x 1-1/4 x 16 Ga.
25	106888X	Spring, Rod, Brake	161	72140406	Bolt Rdhd Sqnk 1/4-20 x 3/4 Gr 5
26	19131316	Washer 13/32 x 13/16 x 16 Ga.	162	73680400	Nut Crownlock 1/4-20 Unc
27	76020412	Pin, Cotter 1/8 x 3/4	163	74780416	Bolt Hex Fin 1/4-20 Unc x 1 Gr 5
28	175765	Rod, Parking Brake	164	19091010	Washer 5/8 x .281 x 10 Ga.
29	71673	Cap, Parking Brake	165	165623	Bracket Pivot Lever
30	169592	Bracket, Mfg. Transaxle	166	166880	Screw 5/16-18 x 5/8
34	175578	Shaft, Asm Pedal Foot CRD	167	165588	Bracket Support Shift CRD
35	120183X	Bearing, Nylon	168	165492	Bolt Shoulder 5/16-18 x .561
36	19211616	Washer 21/32 x 1 x 16 Ga.	169	165580	Plate Fastening Lt
37	1572H	Pin, Roll 3/16 x 1"	171	17490608	Screw Thdrol 3/8-16 x 1/2 Ty-Tt
38	165936	Pulley Flat Composite 3.06"	172	170271	Shaft Asm Shifter Frt CRD
39	74760644	Bolt Fin Hex 3/8-16 Unc x 2-3/4	177	165932	Keeper Flat Idler 3.06" CRD
40	4470J	Spacer, Split 395 x 59 Bzp	178	165933	Keeper Belt Idler 1.88" CRD
42	19131312	Washer 13/32 x 13/16 x 12 Ga.	179	120958X	Washer Sintered
47	127783	Pulley, Idler, V Groove Plasic	180	165630	Pulley, Idler, Flat 1.88" CRD
48	154407	Bellcrank Clutch Grnd Drv	181	180211	Bracket Idler Ground Drive CRD
49	123205X	Retainer, Belt Style Spring	182	165634	Keeper Belt 2.5" Od V-Idler CRD
50	74760624	Bolt Hex Hd 3/8-16 UNC x 1-1/2	183	179050	Pulley V-Idler 2.50" Od CRD
51	73680600	Nut, Crownlock 3/8-16 UNC	184	17490644	Screw Hexwsh Thdrol 3/8-16 x 2-3/4
52	7368500	Nut Crownlock 5/16-18	185	170008	Link Shift
53	105710X	Link, Clutch 7.66	186	165614	Hub Tapered Round CRD
55	105709X	Spring, Return, Clutch	187	17580520	Screw Thdrol 5/16-18 x 1.25
56	17060620	Screw 3/8-16 x 1-1/4	197	169613	Nyliner Snap-In 5/8
57	170140	V-Belt Kev 112" 0650 CRD	199	169612	Bolt Shoulder 5/16-18 Unc
62	8883R	Cover, Pedal	200	72140508	Bolt RDHD SQNK 5/16-18 x 1
65	10040700	Washer	202	72110612	Bolt Carr. Sh. 3/8-16 x 1-1/2 Gr. 5
66	154778	Keeper, Belt Engine F-Proof	203	71170780	Bolt Hex 7/16-20 x 5
71	169183	Strap, Torque, Lh	207	169845	Washer Nylon Rear
73	169182	Strap, Torque, Rh	214	175609	Shaft Asm. Brake
74	137057	Spacer, Split	215	175652	Rod Brake Hydro
75	121749X	Washer 25/32 x 1-1/4 x 16 Ga.	250	17070612	Screw 3/8-16 x .75
76	12000001	Ring, E	253	175028	Bracket Cable Chassis
77	123583X	Key, Square	254	17060616	Screw 3/8-16 x 1
78	121748X	Washer 25/32 x 1-5/8 x 16 Ga.	255	175608	Brace Shaft Brake Mtg.
81	170006	Asm, Shaft	258	178062	Clip Retainer
82	165711	Spring, Torsion	259	180212	Bracket Pulley
83	19171216	Washer 17/32 x 3/4 x 16 Ga.			
84	170007	Link, Transaxle			

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. RER155H42E

STEERING ASSEMBLY



REPAIR PARTS

TRACTOR- -MODEL NO. RER155H42E

STEERING ASSEMBLY


KEY NO.	PART NO.	DESCRIPTION
1	133741X428	Steering Wheel
2	172393	Axle Asm Cast Iron Lt
3	169840	Spindle Assembly, L.H.
4	169839	Spindle Assembly, R.H.
5	6266H	Washer, Thrust .75 x 1.230
6	121748X	Washer 25/32 x 1-5/8 x 16 Gauge
8	12000029	Ring, Klip
10	175121	Link, Drag
11	10040600	Washer, Lock
13	136518	Spacer Brg Axle Front
15	145212	Nut, Hex Flange Lock
17	177876	Shaft Assembly, Steering
29	17060612	Screw 3/8-16 x 3/4
32	170162	Rod, Tie
33	19111216	Washer 11/32 x 3/4 x 16 Ga.
34	10040500	Washer Lock Hvy Hlcl Spr 5/16
35	73540500	Crownlock Nut 5/16-24 Unf
36	155099	Bushing, Steering
37	152927	Screw TT #10-32 x 5 x 3/8 Flange
38	133742X428	Cap Wheel Steering
39	19133812	Washer 13/32 x 2-3/8 x 12 G
40	7810H	Nut Lock Center 3/8-24 Unf
41	100711L	Adaptor, Steering Wheel
42	145054X428	Boot, Steering Dash P/L Mtl
43	121749X	Washer 25/32 x 1-1/4 x 16 Gauge
44	153720	Extension Steering
46	121232X	Cap, Spindle
51	73800500	Nut Lock Hex 5/16-18
54	74780520	Bolt Fin Hex 5/16-18 x 1-1/4
63	74780616	Bolt Fin Hex 3/8-16 Unc x 1 Gr. 5
65	160367	Spacer Brace Axle
67	72140618	Bolt Rdhd Sq 3/8-16 x 2-1/4
68	169827	Brace Axle
71	175146	Steering Asm.
82	169835	Bracket Susp Chassis Front 15"
87	173966	Washer Flat .781 x 1-1/2 x .14
88	175118	Bolt Shoulder 7/16-20 UNC
91	175553	Clip Steering

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm.

REPAIR PARTS

TRACTOR- -MODEL NO. RER155H42E

SEAT ASSEMBLY



KEY NO.	PART NO.	DESCRIPTION
1	175390	Seat
2	140551	Bracket Pnt Pivot Seat (blk)
3	71110616	Bolt Fin Hex 3/8-16 Unc x 1
4	19131610	Washer Flat 13/32 x 1 x 10 Ga.
5	145006	Clip Push In Hinged
6	73800600	Nut Lock Hex w/Ins 3/8-16 Unc
7	124181X	Spring Seat Cprsn 2 250 Blk Zi
8	17000616	Screw 3/8-16 X 1-1/2
9	19131614	Washer 13/32 X 1 X 14 Ga
10	174894	Pan Assembly Seat Tool-Free
11	166369	Knob Seat Adj. Wingnut
12	121246X	Bracket Pnt Mounting Switch


KEY NO.	PART NO.	DESCRIPTION
13	121248X	Bushing Snap Blk Nyl 50 Id
14	72050412	Bolt Rdhd Sht Nk 1/4-20x1-1/2
15	121249X	Spacer Split
16	123740X	Spring Cprsn Plate SW 1.310 Ga
17	123976X	Nut Lock 1/4 Lge Flg Gr 5 Zinc
21	171852	Bolt Shoulder 5/16-18 Unc-2A
22	73800500	Nut Hex Lock w/Ins 5/16-18
24	19171912	Washer 17/32 X 1-3/16 X 12 Ga.
25	127018X	Bolt Shoulder 5/16-18 X 62

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. RER155H42E

ENGINE



KEY NO.	PART NO.	DESCRIPTION
1	170865	Control Throt/Ch
2	17720408	Screw Hex Thd Cut 1/4-20 x 1/2
3	-----	Engine Briggs Model 28U707 (Order Parts from Engine Manufacturer)
4	137352	Muffler Exhaust B&S Lt
13	165291	Gasket 1 313 Id Tin Plated
14	148456	Tube Drain Oil Easy
15	13200300	Elbow
16	11050600	Washer Lock Ext Tooth 3/8
23	169837	Shield Browning/Debris Guard
29	137180	Arrestor Spark
31	180645	Tank Fuel
32	140527	Cap Asm Fule Top Vent N/Lany
33	123487X	Clamp Hose Blk


KEY NO.	PART NO.	DESCRIPTION
37	137040	Line Fuel 20"
38	148315	Plug Drain Oil Easy
40	124028X	Bushing Snap
41	139277	Stem Tank Fuel
44	17670412	Screw Hexwsh Thdrol 1/4-20x3/4
45	17000612	Screw Hexwsh Thdrol 3/8-16 x 3/4
46	19091416	Washer 9/32 X 7/8 X 16ga
62	10040500	Washer Lock Hvy Hlcl Spr 5/16
66	127951	Stop Throttle
72	71070512	Screw Hex Hd Cap 5/16-18 x 3/4
78	17060620	Screw 3/8-16x1-1/4
81	73510400	Nut Keps Hex 1/4-20 Unc
112	3645J	Bushing

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. RER155H42E

MOWER LIFT



KEY NO.	PART NO.	DESCRIPTION
1	159460	Washer Asm Inner Spring W/Plunger
2	159471	Shaft Asm. Lift
3	105767X	Pin Groove
4	12000002	E Ring #5133-62
5	19211621	Washer 21/32 x 1 x 21 Ga.
6	120183X	Bearing Nylon
7	109413X	Grip Handle
8	124526X	Button Plunger Black
11	165829	Link Asm Lift L.H.
12	165831	Link Asm Lift R.H.


KEY NO.	PART NO.	DESCRIPTION
13	4939M	Retainer Spring
15	173288	Link Front
16	73350800	Nut Jam Hex 1/2-13 Unc
17	175689	Trunnion
18	73800800	Nut Lock w/Wsh 1/2-13 Unc
19	139868	Arm Suspension Mower
20	163552	Retainer Spring
31	169865	Bearing, Pvt. Lift.
32	73540600	Nut Crownlock 3/8-24

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. RER155H42E

MOWER



REPAIR PARTS

TRACTOR- -MODEL NO. RER155H42E

MOWER

KEY NO.	PART NO.	DESCRIPTION
1	169160	Housing Asm. Mower
2	72140506	Bolt Rdhd Sqnk 5/16-18 Unc x 3/4
3	165569	Bracket Asm. S-Bar Chass
4	169167	Bracket Bar Sway Deck
5	4939M	Retainer Spring
6	165557	Bar Sway
8	850857	Bolt 3/8-24 x 1.25 Gr8 Patched
9	10030600	Washer Lock Hvy 3/8 Unplated
10	140296	Washer Hard Blade Mower vented
11	175450	Blade 3-1 Lh
13	137645	Shaft Asm. W/Lower Bearing
14	128774	Housing Mandrel Vented (Machd)
15	110485X	Bearing Ball Mandrel
16	175451	Blade 3-1 Rh
17	72140610	Bolt Carr 3/8-16 x 1-1/4
19	132827	Bolt Shoulder 5/16-18 Thd Form
20	165484	Bolt 3/8-24 x 1.25 Gr8 Ptch Lhthd
21	73680500	Nut Crown Lock 5/16-18
22	169165	Bracket Idler Sprt RR
23	169166	Bracket Idler Sprt RF
24	169170	Bracket Suspension LF
25	169171	Bracket Suspension RF
26	165237	Brace Support Susp Frt CRD
27	169172	Bracket Asm. Susp RR
28	169168	Bracket Asm. Susp LR
30	173984	Screw Thd Rolling
31	129963	Washer Spacer Mower Vented
32	175707	Mandrel Pulleys
33	178342	Nut Flg Top Lock
34	176292	Bracket Gauge Wheel RF/LR
35	179509	Bracket Gauge Wheel LF/LR
36	146763	Pulley Idler V-Groove Dim 4.25
37	19131316	Washer 11/32 x 13/16 x 16 Ga
38	169851	Spacer Hub Arm Idler


KEY NO.	PART NO.	DESCRIPTION
39	72110622	Bolt RhHd 3/8-16 Unc x 2-3/4 Gr.5
40	73680600	Nut Crownlock 3/8-16 Unc
41	73900600	Nut Lock Flg 3/8-16
44	175538	Cover Mandrel Lh
45	175539	Cover Mandrel Rh
46	137729	Screw Thd Roll 1/4-20 x 5/8
55	169849	Arm Idler
61	175159	Spring Tension Belt
67	106932X	Knob Rd 3/8-16 Plstc Thds Blk
68	169178	Hex-Belt Mower
69	165482	Shaft Asm W/Lwr Brg Rh Thd CRD
84	156085	Keeper Belt Idler
116	137644	Bolt Shoulder
117	133957	Wheel Gage Donut Wide
118	73930600	Nut Centerlock 3/8-16 Unc
119	19121414	Washer 3/8 x 7/8 x 14 Ga.
124	72110612	Bolt Carr Sh 3/8-16 x 1-1/2 Gr5
130	72110506	Bolt Rdhdsqnk 5/16-18 Unc x 3/4
131	165661	Chute Bagger CRD 92cm
151	169670	Bracket Clutch Cable
152	176074	Clutch Cable
153	169674	Washer Flat 3/8" Type B
154	169675	Spring Retainer
155	169671	Spring Retention Lvr Cltch Cab
156	169672	Spacer Clutch Cable
157	169669	Rod Clutch Cable 3/8"
158	17720408	Screw Hex Thd Cut 1/4-20 x 1/2
160	175160	Guide Belt
--	130794	Mandrel Asm Service
--	165579	Mandrel Asm CRD Lh Threads SVC
--	180387	Deck Mower Complete

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. RER155H42E


DECALS



KEY NO.	PART NO.	DESCRIPTION
1	145498	Decal Read Owner's Manual Sym
2	176398	Decal Hp Engine
3	181144	Decal Hood Rh
4	181145	Decal Hood Lh
6	126187X	Decal 100 DBA
7	127075	Decal Ins Strg Whl
8	145437	Decal Europe Stand Ce
9	181146	Decal Fender Logo
10	145005	Decal Bat Dan/Poi P/L Sym Wpn
11	145494	Decal Mower Cut Finger Symbol
12	159737	Decal Brake/Clutch Symbol Lt

KEY NO.	PART NO.	DESCRIPTION
14	159736	Decal Chassis Hot Muffler
17	140837	Decal Saddle Brake Parking
18	181149	Decal Chassis
19	166960	Decal Bypass Fender
20	134999	Decal Enviro Deck
21	166286	Decal Deck Sch 92 CRD
—	138311	Decal Lift Handle
—	181518	Manual Operator's (Euro)
—	181519	Manual Operator's (Scan)
—	181520	Manual Parts

WHEELS & TIRES




KEY NO.	PART NO.	DESCRIPTION
1	59192	Cap Value Tire
2	65139	Stem Value
3	106222X	Tire F Ts 15 X 6 0 - 6 Service
4	59904	Tube Inner Front #35060
5	106732X421	Rim Asm 6" front Service
6	278H	Fitting Grease
7	9040H	Bearing Flange
8	106108X421	Rim Asm 8" rear Service
9	124635X	Tire R Ts 18 x 8.5-8 Service
10	7152J	Tube Rear 9 5 X 8 Service
11	104757X428	Cap Axle Blk 1 50 X 1 00
--	144334	Sealant, Tire (10 oz. tube)

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. RER155H42E

BAGGER



REPAIR PARTS

TRACTOR- -MODEL NO. RER155H42E

BAGGER

KEY NO.	PART NO.	DESCRIPTION
1	165249	Tube Handle Bagger CRD
2	72140416	Bolt Carriage 1/4-20 x 2.0 Gr.5
3	123976X	Nut Lock 1/4 Lge Flg Gr. 5 Zinc
4	169916	Handle Bagger w/Lvrs Blk CRD
5	74981024	Screw Pan Head #10-24 x 1.50 Blk
6	74981032	Screw Pan Hd
7	73401000	Nut Wiz Lock Hex Serr/Hd 10-24
8	169963X505	Cover Bagger
9	72140418	Bolt Carriage 1/4-20 x 2.25d x Gr.5
10	181282	Tube Support Bagger CRD
11	165719	Bracket Support Upper Bag CRD
12	169685	Bracket Horizon Adj Bggr Lh CRD
13	72110606	Bolt Rdhd Sht Sqnk 3/8-16 x 3/4
14	72140620	Bolt Rdhd Sqnk 3/8-16 x 2-1/2 Gr. 5
15	4939M	Retainer Spring
16	73900600	Nut Lock Flg 3/8-16 Unc
17	72140506	Bolt Rdhd Sht Sqnk 5/16 -18 Unc x 3/4
18	19111216	Washer 11/32 x 3/4 x 16
19	73900500	Nut Lock Hex Flange 5/16-18
20	169684	Bracket Horiz Adj Bggr RH CRD
21	180880	Bag Asm CRD
22	165781	Bracket Side Bagger CRD
23	165782	Tube Upper Bagger CRD
24	165783	Tube Pivot Bagger CRD
25	180124	Tube Front Bagger CRD
26	165785	Tube Lower Bagger CRD
27	169692	Bushing Snap Bagger CRD
28	165787	Grip Handle
31	4497H	Retainer Spring 1" Zinc/Cad
32	126875X	Rivet Rd Hd Drilled 3/8 Dia
33	169380	Plug Mulch
34	165570	Handle Mulcher
35	165572	Pin Mulcher
36	19132016	Washer 13/32 x 1-1/4 x 16 Ga.
37	175401	Plug Support
38	72010520	Bolt 5/16-18 x 2-1/2
39	180985	Seal Trim 37"
41	169683	Bracket Vert Adj Bagger CRD
42	73800500	Nut Lock Hx W/Ins 5/16

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm