


REPAIR PARTS

ROTARY LAWN MOWER - MODEL NUMBER WE4T22SA



REPAIR PARTS

ROTARY LAWN MOWER - MODEL NUMBER WE4T22SA

KEY NO.	PART NO.	DESCRIPTION
1	63601	Locknut 1/4-20
2	86902	Control Bar
3	132001	Rope Guide
4	160834X479	Upper Handle
5	160609X479	Lower Handle
7	131959	Handle Bolt 5/16-18
11	701181	Engine Zone Control Cable
12	750097	Hex Washer Head Screw #10-24 x 1/2
13	850733X004	Up-Stop Bracket
16	128638	Handle Knob
19	51793	Hairpin Cotter
21	165858	Rear Deflector
22	66426	Wire Tie
23	160831	Discharge Guard
27	160832	Torsion Spring
30	160833	Hinge Rod
33	751153	Nut Hex Flange Lock 5/16 - 18
34	168164X479	Wheel Bracket Support (Left)
35	168165X479	Wheel Bracket Support (Right)
36	160835X007	Wheel Bracket Adjuster
39	168360X004	Selector Spring
40	87877	Selector Knob
43	19112222	Washer

KEY NO.	PART NO.	DESCRIPTION
44	160828	Shoulder Bolt (5/16-18 x .33)
45	800220	Wheel Assembly
46	83923	Locknut 1/16-18
50	800090	Hubcap
51	17600406	Screw Hex Serrated 1/4 x 20.tt
52	150406	Hex Head Thread Rolling Screw 3/8-16 x 1
55	85463	Danger Decal
59	164594	Lawn Mower Housing (Incl. Key Nos. 55)
61	851514	Blade Adapter
62	141114	22" Blade
63	851074	Hardened Washer
64	850263	Helical Lockwasher 3/8
65	851084	Screw Hex Head 3/8-24 x 1-3/8 (Grd. 8)
67	-----	Engine - Tecumseh LEV100
		Order parts from engine manufacturer
72	167132X004	Axle Arm Assm. ((LF/RR)
73	167133X004	Axle Arm Assm. (RF/LR)
74	751153	Nut
76	161622	Clip. Closeout
77	750097	Screw
78	87584X004	Shoulder Bolt (5/16-18X.51)
79	160828	Shoulder Bolt (5/16-18 x .51)
80	144929	Screw
81	158059	Throttle
--	161116	Operator's Manual (English)
--	169193	Replacement Parts Manual
--	161058	Warning Decal (Not Shown)

Available accessories not included with mower:

-- GCK3300 Grass Catcher