

YARD TRACTOR

This diagram illustrates the electrical system of a vehicle, showing the battery, starter, engine regulator, and various wiring harnesses. The components are labeled with numbers and letters, and the connections are shown with lines and arrows.

Key Components and Labels:

- Battery:** Labeled 1, 3, 4, 5, 6, 12, 13, 15, 27, 27 A, 32, 61, 63.
- Starter:** Labeled 11, 10, 11, 10, 11, 10.
- Engine Regulator:** Labeled 7, 31, 31, 31.
- Electric Clutch:** Labeled 10, 11, 10, 11, 10, 11.
- Wiring Harnesses:** Labeled 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100.
- Other Labels:** A, B, C, D, E, F, G, H, I, J, K, L, M, N, O, P, Q, R, S, T, U, V, W, X, Y, Z.

The diagram shows the battery at the bottom right, connected to the starter and engine regulator. The wiring harnesses are shown as bundles of wires with various connectors and terminals. The components are labeled with numbers and letters, and the connections are shown with lines and arrows.


KEY PART NO. NO.	DESCRIPTION
1 532123198	Wing Nut 1/4-20
2 819091016	Washer 9/32 x 5/8 x 16 Ga
3 532102476	Guard, Terminal
4 872240460	Battery, Bolt (Bolt, Carriage) 1/4-20 x 7-1/2
5 532121537	Battery, 30 Amp.
6 532124886	Battery Tray
7 532123826	Harness, Ignition (includes item 30A)
10 532110859	Harness, Light Socket
11 532124893	Bulb, Light
12 532100541	Tube, Battery Tray
13 532124756	Cable Tie
14 532109553	Switch, Interlock, Clutch
15 532124503	Cable, Battery (Battery to Solenoid)
16 532102972	Ignition Switch
18 532109788	Nut, Ignition
19 532122147	Key
21 532110712	Switch, Light
22 873680400	Nut, Crownlock 1/4-20
26 532124783	Terminal Cover
27 532124773	Cable, Battery (Battery to Ground)
30 817021008	Screw, Tap, Hex Hd, No. 10-24 UNC
30A 532109748	Relay

KEY PART NO. NO.	DESCRIPTION
31 532124996	Clip, Fuel Line
32 532109596	Clamp, Hose
35 874780408	Bolt, Hex 1/4-20 x 1/2 Gr. 5
36 873510400	Nut, Keps, Hex 1/4-20
37 874760412	Bolt, Hex 1/4-20 x 3/4
39 873220400	Nut, Hex 1/4-20
40 811050400	Washer, Lock 1/4 Ext, Tooth
43 810040400	Lockwasher 1/4
45 532108824	Fuse, 30 Amp,
48 811050600	Washer, Lock, External, Tooth 3/4
51 532102501	Loop, Wire Tiller Attachment
52 532124995	Clip, Insulated
55 532126018	Switch PTO
56 532124932	Nut, Hex
57 532109787	Bezel, Ignition
58 532121305	Switch, Plunger
61 532121264	Caps, Battery Set
62 532124524	Light Package
63 532121549	Decal, Battery, Caution
65 874760616	Bolt, Fin, Hex 3/8-16 UNC x 1
— 532101539	Sheet, Instruction, Tractor 15° Slope (English)
— 532126606	Operators Manual (English)
— 532126888	Parts Manual

REPAIR PARTS

YARD TRACTOR

CHASSIS AND ENCLOSURES




REPAIR PARTS

YARD TRACTOR

CHASSIS AND ENCLOSURES


KEY PART NO. NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION	
1	532124186	Seat	71	817490608	Screw, Hex Washer Thread Rolling 3/8 - 16 x 1/2
2	532124294	Pan, Seat	72	817490612	Screw, Hex Washer Thread Rolling 3/8, 16 x 3/4
3	532126656	Bracket, Pivot, Seat	74	872140606	Bolt, Carriage 3/8 - 16 x 3/4
4	532120822	Decal, Caution, OPEI	75	817431008	Screw, Hex Self Tapping No 10 - 16 x 1/2
5	532124974	Fender	76	874760616	Bolt, Hex 3/8 - 16 x 1
6	532106202	Reflector,Tail Light	77	532121794	Cover, Access
7	532124484	Decal, Fender	80	873510400	Nut, Hex, Keps
9	532105511	Strap, Fender	81	873220400	Nut, Keps, 5/16 - 18
10	532124181	Spring, Compression, Seat	82	874760532	Bolt, Hex 5/16 - 18 x 2
11	532105531	Nut, Push	83	873510500	Nut, Keps 5/16 - 18
12	532105509	Bracket, Fender	88	532123481	Bolt, Shoulder 1/4 - 20
13	532006431	Pad, Spacer	89	873680400	Nut, Crownlock 1/4 - 20
14	532124462	Cap, Fuel	90	874191008	Screw, Pan Hd. Machine No. 10 - 24 x 1/2
15	532106020	Tank, Fuel	91	810071000	Washer, Lock No. 10
16	532003645	Bushing	93	819131312	Washer 13/32 x 13/16 x 12 Ga.
17	532124951	Stem, Tank, Fuel	94	532120529	Washer, Nylon, .44 x .75 x .032
18	532123487	Clamp, Hose	95	532124763	Pointer, Height, Indicator
19	532124953	Line, Fuel	96	874760612	Bolt, Hex 3/8 - 16 x 3/4
21	532124118	Panel, Dash, L.H.	98	532109808	Latch, Hood
24	532124722	Footrest, L.H.	99	873731000	Nut, Keps 10 - 24
25	532101892	Decal, Clutch/Brake	100	532007206	Spacer, Split 10 x 3/4
26	532121215	Decal, Drive Belt	101	819070818	Washer 7/32 x 1/2 x 18 Ga.
27	532108256	Pad, Footrest	102	874981020	Screw, Mach. Pan 10-24 x 1 - 1/4
28	532121306	Drawbar	104	819111116	Washer, 11/32 x 11/16 x 16 Ga.
30	874180512	Screw, Cr. Thd. 5/16-18 x 3/4	109	532124996	Clip
31	532121277	Chassis	113	532121144	Bolt, Shoulder 5/16 - 18
32	532125036	Footrest, R.H.	116	532121236	Spacer
33	532110828	Panel, Dash, R.H.	120	532110853	Bracket Assembly, R.H.
34	532004171	Clip, Insulated	121	532110852	Bracket Assembly, L.H.
35	532110436	Grommet, Split	123	532120068	Adjustment Knob
36	532124934	Grommet	124	819171912	Washer 17/32 x 1-3/16 x 12 Ga.
37	532124766	Saddle	125	811050600	Lockwasher 3/8 Ext. Tooth
38	532124720	Bushing, Steering	126	819131614	Washer 13/32 x 1 x 14 Ga.
39	532108813	Decal, Instructions, Caution	129	811030400	Lockwasher Ext. Tooth
40	532104805	Dash Assembly, Lower	130	873490400	Wing Nut
41	532124182	Dash	131	811050400	Washer, 1/4 Ext. Tooth
42	532125004	Nut-Weld	132	532110356	Cap, Snap
43	532124798	Plate, Dash	133	532110357	Washer, Cap, Snap
46	532125009	Panel, Side, L.H.	134	532121248	Bushing, Snap
47	532124486	Decal, Side Panel HVYTH140	135	532123976	Nut, Hex, Large, Flange Lock
48	532124483	Decal, Grill, Husky	136	532121246	Bracket, Switch Mount
49	532124480	Decal, Hood L.H.	137	532121249	Spacer, Split .28 x .88
50	532106784	Strap Assembly, Hinge, Rear	138	872170410	Bolt, Carr. 1/4 x 1-1/4
51	532104618	Strap Assembly, Hinge, Front	139	532121251	Foam Strip
52	532125007	Hood	140	532121250	Spring, Compression
53	532005479	Plug, Button	141	874641008	Screw, Pan Hd. #10, 32
54	532124130	Support, Dash	142	873951000	Nut, Keps #10
55	532106965	Plate, Support, Battery	143	874760424	Bolt, Fin, Hex 1/4-20 x 1-1/2
57	532125008	Panel, Side, R.H.	144	532121249	Spacer, Split
58	532124481	Decal, Hood, R.H.	145	819091216	Washer, 9/32 x 3/4 x 16 Ga.
59	532124250	Lens, L.H.			
60	532124251	Lens, R.H.			
63	532124574	Support, Grill, Asm.			
64	532124573	Grill Assembly			
65	532105529	Bolt -Shoulder 5/16, 18			
66	873680500	Nut, Lock 5/16, 18			
67	874760612	Bolt, Hex 3/8 - 16 x 3/4			
68	532001260	Spacer			
70	873680600	Nut, Crownlock 3/8 - 16.			

FF




129

HH




76

BB



123

KK



113

F F

129

130

H H

76

125

70

B B

123

124


K K

113

REPAIR PARTS

YARD TRACTOR

DRIVE




REPAIR PARTS

YARD TRACTOR

DRIVE

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532123816	Muffler	50	532124236	Cap, Plunger
3	532123818	Engine, 14 H.P.	51	532125637	Rod, Brake, Park
5	532101326	Deflector, Exhaust	52	532105710	Link, Clutch
7	819090816	Washer, 9/32 x 1/2 x 16 Ga.	53	873680600	Nut, Lock, 3/8-16
12	532121527	Control, Throttle/Choke	54	532123205	Retainer, Belt
14	532123461	V-Belt, Drive	55	812000039	Klip Ring
15	532124996	Clip	56	532110812	Washer, Hardened
16	532121187	Bracket, Mounting, Hydro T/A	57	532123789	Arm, Asm, Idler (Incl. Key No. 62)
17	532126649	Bracket, Transaxle	58	532105709	Spring, Return, Clutch
18	532123583	Key, Square 1/4 x 2	59	532123102	Bracket, Clutch, Asm.
19	810040500	Washer, Lock, Hvy. Hel. Spring	60	874760624	Bolt, Hex, 3/8 - 16 x 1-1/2
20	532121189	U-Bolt, 3/8 - 16 x 2-3/4	61	532106298	Pulley, Idler
21	532121199	Spacer, Split	62	532105706	Bearing
22	532121748	Washer, 1-1/32 x 1-5/8 x 16 Ga.	63	819211616	Washer, 21/32 x 1 x 16 Ga.
23	532124723	Rim, Rear, 8"	64	873800600	Nut
24	812000001	E-Ring	65	817720410	Screw, Hex Thread Cut. 1/4 - 20 x 5/8
25	532124578	Cover, Wheel, 8"	66	532125006	Screw, M8 x 1.25 x 25mm
27	532065139	Stem, Valve	67	811050600	Washer, Lock Ext Tooth 3/8
28	532059192	Cap, Valve	68	874760612	Bolt, Hex 3/8 - 16 x 3/4
29	532125005	Bolt, Fin M10 x 1.5 x 100 mm	69	874760616	Bolt, Hex 3/8 - 16 x 1
30	532126197	Washer, 1-1/2 OD x 15/32 ID x .250	70	872140606	Bolt, Carr., 3/8- 16 x 3/4
31	810040700	Washer, Lock 7/16	71	876020412	Pin, Cotter, 1/8 x 3/4
32	532108218	Clutch, Electric	72	817490612	Screw, Hex, Thdrol 3/8-16 x 3/4
33	532109841	Pulley, Engine	80	532106268	Tire, 18 x 9.50 x 8
35	874760644	Bolt, Hex 3/8 - 16 x 2-3/4	80A	532007152	Tube (not furnished with tractor)
36	532004859	Idler, Flat	82	532108236	Bracket, Switch
37	532004470	Spacer	83	817021008	Screw, Tap. Hex Hd, No. 10 - 24 x 1/2 Type T
38	819131312	Washer, 13/32 x 13/16 x 12 Ga.	84	532110422	Spring, Brake Return
39	532109070	Retainer, Belt	87	819111212	Washer, 11/32 x 3/4 x 12 Ga.
40	532121218	Keeper, Belt, Engine, L.H.	88	874760516	Bolt, Hex Hd. 5/16-18 x 1
41	532109169	Retainer, Clutch Assembly	89	872140506	Bolt, Carriage 5/16 - 18 x 3/4
42	532105730	Belt, Keeper, Engine, R.H.	90	873680500	Nut, Lock 5/16- 18
44	532106888	Spring - Rod, Brake	92	819131316	Washer, 13/32 x 13/16 x 16 Ga.
45	532121200	Rod, Brake	93	532124128	Bolt, Hex, M6 x 1 x 12mm
46	532124872	Cover, Pedal	95	817030808	Screw, Spider Lock #8 x 1/2
47	532120183	Bearing, Nylon	98	873350600	Nut, Hex Jam 3/8 X 16 UNC
48	532122424	Shaft, Foot Pedal, Asm.	99	532124788	Clip, Hairpin
49	532001572	Pin, Roll, 3/16 x 1			



STEERING ASSEMBLY




REPAIR PARTS

YARD TRACTOR

STEERING ASSEMBLY


KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
2	532124416	Insert, Steering Wheel	55	873901000	Nut, Lock Flange 5/8-11
3	873940800	Nut, Jam, Toplock 1/2-20	56	532108075	Axle, Front
4	532100712	Washer	57	532105654	Spindle, R.H.
5	532124415	Wheel Steering	58	532000278	Fitting, Grease
6	532100711	Adapter, Steering Wheel	59	532065139	Stem, Valve
9	532004921	Spring, Retainer	60	532059192	Cap, Valve
10	532102670	Spring, Compression	61	532009040	Bearing
12	873610600	Nut, Fin Hex 3/8 - 24 UNF	62	532124801	Rim 6" Front
13	532124577	Cover, Wheel	63	532106222	Tire, Front
14	532121274	Knob, Gear Shift	63A	532059904	Tube, Tire Front (not furnished with tractor)
15	532110845	Rod, Control	64	873800600	Nut, Hex, Lock w/ Wsh. Ins. 3/8 - 16
16	532121631	Spring, Torsion	65	532108212	Trunnion
17	532108196	Bracket, Control Rod	66	532121750	Rod, Control, Adjustable
18	532109557	Shaft, Steering	67	532124788	Clip, Hairpin
19	532002882	Pin, Drive 3/16 x 1	70	817490612	Screw, Hex Washer Thread Rolling 3/8 - 16 x 3/4
20	532074580	Spacer	71	817490508	Screw, Hex Washer Thread Rolling 5/16 - 18 x 1/2
21	532071208	Bushing	74	532121748	Washer 25/32 x 1 - 5/8 x 16 Ga.
22	532109432	Bracket, Steering	77	532108685	Gear, Pinion
24	812000029	Klip Ring	78	532109816	Nyliner, Snap - In
25	532124931	Bearing, Thrust	79	532101930	Washer, Hardened
26	532108683	Rod, Steering	81	819131212	Washer 13/32 x 3/4 x 12 Ga.
27	532108972	Washer, Phenolic	82	532121749	Washer 25/32 x 1 1/4 x 16 Ga.
28	532108684	Gear, Sector	83	819111216	Washer 11/32 x 3/4 x 16 Ga.
29	532106126	Key, Woodruff	84	819151516	Washer 15/32 x 15/16 x 16 Ga.
30	876020412	Pin, Cotter 1/8 x 3/4	85	532110739	Washer, Spring
31	873680600	Nut, Lock 3/8 - 16	86	532121232	Cap, Spindle
32	532108200	Washer, Friction	87	532121217	Guide, Control
34	532108518	Bolt, Hex Shoulder 3/8 - 16 x 1 - 3/8	88	532121216	Bracket, Control Guide
35	819212016	Washer 21/32 x 1 - 1/4 x 16 Ga.	89	817490512	Screw, Hex Washer Thrd Rolling 5/16 - 18 x 3/4 Type TT
36	532108201	Spacer	90	817021008	Screw, Tap Hex Hd. #10 - 24 UNC x 1/2 Type - T
37	532121202	Link, Control, Pump	91	819070816	Washer 7/32 x 1/2 x 16 Ga.
38	532108844	Spring, Compression	92	874561014	Screw, Hex Socket Hd. #10-24 UNC
39	819132012	Washer 13/32 x 1 - 1/4 x 12 Ga.	93	532069180	Nut, Lock, #10-24 UNC
40	874760648	Bolt, Hex 3/8 - 16 x 3	94	532121204	Bellcrank
41	532121209	Lever, Pump Control	95	532121206	Bracket, Bellcrank Pivot
42	532105663	Support, Saddle, Rear	96	532100536	Bolt, Shoulder
43	874761060	Bolt Hex 5/8 - 11 x 3 - 3/4	97	874760612	Bolt, Fin Hex 3/8 UNC - 16 x 3/4
44	532105664	Support, Saddle, Front	98	873680500	Nut, Lock 5/16 - 18
45	532105727	Link, Drag	99	532121190	Keeper, Centerspan
46	810040600	Lockwasher 3/8	100	532123186	Bracket, Chassis, Reinforcement, Hydro
47	810040500	Washer, Lock 5/16	101	532122819	Screw, Special 3/8 - 16 x 3/4
48	532121334	Rod, Tie			
49	873810500	Nut, Hex 5/16 - 24			
50	532105656	Spindle L.H.			
51	819272016	Washer 27/32 x 1 - 1/4 x 16 Ga.			
52	532110438	Spacer, Bearing			
54	532003366	Bearing			



REPAIR PARTS

YARD TRACTOR

LIFT ADJUSTMENT




REPAIR PARTS

YARD TRACTOR

LIFT ADJUSTMENT

KEY PART NO. NO.	DESCRIPTION	KEY PART NO. NO.	DESCRIPTION
1 532121891	Knob, Depth Adjustment	24 873710700	Nut, Lock 7/16- 14
2 873360700	Nut, Hex 3/8 - 16	25 812000037	Klip Ring
3 532110729	Rod, Adjust - Lift	26 532105864	Bracket, Suspension
4 876020308	Pin, Cotter 3/32 x 1/2	27 532121252	Upstop, Mower
5 532124874	Spring	28 532121598	Arm, Suspension R.H.
6 819131016	Washer 13/32 x 5/8 x 16 Ga.	29 532009135	Retainer, Spring
7 873680600	Nut, Lock 3/8 x 16	30 532106308	Trunnion, Lift, Lower
8 819151216	Washer 15/32 x 3/4 x 16 Ga.	31 872140608	Bolt, Carriage 3/8 - 16 x 1.00
9 532110810	Trunnion, Depth Stop	32 873220800	Nut, Hex Fin. 1/2- 13
10 532105848	Bolt, Shoulder 3/8 - 16	33 532121599	Arm, Suspension, L.H.
11 532109413	Grip Handle	34 812000022	E - Ring, Truarc
12 532122364	Plunger, Lever, Lift	36 872140606	Bolt, Carriage 3/8- 16 x 3/4
13 532121002	Lever, Lift	37 819292016	Washer 29/32 x 1 - 1/4 x 16 Ga.
14 532110739	Spring, Washer	38 532110807	Nut, Special
15 873980600	Nut, Center, Lock, Flange 3/8 x 16	39 873350600	Nut, Hex Jam 3/8 x 16 UNC
16 532124670	Retainer, Spring	40 874780624	Bolt, Hex 3/8 - 16 x 1 - 1/2
17 532121006	Rod, Lever	41 532124526	Button, Plunger
18 532004921	Retainer, Spring	42 532123934	Scale, Height, Indicator
19 819171516	Washer 17/32 x 15/16 x 16 Ga.	43 819112410	Washer, 11/32 x 1-1/2 x 10 Ga.
20 532110029	Link, Lift	44 810040500	Washer, Lock, Hvy., Hel., Spring
21 532124516	Shaft, Lift, Asm.	45 874780516	Bolt, Hex, Fin 5/16-18UNC x 1.00
22 532110448	Link Lift, Adjust	46 532123935	Plug, Hole
23 532110447	Trunnion, Lift		



YARD TRACTOR

REPAIR PARTS

YARD TRACTOR

MOWER

KEY PART
NO. NO.


DESCRIPTION

1	873680600	Nut, Lock 3/8 x 16
2	819131614	Washer 13/32 x 1 x 14 Ga.
3	532121316	Pulley, Idler
4	532106902	Spacer
6	532124858	Pulley, Idler
7	532106513	Washer, Wear
8	532121425	Arm, Idler
9	532109776	Pin, Pivot
10	532106523	Bar, Support, Idler
11	532106522	Brace, Idler, Deck
12	532121236	Spacer
13	819131316	Washer 13/32 x 13/16 x 16 Ga.
14	532121687	Mandrel, Secondary
15	532106214	Guard
16	532106085	V-Belt
17	873220600	Nut, Hex 3/8 x 16
18	810040600	Washer, Lock 3/8
19	532102932	Idler, Flat
20	532106526	Arm, Idler, Deck
21	532124885	Spring, Extension
22	532121705	Mandrel, Primary
23	810030600	Washer, Lock, Hvy. Helical
24	532109599	Bracket, Lift, L.H.
25	532105662	Link, Parallel
26	532004921	Retainer, Spring
27	532105744	Pin, Front, Hinge
28	532109835	Pin, Rear, Hinge
29	532109600	Bracket, Lift, R.H.
30	532108119	Guard, Belt, R.H.
32	532124950	Runner, R.H.
33	532121423	Housing, Mower
34	532105304	Cap, Sleeve
35	532106734	Spring, Deflector
36	532110452	Nut, Push
37	532109743	Bracket, Deflector
38	532109785	Guard, Discharge
39	532121349	Decal, Danger, Warning
40	819111016	Washer 11/32 x 5/8 x 16 Ga.
41		Decal Safety Standard (not serviced)

KEY PART
NO. NO.

DESCRIPTION


42	532106735	Rod, Hinge
43	532106635	Blade
44	874610624	Bolt, Hex 3/8 - 24 x 1 1/2 Gr, 5
45	819132012	Washer 13/32 x 1 1/4 x 12 Ga.
46	532125074	Runner, L.H.
47	532123807	Bracket, Suspension, Rear, R.H.
48	532123808	Bracket, Suspension, Rear, L.H.
49	532108592	Decal, V-Belt, Schematic
50	532105185	Decal, Instruction, Caution
51	872140614	Bolt, Carriage 3/8 - 16 x 1 3/4
52	872140608	Bolt, Carriage 3/8 - 16 x 1
53	872140612	Bolt, Carriage 3/8 - 16 x 1 1/2
54	874760620	Bolt, Hex 3/8 - 16 x 1 1/4
55	872140506	Bolt, Carriage 5/16 - 18 x 3/4
56	819111116	Washer 11/32 x 11/16 x 16 Ga.
57	873680500	Nut, Lock 5/16 - 18
58	874760648	Bolt, Hex 3/8 - 16 x 3
59	874110632	Screw, Flat Head 3/8 - 16 x 2
60	874760616	Bolt, Fin. Hex 3/8 - 16 x 1
61	819111216	Washer 11/32 x 3/4 x 16 Ga.
62	874760580	Bolt, Hex 5/16 - 18 x 5
63	876020412	Pin, Cotter
64	819151616	Washer, 15/32 x 1 x 16 Ga.
66	817490612	Screw, Hex Washer Thread Rolling 3/8 - 16 x 3/4
67	872140606	Bolt, Carriage 3/8 - 16 x 3/4
68	532102727	Spring, Extension
69	873930600	Nut, Centerlock 3/8 - 16
70	872110506	Bolt, Carriage 5/16 - 18 x 3/4
72	532124949	Nut, Lock 5/16 - 18
73	532109729	Roller, Nose
74	819151610	Washer 15/32 x 1 x 10 Ga.
75	872140620	Bolt, Carriage 3/8 - 16 x 2 1/2
76	819131210	Washer 13/32 x 3/4 x 10 Ga.
77	819131410	Washer 13/32 x 7/8 x 10 Ga.
78	532121352	Keeper, L, H, Mandrel
79	872110505	Bolt, Carriage 5/16 - 18 x 5/8
80	532102403	Idler, Pulley



REPAIR PARTS

YARD TRACTOR

TRANSAXLE AND PUMP ASSEMBLY



KEY PART NO. NO.

DESCRIPTION

1	532123634	Control, Asm., Free Wheel
4	532121188	Bracket, Pnt. Mounting Differential
5	874780412	Bolt, Hex Hd. 1/4- 20 UNC x 3/4
6	532121186	Fan, Hydro 8"
7	532121180	Pulley, Transaxle
8	532121211	Standoff, Fan Hydro
9	532121182	Guard Assembly, Belt
10		Differential Assembly (See pages 15 and 16)
11		Pump Assembly (See page 14)
12	874760572	Bolt, Hex Fin. 5/16 - 18 UNC x 4.5
13	532121323	Reservoir Pump

KEY PART NO. NO.

DESCRIPTION

14	873680500	Nut, Crown Lock 5/16 - 18
15	532121250	Spring, Compression
16	874760612	Bolt, 3/8 - 16 x 3/4
17	873680600	Nut 3/8 - 16 UNC
18	810040500	Lockwasher, Hvy., Helical
19	532124236	Cap, Plunger
20	532124815	Bolt Shoulder 1/4 - 20 UNC
21	532120529	Washer, Nylon
22	873680400	Nut, Crown lock 1/4 - 20 UNC
23	819092016	Washer 9/32 x 1 - 1/4 x 16 ga.
24	810040400	Lockwasher, Hvy., Helical


A



REPAIR PARTS

YARD TRACTOR

PUMP




1	122756X	Shaft, Pump Splined 36T
2	122716X	Retaining Ring
3	122745X	Ball Bearing
4	122715X	Spacer
5	122700X	Seal, Lip, Pump Shaft
6	122699X	Retaining Pin
8	122767X	Cradle Bearing
9	122729X	Plug
10	122746X	O-Ring
11	122747X	Journal Bearing - Trunnion
12	122717X	Seal, Lip
13	122748X	Trunnion Arm
14	122749X	Slot Guide
15	122768X	Housing
16	122769X	Journal Bearing
17	122770X	Ball Bearing Assembly
18	122771	Plug, Pipe
19	122772X	Center Section
20	122773X	Needle Bearing
21	122722X	Seal, Lip, Motor Shaft
22	122750X	Shaft, Motor Splined 36 Tooth
23	122774X	Washer
25	122775X	Swashplate
26	122776X	Bearing Guide
27	122777X	Thrust Washer
28	122778X	Thrust Roller
29	122779X	Thrust Plate
30	122723X	Seal, Lip, Thru Pump Shaft

31	122780X	Cylinder Block
32	122781X	Cylinder Block
33	122782X	Piston
34	122784X	Piston, Spring
35	122785X	Thrust Washer
37	122786X	Pin, Std. Hdls.
38	122718X	Gasket
39	122731X	Filter
40	122730X	Washer, Filter
41	122728X	Spring, Filter
42	122706X	Plug, Check Valve
43	122705X	O-Ring
44	122702X	Ball
45	122704X	Spring, Check
46	122787X	Plug, Std. Thd.
47	122752X	Screw, Socket Hd. M8 x 35
48	122753X	Screw, Socket Hd. M8 x 20
50	122788X	Washer, Thrust
51	122789X	Pin, Spiral
52	122754X	Plug, Std. Thd.
53	122711X	O-Ring Bypass Valve
54	122708X	Spring
55	122709X	Bypass Spool
56	122712X	Bypass Plug
57	122710X	O-Ring, Bypass Valve
58	122727X	Nameplate
59	122790X	Plug, Plastic
60	122791X	Spring
	121430X	Pump Assy. Complete

REPAIR PARTS

YARD TRACTOR

TRANSAXLE



REPAIR PARTS

TRANSAXLE

YARD TRACTOR

1	122614X	Housing, Half L.H.	31	122659X	Washer, Flat .343 x .88 x .062
2	122615X	Housing, Half R.H.	32	122660X	Arm, Brake Actuator
3	122616X	Axle L.H.	33	122662X	Pin, Brake Actuating
4	122620X	Axle R.H.	34	122663X	Brake, Yoke
5	122621X	Bearing, Ball	35	122664X	Disc, Brake
6	122622X	Washer, Flat 3/4 x 1 - 1/8 x .030	36	123065X	Key 3/16 x 5/8
7	122623X	Gear, Miter	37	122666X	Screw, Hex 1/4 - 20 x 1.50
8	122624X	Gear, Miter	38	122667X	Plate, Puck
9	122625X	Nut, Hex Jam W/Patch 1/2 - 20	39	122668X	Puck, Brake
10	122626X	Shaft, Cross	40	123066X	Screw, Hex W/Patch 1/4 - 20 x 2.00
11	122688X	Screw, Stud	41	122670X	Screw, Hex Self-Tap 1/4 - 20 x 2.00
12	122629X	Snap Ring	42	122671X	Screw, Hex Self-Tap 1/4 - 20 x 3.00
13	122631X	Bearing, Thrust	43	122672X	Bearing, Ball
14	122633X	Housing Assembly, Differential	44	122673X	Bearing, Ball
15	122634X	Bearing, Flange	45	122674X	Shaft, Pinion N/11 Tooth Gear
16	122640X	Gear, Differential 72 Tooth	46	122675X	Shaft, Drive
17	122641X	Screw, Pan Hd. W/Patch 1/4 - 20 x .500	47	123059X	Bearing, Needle
		Lg.	48	123060X	Bronze Thrust Brg. 5/8 x 11/4 x 7/64
18	122642X	Shaft, Input	49	122654X	Washer, Flat .62 - 1.0 x .040
19	122643X	Snap, Ring	50	122689X	Spacer
20	122644X	Retaining Ring 7/16"	51	121839X	Coupling
21	122645X	Housing, Input Bearing	52	122681X	Gear, 60 & 17 Tooth
22	122646X	Bearing, Needle	53	122682X	Nut, Hex 1/4 - 20
23	122647X	Bearing, Thrust	54	122683X	Gear, Drive Pinion 17 Tooth
24	122648X	Washer, Flat 5/8 x 1 - 1/8 x .030	55	122684X	Bolt, Square Head
25	122649X	Key #4, 3/32 x 5/8	56	122685X	Washer 15/16 x .265 x .125
26	122650X	Screw, Hex W/Patch 1/4 x 3/4	57	122686X	Washer 1/4" Spring Lock
27	122651X	Gear, Input Pinion 17 Tooth	58	122687X	Pin, Roll 3/16" x 1/2" Lg.
28	122652X	Washer, Flat .62 - 1.0 x .030	59	122678X	Washer, Flat 5/8 x 1 - 1/8 x .060
--	122653X	Washer, Flat .62 - 1.0 x .020		123061X	Washer, Flat 5/8 x 1 x .050
--	122654X	Washer, Flat .62 - 1.0 x .040	60	123062X	Pin, Dowel 3/32 x 1/4
29	122656X	Pin, Cotter	61	123063X	Seal, Grease
30	122658X	Nut, Castle 5/16 - 24		121431X	Transaxle Assy. Complete