


Model Series 440



Ref.	Part No.	Description
1	747-1161A	Blade Control
2	749-1092A	Upper Handle
	749-1233D†	Upper Handle
3	747-04080	Grass Catcher Frame
4	749-0928A	Lower Handle
5	720-0279	Wing Nut
6	710-1205	Rope Guide
7	710-1174	Carriage Bolt ,5/16-18 x 2
8	664-04011	Grass Bag Assembly
9	720-04072	Hand Knob
10	750-04595	Sleeve Spacer - LH
11	726-0240	Cable Tie
12	710-0703	Carriage Bolt ,1/4-20
13	731-04134A	Rear Discharge Door
14	710-04531	Screw 1/4-20
15	731-04204	Bail Cover
16	732-04090A	Torsion Spring - RH
17	734-04014B	Rear Wheel, 8" x 2.125"
18	731-04150C	Rear Baffle
19	736-0474	Washer, 1.5" OD
20	787-01277	Deck - 21"
21	716-0102	Snap Ring
22	782-5002B	Front Baffle
23	748-04015A	Blade Adapter w/Pulley
24	742-0741	21" Standard Cut Blade
25	710-1257	Hex Bolt , 3/8-24 x 2.5
26	687-02044	Pivot Plate Assembly
27	736-0524B	Blade Bell Support
28	787-01298	Height Adjustment Plate - RH
	787-01299	Height Adjustment Plate - LH
29	720-0426	Adjustment Lever Knob
30	732-0706	Front Lever - RH
	732-0707	Front Lever - LH
31	738-0507B	Shoulder Screw
32	734-04018A	Front Wheel, 8" x 2.125"
33	710-1241	Screw, 1/4-15 x 1.000
34	746-1132	Control Cable - 40.75"

Ref.	Part No.	Description
35	750-04594	Sleeve Spacer - RH
36	731-05642	Trailshield
37	782-7551A	Wheel Dust Cap
38	712-0397	Wing Nut, 1/4-20
39	747-04587	Rear Door Pivot Rod
40	732-04175	Spring Lever
41	687-02071A	Pivot Arm Assembly - RH
	687-02070A	Pivot Arm Assembly - LH
42	710-1652	AB Screw
43	712-04065	Flange Lock Nut, 3/8-16
44	714-0104	Hairpin Clip
45	710-0654A	TT Sems Screw, 3/8-16 x 1.00
46	687-02193	Ht. Adj. Assy. Front - LH
	687-02194	Ht. Adj. Assy. Front - RH
47	687-02270	Rear Handle Bracket Assy. - LH
	687-02271	Rear Handle Bracket Assy. - RH
48	747-1214	Drive Control
49	710-1650	Shoulder Screw
50	746-04203	Drive Cable
51	754-0637A	V-Belt
52	618-04376A	Transmission Assembly
53	731-05020A	Front Drive Cover
54	732-1043	Belt Tension Spring
55	682-0015	Bearing Assembly
56	736-0447	Wave Washer
57	710-0216	Hex Screw
58	715-0221	Dowel Pin
59	717-1762	Gear, 14T - RH
	717-1761	Gear, 14T - LH
60	625-04029†	Electric Start Harness Assembly
61	725-04347†	Key Switch
62	725-04329†	Battery Charger 12V
63	725-0201†	Key
64	710-1667A†	Screw, #10-16 x .75
65	725-04323†	12 Volt Battery
66	728-0199†	Plastic Rivet

† Electric Start Models