


Model Series 820




Ref. No.	Part No.	Description
1	746-04265A	Drive Cable
2	735-04059	Rubber Grommet
3	753-05096A	Drive Control Assembly
4	747-1161A	Blade Control
5	746-04213	Control Cable
6	749-04037	Lower Handle
7	725-0157	Cable Tie
8	732-04265	Torsion Spring, LH
9	710-0599	TT Screw, 1/4-20 x .500
10	787-01343A	21-inch Deck
11	710-0654A	TT Screw, 3/8-16 x 1.00
12	787-01346	Deck Baffle
13	756-04157B†	Upper Engine Pulley
	756-04273††	Upper Engine Pulley
14	756-04156B†	Lower Engine Pulley
	756-04272††	Lower Engine Pulley
15	736-0514†	Flat Washer, .885 x 1.850 x .060
16	748-0376C†	Blade Adapter
	748-04096††	Blade Adapter
17	710-1044	Screw, 3/8-24 x 1.50
18	736-0524B	Blade Bell Support
19	742-0741	21" Mulching Blade

Ref. No.	Part No.	Description
20	736-0513†	Sprg Washer, .890 x 1.70 x .048
21	750-1071†	Sleeve Spacer
	750-04818††	Slv. Spcr., 25mm x 1.375 x .375
22	750-04825††	Sleeve Spacer
23	731-05463A	Deck Baffle
24	710-0260A	Carriage Bolt, 5/16-18 x .62
25	712-04063	Flange Lock Nut, 5/16-18
26	731-05462A	Trailshield
27	731-05157	Mulch Plug
28	731-05017A	Rear Door
29	710-1241	Screw, 1/4-15 x 1.00
30	720-04072	Star Knob
31	732-04264	Torsion Spring, RH
32	711-04374	Door Pivot Rod
33	647-04051	Grass Catcher Frame
34	664-04047	Grass Catcher
35	710-1174	Carriage Bolt, 5/16-18 x 2.00
36	720-0279	Wing Nut
37	710-1205	Eye Bolt
38	749-04206	Upper Handle
39	731-05903	Engine Baffle
40	736-0447††	Washer, Wave, 1.5 x 1.0 x .029

† Equipped on Units with Briggs & Stratton Engine

†† Equipped on Units with Honda Engine

Model Series 820



Ref. No.	Part No.	Description
1	754-04093	V-Belt
2	732-04338	Spring Lever
3	720-0230	Foam Grip
4	717-04184A	Spur Gear, 14T - LH
5	710-0599	TT Screw, 1/4-20 x 0.50
6	750-04305A	Spacer
7	749-04267A	Cross Bracket
8	687-02204	Front Bracket Assembly
9	731-05470	Clip Spacer
10	741-04136B	Split Hex Flange Bearing
11	734-1987	Front Wheel
12	712-04065	Flange Lock Nut, 3/8-16
13	634-04363	Rear Wheel
14	710-04531	Screw, 1/4-20 x .39
15	717-04192A	Spur Gear, 14T - RH
16	736-3084	Flat Washer
17	782-7551A	Wheel Dust Cover
18	748-04159	Transmission Bearing Support
19	731-05872	Clip Spacer
20	716-0198	Retaining Ring .875
21	687-02314	Rear Bracket Assembly
22	732-0320	Extension Spring
23	756-04237	Pulley, 3.36 OD
24	736-0258	Flat Washer, .385 x 1.0 x .135
25	712-04063	Flange Lock Nut, 5/16-18
26	687-02205	Handle Bracket Assembly LH
27	715-0221	Dowel Pin
28	618-04492	Transmission Assembly
29	687-02206	Handle Bracket Assembly RH
30	748-0390	Spacer, Bearing Support
31	750-04640	Spacer, .375 ID x .255 Lg.