


**MODEL 131K**  
**4 HP 21" Cut Deluxe Convertible Mower**



**MODEL 131K**  
**4 HP 21" Cut Deluxe Convertible Mower**

Index No.	Part No.	Description	Index No.	Part No.	Description
1	042994	Wheel - Rear 10"	53	156810	Rivet - Spec. Pop 3/16
2	380568	Bolt - Blade	54	109504	Support - Chute Opening
3	449587	Bolt - 1/4-20 x 5/8	55	715136	Washer - Flat #10
4	031245	Blade - 21	56	001800	Decal - Catcher Warning
5	089904	Coupling - Blade	57	157552	Clamp - Cable
6	150276	Key - Woodruff #6	58	001206	Decal - Blade Rotation Warning
7	156406	Nut - 3/8-16 Flange Lock	59	110379	Tie - Cable
8	158907	Bolt - Carriage 5/16-18 x 5/8	60	148411	Decal - Warning Oil Overfill
9	796599	Decal - Lawn Chief	61	715292	Bolt - 1/4-20 x 1
10	091819	Wheel Arm	62	793844	Decal - Engine Control
11	157610	Locknut - Flange 5/16-18	63	156422	Insert - Plastic 1/4
12	452573	Nut - 1/4-20 Acorn	64	381475	Spacer
13	157420	Bolt - Wheel	65	152371	Guide - Upper Rope
14	042952	Wheel - Front 8"	66	715037	Nut - Hex Keps 1/4-20
15	150029	Bolt-Curved Head 1/4 x 1-1/2	67	052209	Cable - Engine/Blade Control
16	091835	Lever - Height Adjustment	68	451492	Nut - Flange Top Lock 3/8-16
17	114462	Tip - Plastic Lever	69	073221	Handle - Lower
18	001818	Decal - Chute Warning	70	161042	Top - Catcher
19	091850	Plate - Back	71	073015	Bail - Coated
20	112052	Cover - Deck	72	073205	Handle - Upper
21	156265	Screw - Wing 1/4-20 x 3/4	73	114595	Cover - Body Assembly - Chute
22	462093	Washer - Flat 1/4	74	744284	Knob - Handle
23	156281	Nut - Speed 1/4	75	672345	Cap - Hub
24	018358	Deck - Push 21	76	160879	Frame & Bag Assembly
25	087874	Baffle - Rear	77	110064	Cap - Plastic Bolt
26	109165	Baffle - Front	78	017921	Support - Catcher
27	114124	Bracket - Grassbag Support	79	156414	Bolt - Hex Flange 3/8 x 1
28	457168	Bolt - Hex 5/16-18 x 1-1/4 Gr. 5	80	380550	Bolt - Curved Head 1/4-20 x 2-1/4
29	019158	Bracket - Handle LH	81	052555	Control - Throttle
30	019141	Bracket - Handle RH	82	164020	Washer - Hardened
31	156349	Rivet - Pop 1/8 x 1/4	83	143115	Decal - Warning CPSC
32	715243	Rivet - Pop 3/16 x 7/16	84	089896	Adapter - Blade
33	113878	Shield - Trailing	85	031252	Tip - Air Lift
34	152389	Rivet - 3/16 x 11/32	86	153510	Washer - 5/16 Int. Tooth
35	109496	Strip - Backing	87	157974	Nut - 5/16 Hex
36	159780	Bolt - Hex 5/16-18 x 5/8	88	163691	Screw - 5/16-24 x 1/2
37	150623	Screw - Hex Slotted #10 x 5/8	89	086769	Bracket - Starter Rope
38	001446	Decal - 21"	90	086702	Pulley - Steel
39	715508	Nut - 1/4-20 Toplock	91	158773	Bolt - Wheel, Rear
40	111963	Clip - Handle	92	715441	Nut - 3/8-16 Twin Whiz
41	134445	Seal - Door	93	715607	Washer - Belleville
42	134452	Seal - Bag	94	085498	Muffler - Deflector
43	156299	Knob Catcher	95	120048	Screw - #8-32 x 3/8
44	156307	Shaft - Connecting	96	155549	Washer - 1/2
45	310052	Nut - Hex 1/4-20	97	030528	Blade - 21" Mulcher
46	156844	Nut - Push 1/8	98	156232	Bolt - Blade
47	153510	Lockwasher - Internal Tooth 5/16	99	615674	Lockwasher - 1/2
48	150201	Washer - Curved 5/16	100	715326	Bolt - 3/8-16 x 1 Gr. 5
49	114520	Chute - Curved 5/16	101	715086	Locknut - Hex 3/8-16
50	151936	Bolt - Curved Head 5/16-18 x 2-1/4	102	163972	Bolt - Shoulder
51	381442	Clip - Tinnerman			
52	178848	Bracket - Pulley Support			

- This parts list covers several different mower models; not all of the parts listed may be used on the particular model you are working with.
- When servicing use only **Genuine Factory Replacement Parts (OEM)** that are specifically designed for the particular model that you are working with.
- Parts are right or left hand as viewed from the operator's position.
- Model specifications are subject to change without prior notice.
- **Do not operate** the mower unless all parts are attached and in good working order.
- Lawn mower deck and/or other painted parts differing in color may be substituted without notice.