






Ref #	Part Number	Qty	Description
1	731-0220		Steering Wheel Cap
	731-1459A		Steering Wheel Cap
	731-1460		Steering Wheel Cap
2	710-0643		Hex Bolt 5/16-18 x 1" Lg.
3	736-0242		Belleville Wash. .345" I.D.
4	731-1693		Steering Wheel
	731-1687		Steering Wheel
	631-0027		Steering Wheel
5	731-0559A		Steering Bellow-4.5"
	731-0954		Steering Bellow-9"
	731-1542		Steering Bellow-3.25"
26	712-0240		Hex Jam Nut 7/16-20 Thd.
7	741-0587		Flange Bearing .628" I.D. x 1.36 O.D.
28	723-0448		Ball Joint 7/16-20 Thd.
9	17198A		Retainer Plate
10	738-0141		Shoulder Bolt .437 x .35 Lg. 5/16-18
11	710-0152		Hex Bolt 3/8-24 x 1.0" Lg. (Gr. 5)
13	750-0535		Spacer .380" I.D. x .625" O.D.x
14	736-0217		L-Wash. 3/8" I.D. (H.D.)
15	710-0726		Hex Wash. Hd. Self-Tap Scr.
16	711-1107		Steering Drag Link
17	783-0041B		Front Pivot Brkt.
18	738-0527		Shoulder Bolt
19	712-0431		Flanged L- Nut 3/8-16 Thd.
21	712-0411		Hex L-Nut 5/16-24 Thd.
22	16481A		Steering Arm Front Axle
23	710-0593		Hex Bolt 5/16-24 x 2.25" Lg.
24	741-0659		Hex Flg. Brg. .632 I.D.
25	683-0128A		Pivot Bar Ass'y. (Steel)
	719-0342A		Pivot Bar Ass'y. (Cast Iron)
	737-0212A		Grease Fitting (Cast Iron)
26	683-0127		Front Axle Ass'y.-L.H.
	683-0125		Front Axle Ass'y.-L.H.
27	712-0241		Hex Nut 3/8-24 Thd.
28	736-0169		L-Wash. 3/8" I.D.
29	723-3018		Ball Joint 3/8-24 Thd.
30	747-0753		Tie Rod
	747-0861		Tie Rod
31	712-0711		Hex Jam Nut 3/8-24 Thd.
32	683-0126		Front Axle Ass'y.-R.H.
	683-0124		Front Axle Ass'y.-R.H.
33	634-0056A		Wheel Ass'y. Comp.
	734-0864		Tire Only
	734-0255		Air Valve
	634-0105A		Wheel Ass'y. Comp.
	734-1731		Tire Only
34	634-0024		Rim Only
35	741-0487A		Bearing
36	736-0285		FI-Wash. .635 I.D. x 1.59" O.D.
37	731-0484A		Front Wheel Hub Cap
	734-1787A		Spoked Hub Cap
	734-1613A		Spoked Hub Cap
	734-1612A		Spoked Hub Cap
38	714-0470		Cotter Pin 1/8" Dia. x 1.25"
39	736-0162		FI-Wash. .640" I.D. x 1.24" O.D.
40	726-0214		Push Cap 5/8" Dia. Rod
42	712-0262		Hex Jam Nut 3/8-24 Thd.
43	710-1309		Hex Patch Bolt 5/16-18 x .62"
44			UNKNOWN
46	748-0389		Cap


Ref #	Part Number	Qty	Description
46	748-0389		Cap
47	712-0214		Hex Cent. L-Nut 3/8-24 Thd.
48	736-0169		L-Wash. 3/8" I.D.
49	712-0158		Hex Cent. L-Nut 5/16-18 Thd.
50	736-0119		L-Wash. 5/16" I.D.
51	717-0622A		Steering Gear Segment
52	741-0656		Hex Flg. Brg. .634 I.D.
53	736-0187		FI-Wash. (Hardened)
54	738-0919		Steering Shaft
57	710-0837		Oval Hd. Cr.-Sunk Scr.
58	736-3081		Wave-Wash. .32" I.D. x .60" O.D.
59	736-0187		FI-Wash. (Hardened)
60	723-0448		Drag Link Ball Joint 7/16-20 Thd.
61			UNKNOWN
63	727-0425A		Spring Clip
64	736-0356		Bell-Wash. .39" I.D. x 1.38" O.D.
65	731-1291A		Pivot Bar End Cap
66	710-0459		Hex Bolt 3/8-24 x 1.5" Lg. (Gr. 5)
69	731-1649		Axle Cap
70	731-0955		Steering Wheel Insert



Ref #	Part Number	Qty	Description
2	710-1260A		Hex Wash. TT-Tap Scr. 5/16-18 x .75"
3	683-0129		38" Deck Ass'y.
	753-0694		38" Deck Ass'y. Comp.
4	783-0343A		Belt Guard Deck
7	712-3006		Hex L-Nut 1/4-20 Thd.
8	710-0751		Hex Bolt 1/4-20 x .62"
10	711-0792		Hinge Pin
13	712-0181		Hex Top L-Nut 3/8-16 Thd.
14	712-3006		Hex Nut 1/4-20 Thd. (Gr. 5)
17	734-0973		Deck Wheel-5"
18	736-0105		Bell-Wash. .40" I.D. x .88" O.D.
22	738-0373		Shld. Bolt .498" Dia. x 1.53"
23	742-0610		3 in 1 Blade
26	754-0329A		V-Belt
27	736-0270		Bell-Wash. 1/4" I.D.
28	783-0342		Brake Disc
?33	710-0157		Hex Bolt 5/16-24 x .75" Lg.
35	712-0417A		Hex Flange Nut 5/8-18 Thd.
?37	736-0158		L-Wash. 5/8" I.D.
39	618-0138		Blade Spdl Ass'y.
42	756-0969		5" Dia. Pulley
52	703-1693		Hinge Mtg. Brkt.
53	732-0602		Torsion Spring
54	726-0106		Push Nut
55	731-1032		Chute Ass'y.
56	710-0597		Hex Bolt 1/4-20 x 1" Lg.
57	712-3087		Wing Nut 1/4-20 Thd.
58	731-1643A		Mulching Plug
59	16606		Retainer Hook Brkt.
60	712-3027		Hex Flange Nut 1/4-20 Thd.
61	710-0751		Hex Bolt 1/4-20 x .62" Lg.
62	736-0173		Flat Washer .28 ID x .74 OD




Ref #	Part Number	Qty	Description
1	783-0103		Connecting Rod
2	683-0029A		Pivot Link Ass'y. - L.H.
3	683-0028A		Pivot Link Ass'y. - R.H.
4	17710		Deck Hanger Link Ass'y.
5	14800A		Deck Hanger Link Ass'y.
6	14804A		Deck Hanger Link Ass'y.
7	748-0331		Shld. Spacer .318" I.D.
8	736-0231		Fl-Wash. .344" I.D. x 1.125" O.D.
9	736-0119		L-Wash. 5/16" I.D.
10	712-3004A		Flange Lock Nut 5/16-18 Thd. (Gr. 5)
12	714-0470		Cotter Pin 1/8" Dia.
13	736-0256		Fl-Wash. .635" I.D. x 1.0" O.D.
14	683-0003		Hgt Adj. Stop Lever Ass'y.
15	08540		Knob
16	710-0604A		Hex Wash. TT-Tap Scr.5/16-18 x .75"
17	748-0176		Flange Brg. .63" I.D.
18	710-1238		Hex Wash. Hd. Scr. 5/16-18 x .875" Lg.
19	710-3008		Hex Bolt 5/16-18 x .75" Lg.
20	17730		Index Brkt.
21	783-0042B		Upper Frame-R.H.
23	736-0267		Fl-Wash. .385" I.D. x .87" O.D.
24	736-0160		Fl-Wash. .531" I.D. x .93" O.D.
25	726-0272		Clamp
26	738-0526		Running Board Rod
27	710-3007		Hex Wash. Hd. Tap Scr.
28	14802A		Link Deck Lift Ass'y.
29	711-0723A		Adj. Ferrule 3/8-24 Thd.
30	17712		Adj. Deck Lift Link
31	712-3066		Hex Nut 1/2-20 Thd. (Gr. 5)
32	711-0841		Lift Link Adjuster
33	17637A		Lift Shaft Ass'y.
34	725-1657A		Safety Switch (Deck)
35	714-0145		Inter. Cotter Pin 3/8" Dia.
36	732-0637		Extension Spring
37	17636C		Stabilizer Bracket
38	738-0670A		Shaft 1/2" Dia. x 10.28" Lg.
39	732-0638		Extension Spring
40	720-0233		Grip (Lift Handle)
41	97675A		Deck Lift Handle Ass'y.
42	738-0669		Shaft 3/8" Dia. x 9.34" Lg.
43	747-0598		Disengagement Rod
44	97624		Stabilizer Shaft Ass'y.
45	732-0556		Extension Spring 7.58" Lg.
46	783-0043		Upper Frame-L.H.
47	741-0313		Flange Brg. .632" I.D.
48	17128A		Spring Retainer Brkt.
49	716-0104		"E"-Ring
50	736-0425		Bell-Wash. .325" I.D.




Ref #	Part Number	Qty	Description
2	17840		Transaxle Mtg. Brkt.
5	736-0119		L-Wash. 5/16" I.D.
6	710-0599		Self-Tap Screw 1/4 x .50
10	710-1315		Hex TT-Tap Scr. 3/8-16 x 1.5" Lg.
11	783-0310C		Lower Frame Ass'y.
13	712-3006		Hex Nut 1/4-20 Thd. (Gr. 5)
14	736-0329		L-Wash. 1/4" I.D.
17	736-0242		Bell-Wash. .345" I.D. x .88"
18	712-3010		Hex Nut 5/16-18 Thd. (Gr. 5)
19	711-1044		Belt Guard Stud 4.75" Lg.
21	756-0982		Engine Pulley
?22	736-0322		FI-Wash. 7/16" I.D. x 1.25"
23	736-0171		L-Wash. 7/16" I.D.
?24	710-0757		Hex Bolt 7/16-20 x 1.50" Lg.
25	754-0280A		Variable-Speed Belt
26	710-3008		Hex Bolt 5/16-18 x .75" Lg.
27	17963		Bearing Shaft Bracket Ass'y.
28	741-0495		Flanged Nyliner Brg. 5/8" I.D. x .88" Lg.
29	712-0241		Hex Nut 3/8-24 Thd.
30	17643		Idler Bracket
	17694		Idler Bracket
31	736-0169		L-Wash. 3/8" I.D.
32	712-0241		Hex Nut 3/8-24 Thd.
33	17629A		Transaxle Support Brkt.
34	732-0556		Ext. Spring .94" O.D. x 7.58"
35	714-0149B		Inter. Cotter Pin
36	750-0802		Spacer .63" I.D.
37	710-3029		Cap Screw 7/16-20 x 1.25
38	736-0322		Flat Washer .450
39	712-0138		Hex Nut 1/4-28 Thd.
?40	710-0776		Hex AB-Tap Scr. 1/4" x .62" Lg.
42	736-0222		Ext. L-Wash. 1/4" I.D.
43	710-0599		Hex Wash. S-Tap Scr. 1/4-20 x .50" Lg.
44	683-0123		Clutch/Brake Pedal Ass'y.
45	736-0140		FI-Wash. .344" I.D. x .62"
47	747-0755A		Brake Rod Ass'y.
48	735-0196		Foot Pad
51	17705		Shift Lever Ass'y.
54	732-0413		Ext. Spring .59" O.D. x 7.08"
	732-0642		Ext. Spring 7.33" Lg.
55	710-1068		Hex Bolt 5/16-18 x 3.5" Lg.
	710-0189		Hex Bolt 5/16-18 x 3" Lg.
56	734-1675		Wheel Ass'y. Comp.
	734-1596		Tire Only
	634-0104		Wheel Ass'y Comp.
	734-1730		Tire Only
57	634-0070		Rim Only
58	734-0255		Air Valve
59	710-0627		Hex Bolt 5/16-24 x .75" Lg.
63	736-0275		FI-Wash. .34" I.D. x .68" O.D.
64	710-0428		Hex Bolt 1/4-28 x 1.25" Lg.
?65	732-0568		Ext. Spring
66	732-0384		Ext. Spring .62" O.D. x 6.12"
67	16554A		Variable Speed Torque Brkt. Ass'y.
68	741-0419		Flanged Bearing
69	714-0111		Cotter Pin 3/32" Dia.
70	748-0234		Shoulder Spacer .27" Lg.
71	747-0530A		Speed Control Link
72	741-0405		Truss Bearing .56 Dia. x 1.25"
73	720-0232		Shift Knob


Ref #	Part Number	Qty	Description
73	720-0232		Shift Knob
74	756-0643		FI-Idler Pulley 3.12" Dia.
75	656-0005		"V" Pulley
	656-0004		"V" Pulley
76	736-0427		Bell-Wash. .56" I.D. x 1.125"
77	712-3035		Hex Jam Nut 5/16-18 Thd.
78	710-0539		Hex Bolt 3/8-24 x 1.75" Lg.
79	754-0370		Variable Speed Belt
80	716-0114		Snap Ring .56" Dia.
81	736-0355		FI-Wash.
82	717-0800A		Variable Speed Pulley Ass'y.
84	16354B		Variable Speed Brkt. Ass'y.
85	732-0525		Comp. Spring-Clip
86	17668		Axle Support Brkt.-R.H.
	17669		Axle Support Brkt.-L.H.
88	725-1426		Solenoid
89	17630		Shift Lever Bracket
90	736-0414		Teflon Washer .565" I.D.
91	750-0956		Spacer 1" I.D. x 1.25" Lg.
92	711-1000		Belt Keeper 3" Lg.
93	725-1657A		Safety Switch (Clutch)
94	738-0755		Shld. Bolt 3/8-24 x 3.12" Lg.
96	748-0344		Transaxle Spacer
97	736-0105		Bell-Wash. .38" I.D. x .88"
98	738-0569		Shaft .56" Dia. x 3.875" Lg.
99	736-0331		Bell-Wash. .39" I.D. x 1.12"
100	736-0256		FI-Wash. .64" I.D. x .94"
101	714-0470		Cotter Pin 1/8" Dia. x 1.25"
102	710-0604A		Hex Wash. Hd. Scr. 5/16-18 x .62"
103	734-1615A		Hub Cap
	734-1614A		Hub Cap
	734-1788A		Hub Cap
107	17860		Pedal Bracket
109	711-0198		Ferrule
111	710-0195		Hex Bolt 1/4-28 x .50" Lg.
112	736-0270		Bell-Wash. .265" I.D. x .75"
113	17707		Shift Lever Link Ass'y.
115	736-0140		FI-Wash. .385" I.D. x .62"
116	741-0404		Needle Brgs.
117	727-0425A		Spring Clip
128	710-1238		Hex Wash. TT-Tap Scr. 5/16-18 x .75"
129	710-0726		Hex Wash. AB-Tap Scr. 5/16-18 x .75"
130	712-0265		Hex Sems Nut 5/16-18 Thd.
131	732-0750A		Spring Switch




Ref #	Part Number	Qty	Description
1	629-0305D		Wire Harness w/Light Switch & Amp
	629-0301D		Wire Harness w/o Light Switch & Amp
2	725-0267		Ignition Switch
3	725-0634		Light Switch
4	725-0925		Ammeter
5	725-0963		Bulb
6	725-1426		Solenoid
7	725-1643		Safety Switch
8	725-1657A		Safety Switch
10	726-3046		Ratchet



Ref #	Part Number	Qty	Description
	634-0056A		Wheel Ass'y. Comp.
	734-0864		Tire Only
	634-0024		Rim Only
	741-0487A		Bearing
	734-0255		Air Valve
	737-0212A		Grease Plug
	683-0127		Front Axle Ass'y.-L.H.
	683-0126		Front Axle Ass'y.-R.H.
	683-0125		Front Axle Ass'y.-L.H.
	683-0124		Front Axle Ass'y.-R.H.
	634-0105A		Wheel Ass'y. Comp.
	734-1731		Tire Only



Ref #	Part Number	Qty	Description
1	783-0250		Hood
2	738-0952A		Shld. Bolt .375" Dia. x .125" Lg.
6	712-3006		Hex Sems Nut 1/4-20 Thd.
9	712-3027		Flange L-Nut 1/4-20 Thd.
10	783-0156A		Grille
13	725-0963		Lamp
14	725-1651		Socket
15	710-0703		Carriage Bolt 1/4-20 x .75" Lg.
17	736-0173		Fl-Wash. .281" I.D. x .73" O.D.
18	726-0233		Bolt Retainer 1/4" I.D.
19	712-0185		Speed Nut 1/4-20 Thd.
20	710-0376		Hex Bolt 5/16-18 x .1" Lg. (Gr.5)
21	17632A		Gas Tank Support Brkt.
22	731-1096B		Dash w/Ammeter Hole
	731-1337A		Dash w/o Ammeter Hole
23	725-0267		Ignition Switch
24	725-0201		Ignition Key
25	746-0616A		Choke Control 23" Lg.
	746-0614A		Choke Control 38" Lg.
	746-3021		Choke Control 29" Lg.
	746-0720		Choke Control 20" Lg.
26	725-0634		Light Switch
27	725-0925		Ammeter
32	710-0924		Pan Hd. Scr. 1/4-20 x .75" Lg.
34	17870A		Fender
35	17871B		Fender w/Cutout
38	710-0726		Hex Wash. Hd. AB-Tap Scr.5/16 x
39	17954B		Shift Cover w/Cutout
40	17286B		Shift Cover
41	831-0823A		Throttle Box Ass'y.
42	710-0779A		Truss Mach. AB-Tap Scr.#10 x .5"
43	746-0776		Throttle Control Wire 18.5" Lg.
	746-0634		Throttle Control Wire 35" Lg.
	746-0638		Throttle Control Wire 22" Lg.
45	710-0603		Hex Wash. Hd. B-Tap Scr.
46	17782		Choke Retainer
47	710-0642		Hex TT-Tap Scr. 1/4-20 x .75"Lg.
49	731-1503A		Lens
?50	783-0367		Side Panel L.H.
51	783-0366		Side Panel R.H.
71	726-0211		U-Nut 5/16-18 Thd.
72	710-0286		Truss Mach. Scr. 1/4-20 x .5" Lg.
73	749-0722B		Grille Support
74	732-0699		Hood Spring
75	726-0130		Speed Nut
76	710-0751		Hex Bolt 1/4-20 x 5/8" Lg.
77	736-0342		Fl-Wash. .283" I.D. x .75" O.D.
78	710-0589		Hex Hd. Tap Scr. #10-16 x .75"
	629-0309		Headlight Harness




Ref #	Part Number	Qty	Description
1	710-0148		Hex Bolt #8-32 x .38" Lg.
2	710-0599		Hex Wash. Hd. TT-Scr. 1/4-20 x .5"
3	710-0604		Hex Wash. Hd. TT-Scr. 5/16-18 x .62"
4	710-1314		Socket Hd. Bolt 5/16-18 x .62" Lg.
5	710-1315		Hex Wash. Hd. TT-Scr. 3/8-16 x 1.25"
6	712-0271		Hex Sems Nut 1/4-20 Thd.
8	721-0348		Exhaust Gasket
9	726-0205		Hose Clamp
10	726-0272		Clamp
11	736-0119		L-Wash. 5/16" I.D.
13	737-0286		Pipe 3/8 NPT x 3.8" Lg.
	737-0199		Pipe 3/8 NPT x 2" Lg.
14	751-0535-12		Fuel Line
15	751-0564		Muffler Deflector
16	751-0572		Hex Pipe Plug
	737-0143		Oil Drain Cap
17	751-0617		Muffler
18	751-0620		Exhaust Pipe
	751-0622		Exhaust Pipe
19	783-0378A		Heat Shield
20	783-0615		Muffler Bracket

No
Diagram
Available


Parts List
Only

Ref #	Part Number	Qty	Description
	734-1675		Wheel Ass'y. Comp.
	734-1596		Tire Only
	634-0070		Rim Only
	634-0104		Wheel Ass'y Comp.
	734-1730		Tire Only




Ref #	Part Number	Qty	Description
2	710-1208		Hex Tap Scr. 5/16-18 x 3.25"
6	783-0039A		Seat Pivot Bracket
7	751-0603		Fuel Cap
8	751-0555		Fuel Tank
	751-0657		Fuel Tank
9	726-0209		Tie Strap
10	751-0535-15		Fuel Line
11	726-0205		Hose Clamp
13	712-0287		Hex Nut 1/4-20 Thd.
14	736-0329		L-Wash. 1/4" I.D.
16	732-0735		Compression Spring
21	738-0526		Running Board Rod
22	710-0227		Hex AB-Tap Scr. #8 x .50" Lg.
?23	726-0139		Speed Nut #10Z
24	783-0041A		Front Pivot Brkt.
25	710-0870		Hex Tap Scr. 3/8-16 x .62" Lg.
26	710-0726		Hex Wash. Hd. AB-Tap Scr. 5/16 x .75"
28	710-0134		Carriage Bolt 1/4-20 x .62"
29	17770D		Running Board (R.H. & L.H.)
30	761-0168B		Blade Brake Ass'y.
32	731-0909		Rubber Foot Pad-L.H.
	731-0910		Rubber Foot Pad-R.H.
	723-0422		Abrasive Foot Pad
33			UNKNOWN
34	783-0310C		Lower Frame
36	726-0278		Insulator Boss Plate
?37	736-0264		Fl-Wash. .344" I.D. x .625" O.D.
38	710-3008		Hex Bolt 5/16-18 x .75" Lg.
39	783-0042B		Upper Frame-R.H.
42	732-0581B		Extension Spring 5.31" Lg.
44	725-1707D		12-V Battery
45	783-0043		Upper Frame-L.H.
46			Shift Cover
47	725-1643		Reverse Safety Switch
48	726-0279		Insulator Plate
49	17951A		Seat Pivot Brkt. Support-L.H.
50	783-0355A		Hitch Plate
51	712-0267		Hex Nut 5/16-18 Thd.
52	736-0119		L-Wash. 5/16" I.D.
53	17239A		Seat Lift Brkt.
54	757-0363A		Seat 8-7/8" High
	757-0364A		Seat 8-7/8" High
	757-0360A		Seat 10-5/8" High
	757-0365		Seat 10-5/8" High
	757-0348A		Seat 14-1/4" High
	757-0372		Seat 14-1/4" High
	757-0350		Seat 14-1/4" High w/ Drain holes
55	17950A		Seat Pivot Brkt. Support-R.H.
56	738-0296		Shld. Bolt .437" Dia. x .268"
57	725-1303		Spring Switch
?59	710-0650		Hex TT-Tap Scr. 5/16-18 x 7/8"
62	726-0320		Insulatop Nut Plate
63	725-1439		Safety Switch (Seat-Inner)
65	783-0345		Battery Tray
66	710-0351		Truss Mach. B-Tap Scr.#10 x .5" Lg.
67	748-0347		Spring Spacer
68	710-0323		Truss Mach. Scr. 5/16-18 x .75"
69	710-3008		Hex Bolt 5/16-18 x .75" Lg.
?70	731-0405		Snap Bushing
71	723-3064		Battery Retainer Strap

Ref #	Part Number	Qty	Description
71	723-3064		Battery Retainer Strap
72	712-3010		Hex Nut 5/16-18 Thd.
73	712-0265		Hex Sems Nut 5/16-18 Thd.
74	712-0271		Hex Sems Nut 1/4-20 Thd.
75	738-1007		Shoulder Screw 3/8-16 x .5
76	710-1268		Hex Wash. Hd. B-Tap Scr.
77	712-3027		Hex Flanged L-Nut 1/4-20 Thd.
78	720-0309A		Seat Adjustable Grip
79	731-1989		Spacer
80	732-0499		Compression Spring 1.5" Lg.
81	736-0175		Spring Wash. .265" I.D.
82	736-0204		Fl-Wash. .344" I.D. x .62" O.D.
84	738-0137A		Shld. Bolt .34" x 1/4 -20 Thd.
85	783-0607A		Seat Pivot Bracket
86	783-0609		Seat Lever
87	783-0753		Seat Selector
88	783-0611		Seat Stop
?89	747-1216		Stop Rod
?90	712-3017		Hex Nut 3/8-16
?91	736-0169		Lock Washer



Ref #	Part Number	Qty	Description
1	732-0645		Compression Spring
2	712-0267		Hex Nut 5/16-18 Thd.
3	736-0119		L-Wash. 5/16" I.D.
4	17956		Shift Lever Support
5	711-0198		Ferrule 3/8-24 Thd.
6	747-0787		Speed Control Rod
7	750-0662		Spacer 1.56" Lg.
8	736-0253		Bell-Wash. .505" I.D. x 1"
9	736-0300		Fl-Wash. .385" I.D. x .87"
10	17888A		Speed Selector Lever
11	720-0232		Shift Knob
12	750-0913		Spacer 1.46" Lg.
13	736-0159		Fl-Wash. .345" I.D. x .88"
14	710-3056		Hex Bolt 5/16-18 x 3.25" Lg.
15	714-0111		Cotter Pin 3/32" Dia. x 1"
16	736-0226		Fl-Wash. .469" I.D. x .88"
17	736-0418A		Fl-Wash. .34" I.D. x 2.25"
18	726-0201		Speed Nut 5/16-18 Thd.



Ref #	Part Number	Qty	Description
1	732-0614		Wire Ring
2	716-0231		"E"-Ring
4	710-1325		Hex Tap Scr. 1/4-20 x 1.625 Lg.
5	719-0367		Upper Housing
8	711-1109		Input Shaft
10	736-0335		Thrust Washer 5/8" I.D. x 1.25" O.D.
11	717-1464		Pinion Input 14T
12	716-0108		Retaining Ring
13	711-1003		Drive Shaft-R.H. Brake
14	741-0336		Flange Brg. 5/8" I.D. x 3/4" Lg.
15	717-1362		Bevel Gear 42T Small I.D.
16	717-1363		Bevel Gear 42T Large I.D.
17	718-0228		Clutch Collar
21	710-0862A		Pan Head Scr. 1/4-20 x .50" Lg.
23	741-0340		Sleeve Bearing 3/4" I.D. x 1.0" Lg.
24	721-0338		Oil Seal 3/4" I.D.
26	736-0445		FI-Wash. .760" I.D. x 1.5" O.D.
32			Washer
	736-0495		Thrust Wash. 5/8" I.D. x 1" O.D. x .025" Thk.
	736-0336		FI-Wash. 5/8" I.D. x 1" O.D. x .030" Thk.
	736-0494		Thrust Wash. 5/8" I.D. x 1" O.D. x .035" Thk.
	736-0337		Thrust Wash. 5/8" I.D. x 1" O.D. x .040" Thk.
34	719-0313B		Lower Housing
35	718-0150		Anti-Rotation Brkt.
37			Washer
	736-0349		FI-Wash. 5/8" I.D. x 1" O.D. x .020" Thk.
	736-0336		FI-Wash. 5/8" I.D. x 1" O.D. x .030" Thk.
	736-0337		FI-Wash. 5/8" I.D. x 1" O.D. x .040" Thk.
38	712-0273		Hex Nut 5/16-24 Thd.
39	736-0371		FI-Wash. .344" I.D. x .875" O.D.
40	717-0700		Actuating Arm
41	761-0198		Brake Yoke
42	717-0682		Puck Plate
43	717-0678		Brake Puck
45	761-0202		Brake Disc
46	741-0337		Flange Bearing 5/8" I.D. x 15/16" Lg.
48	611-0011		Shift Fork Ass'y.
49	741-0862		Ball Detent .250" Dia.
50	732-0863		Spring Detent
52	741-0335		Needle Brg. 5/8" I.D. x 1/2" Lg.
54	736-0349		FI-Wash. 5/8" I.D. x 1" O.D. x .020 Thk.
55	741-0343		Actuating Pin 5/16" Dia.
56	710-1206		Hex Wash Hd. Self-Tap Scr. 1/4-20
58	736-0349		FI-Wash. 5/8" I.D. x 1" O.D. x .020 Thk.
	736-0495		Thrust Wash. 5/8" I.D. x 1" O.D. x .025"
60			Washer
	736-0492		FI-Wash. .76" I.D. x 1.5" O.D. x .010" Thk.
	736-0493		FI-Wash. .76" I.D. x 1.5" O.D. x .020" Thk.
	736-0351		FI-Wash. .76" I.D. x 1.5" O.D. x .030" Thk.
	736-0445		FI-Wash. .76" I.D. x 1.5" O.D. x .060" Thk.
61	736-0519		Thrust Washer
62	618-0162		Differential Ass'y.
63	732-0742		R.H.-Brake Spring
	737-0148		Grease-Shell
	618-0163B		Transaxle Comp.