





Ref #	Part Number	Qty	Description
1	17347		Deck Stabilizer
2	17264		Diagonal Brace
6	683-0052		46" Deck Ass'y. Comp.
	683-0053		46" Deck Ass'y. Comp.
	683-0054		46" Deck Ass'y. Comp. (Electric Clutch)
7	710-0258		Hex Bolt 1/4-20 x .62" Lg.
8	711-0792		Hinge Pin
9	712-0287		Hex Nut 1/4-20 Thd.
10	714-0149B		Hairpin Clip
12	736-0270		Bell-Wash. 1/4" I.D.
13	738-0392		Deck Connecting Rod
22	618-0111		Spindle Ass'y. (R.H. & Center)
23	618-0112		Spindle Ass'y. (L.H.)
29	736-0119		Lock Wash. 5/16" I.D.
30	736-0510		Bell-Wash. .47" I.D. x 1.5"
31	742-0543		High Lift Blade 14.88" Lg. (Middle)
32	742-0542		High Lift Blade 16.28" Lg. (R.H. & L.H.)
35	17116		Deck Brake Brkt. Ass'y.
36	17213		Idler Bracket
37	17258A		Belt Cover Brkt. - R.H.
38	783-0066		Belt Cover - L.H.
39	710-0152		Hex Bolt 3/8-24 x 1.0" Lg.
40	710-0151		Hex Bolt 3/8-24 x 2" Lg.
41	710-0559		Hex Bolt 1/4-28 x 1.75" Lg.
42	710-0599		Hex Wash. Hd. Tap-Scr. 1/4-20 x .5" Lg.
43	710-0624		Hex Bolt 5/16-24 x 1.5" Lg.(Grade 5)
44	710-0698		Hex Bolt 1/4-28 x 1.5" Lg.
46	711-0993		Belt Guard Pin 1/4" Dia.
47	712-0117		Hex Cent. L-Nut 1/4-28 Thd.
48	712-0123		Hex Nut 5/16-24 Thd.
49	712-0138		Hex Nut 1/4-28 Thd.
50	712-0241		Hex Nut 3/8-24 Thd.
51	712-0287		Hex Nut 1/4-20 Thd.
52	712-0417		Hex Flange L-Nut 5/16-18 Thd.
53	727-0426		Brake Cable Ass'y.
	727-0445		Brake Cable Ass'y.
54	732-0594A		Extension Spring 6.17" Lg.
55	732-0429A		Extension Spring 3.97" Lg.
56	736-0105		Bell-Wash. .38" I.D. x .88" O.D.
57	736-0331		Bell-Wash. .39" I.D. x 1.13" O.D.
61	736-0329		L-Wash. 1/4" I.D.
62	736-0416		FI-Wash. 5/16" I.D. x 3" O.D.
63	738-0347		Shld. Spacer .625" I.D.
64	748-0234		Shld. Spacer
65	750-0214		Spacer .34" I.D.
66	750-0470		Spacer .326" I.D.
67	754-0349		V-Belt
68	754-0350		V-Belt
69	756-0627		FI-Idler Pulley 3.5" O.D.
70	756-0969		Pulley 5.0" Dia.
71	756-0977		Double Pulley 5.0" Dia.
72	711-0701		Clevis Pin 1/4" Dia. x .53" Lg.
73	712-0798		Hex Nut 3/8-16 Thd.
74	714-0104		Intern. Cotter Pin 5/16" Dia.
75	714-0145		Intern. Cotter Pin 3/8 Dia.
76	734-0973		Deck Wheel 5" Dia.
77	734-3058B		Deck Wheel w/Insert 5" Dia.
78	736-0169		L-Wash. 3/8" I.D.
79	736-0192		FI-Wash. .531" I.D.
80	738-0533		Shoulder Bolt .498" Dia. x 1.64" Lg.


Ref #	Part Number	Qty	Description
80	738-0533		Shoulder Bolt .498" Dia. x 1.64" Lg.
81	738-3056		Shoulder Bolt
83	732-0602		Torsion Spring
84	703-1693		Hinge Mtg. Brkt.
85	726-0106		Push Nut
86	731-1032		Chute Ass'y. Comp.
87	750-0757		Spacer 5/8" I.D. x 7/8" O.D.
88	17982		Spindle Reinforcement Plate
89	710-1261		Hex Wash. Hd. Scr. 5/16-18 x 1" Lg.
90	710-1260		Hex Wash. Hd. Scr. 5/16-18 x .75" Lg.
91	710-1262		Hex L-Bolt 7/16-20 x 1" Lg.
92	711-0242		Spacer .38" I.D.
93	710-0289		Hex Bolt 1/4-20 x .5" Lg.




Ref #	Part Number	Qty	Description
1	720-0218		Shift Knob
2	647-0010		Speed Control Lever Ass'y.
3	732-0433		Ext. Spring 2.75" Lg.
4	736-0119		L-Wash. 5/16" I.D.
5	712-0123		Hex Nut 5/16-24 Thd.
6	738-0296		Shld. Bolt .437" Dia. x .268"
7	736-0141		Spr. Wash. .445" I.D. x .75" O.D.
8	723-3012		Ball Joint 5/16-24 Thd.
9	747-0857		Speed Selector Adjusting Rod
10	720-0166		Ball Knob
11	747-0876		Brake Lockout Rod
12	16980		Brake Lockout Brkt.
13	750-0214		Spacer .34" I.D. x .88" O.D.
14	712-0267		Hex Nut 5/16-18 Thd.
15	748-0234		Shld. Spacer .27" Lg.
16	741-0225		Hex Flange Bearing
17	710-0528		Hex Bolt 5/16-18 x 1.25" Lg.
18	735-0196		Foot Pad
19	17911		Foot Pedal Ass'y.
20	714-0111		Cotter Pin 3/32" Dia. x 1" Lg.
21	736-0275		FI-Wash. .34" I.D. x .68" O.D.
22	714-0115		Cotter Pin 1/8" Dia. x 1" Lg.
23	710-0436		Hex B-Tap Scr. #10 x .62" Lg.
24	17962		Switch Plate
25	710-0118		Hex Bolt 5/16-18 x .75" Lg.
26	725-1657		Safety Switch (Clutch)
27	16924A		Clutch Ass'y. Mtg. Brkt.
28	732-0395		Ext. Spring 2.51" Lg.
29	736-0169		L-Wash. 3/8" I.D.
30	712-0798		Hex Nut 3/8-16 Thd.
31	783-0056		Idler Brkt.
32	732-0470		Ext. Spring 4.75" Lg.
33	710-0344		Hex Bolt 3/8-16 x 1.5" Lg.
34	17344A		Hitch Plate
35	710-0726		Hex Wash. AB-Tap Scr. 5/16 x .75" Lg.
36	714-0147		Hitch Pin
37	738-0482		Hitch Rod
38	738-0347		Shld. Spacer .625" I.D.
39	710-0176		Hex Bolt 5/16-18 x 2.75" Lg.
40	710-0599		Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5" Lg.
41	17358D		Belt Guard Brkt.
42	710-0833		Hex Bolt 5/16-18 x 5.25" Lg.
43	736-0242		Bell-Wash. .345" I.D. x .88" O.D.
45	16888		Deck Idler Support Brkt.
46	721-0330		O-Ring
51			UNKNOWN
53	754-0435		"V"-Belt
54	756-0116		Idler Pulley
55	756-0515		FI-Idler Pulley
56	710-3096		Hex Bolt 3/8-16 x 2" Lg. (Gr. 8)
57	756-0636		Engine Pulley
58	714-0118		Sq.-Key 1/4" x 1.5" Lg.
60	732-0322		FI-Wash. .44" I.D. x 1.25"
61	736-0171		L-Wash. 7/16" I.D.
62	710-0757		Hex Cap Bolt 7/16-20 x 1.5" Lg.
63	736-0179		FI-Wash. .531" I.D. x 1.25" O.D.
64	683-0030		Neutral Return Link Ass'y.
65	736-3074		FI-Wash. .344" I.D. x 1.12" O.D. (Hdn.)
66	747-0880		Connecting Rod
67	732-0387		Ext. Spring 2.5" Lg.

Ref #	Part Number	Qty	Description
67	732-0387		Ext. Spring 2.5" Lg.
68	17757		Balancer Brkt.
69	17755A		Bracket
70	732-0717		Ext. Spring 3.94" Lg.
71	736-0141		Spr.-Wash. .445" I.D. x .75" O.D.
72	726-0281		Rod End Clevis Clip - R.H.
73	726-0280		Rod End Clevis Clip - L.H.
74	712-0116		Hex Ins. L-Nut 3/8-24 Thd.
75	683-0032A		Pintle Bracket Ass'y.
76	783-0053		Flat Scissors
77	736-0174		Spr. Wash. .625" I.D. x .885" O.D.
78	783-0054		Offset Scissors
79	736-3078		FI-Wash. .344" I.D. x 1" O.D. (Hdn.)
82	736-0185		FI-Wash. .406" I.D. x .75" O.D.
83	710-0257		Hex Socket Set Screw
84	720-0187		Ball Knob
85	647-0006		Brake Rod Ass'y.
86	710-0778		Hex Wash. Hd. Scr. 1/4-20 x 1.5" Lg.
87	750-0555		Spacer .39" Lg.
88	712-3006		Hex Nut 1/4-20 Thd. (Gr. 5)
89	783-0051		Transaxle Torque Brkt.
90	731-0555A		Grommet
91	710-0604		Hex Wash. Hd. TT-Tap Scr. 5/16-18 x .62" Lg.
92	783-0050		Transaxle Torque Brace
93	710-0189		Hex Bolt 5/16-18 x 3" Lg.
94	718-0241		Transaxle
95	747-0909		Bypass Rod
96	711-0198		Ferrule 3/8-24 Thd.
97	712-0711		Hex Jam Nut 3/8-24 Thd.
98	732-0716		Ext. Spring 4.01" Lg.
99	736-3008		FI-Wash. .312" I.D. x .75" O.D.
100	732-0718		Comp. Spring 1.19" Lg.
101	761-0196		Friction Washer
102	736-0219		Bell-Wash. .40" I.D. x 1.13" O.D.
103	712-0375		Hex Cent. L-Nut 3/8-16 Thd.
104	750-0808		Spacer
105	710-1012		Rib Neck Bolt 5/16-18 x .62" Lg.
106	710-0299		Hex Bolt 1/4-28 x 1" Lg. (Gr. 5)
107	736-3090		FI-Wash. .26" I.D. x .72" O.D.
108	783-0052		Scissors Mtg. Brkt.
109	750-0918		Centering Gauge Spacer
110	736-0270		Bell-Wash. 1/4" I.D.
111	712-0138		Hex Nut 1/4-28 Thd.
112	738-0879		Friction Disc Stud
113	710-0459		Hex Bolt 3/8-24 x 1.5" Lg.
114	712-0214		Hex Cent. L-Nut 3/8-24 Thd.
115	756-0293A		V-Belt Idler
116	738-0129		Shld. Bolt .498" Dia. x 2.05
117	732-0478		Ext. Spring 6.12" Lg.
118	738-0155		Shld. Bolt .437" Dia. x .162"
119	13833		Parking Brake Mtg. Brkt.
120	736-0105		Bell-Wash. .38" I.D. x .88" O.D.
121	14076A		Idler Brkt. Deck Ass'y.
122	710-3007		Hex Wash. Hd. Tap Scr. #12 x 3/8" Lg.
123	712-3035		Hex Jam Nut 9/16-18 Thd.
124	731-1449		Fan
125	756-0635A		Input Pulley
126	731-1480		Plastic Vent
127	726-0324		Hose Clamp
128	725-0157		Cable Tie

Ref #	Part Number	Qty	Description
128	725-0157		Cable Tie
129	751-0588		Hose 1/2" I.D. x 18" Lg.
130	731-1485		Hose Fitting
131	732-0308		Ext. Spring 6.37" Lg.
132	731-0757		Convuluted Conduit
133	747-0708		Deck Control Rod
134	714-0104		Internal Cotter Pin
135	13887		Deck Control Pivot Brkt.
136	748-0278		Spacer
137	710-0501		Hex Bolt 1/4-20 x 2" Lg.
138	712-0287		Hex Nut 1/4-20 Thd.
139	736-0329		L-Wash. 1/4" I.D.
140	732-0145		Comp. Spring 1" Lg.
141	714-0104		Hairpin Clip
142	736-0463		FI-Wash. 1/4" I.D.
143	731-1481		Plastic Vent Cap




Ref #	Part Number	Qty	Description
1	725-0925		Ammeter
2	725-1625		Fuse 7.5 Amp
2	725-1381		Fuse 20 Amp
3	725-1426		Solenoid
4	725-0561		Wire
5	725-0996		6 Ga. Black Wire 7.5" Lg.
6	725-0963		Bulb
7	725-1650		Socket
8	629-0110		Wire Harness
	629-0117		Wire Harness
9	725-1657		Safety Switch (Clutch)
11	725-1635		Battery (275 Cold Crank Amps)
14	725-0634		Light Switch
15	725-0267		Ignition Switch
17	725-0465A		Safety Switch (Deck)
18	725-1643		Spring Lever
20	725-1303		Safety Switch (Seat)
27	725-1365		Bulb
31	725-1439		Safety Switch (Seat)
38	751-0537		Oil Pressure Switch




Ref #	Part Number	Qty	Description
1	631-0013		Hood w/Foam
2	738-0141		Shld. Bolt .437" Dia. x .35"
3	726-0233		Bolt Retainer 1/4" I.D.
4	710-0776A		Hex AB-Tap Scr. 1/4 x .62" Lg.
6	710-0351		Truss Mach. B-Tap Scr. #10 x .5" Lg.
8	16808		Hood Reinforcement
10	17761		Hood Hinge - L.H.
11	746-0614A		Choke Control
12	17294		Dash Support Brkt.- L.H.
14	17760		Hood Hinge - R.H.
15	725-0963		Lamp
16	725-1650		Twist Lock - Lamp Socket
17	731-0705		Headlight Housing
19	731-1053A		Speed Control Index Brkt.
20	710-0118		Hex Bolt 5/16-18 x .75" Lg.
21	731-1442		Grille
22	17293		Dash Support Bracket - R.H.
23	736-0119		L-Wash. 5/16" I.D.
24	712-0267		Hex Nut 5/16-18 Thd.
25	736-0176		Fl-Wash. 1/4" I.D. x .93" O.D.
26	726-0278		Insulator Boss Plate
27	725-1439		Seat Spring Switch
29	710-0376		Hex Bolt 5/16-18 x 1.0" Lg.
32	710-0726		Hex Wash. Hd. AB-Tap Scr. 5/16 x .75" Lg.
33	738-0435		Running Board Rod
34	16922		Running Board - R.H.
	16921		Running Board - L.H.
36	712-0287		Hex Nut 1/4-20 Thd.
37	736-0329		L-Wash. 1/4" I.D.
39	710-0166		Truss Mach. Scr. 1/4-20 x 1.0" Lg.
41	17360A		R.H. Side Frame
42	17635		Battery Plate
43	17330A		Rear Fender
44	17223		Light Bracket
45	710-0167		Carriage Bolt 1/4-20 x .50" Lg.
46	736-0278		Fl-Wash..328" I.D. x .68" O.D.
47	17393A		Transmission Panel
48	725-1643		Reverse Safety Switch
49	726-0279		Insulator Plate
50	16848C		Seat Plate
51	17361B		L.H. Side Frame
54	712-0158		Hex Cent. L-Nut 5/16-18 Thd.
55	631-0014		Side Panel Ass'y. - R.H.
	631-0015		Side Panel Ass'y. - L.H.
	731-1434		Side Panel Ass'y. - R.H.
	731-1435		Side Panel Ass'y. - L.H.
56	710-0896		Hex Wash. Hd. B-Tap Scr. 1/4 x .62" Lg.
58	736-0222		Ext. L-Wash. 1/4" I.D.
59	831-0823A		Throttle Control Box Ass'y.
60	746-0634		Throttle Control Wire 35" Lg.
	746-0630		Throttle Control Wire - 39" Lg.
62	731-0948		Lens - R.H.
63	725-1341B		Ignition Key
64	725-0267		Ignition Switch
65	731-0957A		Dash Panel
66	725-0634		Light Switch
67	725-0925		Ammeter
68	731-0949		Lens - L.H.
69	725-1347		Ignition Switch Cap
70	757-0365		Seat Ass'y.

Ref #	Part Number	Qty	Description
70	757-0365		Seat Ass'y.
	757-0372		Seat Ass'y.
72	726-0139		Speed Nut #10Z
73	725-1346		Ignition Switch Nut
74	710-0779A		Truss Mach. AB-Tap Scr. #10 x .5" Lg.
77	710-0642		Hex Wash. Hd. Tap Scr. 1/4 x .75" Lg.
78	731-0405		Snap Bushing
79	710-0227		Hex Wash. Hd. AB-Tap Scr. #8 x .50" Lg.
84	732-0581B		Ext. Spring 5.31" Lg.
85	17239A		Seat Lift Brkt.
86	736-0242		Bell-Wash. .345" I.D. x .88" O.D.
87	710-0323		Truss Machine Scr. 5/16-18 x .75" Lg.
88	17406		Fender Bracket - R.H.
	17407		Fender Bracket - L.H.
90	738-0296		Shld. Bolt .437" Dia. x .268"
91	17701		Seat Pivot Brkt. Support - L.H.
92	738-0155		Shld. Bolt .437" Dia. x .162"
93	17702		Seat Pivot Brkt. Support - R.H.
94	725-1303		Spring Switch
95	736-0141		Spr.-Wash. .445" I.D.
96	710-0601		Hex Wash. Hd. Tap Scr. 5/16-18 x .75" Lg.
97	736-3078		Fl-Wash. .344" I.D. x 1" O.D.
98	722-0160		Bushing
99	732-0588		Compression Spring
100	783-0039		Seat Pivot Bracket
101	710-0623		Hex Tap Scr. 3/8-16 x .75"
104	731-1051		Foot Pad
105	710-0599		Hex Tap Scr. 1/4-20 x .5" Lg.
111	712-0185		Speed Nut 1/4-20 Thd.
114	725-1426		Solenoid
115	712-0271		Hex Sems Nut 1/4-20 Thd.
116	710-0289		Hex Bolt 1/4-20 x .5" Lg.
117	710-1012		Rib Neck Bolt 5/16-24 x .75" Lg.
118	712-0123		Hex Nut 5/16-24 Thd.
119	17782		Retainer Clip
120	726-0320		Insulator Nut Plate
121	17762		Hood Reinforcement Spacer




Ref #	Part Number	Qty	Description
1	16512		Steering Column Ass'y.
2	738-0763		Lower Steering Shaft
3	710-0958		Hex Bolt 1/4-20 x 1.31" Lg.
4	712-0324		Hex L-Nut 1/4-20 Thd.
5	712-0337		Hex Nut 5/8-18 Thd.
6	717-0943A		Steering Gear Segment
7	736-0317		Bell-Wash. 5/8" I.D. x 1.25" O.D.
8	712-0241		Hex Nut 3/8-24 Thd.
9	712-0711		Hex Jam Nut 3/8-24 Thd.
10	736-0169		L-Wash. 3/8" I.D.
11	738-0768		Steering Gear Segment Shaft
12	736-0187		FI-Wash. .64" I.D. x 1.24" O.D.
13	748-0227A		Hex Flange Brg. .63" I.D.
14	723-3018		Ball Joint Ass'y.
15	710-0599		Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5" Lg.
16	16888A		Deck Idler Support Brkt.
17	736-0343		FI-Wash. .33" I.D. x 1.25" O.D.
18	750-0532		Spacer .985" I.D. x 1.25" O.D.
19	736-0119		L-Wash. 5/16" I.D.
20	712-0123		Hex Nut 5/16-24 Thd.
21	736-0242		Bell-Wash. .345" I.D. x .88" O.D.
22	16894		Bearing Retainer Brkt.
23	710-0157		Hex Bolt 5/16-24 x .75" Lg.
24	710-0793		Ribbed Neck Bolt 3/8-24 x .8" Lg.
25	710-0604		Hex Wash. TT-Tap Scr. 5/16-18 x .62" Lg.
26	747-0579		Steering Drag Link
	747-0899		Steering Drag Link
27	16896A		Pivot Bar Side Plate - R.H.
28	16897A		Pivot Bar Side Plate - L.H.
29	710-0538		Hex Bolt 5/16-18 x .62" Lg.
30	683-0061		Steering Arm Ass'y.
31	738-0777		Deck Connecting Rod
32	738-0775		Pivot Bar Shld. Bolt 3/8-16 x 5/8" Lg.
33	731-0484A		Cap
34	714-0121		Cotter Pin 5/32" Dia.
35	736-0316		Flat Washer
36	741-0523		Flange Brg. .757" I.D.
37	747-0721		Tie Rod 20.25" Lg.
38	16843		Pivot Bar Assy.
39	16889		Pivot Bar Support Brkt. - Front
40	16890		Pivot Bar Support Brkt. - Rear
41	736-0188		FI-Wash. .76" I.D. x 1.49" O.D.
42	16915		Front Axle Ass'y. - L.H.
43	16914		Front Axle Ass'y. - R.H.
44	736-0286		Bowed Washer
45	748-0160		Spacer .755" I.D. x 1.25" O.D.
46	710-0331		Hex Bolt 3/8-24 x 2.25" Lg.
47	712-0798		Hex Nut 3/8-16 Thd.
48	741-0516		Flange Brg. .75" I.D.
49	736-0316		FI-Wash. .71" I.D. x 1.5" O.D.
50	634-0084		Wheel Ass'y. Comp.
	734-1727		Tire Only
51	634-0067		Rim Only
52	726-0271		Push Nut
53	711-0222		Battery Hold Down Rod
54	17635		Battery Plate
58	725-1635		Battery (275 Cold Crank Amps)
59	731-1132		Battery Cover
60	712-0113		Wing Nut Plastic 1/4-20 Thd.
61	731-0954		Steering Bellow

Ref #	Part Number	Qty	Description
61	731-0954		Steering Bellow
64	731-0806A		Steering Wheel
65	731-0955		Steering Wheel Insert
66	712-0237		Hex L-Nut 5/16-24 Thd.
67	17359B		Lower Frame
68	731-1049		Pivot Bar End Cap
69	737-0280		Grease Fitting
70	714-0149B		Internal Cotter Pin
71	734-1788		Hub Cap
72	727-0425A		Spring Clip
76	710-0776A		Hex AB-Tap Scr. 1/4 x .62" Lg.
77	712-0446		Hex Jam L-Nut 3/8-24 Thd.
78	737-0280		Grease Fitting
79	734-0255		Air Valve
80	710-0286		Truss Mach. Scr. 1/4-20 x .5" Lg.
81	720-0232		Shift Knob
82	747-0708		Deck Control Knob
83	712-0272		Hex Sems Nut #10-24 Thd.
84	712-0271		Hex Sems Nut 1/4-20 Thd.
85	725-0465A		Safety Switch
86	710-0473		Truss Mach. Scr. #10-24 x .5"
87	726-0106		Push Nut
88	747-0513		Blade Clutch Lever
89	13950A		Deck Clutch Control Brkt.
90	710-0106		Hex Bolt 1/4-20 x 1.25" Lg.
91	735-0126		Rubber Washer
92	736-0173		Fl-Wash. .281" I.D. x .73"
93	712-0324		Hex L-Nut 1/4-20 Thd.



Ref #	Part Number	Qty	Description
1	HG-52881	1	Housing - L.H. Ass'y.
2	HG-52879	1	Housing - R.H. Ass'y.
7	HG-44782	2	Oil Seal .984" x 1.5" x .25"
8	HG-50070	1	Quad Ring
9		2	Capscrew, 1/4-20 x 1
10	HG-44920	1	Filter Base Gasket
11	HG-70053	1	Filter Base Ass'y.
12	HG-62876	1	Pinion Ass'y.
16	HG-62877	1	Brake Shaft Ass'y.
21	HG-44805	2	Washer, 1.0" x 1.63" x .08"
22	HG-44806	2	Washer, 1.0" x 2.06" x .09"
25	HG-82888	2	Axle Mounting Horn Ass'y.
28	HG-70054	1	Input Ass'y.
31	HG-44800	2	Ret. Bearing
32	HG-44802	2	O-Ring 2-1/2" O.D.
33	HG-62589	1	(Sub) Brake Yoke Ass'y.
35	HG-44094	1	Brake Arm
36	HG-44134	1	Puck Plate
37	HG-44132	2	Brake Puck
38	HG-44130	2	Washer, 7/16" x 7/8" O.D. x .060 H.T.
39	HG-44142	1	Nut, Castle 5/16-24 PL
40	HG-44101	1	Cotter Pin
41	HG-44127	2	Brake Actuating Pin
42	HG-44143	1	Hi-Pro Key 3/16" x 5/8"
43	HG-23711	1	Torsion Spring Spacer
44	HG-44278	1	Washer 7/8 O.D. x .260 I.D. x 1/8
45	HG-44090	1	Disc Brake
46	HG-44300	1	Bolt 1/4-20" x 2 W/Nylok Gr. 5
47	HG-44433	1	Bolt 1/4-20" x 1 W/Nylok Gr. 5
48	HG-62834	1	Differential Ass'y.
62	HG-44843	1	Wave Washer
63	HG-44757	2	Dowel Pin
64	HG-44776	1	Reduction Gear 14T - 38T
65	HG-70051	1	Final Drive Pinion Ass'y.
67	HG-44779	1	Jack Shaft
68	HG-44781	1	O-Ring
69	HG-44795	2	Fl-Wash. 5/8" I.D. x 1-5/32" O.D. Ht.
70	HG-44794	1	Fl-Wash. 7/8" I.D. x 1-1/2" O.D. Ht.
71	HG-44827	2	Hex Bolt H.D. 5/16-18" x 3-1/2"
72	HG-43064	4	Hex Lock Nut 5/16-18" 2-Way Plt.
73	HG-44841	11	Hex Bolt 5/16-18" x 1-1/2" Gr. 5 Plt.
74	HG-45089	7	Hex Bolt 5/16-18" x 1
75	HG-44880	1	Differential Washer .050
76	HG-44785	1	Shld. Bolt
77	HG-44786	1	Freewheel Actuating Arm
78	HG-44761	2	Oil Seal .625" x 1.0" x .25"
81	HG-43084	1	Hex Bolt 5/16-18" x 1-3/4"
82	HG-44820	3	Hex Bolt 5/16-18" x 4-1/2"
84	HG-50009	1	SAE Port Straight Fltting 7/8"
85	HG-50010	1	SAE Port Straight Fltting 7/16"
87	HG-50011	1	Hose, 8-1/2" Long
88	HG-50012	1	Hose 10-1/2" Long
89	HG-50037	1	Spin-On Filter
91	HG-BDU-10L-256	1	Transmission
93	17434A	1	Bracket
95	HG-9005110-5600	1	Straight Thread Plug
99	HG-50136	1	Washer 5/16" I.D. x 9/16" O.D.
100	HG-50133	1	Vent Bushing
101	HG-50134	1	Vent
?102	HG-70052	1	Seal Kit

Ref #	Part Number	Qty	Description
?102	HG-70052 718-0241	1	Seal Kit Hydrostatic Transmission



Ref #	Part Number	Qty	Description
1	720-0233		Grip
2	17282		Lift Handle Ass'y.
3	710-0442		Hex Bolt 5/16-18 x 1.5" Lg.
4	748-0274A		Lift Shaft Drive
5	741-0225		Plastic Hex Brg. 5/8" I.D.
6	14231		Index Brkt. Deck Lift
7	737-0164		Oil Drain Pipe
8	737-0143		Oil Drain Cap
10	736-0163		Fl-Wash. 1.03" I.D. x 1.62" O.D.
13	750-0762		Spacer 1" I.D. x 1.25" O.D.
14	13889		Lift Shaft Ass'y.
15	13895		Lift Pivot Brkt. Ass'y.
16	17303		Adj. Deck Lift Link
17	736-0192		Fl-Wash. 1/2" I.D. x 1.00" O.D. x .090"
18	714-0101		Hairpin Cotter
19	741-0295		Nyliner 5/8" I.D. x .88" Lg.
20	738-0445		Shld. Bolt 5/8" Dia. x .96" Lg. 3/8-16
21	13790		Connecting Link
22	714-0142		Cotter Pin 3/16" Dia. x 1.5" Lg.
25	710-0502A		Hex Wash. Hd. Scr. 3/8-16 x 1.25" Lg.
26	710-0726		Hex Thd. Rolling Scr. 5/16-18 x .75" Lg.
27	738-0435		Running Board Rod
28	726-0272		Clamp
29	734-0255		Air Valve
30	634-0086		Rear Wheel Ass'y. Comp.
	734-1728		Tire Only
31	734-1015		Rear Wheel Rim Only
32	736-0345		Flat Washer
33	710-0258		Hex Bolt 1/4-20 x .62" Lg.
34	711-0817		Eye Bolt Adj. Link 1/2-13 Thd.
36	712-0158		Hex Cent. L-Nut 5/16-18 Thd.
37	710-0237		Hex Bolt 5/16-24 x .62" Lg.
38			UNKNOWN
39	712-0181		Hex Top L-Nut 3/8-16 Thd.
40	732-0369		Compression Spring
41	738-0777		Deck Connecting Rod
42	712-0287		Hex Nut 1/4-20 Thd.
43	14170		Index Brkt. Reinforcement Plate
44	751-0474		Muffler
	751-0557		Muffler
45	710-0118		Hex Bolt 5/16-18 x .75" Lg.
46	726-0273		Mounting Clamp
47	734-1789		Hub Cap
48	710-0599		Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5" Lg.
49	736-0119		L-Wash. 5/16" I.D.
50	714-0111		Cotter Pin .09 Dia. x 1.0" Lg.
51	714-0149B		Int. Cotter Pin
52	736-0231		Flat Wash. .34" I.D. x 1.12" O.D. x .125"
53	710-0600		Hex Wash. Hd. AB-Tap Scr. 5/16-24 x .5" Lg.
54	712-0206		Hex Nut 1/2-13 Thd.
55	14399		Deck Link
56	736-0264		Fl-Wash. .344" I.D.
57	736-0219		Bell-Wash. .4" I.D. x 1.13" O.D.
58	712-0267		Hex Nut 5/16-18 Thd.
59	783-0023		Heat Shield
60	16934		Front Heat Shield
	783-0105A		Front Heat Shield
61	736-0170		Spec. L-Wash. 5/16" I.D.
62	710-1177		Cap Scr. 5/16-18 x 1" Lg.
63	736-0329		L-Wash. 1/4" I.D.

Ref #	Part Number	Qty	Description
63	736-0329		L-Wash. 1/4" I.D.
64	731-0511-12		Trim Strip 12" Lg.
65	751-0535-46		Fuel Line 46" Lg.
66	726-0205		Hose Clamp
67	710-0776		Hex AB-Tap Scr. 1/4 x .62" Lg.
68	17424		Fuel Tank Strap
69	751-0566		Gas Tank
70	751-0531B		Gas Gauge
71	16848C		Seat Plate
72	17344A		Hitch Plate
73	738-0482		Hitch Rod
74	723-3061		Heat Baffle Seal
75	727-0425A		Spring Clip
76	710-0351		Truss Mach. B-Tap Scr. #10 x .5" Lg.
77	726-0272		Hose Clamp
78	17958		Muffler Mounting Brkt.
79	710-0258		Hex Bolt 1/4-20 x .62" Lg.
80	751-0564		Muffler Deflector
81	710-0148		Hex Wash. Hd. F-Tap Scr. #8 x .32" Lg
82	710-0604		Hex Wash. Hd. TT-Tap Scr. 5/16" - 18 x .62" Lg.
83	751-0598		Exhaust Tube - R.H.
84	751-0599		Exhaust Tube - L.H.
85	17319		Top Heat Shield
	783-0104		Top Heat Shield
87	714-0120		Sq. Key 1/4" x 3" Lg.
88	736-3067		FI-Wash. .188" I.D. x .438" O.D.
89	726-0272		Clamp