




Illustrated Parts List



21" Three-in-One Self Starter Self-Propelled Mower


Model
Series 560

IMPORTANT: Read safety rules and instructions carefully before operating equipment.

Warning: This unit is equipped with an internal combustion engine and should not be used on or near any unimproved forest-covered, brush-covered or grass-covered land unless the engine's exhaust system is equipped with a spark arrester meeting applicable local or state laws (if any). If a spark arrester is used, it should be maintained in effective working order by the operator. In the State of California the above is required by law (Section 4442 of the California Public Resources Code). Other states may have similar laws. Federal laws apply on federal lands. A spark arrester for the muffler is available through your nearest engine authorized service dealer or contact the service department, P.O. Box 361131 Cleveland, Ohio 44136-0019.

MTD LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019

SECTION 10: ILLUSTRATED PARTS LIST FOR MODEL SERIES 560



Model Series 560

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	747-2136	Lower Bail Handle	40.	749-0907B	Lower Handle
2.	710-0599	TT Screw 1/4-20 x 0.5	41.	734-1426	Hub Cap
3.	736-0270	Bell Washer.265 x 0.75	42.	732-04089	Torsion Spring - L.H.
4.	17032A	Chute Deflector Adapter	43.	734-2042	Wheel 8 x 2.125
5.	732-1014	Torsion Spring	44.	716-0865	Snap Ring
6.	712-3005	Lock Nut	45.	717-1762	Gear 14T RH FWD
7.	647-0070	Blade Control Handle		717-1761	Gear 14T LH FWD
8.	749-1499	Upper Handle	46.	747-04080	Grass Bag Frame
9.	712-0324	Hex Lock Nut, 1/4-20	47.	736-0451	Saddle Washer
10.	732-1172	Torsion Spring	48.	710-0896	Hex Scr. w/Washer 1/4-14 x.625
11.	710-0501	Hex Hd. Cap Screw	49.	687-02033	RH Handle Bracket
12.	720-0279	Handle Knob		687-02031	LH Handle Bracket
13.	720-0284	Handle Knob	50.	715-0221	Dowel Pin
14.	710-1205	Eye Bolt	51.	17488A	RH Pivot Bar
15.	746-1141	Control Cable		17489A	LH Pivot Bar
16.	710-1174	Carriage Bolt 5/16-18 x 2.0	52.	732-0866	Height Adj. Lever
17.	687-02032	LH Bracket Assembly	53.	720-0312	Foam Grip
	687-02034	RH Bracket Assembly	54.	738-0507B	Shoulder Scr.500 Dia. x.434
18.	726-0240	Cable Tie	55.	736-0105	Washer.401 x.870 x.063
19.	714-0104	Cotter Pin	56.	734-2043	Wheel 14 x 2.125
20.	710-1008	Self-Tapping Sems Screw	57.	736-0182	Spring Washer.50 I.D. x 1.0 O.D.
21.	746-04026	Drive Cable	58.	736-0272	Flat Washer
22.	664-04012	Grassbag Assembly	59.	738-0481A	Shoulder Screw
23.	710-1650	Shoulder Screw # 12 -24	60.	732-0700	Wire
24.	631-0075B	Engine Spacer	61.	731-1236	Rear Trailing Shield
25.	710-0606	Hex Bolt 1/4-20 x 1.5	62.	747-0996	Pivot Rod
26.	787-01106	21" Deck	63.	731-04134	Rear Discharge Door
27.	782-5003	RH Rear Baffle	64.	710-0286	Machine Screw
28.	710-1017	Screw AB: 1/4-14:.625	65.	750-04162	Spacer.375 x.50 x 1.02" Lg.
29.	782-5004A	LH Rear Baffle	66.	710-0703	Carriage Bolt 1/4-20
30.	710-0216	Hex Screw 3/8-16 x.75	67.	712-0397	Wing Nut
31.	732-04090	Torsion Spring - R.H.	68.	710-0216	Hex Bolt 3/8-16 x 1.0"
32.	712-0431	Hex Nut 3/8-16	69.	732-1043	Belt Tension Spring
33.	731-2600	Transmission Cover (Yellow)	70.	756-04017	Input Pulley
34.	782-5002A	Front Baffle	71.	750-1166	Slev. Spacer LH
35.	754-0637	V-Belt		750-1346	Slev. Spacer RH
36.	748-04015	Blade Adapter w/ Pulley	72.	618-0657	Transmission Assembly
37.	742-0741	21" Mulching Blade	73.	715-04011	Roll Pin
38.	736-0524A	Blade Bell Support	88.	682-0511A	Height Adjustment Assembly LH
39.	710-1257	Hex Screw 3/8-24 x 2.50		682-0512A	Height Adjustment Assembly RH

Model Series 560

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
89.	782-7551	Wheel Dust Cap	100.	747-0710	Hinge Pin
90.	716-0102	Snap Ring	101.	687-02055	Mulch Plug Complete
91.	736-0474	Washer	102.	731-04177	Chute Deflector
92.	720-0426	Adjustment Knob	103.	731-2532	Control Lever LH
93.	732-0706	Front Lever Assy. RH	104.	731-2533	Control Lever RH
	732-0707	Front Lever Assy. LH	105.	710-1256	Hi-Low Screw
94.	687-02044	Pivot Plate Assembly	106.	731-2623	Bail Cover
95.	782-0512B	Height Adj. Plate RH	107.	720-0428	Button
	782-0511A	Height Adj. Plate LH	108.	732-1171	Compression Spring
96.	736-0447	Wave Washer	109.	782-0156	Lever
97.	748-0355	Bearing Support	110.	715-0168	Pin
98.	741-0604A	Bearing Sleeve	111.	716-0209	Retention Ring
99.	732-0708	Bearing Retainer			