


Style 0




Style 0

REF. NO.	PART NO.	DESCRIPTION
1.	783-0250	Hood
2.	738-0952A	Shld. Bolt .375" Dia. x .125" Lg.
4.	710-0924	Pan Hd. Scr. 1/4-20 x .75" Lg.
6.	712-3006	Hex Sems Nut 1/4-20 Thd.
7.	749-0812	Grille Support Rod
8.	731-1099A	Headlight Lens w/o Logo
	731-1767	Headlight Lens w/ Logo
9.	712-3027	Flange Lock Nut 1/4-20 Thd.
10.	731-1097E	Grille
13.	725-0963	Lamp
14.	725-1649	Socket
15.	710-0703	Carriage Bolt 1/4-20 x .75" Lg.
16.	710-0599	Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5"
17.	736-0173	Flat Washer .281" I.D. x .73" O.D.
18.	726-0233	Bolt Retainer 1/4" I.D.
19.	712-0185	Speed Nut 1/4-20 Thd.
20.	710-3008	Hex Bolt 5/16-18 x .75" Lg. (Gr.5)
21.	17632A	Gas Tank Support Brkt.
22.	731-1096B	Dash w/Ammeter Hole
	731-1337A	Dash w/o Ammeter Hole
23.	725-0267	Ignition Switch
24.	725-0201	Ignition Key
25.	746-0616A	Choke Control 23" Lg.
	746-0614A	Choke Control 38" Lg.
	746-0720	Choke Control 20" Lg.
	746-3021	Choke Control 29" Lg.
26.	725-0634	Light Switch**
27.	725-0925	Ammeter**
32.	710-0286	Truss Mach. Scr. 1/4-20 x .5" Lg.
35.	17871B	Fender w/Cutout
38.	710-0726	Hex Wash. Hd. AB-Tap Scr. 5/16 x .75"
41.	831-0823A	Throttle Box Assembly
42.	710-0779A	Truss Mach. AB-Tap Scr. #10 x .5" Lg.
43.	746-0776	Throttle Control Wire 18.5" Lg.
	746-0634	Throttle Control Wire 35" Lg.
	746-0638	Throttle Control Wire 22" Lg.
44.	777-9206	Grille Reflector Label
45.	710-0603	Hex Wash. Hd. B-Tap Scr. 5/16-18 x .5"
46.	17782	Choke Retainer
47.	710-0642	Hex TT-Tap Scr. 1/4-20 x .75" Lg.
48.	726-0201	U-Nut 5/16-18 Thd.
49.	736-3078	Flat Washer .34" I.D. x 1" O.D.
50.	736-0119	Lock Washer 5/16" I.D.
51.	712-3010	Hex Nut 5/16-18 Thd. (Gr.5)
—	629-0309	Headlight Harness (Not Shown)

** Optional Parts

NOTE: For faster service, obtain the standard fasteners locally. If these are not available locally, call 1(800) 800-7310 or 1(330) 220-4MTD to order by part number and size as shown here.

Style 3




Style 3

REF. NO.	PART NO.	DESCRIPTION
1.	783-0250	Hood
2.	738-0952	Shld. Bolt .375" Dia. x .125" Lg.
6.	712-0271	Hex Sems Nut 1/4-20 Thd.
9.	712-3027	Flange Lock Nut 1/4-20 Thd.
10.	783-0156A	Grille
13.	725-0963	Lamp
14.	725-1651	Socket
15.	710-0703	Carriage Bolt 1/4-20 x .75" Lg.
16.	710-0599	Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5"
17.	736-0173	Flat Washer .281" I.D. x .73" O.D.
18.	726-0233	Bolt Retainer 1/4" I.D.
19.	712-0185	Speed Nut 1/4-20 Thd.
20.	710-0376	Hex Bolt 5/16-18 x .1" Lg.
21.	17632A	Gas Tank Support Brkt.
22.	731-1096B	Dash w/Ammeter Hole
	731-1337A	Dash w/o Ammeter Hole
23.	725-0267	Ignition Switch
24.	725-0201	Ignition Key
25.	746-0616A	Choke Control 23" Lg.
	746-0614A	Choke Control 38" Lg.
	746-3021	Choke Control 29" Lg.
	746-0720	Choke Control 20" Lg.
26.	725-0634	Light Switch**
27.	725-0925	Ammeter**
32.	710-0924	Pan Hd. Scr. 1/4-20 x .75" Lg.
35.	17871B	Fender
38.	710-0726	Hex Wash. Hd. AB-Tap Scr. 5/16 x .75"
41.	831-0823A	Throttle Box Assembly
42.	710-0779A	Truss Mach. AB-Tap Scr. #10 x .5" Lg.
43.	746-0776	Throttle Control Wire 18.5" Lg.
	746-0634	Throttle Control Wire 35" Lg.
	746-0638	Throttle Control Wire 22" Lg.
45.	710-0603	Hex Wash. Hd. B-Tap Scr. 5/16-18 x .5"
46.	17782	Choke Retainer
47.	710-0642	Hex TT-Tap Scr. 1/4-20 x .75" Lg.
49.	731-1503A	Lens
50.	783-0151A	Side Panel—LH
51.	783-0150A	Side Panel—RH
71.	726-0211	U-Nut 5/16-18 Thd.
-	629-0309	Headlight Harness (Not Shown)

** Optional Parts

NOTE: For faster service, obtain the standard fasteners locally. If these are not available locally, call 1(800) 800-7310 or 1(330) 220-4MTD to order by part number and size as shown here.

Style 4




Style 4

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
9.	710-3008	Hex Bolt 5/16-18 x .75" Lg. (Gr.5)	82.	726-0233	Push Nut Fastener
10.	712-3010	Hex Nut 5/16-18 Thd. (Gr.5)	83.	736-0176	Flat Washer .27" I.D. x .948"
11.	736-0119	Lock Washer 5/16" I.D.	84.	725-0925	Ammeter
12.	736-3078	Flat Washer .34" I.D. x 1" O.D.	85.	712-0185	Speed Nut 1/4-20 Thd.
13.	712-0271	Hex Sems Nut 1/4-20 Thd.	86.	731-0961A	Dash Panel
26.	710-0726	Hex Wash. Hd. AB-Tap Scr.5/16 x .75"	87.	710-0599	Hex Wash. Hd. B-Tap Scr.1/4 x .75" Lg.
27.	736-0142	Flat Washer .218" I.D. x .5" O.D.	88.	783-0121	Hood Reinforcement
32.	731-0911	Rubber Foot Pad—LH **	89.	783-0123	Hood Hinge
	731-0912	Rubber Foot Pad—RH**	90.	17762	Hood Reinforcement Spacer
33.	710-3008	Hex Bolt 5/16-18 x .75" Lg.	92.	17223	Light Bracket
38.	710-0258	Hex Bolt 1/4-20 x .62" Lg.	93.	712-0158	Hex Lock Nut 5/16-18 Thd.
51.	712-0265	Hex Sems Nut 5/16-18 Thd.	94.	712-0107	Hex Lock Nut 1/4-20 Thd.
65.	783-0041A	Pivot Bar Brkt.	95.	712-3007	Hex Jam Nut 5/16-18 Thd.
66.	783-0350	Fender	96.	710-0874	Hex Bolt 5/16-18 x 7/8" Lg.
67.	710-0167	Carriage Bolt 1/4-20 x .62" Lg.	97.	710-0351	Truss Mach. B-Tap Scr. #10 x .5" Lg.
70.	746-0776	Throttle Wire 18.5" Lg.	98.	731-1434	Side Cover—RH - Red
	746-0634	Throttle Wire 35" Lg.		731-2256	Side Cover—RH - Black
	746-0636	Throttle Wire 28" Lg.		731-1435	Side Cover—LH (Not Shown) - Red
71.	831-0823A	Throttle Control Box Assembly		731-2255	Side Cover—LH (Not Shown) - Black
72.	725-1341B	Ignition Key	99.	731-1442A	Grille - Red
73.	725-1346	Ignition Switch Nut		731-2254	Grill - Black
74.	725-1347	Ignition Switch Cap	100.	731-0949	Lens—LH
75.	725-1396	Ignition Switch		731-0948	Lens—RH
76.	731-1433	Hood - Red	101.	725-1650	Twist Lock-Lamp Socket
	731-2253	Hood - Black	102.	725-0963	Lamp
77.	710-0779A	Truss Mach. AB-Tap Scr. #10 x .5" Lg.	103.	731-0705	Headlight Housing
78.	725-0634	Light Switch	104.	17300D	Dash Support Brkt.
79.	746-3021	Choke Control 29" Lg.	105.	17633A	Support Brkt.
	746-0614A	Choke Control 38" Lg.	106.	17782	Choke Retainer
80.	710-0642	Hex Wash. Hd. Tap Scr. 1/4 x .75" Lg.	—	629-0309	Headlight Harness (Not Shown)
81.	710-0599	Hex Tap Scr. 1/4-20 x .5" Lg.			

** Optional Parts

NOTE: For faster service, obtain the standard fasteners locally. If these are not available locally, call 1(800) 800-7310 or 1(330) 220-4MTD to order by part number and size as shown here.

Style 5




Style 5

REF. NO.	PART NO.	DESCRIPTION
1.	783-0250	Hood
2.	738-0952	Shld. Bolt .375" Dia. x .125" Lg.
3.	736-0119	Lock Washer 5/16" I.D.
4.	712-3010	Hex Nut 5/16-18 Thd.
6.	712-0271	Hex Sems Nut 1/4-20 Thd.
8.	731-1099A	Headlight Lens w/o Logo
	731-1767	Headlight Lens w/ Logo
9.	712-3027	Flange Lock Nut 1/4-20 Thd.
10.	731-1097E	Grille
11.	736-3078	Flat Washer .344" I.D. x 1" O.D.
12.	712-0267	Hex Nut 5/16-18 Thd.
13.	725-0963	Lamp
14.	725-1649	Socket
15.	710-0703	Carriage Bolt 1/4-20 x .75" Lg.
16.	710-0599	Hex Wash. Hd. TT-Tap Scr.1/4-20 x .5" Lg.
17.	736-0173	Flat Washer .281" I.D. x .73" O.D.
18.	726-0233	Bolt Retainer 1/4" I.D.
19.	712-0185	Speed Nut 1/4-20 Thd.
20.	710-3008	Hex Bolt 5/16-18 x .75" Lg. (Gr.5)
21.	17632A	Gas Tank Support Brkt.
22.	731-1096B	Dash w/Ammeter Hole
	731-1337A	Dash w/o Ammeter Hole
23.	725-0267	Ignition Switch
24.	725-0201	Ignition Key
25.	746-0616A	Choke Control 23" Lg.
	746-0614A	Choke Control 38" Lg.
	746-3021	Choke Control 29" Lg.
	746-0720	Choke Control 20" Lg.
26.	725-0634	Light Switch**
27.	725-0925	Ammeter**
32.	710-0924	Pan Hd. Scr. 1/4-20 x .75" Lg.
35.	17871B	Fender w/Cutout
38.	710-0726	Hex Wash. Hd. AB-Tap Scr.5/16 x .75" Lg.
41.	831-0823A	Throttle Box Assembly
42.	710-0779A	Truss Mach. AB-Tap Scr.#10 x .5" Lg.
43.	746-0776	Throttle Control Wire 18.5" Lg.
	746-0634	Throttle Control Wire 35"Lg.
	746-0638	Throttle Control Wire 22" Lg.
44.	777-9206	Grille Reflector Label
45.	710-0603	Hex Wash. Hd. B-Tap Scr.5/16-18 x .5" Lg.
46.	17782	Choke Retainer
47.	710-0642	Hex TT-Tap Scr. 1/4-20 x .75" Lg.
49.	783-0150A	Side Panel-RH
50.	783-0151A	Side Panel-LH
72.	710-0286	Truss Mach. Scr. 1/4-20 x .5" Lg.
73.	736-0342	Flat Washer .283" I.D. x .75" Lg.
74.	732-0835	Hood Latch **
75.	712-0272	Hex Sems Nut 10-24 Thd. **
76.	710-0473	Truss Mach. Scr. 10-24 x .5" Lg. **
—	629-0309	Headlight Harness (Not Shown)

** Optional Parts

NOTE: For faster service, obtain the standard fasteners locally. If these are not available locally, call 1(800) 800-7310 or 1(330) 220-4MTD to order by part number and size as shown here.

Style 8




Style 8

REF NO.	PART NO.	DESCRIPTION
1.	783-0551	Hood Brkt.
2.	783-0477A	Grille
3.	783-0476B	Side Panel -RH
4.	783-0475A	Side Panel - LH
5.	738-0255	Shld. Bolt .375" Dia.
6.	736-0413	Spr. Wash. .39" I.D. x .62" O.D.
7.	731-1854A	Lens
8.	726-0233	Retainer Nut
9.	726-0211	U - Nut 5/16-18 Thd
10.	725-1651	Socket
11.	712-0292	Tinn. Nut 1/4-20 Thd.
12.	712-0271	Hex Sems Nut 1/4-20 Thd.
13.	710-0924	Pan Hd. Mach. Scr. 1/4-20 x .75" Lg.
14.	710-0599	Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5"
15.	710-0751	Hex Bolt
16.	710-0376	Hex Bolt 5/16-18 x .1" Lg. (Gr.5)
17.	683-0168	Hood Pivot Brkt. Assembly
18.	783-0478A	Hood
19.	629-0309	Headlight Harness
20.	17782	Choke Retainer
21.	725-0157	Cable Tie
22.	710-0607	Hex Wash. Hd. Tap Scr. 5/16-18 x .5"
23.	725-0963	Lamp
24.	17632B	Gas Tank Support Brkt.
25.	710-0703	Carriage Bolt 1/4-20 x .75" Lg.
26.	731-1852	Dash Panel
27.	783-0350	Fender
28.	710-0726	Hex Wash. Hd. Tap Scr. 5/16 x .75"
29.	710-0286	Truss Mach. Scr. 1/4-20 x .5" Lg.
30.	725-0925	Ammeter
31.	725-0634	Light Switch
32.	725-0201	Ignition Key
33.	725-0267	Ignition Switch
34.	831-0823A	Throttle Box Assembly
35.	710-0779A	Truss Mach. AB-Tap Scr. #10 x .5"
36.	746-0776	Throttle Control Wire 18.5" Lg.
	746-0638	Throttle Control Wire 22" Lg.
	746-0634	Throttle Control Wire 35" Lg.
37.	746-0720	Choke Control 20" Lg.
	746-0616A	Choke Control 23" Lg.
	746-3021	Choke Control 29" Lg.
	746-0614A	Choke Control 38" Lg.
40.	16988A	Engine Baffle †
41.	783-0553A	Hood Brkt. Support
42.	710-0351	Pan Hd. Scr. #10-16 x .5" Lg.
43.	726-0293	Retainer Nut
44.	710-0896	Hex Wash. AB-Tap Scr. 1/4-14 x .625"
45.	710-0166	Pan Hd. Scr. 1/4-20 x 1" Lg.†
46.	731-0511-18	Trim Strip †

† B&S Twin Cylinder Engine Only.

NOTE: For faster service, obtain the standard fasteners locally. If these are not available locally, call 1(800) 800-7310 or 1(330) 220-4MTD to order by part number and size as shown here.

Style 9




Style 9

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
3.	710-0376	Hex Bolt 5/16-18 x .1" Lg.	37.	750-0218	Spacer .262" I.D. x .31"
5.	710-0603	Hex Wash. Hd. Scr. 5/16" x .5" Lg.	39.	16903A	Hood Plate
7.	710-0286	Truss Mach. Scr. 1/4-20 x .5" Lg.	40.	710-1005	Hex Wash. Hd. Tap Scr. 1/4-20 x .5" Lg.
8.	710-0726	Hex Wash. Hd. Tap Scr. 5/16 x .75" Lg.	41.	731-1048B	Dash
9.	17633A	Support Bracket	42.	725-0925	Ammeter
10.	17300D	Dash Support Bracket	43.	831-0823A	Throttle Control Box Assembly
11.	783-0350	Rear Fender	44.	710-0919	Mach. Scr. #10 x .44" Lg.
12.	730-3000	Reflector **	45.	746-0616A	Choke Control 23" Lg.
14.	16725	Side Panel—RH †		746-0614A	Choke Control 38" Lg.
	17458A	Side Panel w/Foam—RH		746-3021	Choke Control 29" Lg.
	17459A	Side Panel Assembly w/Foam—LH(Not Shown)		746-0720	Choke Control 20" Lg.
	17309B	Side Panel-LH (Not Shown)	46.	746-0776	Throttle Control Wire 18.5" Lg.
15.	710-0286	Truss Mach. Scr. 1/4-20 x .5" Lg.		746-0634	Throttle Control Wire 35" Lg.
16.	710-0166	Truss Mach. Scr. 1/4-20 x 1.0" Lg.		746-0638	Throttle Control Wire 22" Lg.
17.	710-1026	Hex Wash. TT-Tap Scr. 1/4-20 x 1.75"	47.	725-0267	Ignition Switch
18.	750-0768	Spacer .26" I.D. x 1.32"	48.	725-0201	Ignition Key
19.	710-0642	Hex Rolling Tap Scr. 1/4-20 x .75" Lg.	49.	731-1491A	Hood-Red
21.	731-0511-18	Trim Strip-18" Lg.		731-1531A	Hood-Charcoal
22.	736-0329	Lock Washer 1/4" I.D.		731-1497A	Hood-Oyster Gray
23.	712-0271	Hex Sems Nut 1/4-20 Thd.		731-1704A	Hood-Evergreen
24.	726-0201	Speed Nut 5/16" Thd.		731-1893A	Hood-Black
27.	17410	Grille Assembly	71.	749-0814	Grille Support Tube
28.	731-1044	Headlight Lens	73.	736-0607	External Lock Washer 5/16" I.D.
29.	731-0705	Headlamp Housing	76.	17782	Choke Retainer
30.	725-0963	Headlamp	77.	725-0634	Light Switch
31.	725-1650	Twist Lock Lamp Socket	78.	736-3010	Flat Washer .406" I.D. x .812" O.D.
32.	736-0242	BelLock Washer .345" I.D. x .88"	79.	710-0206	Hex Bolt 1/4-20 x .88" Lg.
33.	712-0429	Hex Lock Nut 5/16-18 Thd.	80.	783-0013	Dash Fastening Tab
34.	735-0126	Rubber Washer	81.	725-0157	Cable Tie
35.	783-0190	Hood Hinge	82.	777-8568A	Chrome Label
36.	710-0599	Hex Wash.Hd.B-Tap Scr.1/4-20 x.5"	83.	726-0211	U-Nut 5/16-18 Thd.

** Optional Parts

NOTE: For faster service, obtain the standard fasteners locally. If these are not available locally, call 1(800) 800-7310 or 1(330) 220-4MTD to order by part number and size as shown here.

Model Series 690 Thru 699




Model Series 690 Thru 699

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	17198A	Retainer Plate	28.	738-0919	Steering Shaft
2.	16481A	Steering Arm Front Axle	29.	741-0656	Hex Flg. Brg. .634 I.D.
3.	683-0128A	Pivot Bar Ass'y (Steel)	30.	741-0659	Hex Flg. Brg. .632 I.D.
	719-0342B	Pivot Bar Ass'y (Cast Iron)	31.	747-0861	Tie Rod (Non-Adjustable)
	**	Grease Fitting (Cast Iron)	-	747-1267	Tie Rod (Adjustable)
4.	710-0459A	Hex Bolt 3/8-24 x 1.5" Lg. (Gr. 5)	32.	748-0389	Cap
5.	710-0593	Hex Bolt 5/16-24 x 2.25" Lg.	33.	750-0535	Spacer .380" I.D. x .625" O.D.
6.	710-0643	Hex Bolt 5/16-18 x 1" Lg.	34.	783-0041B	Pivot Bar Bracket
7.	710-0726	Hex Wash. Hd. Self-Tap Scr.	35.	711-1661	Ferrule
8.	710-1039	Hex Hd. Cap Scr. 3/8-24 x 1.0 Gr. 5	36.	714-0470	Cotter Pin 1/8
9.	710-1309	Hex Patch Bolt 5/16-18 x .62"	37.	736-0267	Fl-Wash. 3/8 x .870 I.D. x .060 O.D.
10.	711-1107	Steering Drag Link	38.	731-1649	Axle Cap
11.	712-0158	Hex Cent. L-Nut 5/16-18 Thd.	39.	731-1291A	Pivot Bar End Cap*
12.	712-0214	Hex Cent. L-Nut 3/8-24 Thd.	40.	714-0470	Cotter Pin
13.	712-0240	Jam Nut 7/16-20 Gr. 2	41.	736-0285	Fl-Wash. .635 I.D. x 1.589 O.D.
14.	712-0241	Hex Nut 3/8-24 Gr.5	42.	736-0162	Fl-Wash. .641 I.D. x 1.0 O.D.
15.	712-0262	Hex Jam Nut 3/8-24 Thd.	43.	**	Front Axle Assembly R.H.
16.	712-0411	Hex L-Nut 5/16-24 Thd.	44.	**	Front Axle Assembly L.H.
17.	712-0431	Flanged L-Nut 3/8-16 Thd.	45.	726-0214	Push Cap
18.	717-0622A	Steering Gear Segment	46.	731-0220	Steering Wheel Cap (Round)
19.	723-0448A	Ball Joint 7/16-20 Thd.		731-1460	Steering Wheel Cap (Sq. No Logo)
20.	736-0169	L-Wash. 3.8" I.D.		731-1459A	Steering Wheel Cap (Sq. Logo)
21.	736-0187	Fl-Wash. (Hardened)	47.	731-0954	Steering Bellow
22.	736-0217	L-Wash.	48.	731-1687	Steering Wheel (3 Spoke) †
23.	736-0242	Bell. Wash. .340 I.D. x .872 O.D.		631-0027	Steering Wheel (4 Spoke) ‡
24.	736-0356	Bell. Wash. .39 I.D. x 1.38 O.D.	49.	**	Wheel Assembly Comp.
25.	736-3081	Fl-Wash. .320 x .600 x .060	50.	731-0484A	Front Wheel Hub Cap
26.	738-0141	Shoulder Bolt .437 x .35 Lg.	51.	**	Front Wheel Rim Only
27.	738-0527	Shoulder Bolt			

† Uses Square Steering Wheel Cap

‡ Uses Round Steering Wheel Cap


* If Equipped



** Front Wheel Chart

Description	15" x 6" (Round Shoulder)	15" x 6" (Square Shoulder)
Wheel Ass'y Comp.	634-0056A	634-0105A
Tire Only	734-0864	734-1731
Rim Only	634-0172	634-0172
Bearing	741-0487A	741-0487A
Air Valve	734-0255	734-0255
Grease Fitting (Optional)	737-0211A	737-0211A
Grease Plug	737-0212A	737-0212A
Front Axle Ass'y-L.H.	683-0127	683-0127
Front Axle Ass'y-R.H.	683-0126	683-0126
Front Axle Ass'y-L.H. (46" Deck)	683-0125	683-0125
Front Axle Ass'y- R.H. (46" Deck)	683-0124	683-0124


Model Series 690 thru 699



Model Series 690 thru 699


REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1.	710-0604A	Hex Washer Screw 5/16-18 x .625	44.	783-0093	Offset Scissors
2.	712-3004A	Flange Lock Nut 5/16-18	45.	747-0887	Neutral Return Rod
3.	17840	Transaxle Mounting Bracket	46.	738-1170	Friction Stud
4.	731-1734	Hydro Bracket Indicator	47.	750-0918	Spacer
5.	710-0924	Machine Screw 1/4-20 x .75	48.	761-0196	Friction Washer .385 ID x 1.13 OD
6.	736-0329	Lock Washer 1/4	49.	736-0219	Bell Washer .39 ID x 1.13 OD
7.	710-0227	Hex Washer Screw #8-18 x .50	50.	736-3008	Flat Washer .344 ID x .750 OD
8.	726-0320	Insulator Nut Plate	51.	710-0859	Hex Cap Screw 3/8-16 x 2.50
9.	725-1713	Spring Switch	52.	756-0981A	Flat Idler Pulley
10.	712-3006	Hex Nut 1/4-20	53.	712-0431	Flange Lock Nut 3/8-16
11.	725-1399	Wire Assembly	54.	710-0347	Hex Cap Screw 3/8-16 x 1.5
12.	647-0008A	Control Speed Lever Assembly	55.	738-0347	Shoulder Spacer .625 OD
13.	783-0122	Speed Bracket Control	56.	783-1313	Flat Idler Bracket
14.	712-3010	Hex Nut 5/16-18	57.	783-0095	Return Neutral Mounting Bracket
15.	732-0433	Spring Extension	58.	783-1315	Idler Bracket
16.	712-0241	Hex Nut 3/8-24	59.	710-0642	Hex Washer Screw 1/4-20 x .75
17.	736-0169	Lock Washer 3/8	60.	756-0116	Idler Pulley
18.	714-0104	Cotter Pin	61.	754-0338	Belt
19.	738-0296	Shoulder Screw	62.	720-0166	Ball Knob
20.	736-0141	Spring Washer 7/16 x .740	63.	783-1312	Hydro Trans Bracket
21.	736-0119	Lock Washer 5/16	64.	732-0716	Extension Spring .59 OD x 4.0
22.	748-0234	Shoulder Spacer	65.	747-0608A	Lockout Brake Rod
23.	710-3008	Hex Cap Screw 5/16-18 x .75	66.	747-1274	Brake Rod 22.25 Lg
24.	747-1276A	Engage Rod 12.75 Lg	67.	17755A	Hydro Bracket
25.	711-0832	Ferrule	68.	710-0599	Hex Washer Screw 1/4-20 x .5
26.	736-0413	Spring Washer	69.	735-0196	Foot Pad
27.	736-0185	Flat Washer .375 ID x .738 OD	70.	747-1216	Stop Rod 3/8
28.	783-1314	Return Neutral Bracket	71.	683-0123	Brake Clutch Pedal Assembly
29.	712-3027	Hex Lock Nut 1/4-20	72.	710-1238	Hex Washer Screw 5/16-18 x .875
30.	783-0096	Neutral Return Lever	73.	712-0265	Nut 5/16-18
31.	748-0368	Shoulder Spacer	74.	736-0140	Flat Washer .385 ID x .62 OD
32.	712-0431	Flange Lock Nut 3/8-16	75.	714-0470	Cotter Pin
33.	712-0273	Hex Lock Nut 5/16-24	76.	683-0049	Lockout Bracket Assembly
34.	732-0727	Neutral Return Spring	77.	736-0406	Flat Washer .442 ID x 1.38 OD
35.	731-1449A	Blade Fan	78.	738-0296	Shoulder Screw .437 x .286 Lg
36.	747-1277	Hydro Bypass Rod	79.	732-0728	Extension Spring 4.31 Lg
37.	17994	Transaxle Spring Retainer Bracket	80.	714-0111	Cotter Pin
38.	710-0176	Hex Cap Screw 5/16-18 x 2.75	81.	736-3008	Flat Washer .344 ID x .750 OD
39.	783-0092	Flat Scissor	82.	750-0802	Spacer .640 ID x .760 OD
40.	710-0299	Hex Cap Screw 1/4-28 x 1.0	83.	17860	Pedal Mounting Bracket
41.	736-0159	5/16 Washer	84.	736-0256	Flat Washer .635 ID x .930 OD
42.	750-0808	Spacer .340 ID x .560 OD	85.	710-1012	Bolt 5/16-24
43.	736-0414	Flat Washer .570 ID x 1.20 OD	86.	732-0384	Extension Spring .62 Dia x 6.12 Lg

Model Series 690 thru 699




REF NO.	PART NO.	DESCRIPTION
1.	618-0587	Transmission Comp.

Description	20" x 8" (Round Shoulder)	20" x 8" (Square Shoulder)
Wheel Assembly Comp.	734-1675	634-0104
Tire Only	734-1596	734-1730
Rim Only	634-0070	634-0070



Model Series 690 Thru 699




Model Series 690 Thru 699

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	710-0599	Self Tap Screw 1/4-20 x .50" Lg.	27.	683-0029A	Pivot Link Ass'y -L.H.
2.	712-0271	Sems Hex Nut 1/4-20	28.	736-0231	FI-Wash. .344 I.D. x .125 O.D.
3.	738-0670A	Shaft 1/2" Dia. x 10.50" Lg.	29.	712-3004A	Flange L-Nut 5/16-18 Gr. 5
4.	17636D	Stablizer Bracket	30.	716-0104	"E" Ring
5.	17624	Stablizer Shaft Assembly	31.	14804A	Deck Hanger Link Ass'y
6.	736-0256	FI-Wash. .635 I.D. x .930 I.D.	32.	17710	Deck Hanger Link Ass'y
7.	714-0470	Cotter Pin 1/8" Dia.	33.	14800A	Deck Hanger Link Ass'y
8.	732-0556	Extension Spring 7.58" Lg.	34.	14802A	Link Deck Lift Ass'y
9.	17128A	Spring Retainer Brkt.	35.	17730	Index Brkt.
10.	714-0147	Cotter Pin	36.	736-0267	FI-Wash.
11.	710-1238	TT-Tap Scr. 5/16-18 x .75" Lg.	37.	714-0145	Hairpin Clip
12.	736-0425	Bell-Wash. .325" I.D.	38.	747-0598	Deck Belt Disengagement Rod
13.	720-0233	Grip (Lift Handle)	39.	748-0176	Flange Bearing .83 I.D. x .62 O.D.
14.	17675A	Deck Lift Handle Ass'y	40.	736-0222	L-Wash.
15.	732-0638	Extension Spring	41.	783-0103	Connecting Rod
16.	710-0604A	TT-Tap Scr. 5/16-18 x .625" Lg.	42.	725-1426	Solenoid
17.	736-0231	FI-Wash. .344 I.D. x 1.25 O.D.	42.	711-0841	Lift Link Adjuster
18.	741-0487A	Flange Bearing .632 I.D.	43.	712-3066	Hex Nut 1/2-20 Thd. (Gr. 5)
19.	683-0003	Hgt. Adj. Stop Lever Ass'y (Incl. #20)	44.	738-0669	Shaft 3/8" Dia. x 9.34" Lg.
20.	08540	Knob†	45.	738-0526	Running Board Rod
21.	732-0637	Extension Spring	46.	783-0043B	Upper Frame L.H.
22.	17637A	Lift Shaft Assembly	47.	783-0042D	Upper Frame R.H.
23.	736-0160	FI-Wash. .53 I.D. x .93 O.D.	48.	683-0028A	Pivot Link Assembly- R.H.
24.	17712	Adjustable Deck Lift Link	49.	710-3008	Hex Bolt 5/16-18 x .75" Lg.
25.	711-0723A	Ferrule 3/8-24 x .375 Dia.	50.	712-3010	Hex Nut 5/16-18 Thd.
26.	748-0331	Shoulder Spacer .318" Dia.	51.	736-0119	Lock Washer 5/16" I.D.

† Optional

Model Series 690 Thru 699




Model Series 690 Thru 699

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	726-0209	Cable Tie	34.	17950A	R. H. Pivot Seat Support Brkt.
2.	751-0603	Fuel Cap	35.	732-0581B	Extension Spring
3.	751-0553	Fuel Tank 1.25 Gal.	36.	17239A	Seat Lift Brkt.
	751-0555	Fuel Tank 1.50 Gal.	37.	738-0296	Shoulder Bolt .437" Dia. x .268"
	751-0657	Fuel Tank 3 Gal.	38.	17951A	L.H. Pivot Seat Support Brkt.
4.	712-0271	Sems Hex Nut 1/4-20 Thd.	39.	726-0278	Insulator Boss Plate
5.	723-3064	Battery Strap	40.	710-0870	Hex Tap Scr. 3/8-16 x .62" Lg.
6.	710-3015	Hex Hd. Cap Screw 1/4-20 Gr. 5	41.	783-0039A	Seat Pivot Brkt.
7.	725-1707D	Battery	42.	712-3027	Hex Flanged L-Nut 1/4-20 Thd.*
8.	783-0345	Battery Tray	43.	736-0175	Spring Wash. .265 I.D. x .562 O.D.*
9.	710-0351	Truss Mach. B-Tap Scr. #10 x .5" Lg.	44.	710-1268	Hex Wash. Hd. B-Tap Scr. *
10.	710-0227	Hex AB-Tap Scr. #8 x .50" Lg.	45.	720-0309A	Seat Adj. Grip*
11.	726-0320	Insulatop Nut Plate	46.	783-0611	Seat Adj. Stop*
12.	725-1643	Reverse Safety Switch	47.	732-0499	Compression Spring*
13.	783-0133B	Shift Cover	48.	783-0609	Seat Adj. Lever*
14.	747-1216	Stop Rod	49.	783-0607A	Pivot Seat Brkt.*
15.	710-0604A	TT-Tap Scr. 5/16-18 x .625" Lg.	50.	736-0204	FI-Wash. .344 I.D. x .62 O.D.*
16.	736-0169	L-Wash. 3/8	51.	738-0137A	Shoulder Bolt .34" x 1/4-20 Thd.*
17.	712-3017	Hex Nut 3/8-16 Thd. Gr. 8	52.	738-1007	Shoulder Scr. 3/8-16*
18.	710-0323	Truss Mach. Scr. 5/16-18 x .75"	53.	783-0753	Seat Adj. Selector*
19.	17770F	Running Board (R.H. & L.H.)	54.	731-1989	Seat Adj. Spacer*
20.	726-3046	Ratchet Clip	55.	736-0192	FI-Wash. .344 I.D. x .62 O.D.
21.	736-0119	L-Wash. 5/16" I.D.	56.	757-0363A	Low Back Black Seat
22.	712-3010	Hex Nut 5/16-18 Thd.		757-0360A	Med. Back Black Seat
23.	736-0270	Bell-Wash. .265" I.D. x .75" O.D.		757-0348A	High Back Black Seat
24.	712-3006	Hex Nut 1/4-20		757-0350	High Back Black w/Drain Holes
25.	738-0526	Running Board Rod	57.	761-0168B	Blade Brake Assembly
26.	710-3008	Hex Bolt 5/16-18 x .75" Lg.	58.	712-3006	Hex Nut 1/4-20 Thd.
27.	710-1208	Hex Tap Scr. 5/16-18 x 3.25" Lg.	59.	736-0329	L-Wash. 1/4" I.D.
28.	732-0735	Compression Spring	60.	710-0703	Carriage Bolt 1/4-20 x .62" Lg.
29.	748-0347A	Spring Spacer	61.	710-0751	Hex Hd. Cap Scr. 1/4-20 x .62" Lg.
30.	726-0279	Insulator Plate	62.	735-0689A	Rubber Foot Pad
31.	725-1303	Outer Spring Switch Spring	-	723-0422A	Abrasive Foot Pad (Not Shown)
32.	725-1439	Inner Spring Switch Spring	63.	731-0405	Snap Bushing
33.	710-0726	Hex Wash. AB Scr. 5/16-12 x .75"			

* Optional

Deck F



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
2	710-1260A	Hex Wash. TT-Tap Scr. 5/16-18 x .75"	26	754-0329A	V-Belt
3	683-0129A	38" Deck Ass'y. **	27	736-0270	Bell-Wash. 1/4" I.D.
	753-0694	38" Deck Ass'y. Complete **	28	783-0342	Brake Disc
4	783-0343A	Belt Guard Deck	35	712-0417A	Hex Flange Nut 5/8-18 Thd.†
5	710-0599	Hex Wash. Hd. TT- Tap Scr.1/4-20 Thd.	39	618-0138A	Blade Spdl Assembly
6	710-0134	Carriage Screw 1/4-20 Thd. Gr. 2	42	756-0969	5" Dia. Pulley†
8	710-0751	Hex Bolt 1/4-20 x .62"	52	703-1693A	Hinge Mtg. Brkt.
10	711-0792	Hinge Pin	53	732-0602A	Torsion Spring
12	783-1297	Deck Skirt 38"	54	726-0106	Push Nut
13	712-0181	Hex Top L-Nut 3/8-16 Thd.	55	731-1032B	Chute Assembly
14	712-3006	Hex Nut 1/4-20 Thd. (Gr. 5)	57	712-3087	Wing Nut 1/4-20 Thd. ††
17	734-0973	Deck Wheel—5"	58	731-2363	Mulching Plug ††
18	736-0105	Bell-Wash. .40" I.D. x .88" O.D.	59	16606	Retainer Hook Brkt.
22	738-0373	Shld. Bolt .498" Dia. x 1.53"	60	712-3027	Hex Flange Nut 1/4-20 Thd.
23	742-0610	3 in 1 Blade			

† Deck pulleys and blade nuts must be torqued to 100 ft. lbs. if removed or replaced.


†† If equipped

** Must be ordered with 4 digit color code.

IMPORTANT: For a proper working machine, use Factory Approved Parts.

V-BELTS are specially designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.

Deck G



Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
2	710-1260A	Hex Wash. TT-Tap Scr. 5/16-18 x .75"	26	754-0371A	V-Belt
3	683-0141B	42" Deck Ass'y. **	27	736-0270	Bell-Wash. 1/4" I.D.
	753-0698	42" Deck Ass'y. Complete **	28	783-0342	Brake Disc
4	783-0149B	Belt Guard Deck	35	712-0417A	Hex Flange Nut 5/8-18 Thd.†
5	710-0599	Hex Wash. Hd. TT-Tap Screw 1/4-20 Thd.	39	618-0142A	Blade Spindle Assembly
6	710-0134	Carraige Screw 1/4-20 Thd.	42	756-0980	5.75" Dia. Pulley†
8	710-0751	Hex Bolt 1/4-20 x .62"	52	703-1693A	Hinge Mtg. Brkt.
10	711-0792	Hinge Pin	53	732-0602A	Torsion Spring
12	783-1146A	Deck Skirt 42"	54	726-0106	Push Nut
13	712-0181	Hex Top L-Nut 3/8-16 Thd.	55	731-1032B	Chute Assembly
14	712-3006	Hex Nut 1/4-20 Thd. (Gr. 5)	57	712-3087	Wing Nut 1/4-20 Thd.††
17	734-0973	Deck Wheel—5"	58	731-2363	Mulching Plug ††
18	736-0105	Bell-Wash. .40" I.D. x .88" O.D.	59	16606	Retainer Hook Brkt.
22	738-0373	Shld. Bolt .498" Dia. x 1.53"	60	712-3027	Hex Flange Nut 1/4-20 Thd.
23	742-0616	3 in 1 Blade			

† Deck pulleys and blade nuts must be torqued to 100 ft. lbs. if removed or replaced.


†† If equipped

** Must be ordered with 4 digit color code.

IMPORTANT: For a proper working machine, use Factory Approved Parts.

V-BELTS are specially designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.

46" Deck "H"



46" Deck "H"


Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	16606	Retainer Hook Brkt.	32.	736-0105	Bell-Wash 3/8" x .87" x .064"
2.	17116	Deck Deck Brake Brkt Ass'y	33.	736-0158	L-Wash. 5/8" I.D.
3.	17258C	Belt Cover	34.	736-0290	Fl-Wash. .635" I.D. x 1" O.D.
4.	618-0240A	Spindle Ass'y	35.	736-0329	L-Wash. 1/4" I.D.
5.	983-0120A	46" Deck Ass'y**	36.	736-0331	Bell-Wash. 3/8" x 1.125" x .062"
	913-06921	46" Deck Ass'y Comp. (For Svc.)**	37.	736-3088	Fl-Wash. .635" I.D.
6.	710-0151	Hex Bolt 3/8-24 x 2" Lg.	38.	738-0347	Shoulder Spacer .625" I.D.
7.	710-0167	Carriage Bolt 1/4-20 x .5" Lg.	39.	738-0373	Shld. Bolt .498" x 1.525"
8.	710-0428	Hex Bolt 1/4-28 x 1.25" Lg.	40.	741-0524	Ball Brg. .625" I.D. x 1.574" O.D.
9.	710-0459A	Hex Bolt 3/8-24 x 2" Lg.	41.	742-0644	Blade 16.28" Lg. (L.H. & R.H.)
10.	710-0599	Hex Wash. Hd. TT-Tap Scr.	42.	742-0645	Blade 14.88" Lg. (Middle)
12.	710-0751	Hex Bolt 1/4-20 x .62" Lg.	43.	748-0234	Shoulder Spacer
13.	710-1039	Hex Bolt 3/8-24 x 1" Lg.	44.	750-0932A	Spacer .635" I.D. x .088" O.D.
14.	710-1260A	Hex Flange Bolt 5/16-24 x .75"	45.	750-0960	Spacer .635" I.D. x 1" O.D.
15.	710-3151	Hex Bolt 5/8-18 x 4.25" Lg.	46.	754-0439	V Belt
16.	711-0993	Belt Guard Pin	47.	754-0440	V Belt
17.	712-0138	Hex Nut 1/4-28 Thd.	48.	756-0627B	Idler Pulley
18.	712-0158	Hex Center L-Nut 5/16-18	49.	756-0638	Pulley Double Deck
19.	712-0181	Hex Top Jam Nut 3/8-16 Thd.	50.	783-0046	Idler Deck Bracket
20.	712-0241	Hex Nut 3/8-24 Gr. 5	51.	783-0063A	Belt Cover L.H.
21.	712-0271	Hex Sems Nut 1/4-20	52.	783-0141	46 " Deck Skirt Center
22.	712-0337	Hex Nut 5/8-18 Gr.5	53.	783-0142	46" Deck Skirt R.H.
23.	712-0417A	Hex Flange L-Nut 5/8-18 Thd.	56.	703-1693A	Hinge Brkt.
24.	712-0429	Hex Ins. L-Nut 5/16-18 Thd.	57.	711-0792	Hinge Pin
25.	712-3006	Hex Nut 1/4-20 Gr.5	58.	731-1032B	Chute Ass'y Comp.
26.	712-3027	Hex Lock Nut 1/4-20			(Incl. 12, 56, 57,59, 60, 61, 62, 63,)
27.	716-3020	Internal Snap Ring	-	731-1031B	Chute Deflector
28.	731-1490	Slide Cap	59.	732-0602A	Torsion Spring
29.	732-0594A	Ext. Spring .88" O.D. x 6.17"	60.	736-0270	Bell. Wash. .265 x.75
30.	732-0723	Ext. Spring .788" O.D. x 15.5"	61.	726-0106	Speed Nut Cap
31.	734-0973	Deck Wheel-5"	62.	738-0999	Return Spring Stud
			63.	726-0233	Push Nut

** Must be ordered with 4 digit color code.

IMPORTANT: For a proper working machine, use Factory Approved Parts. **V-BELTS** are specially designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.


Harness Assembly

Briggs & Stratton
Single Cylinder




Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	629-0207	Harness Adapter (Mag.)	6.	725-0963	Bulb (Headlight)
2.	629-0302D	Wire Harness w/Light Switch and Amp	7.	725-1426	Solenoid
	629-0301D	Wire Harness w/o Light Switch and Amp	8.	725-1643	Safety Switch (Reverse)
3.	725-0267	Ignition Switch	9.	725-1657A	Safety Switch Ratchet
4.	725-0634	Light Switch (If equipped)			
5.	725-0925	Ammeter (If equipped)			

Briggs & Stratton
Overhead Valve




Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
2.	629-0305D	Wire Harness w/Light Switch and Amp	7.	725-1426	Solenoid
	629-0304D	Wire Harness w/o Light Switch and Amp	8.	725-1643	Safety Switch (Reverse)
3.	725-0634	Light Switch (If equipped)	9.	725-1657A	Safety Switch Ratchet
4.	725-0925	Ammeter (If equipped)	11.	726-3046	
5.	725-0963	Bulb (Headlight)			
6.	725-1396	Ignition Switch			

Briggs & Stratton Twin Cylinder




Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
2.	629-0208	Harness Adapter	8.	725-1426	Solenoid
3.	629-0302D	Wire Harness w/Light Switch & Amp	9.	725-1643	Safety Switch (Reverse)
	629-0301D	Wire Harness w/o Light Switch & Amp	10.	725-1657A	Safety Switch
4.	725-0267	Ignition Switch	11.	629-0125	Harness Adapter (Alt.)
5.	725-0634	Light Switch	13.	726-3046	Ratchet
6.	725-0925	Ammeter			
7.	725-0963	Bulb			

Tecumseh




Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	629-0302D	Wire Harness w/Light Switch & Amp	6.	725-1426	Solenoid
	629-0301D	Wire Harness w/o Light Switch & Amp	7.	725-1643	Safety Switch (Reverse)
2.	725-0267	Ignition Switch	8.	725-1657A	Safety Switch
3.	725-0634	Light Switch (If equipped)	10.	726-3046	Ratchet
4.	725-0925	Ammeter (If equipped)			
5.	725-0963	Bulb (Headlight)			

Kohler



Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	726-3046	Ratchet	6.	725-0634	Light Switch
2.	725-1657A	Safety Switch	7.	725-0267	Ignition Switch
3.	725-1426	Solenoid	8.	629-0303B	Wire Harness
4.	725-0963	Bulb (Headlight)	9.	629-0209	Wire Harness Adapter
5.	725-0925	Ammeter	10.	629-0132	Wire Harness (Monitor)


Intek Twin



Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	726-3046	Ratchet	6.	725-0925	Ammeter
2.	725-1657A	Safety Switch	7.	725-0634	Light Switch
3.	725-1426	Solenoid	8.	629-0305D	Wire Harness w/Lt./Amp
4.	725-1396	Ignition Switch		629-0306D	Wire Harness w/Lt./Amp/Mon.
5.	725-0963	Bulb (Headlight)			


Engine

Briggs & Stratton Single Cylinder




Ref. No.	Part No.	Description
1.	783-0615	Muffler Bracket
2.	751-0618	Exhaust Pipe
3.	751-0617	Muffler
4.	751-0564	Muffler Deflector
5.	736-0119	Lock Washer 5/16" I.D.
6.	726-0272	Clamp
7.	721-0208	Exhaust Gasket
8.	710-1314	Socket Hd. Bolt 5/16-18 x .62" Lg.
9.	710-0604	Hex Wash Hd. TT-Tap Scr. 5/16-18 x .62"
10.	710-0599	Hex Wash. TT-Tap Scr. 1/4-20 x .5" Lg.
11.	710-0148	Hex Slot Scr. #8-32 x .38" Lg.

Briggs & Stratton Overhead Valve




Ref. No.	Part No.	Description
1.	710-0148	Hex Tap Scr. #8-32 x .38" Lg.
2.	710-0599	Hex TT-Tap Scr. 1/4-20 x .5" Lg.
3.	710-0604	Hex TT-Tap Scr. 5/16-18 x .62"
4.	710-1237	Hex Wash. Scr. #10-32 x .62"
5.	710-1314	Socket Head Scr. 5/16-18 x .62"
6.	710-1315	Hex TT-Tap Scr. 3/8-16 x 1.25"
7.	712-0271	Hex Sems Scr. 1/4-20 Thd.
8.	721-0208	Gasket
9.	726-0205	Hose Clamp
10.	726-0272	Clamp
11.	731-1682A	Oil Drain Sleeve
12.	736-0119	Lock Washer 5/16" I.D.
14.	751B213146	Casing Clamp
15.	751-0535-12	Fuel Line 12" Lg.
16.	751-0564	Muffler Deflector
17.	751-0617	Muffler
18.	751-0619	Exhaust Pipe
19.	783-0615	Muffler Brkt.

Briggs & Stratton Twin Cylinder




Ref. No.	Part No.	Description
1.	710-0148	Hex Tap Scr. #8-32 x .38" Lg.
2.	710-0599	Hex Wash. TT-Tap Scr. 1/4-20 x5" Lg.
3.	710-0604	Hex Wash. TT-Tap Scr. 5/16-18 x .62"
4.	710-0779A	Truss Mach. Scr. #10 x .5" Lg.
5.	710-1315	Hex Hd. Tap Scr. 3/8-16 x 1.25"Lg.
6.	710-3015	Hex Bolt 1/4-20 x .75"Lg.
7.	712-0271	Hex Sems Nut 1/4-20 Thd.
9.	721-0346	Exhaust Gasket
10.	726-0205	Hose Clamp
11.	726-0272	Clamp
12.	736-0329	Lock Washer 1/4" I.D.
13.	736-3067	Flat Washer .188" I.D. x .438" O.D.
14.	737-0143	Oil Drain Cap
15.	737-0164	Pipe Nipple 3/8 x 18 NPT.
17.	751-0535-26	Fuel Line 26" Lg.
18.	751-0564	Deflector: Muffler
19.	751-0616	Muffler
20.	751-0623	Exhaust Pipe—LH
21.	751-0624	Exhaust Pipe—RH
22.	783-0357	Heat Shield
23.	783-0615	Muffler Bracket

Tecumseh




Ref. No.	Part No.	Description
1.	710-0148	Hex Bolt #8-32 x .38" Lg.
2.	710-0599	Hex Wash. Hd. TT-Scr. 1/4-20 x .5" Lg.
3.	710-0604	Hex Wash. Hd. TT-Scr. 5/16-18 x .62"
4.	710-1314	Socket Hd. Bolt 5/16-18 x .62" Lg.
5.	710-1315	Hex Wash. Hd. TT-Scr. 3/8-16 x 1.25"
6.	712-0271	Hex Sems Nut 1/4-20 Thd.
8.	721-0348	Exhaust Gasket
9.	726-0205	Hose Clamp
10.	726-0272	Clamp
11.	736-0119	Lock Washer 5/16" I.D.
13.	737-0286	Pipe 3/8 NPT x 3.8" Lg. (16/17 HP)
	737-0199	Pipe 3/8 NPT x 2" Lg. (12/13 HP)
14.	751-0535-12	Fuel Line
15.	751-0564	Muffler Deflector
16.	751-0572	Hex Pipe Plug (16/17 HP)
	737-0143	Oil Drain Cap (12/13 HP)
17.	751-0617	Muffler
18.	751-0620	Exhaust Pipe (16/17 HP)
	751-0622	Exhaust Pipe (12/13 HP)
19.	783-0378A	Heat Shield (16/17 HP)
20.	783-0615	Muffler Bracket

Kohler



Ref. No.	Part No.	Description
1.	710-0148	Hex Tap Scr. #8-32 x .38" Lg.
2.	710-0599	Hex Wash. TT-Tap Scr. 1/4-20 x5" Lg.
3.	710-0604	Hex Wash. TT-Tap Scr. 5/16-18 x .62"
4.	710-3206A	Hex Bolt M8 x 1.25
5.	712-3086	Hex Flange Nut M8 Thd.
7.	721-0375	Exhaust Gasket
8.	726-0205	Hose Clamp
9.	726-0272	Clamp
10.	736-0607	External Lock Washer 5/16" I.D.
12.	751-0535-12	Fuel Line 12" Lg.
13.	751-0564	Muffler Deflector
14.	751-0617	Muffler
15.	751-0621	Exhaust Pipe
16.	751-3140	Oil Drain
17.	751-3141	Oil Drain Hose
18.	783-0615	Muffler Bracket.

Intek Twin



Ref. No.	Part No.	Description
1.	710-0148	Hex Tap Scr. #8-32 x .38" Lg.
2.	710-0599	Hex Wash. TT-Tap Scr. 1/4-20 x5" Lg.
3.	710-0604	Hex Wash. TT-Tap Scr. 5/16-18 x .62"
4.	710-1314	Socket Head Scr. 5/16-18 x .62"
5.	710-1315	Hex TT-Tap Scr. 3/8-16 x 1.25"
7.	721-0460	Exhaust Gasket
8.	726-0205	Hose Clamp
9.	726-0272	Clamp
10.	736-0119	Lock Washer 5/16" I.D.
12.	751-0535-12	Fuel Line 12" Lg.
13.	751-0564	Muffler Deflector
14.	751-0616	Muffler
15.	751-0650	Exhaust Pipe—RH
16.	751-0651	Exhaust Pipe—LH
17.	751-3140	Oil Drain
18.	751-3141	Oil Drain Hose
19.	783-0615	Muffler Bracket
20.	783-0625	Heat Shield