


SECTION 12: MODEL U804H PARTS LIST



Model U804H

REF. NO.	PART NO.	DESCRIPTION
1	710-0227	Self-tapping Screw, #8-18 x.5
2	710-0599	Self-tapping Screw, 1/4-20 x.5
3	710-0726	Self-tapping Screw, 5/16-12 x.750
4	710-1237	Screw, #10-32 x.625
5	710-1314A	Socket Cap Screw, 5/16-18 x.625
6	710-1315	Self-tapping Screw, 3/8-16 x 1.25
7	712-3017	Hex Nut, 3/8-16
8	721-0460	Exhaust Gasket
9	726-0205	Hose Clamp
10	736-0119	Lock Washer, 5/16
11	736-0300	Flat Washer
12	751B221535	Casing Clamp
13	751-0535	Fuel Line Hose
14	751-0564	Muffler Deflector
15	751-0616	Muffler, Twin Inlet
16	751-0650	RH Exhaust Pipe
17	751-0651	LH Exhaust Pipe
18	751-3140	Oil Drain Valve
19	751-3141	Oil Drain Hose
20	751-3142	Oil Drain Cap
21	783-0615B	Muffler Heat Shield
22	783-0625C	Engine Heat Shield
23	722-0263	Foam (fits over fuel line)
24	746-1086	Throttle Cable


NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665

Yard-Man Yellow: 0674


Powder Black: 0637

Model U804H



REF. NO.	PART NO.	DESCRIPTION
1	710-3015	Hex Cap Screw, 1/4-20 x.75
2	710-0599	Self-tapping Screw, 1/4-20 x.5
3	712-3027	Hex Nut, 1/4-20
4	710-0895	Self-tapping Screw, 1/4-15 x.75
5	710-0924	Pan Phillips Screw, 1/4-20 x.75
6	710-0528	Hex Cap Screw, 5/16-18 x 1.25
7	712-0292	U-type Speed Nut, 1/4-20
8	712-3004A	Flange Lock Nut, 5/16-18
9	726-0201	Speed Nut
11	731-1978	RH Head Light Lens
	731-1979	LH Head Light Lens
12	747-1132A	Hood Support Rod
13	731-1980B	Hood
14	731-1981C	LH Side Panel
15	731-1982C	RH Side Panel
17	736-0342	Flat Washer,.283 x.75 x.030
18	736-0173	Flat Washer,.28 x.74 x.063
19	736-3078	Flat Washer,.349 x 1.0 x.063
20	710-0642	Self-tapping Screw, 1/4-20 x.750
21	783-0808A	Hood Heat Shield w/o Intake Bellow
22	710-0726	Self-tapping Screw, 5/16-12
24	710-3217	Torx Screw, #8-32 x.375
25	712-0142	Hex Nut, 8-32
26	731-0071D	Dash Panel, 4-style
27	731-04214	Parking Brake Lever
28	731-1857	Throttle Control Lever
29	731-04213	Cruise Control Lever
30	747-1155	Brake/Cruise Pivot Rod
31	749-1087C	Dash Support Tube
32	731-2234A	Intake Bellow
33	751-0658D	Fuel Tank, 3-gallon
34	751-0603	Fuel Cap
35	725-1745	Ignition Key w/ plastic cover
	725-1744	Ignition Key w/o plastic cover
37	783-1000A	Grille Support Bracket
38	725-04036	Systems Indicator Monitor
39	725-1741	Ignition Switch
40	725-1649	Lamp Socket
	725-0963	Miniature Lamp
43	731-1996	RH Headlight Reflector
	731-1995	LH Headlight Reflector
—	629-0469B	Headlight Wire Harness
—	629-1071	Tractor Wire Harness (Manual PTO)
—	629-04048	Tractor Wire Harness (Electric PTO)
44	736-0142	Flat Washer,.281 x.50 x.063
45	710-1611B	Self-Tapping Screw, 5/16-18
46	783-0462	Electric PTO Switch Bracket Retainer

Model U804H



Model U804H

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	747-1130B	Deck Stabilizer Rod	34	783-1280	Fender
2	683-0197B	Lift Shaft Assembly	35	783-1489	Seat Mounting Bracket
3	711-0332	Clevis Pin,.5 x.78	36	710-1268	Screw, #10-16 x.375
4	712-0206	Hex Nut, 1/2-13	37	712-3027	Hex Flange Lock Nut, 1/4-20
5	712-0431	Flange Lock Nut, 3/8-16	39	731-04074	Spacer
6	712-3004A	Flange Lock Nut, 5/16-18	40	732-0499	Compression Spring,.41 x 1.5
7	712-3083	Hex Nut, 1/2-13	41	736-0175	Spring Washer,.265 x.562 x.025
8	714-0104	Internal Cotter Pin	42	736-0204	Flat Washer,.344 x.62 x.03
9	714-0145	Internal Cotter Pin	43	738-0137A	Shoulder Screw,.340 x.285,1/4-20
10	716-0106	E-ring	44	738-0966	Shoulder Screw,.50 x.825, 3/8-16
11	720-0311	Handle Grip	45	783-0611	Seat Stop
12	732-0874	Torsion Spring	46	783-0738A	Seat Pivot Bracket
13	732-1184	Extension Spring,.84 x 4.6	47	783-04246	Seat Adjustment Lever
14	736-0275	Flat Washer, 5/16	48	783-0753	Seat Adjustment Selector
15	736-0921	Lock Washer, 1/2	49	757-04012	High Back Seat, Yellow
16	736-3019	Flat Washer,.31 x 1.062 x.134	50	735-0656	RH Foot Pad
17	736-3084	Flat Washer,.51 x 1.12 x.06	51	735-0657	LH Foot Pad
18	738-0138A	Hex Cap Screw, 5/16-18 x.62	—	726-3046	Foot Pad Clips (Not shown)
19	738-0143	Shoulder Screw, 3/8-16	52	714-0111	Cotter Pin
20	741-0225	Hex Flange Bearing	54	783-0209A	LH Seat Lift Bracket
21	741-0715	Snap Flange Bearing	—	17239A	RH Seat Lift Bracket
22	746-0968	Lift Cable, 16.16	55	710-0788	Self-tapping Screw, 1/4-20 x 1.00
23	747-1111A	Lift Handle	57	731-2480A	Shift Lever Cover
24	756-1154	Roller Pulley	58	738-0296	Shoulder Screw,.437 x.286
25	783-0678A	Arm Lift	59	731-2618	RH Fender Flare
26	783-0720A	Deck Stabilizer Bracket	60	731-2619	LH Fender Flare
27	710-0260A	Carriage Bolt, 5/16 x.62	61	736-0160	Flat Washer,.53 x.93 x.050
28	710-0726	AB Screw, 5/16-12 x.75	62	726-0201	Speed Nut
29	710-0895	Self-tapping Screw, 1/4-15 x.75	63	720-04026	Side Seat Adjuster Grip
30	731-1990	Lift Lever Cover	64	725-1713	Switch
31	731-1993	Cover w/ Cup Holder	65	726-0320	Insulator Nut Plate
32	736-3078	Flat Washer,.349 x 1.0 x.063	66	710-0932	Screw, 1/4-20 x 1.00
33	783-0677	Lift Adjustment Bracket	67	712-0271	Hex Nut, 1/4-20


NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665

Yard-Man Yellow: 0674

Powder Black: 0637

Model U804H



REF. NO.	PART NO.	DESCRIPTION
2	710-1238	Self-tapping Screw, 5/16-18 x.875
3	783-0726B	RH Pivot Support Bracket
4	783-0727A	LH Pivot Support Bracket
5	783-0728	Pivot Bar Bracket
6	710-0514	Hex Cap Screw, 3/8-16 x 1.00 (Grade 5)
7	711-1408	RH Drag Link
8	711-1409A	LH Drag Link
9	712-0240	Jam Nut, 7/16-20 (Grade 2)
10	712-0241	Hex Nut, 3/8-24 (Grade 2)
11	712-0431	Flange Lock Nut, 3/8-16
12	712-0459	Flange Lock Nut, 7/16-20
13	712-3004A	Flange Lock Nut, 5/16-18
14	717-1550D	Steering Gear, 11/90 Ratio
15	717-1554	Steering Pinion Gear
16	723-0448A	Ball Joint, 7/16-20
17	736-0169	Lock Washer, 3/8
18	736-3084	Flat Washer,.51 x 1.12 x.06
19	738-1001A	Steering Shaft,.625 OD x 24.4
20	741-0475	Plastic Bushing,.38 ID
21	741-0656	Hex Flange Bearing, 5/8
22	738-0372B	Shoulder Spacer,.38 ID
23	731-04065	Steering Wheel Cover
24	731-1291A	Pivot Bar End Cap w/ Fitting
25	638-0017	LH Axle Assembly,.75 Diameter
26	638-0018	RH Axle Assembly,.75 Diameter
27	683-0128A	Steel Pivot Bar
28	712-0431	Flange Lock Nut, 3/8-16
29	714-0162	Cotter Pin
30	726-0341	Push Cap,.75
31	736-0316	Flat Washer,.78 x 1.589 x.06
32	631-04008	Steering Wheel, Soft Grip, Three Spoke
34	738-1011	Shoulder Screw,.5 x 2.2, 3/8-16
35	741-0660	Flange Bearing,.76 ID x.937 OD
36	634-0183	Wheel Assembly, 16 x 6.5 x 8
		Square Shoulder
	634-0182	Rim Assembly Only
	734-0255	Air Valve (Not Shown)
	734-1727	Tire Only, Square Shoulder
37	731-2290A	Deluxe Hub Cap
38	783-0653F	Steering Support Bracket
39	738-0143	Shoulder Screw, 3/8-16
40	736-0331	Bell Washer,.39 x 1.13 x.062
41	710-1260A	Self-tapping Screw, 5/16-18 x.75
42	736-0242	Bell Washer,.34 x.872
43	710-0643	Hex Bolt, 5/16-18 X 1
44	736-3004	Flat Washer,.406ID x.875OD
45	710-04095	Hex Cap Screw, 3/8-16 x 1.00


NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665

Yard-Man Yellow: 0674

Powder Black: 0637

Model U804H



Model U804H

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	618-0375	Variable-speed Bracket Assembly	46	647-0031B	Brake Control Shaft Assembly
2	618-0376	Two-speed Transmission Assembly	47	647-0032	Speed Control Shaft Assembly
3	631-0009A	Shifter Knob	48	683-0266	Drive Pedal Assembly
4	647-0037	Shift Lever	49	710-1135	Self Tapping Screw, 5/16-18 x 2.5
5	656-0050	Variable-speed Pulley Assembly	51	711-1363	Pin, 3/8-16 x 2.43
6	756-0665	Transmission Pulley, 8.5	52	714-0104	Cotter Pin
7	683-0251	Double-idler Bracket	53	732-0335	Compression Spring,.405 x 1.17
8	710-0176	Hex Cap Screw, 5/16-18 x 2.75	54	732-0955	Extension Spring,.5 OD x 1.41
10	710-0347	Hex Cap Screw, 3/8-16 x 1.75	55	735-0662	Drive Pedal Pad
11	710-0805	Hex Cap Screw, 5/16-18 x 1.5	56	735-3049	Brake Pedal Pad
12	710-0809	Self-tapping Screw, 1/4-20 x 1.25	57	736-0262	Flat Washer,.385ID x.870OD
13	710-0726	Self Tapping Screw, 5/16-12 x.75	58	736-0142	Flat Washer, 9/32 x 1/2 x 1/16
14	710-3011	Hex Cap Screw, 3/8-16 x 2.25	59	736-0187	Flat Washer,.64 x 1.24 x.06
15	711-0677	Ferrule, 5/16 x.312 Dia.	61	738-0155	Shoulder Screw,.437 x 1.62
16	712-0181	Hex Jam Nut, 3/8-16	62	738-0507B	Shoulder Screw,.5 x.434
17	712-0702	Hex Flange Nut, 7/16-20	63	741-0225	Hex Flange Bearing
18	712-0431	Flange Lock Nut, 3/8-16	64	741-3065B	Split Hex Flange Bearing
19	712-3017	Hex Nut, 3/8-16	65	747-04096	Cruise Control Rod
20	712-3004A	Flange Lock Nut, 5/16-18	66	747-04093	Brake Lock Control Rod
21	712-3008	Hex Jam Nut, 3/8-16	67	748-0413	Cruise Latch
22	714-0111	Cotter Pin	68	748-0415B	Spacer, 5/16 x 1.54
23	723-3018	Ball Joint, 3/8-24	69	783-0653F	Steering Support Bracket
24	710-1260A	LD Screw, 5/16-18 x.75	70	783-0732	Drive Lockout Bracket
25	710-0650	Self-tapping Screw, 5/16-18 x.875	71	783-0773A	Brake Pedal
26	732-0384	Extension Spring,.62 Dia. x 6.12	72	736-3008	Flat Washer,.344 x.750 x.120
27	732-0716	Extension Spring,.59 OD x 4.0	73	783-0693	Axle Bracket
28	736-0105	Bell Washer,.401 x.870 x.063	74	683-0304C	Lower Frame Assembly
29	736-0169	Lock Washer, 3/8	75	732-0963	Extension Spring,.5 OD x 6.37
30	736-0275	Flat Washer, 5/16	76	731-2290A	Hub Cap
31	718-0771	Pulley Hub, 1/2 Spline	77	712-3050	Lug Nut, 7/16-14
32	736-0642	Flat Washer,.44 x.75 x.06	78	634-0132	Wheel Assembly Complete, 23 x 9.5 x 12
33	736-3010	Flat Washer,.407 x.812 x.135		634-0194	Rim Only
34	738-0322	Shoulder Screw,.625 Dia. x.21		734-0255	Air Valve
35	747-1122	Brake Rod		734-1728	Tire Only, Square Shoulder
36	747-1123A	Belt Guard	80	750-0566A	Spacer,.372 x.26 x 1.03
37	747-1127	Idler Adjustment Rod, 3/8	81	712-3026	Jam Nut, 3/4-16
40	738-0372B	Shoulder Spacer,.380 ID	82	736-0316	Flat Washer,.78 x 1.59 x.06
41	754-0468	Variable-speed Belt	83	710-1611B	Self-tapping Screw, 5/16-18 x.75
42	754-0467	Drive Belt	84	747-1185	Transmission Belt Guard Rod
43	756-0981A	Flat Idler, 2.75 OD	85	710-0599	Self Tapping Screw,1/4-20 x.5
44	783-0667B	Transmission Torque Bracket	86	756-0639B	Engine Pulley, 3.56"
45	783-0669	Idler Bracket			


NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665

Yard-Man Yellow: 0674

Powder Black: 0637

Model U804H




Model U804H

REF. NO.	PART NO.	DESCRIPTION
1	618-0225	Reverse Collar Assembly
2	618-0226	Hi-Lo Collar Assembly
3	618-0227A	Shift Fork Assembly
4	618-0284	Detent Block Assembly
5	618-0285	Output Bearing Block Assembly
6	618-0286	Output Seal Bearing Block Assembly
7	618-0287	Inboard Sealed Axle Block Assembly
8	618-0302	Inboard Sealed Axle Block Assembly
9	618-0365	Wheel Hub Assembly
10	618-0368	Differential Axle Assembly
11	719-0379A	Upper Housing
12	641-0002A	Axle Bearing Block Assembly
13	661-0012	Brake Assembly
14	710-0642	Self-tapping Screw, 1/4-20 x .75
15	710-0788	Self-tapping Screw, 1/4-20 x 1.0
16	711-1051A	Drive Shaft
17	711-1216	Output Shaft
18	712-1329	Nut, 3/4-16
19	713-0446	9-tooth Sprocket
20	713-0447	16-tooth Sprocket
21	713-0448	22-link Chain,.625
22	716-0131	External Snap Ring
23	717-0678	Brake Pad
24	717-1438	41-tooth Bevel Gear
25	717-1439	20-tooth Spur Gear
26	717-1440	10-tooth Spur Gear
27	717-1441	27-tooth Spur Gear
28	717-1442	37-tooth Spur Gear
29	718-0500	Inner Axle Bearing Block
30	718-0504	Shifter Insert
31	718-0505	Shifter Cover
32	718-0537	Shifter Bearing Block
33	719-0385	Lower Housing
34	718-0540	Lockout Plate
35	736-0337	Flat Washer, 5/8 x 1.0
36	736-3046A	Flat Washer, 1.01 x 1.86 x.060
37	711-1235	Input Shaft
38	747-1140	Shift Lever
39	750-1033A	Spacer, 1.13 x 1.38 x 1.968
40	761-0215	Disc Brake
41	716-0114	Retaining Ring,.56
42	717-1463	13-tooth Bevel Gear
43	736-0335	Flat Washer
44	736-0337	Flat Washer, 5/8 x 1.0 x.040
46	741-0335	Needle Bearing
47	741-0696	Needle Bearing
48	716-0231	E-ring,.75
49	618-0376	Transmission Assembly Complete

NOTE: Transmission has a grease capacity of 32 oz. Order part number 737-0148.

NOTE: Upon reassembling transmission input shaft for any reason, refill its cavity with approximately 2/3 oz. of grease. Order part number 737-0289.

Model U804H (w/ Electric PTO)



Model U804H

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	710-1238	Hex Head Washer Screw, 5/16-18 x.875	25	710-3180	Hex Cap Screw, 5/16-18 x 1.75
2	754-0476	PTO Belt	26	736-0171	Lock Washer, 7/16
3	712-3004A	Flange Lock Nut, 5/16-18	27	736-0322	Flat Washer, .450 x 1.25
4	712-0431	Flange Lock Nut, 3/8-16	28	783-0653F	Steering Support Bracket
5	712-3010	Hex Nut, 5/16-18	29	710-0224	AB Screw, #10-16 x 0.5
6	748-0415B	Spacer, 3/8 x 1.54	30	17962	Switch Plate
7	756-0627B	Idler Pulley, 3.5	31	725-04039	Switch
8	783-0891B	Deck Stop	32	710-0642	Self-tapping Screw, 1/4-20 x 0.75
9	710-0604A	Self Tapping Screw, 5/16-18 x.625	33	783-0693	Axle Bracket
10	732-04035	Compression Spring, 1.28 x 3.125	34	736-0329	Lock Washer
11	723-0444	Battery Strap	35	712-3006	Hex Nut, 1/4-20
12	738-1020	Shoulder Screw, .625 x.5, 7/16-20	36	738-1132	Shoulder Screw
13	736-0407	Bell Washer, .45 x 1.0 x.062	37	710-0607	Self-tapping Screw, 5/16 x 0.5
14	712-0459	Flange Lock Nut, 7/16-20	38	710-3144	Hex Cap Screw, 3/8-16 x 2.0
15	783-1031A	Hitch Plate	39	683-0294	Idler Bracket Assembly
16	783-0349	Battery Tray	40	732-0978	Extension Spring, .62 x 5.62
17	725-1426	Solenoid, 12-Volt, 100 Amp	41	738-0982	Shoulder Screw, .498 x 3.245
18	710-0599	Self Tapping Screw, 1/4-20 x.5	42	710-3025	Hex Cap Screw, 5/16-18 x.625
19	736-0222	Lock Washer, 1/4	43	783-1003	Electric Clutch Anti-rotation Bracket
20	683-0304C	Lower Frame Assembly	44	717-1709	Electric PTO Clutch
21	725-1706	12-volt Battery, 270 CCA	45	710-0859	Hex Cap Screw, 3/8-16 x 2.5
22	710-0703	Hex Cap Screw, 1/4-20 x.75	46	738-0785	Shoulder Spacer, 1.38 x.445 x.36
23	712-0271	Hex Sems Nut, 1/4-20	47	710-1049	Hex Cap Screw, 7/16-20 x 3.75 (Grade 5)
24	712-3044	Wing Nut, 1/4-20	48	756-0639A	Engine Pulley

IMPORTANT: For a proper working machine, use Factory Approved Parts. **V-belts** are designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.


NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665

Yard-Man Yellow: 0674

Powder Black: 0637

Model U804H (w/ Manual PTO)



† Refer to **B** on page 42.

Model U804H



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	647-0064	PTO Engagement Lever Assembly	35	738-1020	Shoulder Screw,.625 x.5, 7/16-20
2	747-1243	Belt Keeper Rod	36	736-0407	Bell Washer,.45 x 1.0 x.062
3	710-0276	Carriage Screw, 5/16-18 x 1.00	37	712-0459	Flange Lock Nut, 7/16-20
4	712-0431	Flange Lock Nut, 3/8-16	38	783-1031A	Hitch Plate
5	710-0831	Hex Cap Screw, 3/8-16 x 5.5	39	783-0349	Battery Tray
6	710-1238	Hex Head Washer Screw, 5/16-18 x.875	40	725-1426	Solenoid, 12-Volt, 100 Amp
7	712-0229	Push Nut, 3/8	41	710-0599	Self Tapping Screw, 1/4-20 x.5
8	754-0487	PTO Belt	42	736-0222	Lock Washer, 1/4
9	712-3004A	Flange Lock Nut, 5/16-18	43	683-0304C	Lower Frame Assembly
10	712-3010	Hex Nut, 5/16-18	44	725-1706	12-volt Battery, 270 CCA
11	714-0470	Cotter Pin, 1/8 x 1.25	45	710-0703	Hex Cap Screw, 1/4-20 x.75
12	726-0201	Speed Nut,.3125	46	712-0271	Hex Sems Nut, 1/4-20
13	731-2111A	PTO Knob	47	712-3044	Wing Nut, 1/4-20
14	683-0438	PTO Engagement Plate Assembly	48	732-1165	Extension Spring,.50 x 5.0
15	732-0991A	Belt Guard	49	710-3180	Hex Cap Screw, 5/16-18 x 1.75
16	736-0108	Flat Washer,.510 x.750 x.033	50	750-0596	Spacer Cup
17	736-0119	Lock Washer, 5/16	51	710-3029	Hex Head Cap Screw, 7/16-20 x 1.25
18	736-0140	Flat Washer,.385 x.62 x.063	52	736-0171	Lock Washer, 7/16
19	736-0275	Flat Washer, 5/16	53	736-0322	Flat Washer,.450 x 1.25
20	736-0300	Flat Washer,.406 x.875 x.059	54	756-0982B	Engine Pulley, 3.56 OD x 5.56
21	736-0331	Bell Washer,.39 x 1.13 x.062	55	732-0944	Extension Spring,.75 x 6.75
22	736-3010	Flat Washer,.407 x.812 x.135	56	783-0653F	Steering Support Bracket
23	738-0372A	Shoulder Spacer,.380	57	732-1013	Belt Guard
24	741-0708	Hex Split Flange Bearing,.5	58	750-0453	Spacer,.375 x 2.5
25	747-1112D	PTO Engagement Handle	59	710-0224	AB Screw, #10-16 x 0.5
26	747-1286	Belt Keeper Rod	60	17962	Switch Plate
27	748-0415B	Spacer, 3/8 x 1.54	61	725-04039	Switch
28	756-0627B	Idler Pulley, 3.5	62	710-0642	Self-tapping Screw, 1/4-20 x 0.75
29	710-0347	Hex Cap Screw, 3/8-16 x 1.75	63	710-0604A	Self-tapping Screw, 5/16-18 x.625
30	783-0744A	Engagement Stop	64	783-0693	Axle Bracket
31	783-0891B	Deck Stop	65	736-0222	Lock Washer
32	710-0604A	Self Tapping Screw, 5/16-18 x.625	66	736-0329	Lock Washer
33	732-04035	Compression Spring, 1.28 x 3.125	67	712-3006	Hex Nut, 1/4-20
34	723-0444	Battery Strap	68	738-1132	Shoulder Screw

IMPORTANT: For a proper working machine, use Factory Approved Parts. **V-belts** are designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665
Yard-Man Yellow: 0674
Powder Black: 0637

Model U804H



† Refer to **B** on page 40.

‡ Found on models equipped with a manual PTO only.

* A single pulley spindle (618-0240A or 618-0430A)

is found in this location on models with a manual PTO.

Model U804H

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	711-04069	Grass Catcher Pin	28	748-0324	Shoulder Spacer
2	17982	Spindle Reinforcement Plate	29	734-0973	Deck Wheel, 5 x 1.38
3	618-0430A	Spindle Assembly, 5.0 Dia.	31	736-0119	Lock Washer, 5/16
	756-1187	Pulley Only	32	736-0270	Bell Washer,.265 x .75 x .062
4	618-0595	Double Pulley Spindle Assembly	33	738-0347	Shoulder Spacer,.625 x 1.16
	756-1214	Double Pulley Only	34	738-0373	Shoulder Screw
5	683-0254	Deck Adjustment Bracket Assembly	35	742-0611	Three-in-one Blade, Star Center, 16.28"
6	683-0199C	46-inch Deck Shell	36	742-0612	Three-in-one Blade, Star Center, 14.88"
7	710-0167	Carriage Screw, 1/4-20 x .50	37	747-1116	Deck Release Pin
8	710-0344	Hex Cap Screw, 3/8-16 x 1.5	38	754-0349	Deck Belt, Poly
9	710-0501	Hex Cap Screw, 1/4-20 x 2.0	39	738-3056	Shoulder Screw, 1/2-2.5
10	710-0514	Hex Cap Screw, 3/8-16 x 1.0	40	756-0627B	Idler Pulley, 3.5
11	710-0528	Hex Cap Screw, 5/8-18 x 1.25	41	734-3058B	Deck Wheel, 5.0
12	710-0599	Self-tapping Screw, 1/4-20 x .5	42	783-0139A	Idler Bracket
13	710-0650	Self-tapping Screw, 15/16-18 x .875	43	783-0141	Center Deck Skirt
14	710-0703	Hex Screw, 1/4-20 x .75	44	783-0142	RH Deck Skirt
15	710-0751	Hex Cap Screw, 1/4-20 x .62	45	783-1347A	LH Belt Cover
16	710-1260A	Self-tapping Screw, 5/16-18 x .75	46	783-1450	RH Belt Cover
17	712-0271	Hex Sems Nut, 1/4-20	47	736-0416	Flat Washer,.320 x 3.0 x .125
18	712-0417A	Hex Flange Nut, 5/8-18	48	738-0572	Shoulder Screw,.374 x 1.16
19	712-0431	Flange Lock Nut, 3/8-16	49	712-3004A	Hex Nut, 5/16-18
20	712-3006	Hex Nut, 1/4-20	50	746-1107	Bracket Cable, 12"
21	712-3027	Hex Flange Lock Nut, 1/4-20	51	750-0807	Spacer,.385 x .625 x .70
22	714-0470	Cotter Pin, 1/8 x 1.25	52	710-0805	Hex Cap Screw, 5/16-18 x 1.5
23	717-1553B	Deck Adjustment Gear	53	17116	Deck Brake Assembly
24	726-0233	Push Nut.25 x .5	54	732-0934	Deck Lift Extension Spring, 1.15 x 5.99
25	731-1032B	Side Discharge Chute Assembly	55	753-0876	Deck Assembly Complete, Manual PTO (w/o Mulch Kit)
26	732-0306	Compression Spring,.406 x .531 x 1.75			
27	732-0594A	Extension Spring,.91 x 7.3	56	732-0429A	Extension Spring,.5 x 3.97

IMPORTANT: For a proper working machine, use Factory Approved Parts. **V-belts** are designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665
Yard-Man Yellow: 0674
Powder Black: 0637