


SECTION 10: PARTS LIST FOR MODEL 566



IMPORTANT: For a proper working machine, use Factory Approved Parts. **V-BELTS** are specially designed to engage and disengage safely. A substitute (non OEM) V-Belt can be dangerous by not disengaging completely.

Model 566

Ref. No	Part No.	Description	Ref. No	Part No.	Description
1.	747-2136	Lower Bail Handle	44.	710-1257	Hex Screw 3/8-24 x 2.50
2.	710-0599	TT Screw 1/4-20 x 0.5	45.	749-0907B	Lower Handle
3.	736-0270	Bell Washer .265 x 0.75	47.	712-0431	Flange Lock Nut
4.	782-7006	Hinged Mounting Bracket	48.	732-04090	Torsion Spring
5.	732-1014	Torsion Spring	49.	734-04018	Wheel 8 x 2.125
6.	712-3005	Lock Nut	50.	716-0865	Snap Ring
7.	647-04014	Control Lever	51.	717-1761	Gear 14T LH FWD
8.	749-1499	Upper Handle		717-1762	Gear 14T RH FWD *
9.	711-1513	Axle: Rear	52.	747-04080	Grass Bag Frame
10.	712-0324	Hex Lock Nut, 1/4-20	53.	736-0451	Saddle Washer
11.	746-0883	Throttle Housing	54.	712-3005	Hex Flange Lock Nut 3/8-16
12.	710-1270	Oval C-Sunk Screw 1/4-20 x 1.31	55.	710-0896	Hex Scr. w/Washer 1/4-14 x .625
13.	720-0279	Handle Knob	56.	687-02056	RH Handle Bracket
14.	720-0284	Handle Knob		687-02057	LH Handle Bracket
15.	710-1205	Eye Bolt	57.	715-0221	Dowel Pin
16.	746-0554	Control Cable: 40.5"	58.	710-0286	Pan Head Screw
17.	710-1174	Carriage Bolt 5/16-18 x 2.0	59.	687-02039	Pivot Bar
18.	687-02034	RH Bracket Assembly	60.	732-0866	Height Adj. Lever
	687-002032	LH Bracket Assembly	61.	720-0312	Foam Grip
19.	726-0240	Cable Tie (not shown)	62.	738-0507B	Shoulder Scr .500 Dia. x .434
20.	714-0104	Cotter Pin	63.	736-0105	Washer .401 x .870 x .063
21.	710-1008	Self-Tapping Sems Screw	64.	734-04019	Wheel, 14 x 2.125
22.	746-04026	Drive Cable	65.	736-0182	Spring Washer .50 I.D. x 1.0 O.D.
23.	664-04011	Grassbag Assembly	66.	736-0272	Flat Washer
24.	710-1650	Shoulder Screw # 12 -24	67.	738-0481A	Shoulder Screw
25.	631-0075B	Engine Spacer	68.	732-0700	Wire
26.	710-0606	Hex Bolt 1/4-20 x 1.5	69.	731-1236	Rear Trailing Shield
27.	712-0324	Lock Nut 1/4-20	70.	747-0996	Pivot Rod
28.	787-01107	21" Deck	71.	732-04090	Torsion Spring
29.	782-5003	RH Rear Baffle	72.	731-04134	Rear Discharge Door
30.	710-1017	Screw AB: 1/4-14: .625	75.	710-1650	Shoulder Screw
31.	782-5004A	LH Rear Baffle	76.	710-0286	Machine Screw
32.	710-0216	Hex Screw 3/8-16 x .75	77.	750-04162	Spacer .375 x .50 x 1.02" Lg.
33.	732-04089	Torsion Spring	78.	738-1002	Shoulder Screw 1/4-14
34.	712-0431	Hex Nut 3/8-16	79.	710-0703	Carriage Bolt 1/4-20
35.	731-2601	Transmission Cover (Black)	80.	712-0397	Wing Nut
36.	782-5002	Front Baffle	81.	710-0216	Hex Bolt 3/8-16 x 1.0"
37.	754-0637	V-Belt	82.	732-1043	Belt Tension Spring
38.	712-0324	Hex Nut 1/4-20	83.	750-1166	Slev. Spacer 2.1" Lg.
39.	750-1165	Sleeve Spacer 10.1" Lg.	84.	756-1231	Input Pulley
40.	748-04015	Blade Adapter w/ Pulley	85.	618-0657	Transmission Assembly
41.	742-0741	21" Mulching Blade	86.	715-0169	Roll Pin
42.	736-0524A	Blade Bell Support	88.	682-0512A	Height Adjustment Assembly RH
43.	710-0606	Hex Screw 1/4-20 x 1.50		682-0511A	Height Adjustment Assembly LH*

* Not shown in illustration

Table continued on next page

Model 566

Table continued from previous page

Ref. No	Part No.	Description
89.	782-7551	Wheel Dust Cap
90.	716-0102	Snap Ring
91.	736-0474	Washer
92.	720-0426	Adjustment Knob
93.	732-0706	Front Lever RH
	732-0707	Front Lever LH*
94.	687-02044	Pivot Plate Assembly
95.	782-0512B	Height Adj. Plate RH
	782-0511A	Height Adj. Plate LH*
96.	736-0447	Wave Washer
97.	748-0355	Bearing Support
98.	741-0604A	Bearing Sleeve
99.	732-0708	Bearing Retainer
100.	747-0710	Hinge Pin
101.	687-02055	Mulch Plug Comp.
102.	731-04177	Chute Deflector

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted powder black, the part number to order would be 700-xxxx-0637.

Red: 0638

Powder Black: 0637

* Not shown in illustration