


SECTION 11: PART LIST FOR MODEL 469



IMPORTANT: For a proper working machine, use Factory Approved Parts. **V-BELTS** are specially designed to engage and disengage safely. A substitute (non OEM) V-Belt can be dangerous by not disengaging completely.

Model 469

Ref. No.	Part No.	Part Description	Ref. No.	Part No.	Part Description
1.	747-2136	Lower Bail Handle	53.	731-2600	Front Drive Cover: Yellow
2.	647-0070	Blade Control Handle	54.	715-04011	Roll Pin
3.	749-1500	Upper Handle	55.	682-0015	Bearing Assembly
4.	712-0324	Hex Lock Nut 1/4-20	56.	736-0447	Wave Washer
5.	746-1141	Control Cable	57.	782-0511A	Height Adj. Plate LH
6.	749-0928A	Lower Handle		782-0512B	Height Adj. Plate RH
7.	746-04026	Drive Cable	58.	687-02044	Pivot Plate Assembly
8.	710-0606	Hex Screw 1/4-20 x 1.5"	59.	748-04015	21" One Piece Blade Adapter
9.	710-1174	Carriage Bolt	60.	742-0741	Mulching Blade w/ Star: 21"
10.	720-0284	Handle Knob	61.	710-0216	Hex Screw
11.	736-0451	Saddle Washer	62.	715-0221	Dowel Pin
12.	720-0279	Wing Nut	63.	717-1762	Gear 14T RH
13.	710-1205	Rope Guide		717-1761	Gear 14T LH
14.	747-04080	Grass Catcher Frame	64.	716-0865	Snap Ring
15.	631-0075B	Engine Spacer Assembly	65.	782-7551	Wheel Dust Cap
23.	714-0104	Hairpin Clip	66.	716-0102	Snap Ring
24.	731-1236	Rear Trail Shield	67.	736-0474	Washer DD 1.5" O.D.
25.	732-0700	Wire: Trail Shield	68.	756-04017	Input Pulley
26.	732-04071	Torsion Spring LH	69.	710-1257	Hex Bolt
27.	782-5003	Rear Baffle LH	70.	664-04012	Grass Bag
28.	710-1017	Scr. AB 1/4-14 x 0.625"	71.	782-5004A	Rear Baffle RH
29.	732-04072	Torsion Spring RH	82.	750-1166	Slev. Spacer LH
30.	710-0896	Hex Scr. w/ Wash. 1/4-14 x 0.62"		750-1346	Slev. Spacer RH
31.	720-0426	Knob	83.	687-02036	Height Adj. Assembly RH Compl.
32.	736-0105	Bell Washer.375 x.870	84.	687-02037	Height Adj. Assembly LH Compl.
33.	734-2004A	Wheel: Rear w/Ball Brg.	85.	731-04134	RD Chute Door
	734-2005A	Wheel: Rear	86.	732-0731	Torsion Spring
34.	738-0102	Shoulder Screw	87.	726-0240	Cable Tie
35.	731-1426	Hubcap	88.	710-1008	TT Screw
36.	787-01015	Handle Bracket Assembly LH	89.	682-0512A	Height Adj. Assembly RH Compl.
	787-01016	Handle Bracket Assembly RH	90.	682-0511A	Height Adj. Assembly LH Compl.
37.	14766	Pivot Bar LH	91.	734-2042	Wheel: Front
	14765	Pivot Bar RH	92.	732-0417A	Spring Lever
38.	687-02018	Front Lever RH	93.	712-0397	Wing Nut
	687-02017	Front Lever LH	94.	710-0703	Hex Carriage Screw 1/4-20
39.	738-0507B	Shoulder Screw	95.	750-04162	Spacer.390OD x.810ID x.950"
40.	747-0710	Hinge Pin	96.	747-04035	Rear Door Pivot Rod
41.	17032A	Chute Deflector Bracket	97.	736-0524A	Blade Bell Support
42.	712-0431	Hex Nut	98.	736-0504†	Wave Washer
43.	732-1043	Belt Tension Spring	99.	731-2532	Control Lever LH
44.	787-01006	3-in-1 Deck: 21"	100.	731-2533	Control Cover RH
45.	754-0637	V-Belt	101.	720-0428	Button
46.	687-02055	Mulch Plug Assembly	102.	732-1171	Compression Spring
47.	731-04177	Discharge Deflector SD	103.	782-0156	Lever
48.	710-0599	TT Screw 1/4-20 x 0.5"	104.	710-1256	Hi-Low Screw
49.	736-0270	Bell Washer 0.265" x 0.75"	105.	715-0168	Pin
50.	782-5002A	Front Baffle	106.	716-0209	Retention Ring
51.	618-0657	Transmission Assembly Compl.	107.	710-0501	Hex Hd. Cap Screw
52.	710-1650	Shoulder Screw	108.	732-1172	Torsion Spring

†Equipped w/ Rear Wheel 734-2004A