



SECTION 6: PARTS LIST ZT42 AND ZT50

REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	603-04303B	Frame Assembly	1
	777I22489	Graphic, Release Lever	2
	777D03399	Graphic, White Outdoor	1
2	703-05829	Idler Arm, Drive	1
3	710-0520	Screw, Hex Cap, 3/8-16 x 1.5 GR5	3
4	710-3005	Screw, Hex Cap, 3/8-16 x 1.25 GR5	1
5	712-04065	Nut, Hx Insert Flange Lck, 3/-16 GrF	4
6	732-0626	Spring, Extension, .75 x 5.06	1
7	738-04058	Spacer, Shoulder, .39 x 1.0 x .7	2
8	738-04162A	Screw, Shoulder, .884 x .19	1
9	756-04129	Pulley, Idler, 4.25 Dia.	1




REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	603-04148A	Axle, Front Pivot	1
2	603-04308	Bracket, Castor Wheel	2
3	634-04237	Wheel Assembly,	2
		11.0 x 4.0 x 5.0	
4	710-04186	Screw, Hex Lock,	2
		1/2-13 x 1.25 GR5	
5	710-0514	Screw, Hex Cap,	2
		3/8-16 x 1.0 GR5	
6	711-04228	Shaft, Axle	1
7	712-3022	Nut, Hex Lock,	2
		1/2-13 GRB	
8	731-05500	Bearing, Flange,	6
		1.0 x 1.246	
9	736-0169	Washer, Lock, 3/8	2
10	736-0227	Washer, Flat,	2
		.39 x 1.5 x .134	
11	736-0250	Washer, Flat,	2
		1.0 x 1.75 x .107	
12	737-3000	Fitting, Lube, 3/16 Drive	3
13	738-04182	Screw, Shoulder,	2
		.75 x 4.75:7/16-14	
14	741-0516B	Bearing, Flange,	2
		.76 x 1.0 x 1.2	
15	741-0990B	Bearing, Flange,	2
		.76 ID w/Lube Ftg.	



NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part.
For instance, if a part, numbered 700-xxxx, is painted red metallic, the part number to order would be 700-xxxx-0650.


Red : 0650
Oyster Grey: 0662
Powder Black: 0637

MODELS ZT42 AND ZT50



REF. NO.	PART NUMBER	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	710-1268	Screw, Hx. Wash. Hd. Tapp #10-16 x .375	2	9	736-0275	Washer, Flat, .344 x .688 x .065	3
2	712-04063	Nut, Hx Insert Flange Lck, 5/16-18 GrF	2	10	736-3019	Washer, Flat, .531 x 1.062 x .134 HT	2
3	712-04064	Nut, Hx Insert Flange Lck, 1/4-20 GrF	1	11	738-0137A	Screw, Shoulder, .34 x .285:1/4-20	1
4	720-0309A	Grip, Seat Adjustment	1	12	738-0296	Screw, Shoulder, .437 x .268:5/16-18	2
5	726-0201	Nut, Speed, .3125	2	13	738-0966A	Screw, Shoulder, .5 x .925:3/8-16 ...	4
6	731-04074	Spacer, Seat Adjustment	4	14	783-0209D	Bracket, Seat Lift	1
7	732-0499	Spring, Compression, .41 x 1.5	1	15	783-0611	Stop, Seat Adjustment	1
8	732-1184	Spring, Extension, .84 Dia. x 4.6	1	16	783-0738C	Bracket, Seat Pivot	1
				17	783-0739A	Lever, Seat Adjustment	1
				18	783-0753	Index Bracket, Seat Adjustment	1

MODELS ZT42 AND ZT50




MODELS ZT42 AND ZT50

REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	710-0227	Screw, Hex Wash. Hd. Tapp #8-18 x .5	2
2	710-0599	Screw, Hex Wash. Hd. Tapp, 1/4-20 x .5	2
3	710-3015	Screw, Hex Cap, 1/4-20 x .75 GR5 ..	2
4	712-0271	Nut, Hex Sems, 1/4-20	4
5	725-04022A	Meter, Hour	1
6	725-04165	Switch, Dbl. Pole - Neutral	2
7	725-04174	Switch, PTO	1
8	725-04228	Switch, Ignition	1
9	725-04232	Switch, 3-Pole, (NC-NO-NO) - Brake	1
10	725-1303	Switch, Outer Seat Spring	1
11	725-1426A	Solenoid	1
12	725-1439	Switch, Inner Seat Spring	1
13	925-1745	Key	1
14	725-1707D	Battery, 235 CCA	1
15	725-3166	Switch, Snap Mount (N.C.) - Reverse	2
16	726-0278	Plate, Insulator Boss	1
17	726-0279	Plate, Insulator	2
18	726-0470	Tie, Cable	2
19	747-04425	Rod, Battery Holddown	1
†	725-04297	Harness Assembly, Wire	1
†	725-04188	Cable Wire, Black - to Ground	1

† NOT SHOWN


MODELS ZT42 AND ZT50



MODELS ZT42 AND ZT50

REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	603-04326	Frame, Seat Box	1
	777I22610	Graphic, Park Brake	1
	777S32354	Graphic, Warning	1
	777I22307	Graphic, Deck Height	1
2	703-05373A	Bracket, Foot Rest	1
	777D08312	Graphic, Troy-Bilt	1
3	703-05467	Bracket, Switch Mounting	2
4	710-04261	Screw, Hex Wash. Hd Tapp	4
		#12-16 x .50	
5	710-0599	Screw, Hex Wash. Hd. Tapp.	4
		1/4-20 x .5	
6	710-0604A	Screw, Hex Wash. Hd. Tapp	20
		5/16-18 x .625	
7	710-0726	Screw, Hex Wash. Hd. Tapp	6
		5/16-12 x .75	
8	710-0778	Screw, Hex Wash. Hd. Tapp.	2
		1/4-20 x 1.5	
9	710-1268	Screw, Hex Wash. Hd Tapp	2
		#10-16 x .375	
10	712-0298	Nut, Hex Jam, 1/4-20 GR2	2
11	712-04092	Nut, U Type Speed, 1/4-20	2
12	712-0431	Nut, Hex Flange Lock, 3/8-16 GRF	2
13	723-04020	Pad, Abrasive Foot Plate	1
14	723-04021	Pad, Abrasive Toe Plate	1
15	731-04662B	Console, LH	1
	777I22611	Graphic, Instruction - ZT 42	1
	777I22608	Graphic, Instruction - ZT 50	1
	777D08311	Graphic, White Outdoor	1
	777I22305	Graphic, Throttle Control 42"	1
	777I22309	Graphic, Throttle Control 50"	1
16	731-04663A	Console, RH	1
	777I22609	Graphic, Instruction	1
	777D08310	Graphic, White Outdoor	1
17	732-04035	Spring, Compression, 1.28 x 3.125	2
18	732-04200	Spring, Switch Actuator	2
19	736-0300	Washer, Flat, .406 x .875 x .059	2
20	738-0430	Screw, Shoulder, .50 x .685:3/8-16 ...	2
21	757-04041	Seat	1
22	783-1489B	Bracket, Seat Pivot	2


MODELS ZT42 AND ZT50



MODELS ZT42 AND ZT50

REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	603-04160A	Shaft Assembly, Deck Lift	1
2	603-04322	Lever, Lapbar, RH	1
3	603-04324	Lever, Lapbar, LH	1
4	703-05387A	Bracket, Lapbar Pivot	2
5	703-05396	Handle, Brake	1
6	703-05414A	Bracket, Front Deck Hanger	1
7	703-05793	Arm, Deck Lift	2
8	710-0433	Screw, Hex Lock, 1/4-20 x .62 GR5	2
9	710-0805	Screw, Hex Cap, 5/16-18 x 1.5 GR5 ...	2
10	710-3005	Screw, Hex Cap, 3/8-16 x 1.25 GR5 ...	1
11	710-3105	Bolt, Carriage, 5/16-18 x .875	2
12	710-3144	Screw, Hex Cap, 3/8-16 x 2.0 GR5	2
13	710-3180	Screw, Hex Cap, 5/16-18 x 1.75 GR5	2
14	711-0832	Ferrule, 3/8-24 x .375	2
15	712-0206	Nut, Hex Jam, 1/2-13 GR5	4
16	712-04063	Nut, Hx Flange Insert Lck, 5/16-18 GrF	6
17	712-04065	Nut, Hx Flange Insert Lck, 3/8-16GrF	2
18	712-0431	Nut, Hex Flange Lock, 3/8-16 GRF	5
19	712-3007	Nut, Hex Jam, 5/16-18 GR5	2
20	712-3008	Nut, Hex Jam, 3/8-16 GR5	2
21	714-0104	Pin, Internal Cotter	6
22	714-3020	Pin, Internal Cotter	1
23	716-0106	E-Ring , .625 Dia. Shaft	4
24	720-0274	Grip, Hand	2
25	720-0311	Grip, Handle	1
26	720-04072	Knob, Nut, 5/16-18 Nylon Lock	2
27	731-04735	Grip, Handle	1
28	732-0334	Spring, Compression	1
29	732-0874	Spring, Torsion	1
30	732-04350	Spring, Compression	2
31	736-0270	Washer, Bell, .265 x .75 x .062	2
32	736-0425	Washer, Bell, .325 x .93 x .045	2
33	736-3019	Washer, Flat, .531 x 1.062 x .134 HT ..	2
34	738-0143	Screw, Shoulder, .498 x .340:3/8-16	4
35	738-0296	Screw, Shoulder, .437 x .268:5/16-18	2
36	741-0225	Bearing, Hex Flange	6
37	741-3074	Bearing, Flange, .626 x .938 x .344	2
38	746-0970	Cable, Deck Lift, 5.05 Long	2
39	747-04224	Rod, Deck Lift Handle	1
40	747-04225A	Rod, Lapbar Control	2
41	747-04226	Shaft, Control	2
42	747-04401A	Rod, Deck Front Hanger	1
43	747-04491	Rod, Brake	2
44	748-04052	Hub, Control	2


MODEL ZT42



MODEL ZT42

REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	603-04156	Bracket, Deck Lift	1
2	603-04335	Housing, Deck	1
	777S32599	Graphic, Danger	1
	777S30503	Graphic, Danger	1
	777I22281	Graphic, Instruction	1
3	618-0427	Spindle Assembly	1
	756-1188	Pulley	1
4	703-05824	Arm, Idler	1
5	710-0347	Screw, Hex Cap, 3/8-16 x 1.75 GR5	2
6	710-0528	Screw, Hex Cap, 5/16-18 x 1.25 GR5	1
7	710-0599	Screw, Hex Wash. Hd. Tapp	5
		1/4-20 x .5	
8	710-0650	Screw, Hex Wash. Hd. Tapp	8
		5/16-18 x .875	
9	710-0726	Screw, Hex Wash. Hd. Tapp	4
		5/16-12 x .75	
10	710-0751	Screw, Hex Cap, 1/4-20 x .62 GR5 ..	2
11	710-3005	Screw, Hex Cap, 3/8-16 x 1.25 GR5	1
12	710-3180	Screw, Hex Cap, 5/16-18 x 1.75 GR5	1
13	711-04069	Pin, Grass Catcher, 1/4-20	1
14	712-0324	Nut, Hex Insert Lock, 1/4-20 GR8	1
15	712-04064	Nut, Hx Insert Flange Lck, 1/4-20 GR5	2
16	712-04065	Nut, Hx Insert Flange Lck, 3/8-16 GrF	3
17	712-0417A	Nut, Hex Flange, 5/8-18	2
18	712-0429	Nut, Hex Insert Lock, 5/16-18 GR5 ..	1
19	712-0431	Nut, Hex Flange Lock, 3/8-16 GrF	2
20	712-0641	Nut, Hex, M16-1.5	1
21	712-3010	Nut, Hex, 5/16-18 GR5	1
22	714-0470	Pin, Cotter, 1/8 x 1.25	2
23	717-1553B	Gear, Deck Adjustment	1
24	721-04041	Adapter, Water Nozzle	1
25	726-0233	Nut, Push, .25 x .5	2
26	731-1032B	Chute Assembly, Discharge	1
	777S30284	Graphic, Danger	1
27	731-2231B	Cover, Belt	2
28	732-0306	Spring, Compression	2
29	732-0459	Spring, Extension, .94 Dia. x 6.74	1
30	734-04155	Wheel, Deck Ball, 5.0	2
31	736-0119	Washer, Lock, 5/16	1
32	736-0760	Washer, Lock,	1
33	736-3072	Washer, Flat, .38 x .93 x .11 HT	2
34	737-04003C	Nozzle, Deck Water	1
35	738-04162A	Spacer, Shoulder, .884 x .19	1
36	738-3056	Screw, Shoulder, .5 x 2.5:3/8-16	2
37	942-0616A	Blade, 3 in 1, 21.23	2
38	747-1116	Rod, Deck Hanger	2
39	754-04045	Belt, V, Type A Sec x 109	1
40	756-04129	Pulley, Idler, 4.25 Dia.	2
41	783-1146A	Skirt, Deck	1


MODEL ZT50



MODEL ZT50

REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	603-04328	Housing, Deck	1
	777S32598	Graphic, Danger	1
	777S30503	Graphic, Danger	1
	777I22282	Graphic, Instruction	1
2	618-04126	Spindle Assembly	3
	756-1171	Pulley, 5.39 Dia	3
	737-3000	Fitting, Lube, 3/16 Drive	3
3	631-04070	Chute Assembly, Discharge	1
	777S30284	Graphic, Danger	1
4	683-0254	Bracket, Deck Hanger	1
5	703-05825	Arm, Idler	1
6	703-3279	Bracket, Stop	1
7	703-3511	Guard, Finger	1
8	710-0347	Screw, Hex Cap, 3/8-16 x 1.75 GR5 ...	3
9	710-0528	Screw, Hex Cap, 5/16-18 x 1.25 GR5 .	1
10	710-0599	Screw, Hex Wash. Hd. Tapp	7
		1/4-20 x .5	
11	710-0726	Screw, Hex Wash. Hd. Tapp	6
		5/16-12 x .75	
12	710-1260A	Screw, Hex Wash. Hd. Tapp	12
		5/16-18 x .75	
13	710-3005	Screw, Hex Cap, 3/8-16 x 1.25 GR5	1
14	710-3168	Screw, Carriage, 3/8-16 x 1.0	1
15	710-3178	Screw, Carriage, 3/8-16 x .75	4
16	712-04065	Nut, Hx Insert Flange Lck, 3/6-16 GrF	9
17	712-0417A	Nut, Hex Flange, 5/8-18	3
18	712-0431	Nut, Hex Flange Lock, 3/8-16 GRF	4
19	712-0641	Nut, Hex, M16-1.5	2
20	714-0470	Pin, Cotter, 1/8 x 1.25	2
21	717-1553B	Gear, Deck Adjustment	1
22	721-04041	Adapter, Water Nozzle	1
23	732-0306A	Spring, Compression	2
24	732-0459	Spring, Extension, .94 Dia. x 6.74	1
25	734-04155	Wheel, Deck Ball, 5.0	4
26	736-0119	Washer, Lock, 5/16	1
27	736-0407	Washer, Bell, .45 x 1.0 x .062	1
28	736-0760	Washer, Lock	2
29	736-3072	Washer, Flat, .38 x .93 x .110 HT	3
30	737-04003C	Nozzle, Deck Water	2
31	738-04162A	Spacer, Shoulder, .884 x .190	1
32	738-3056	Screw, Shoulder, .5 x 2.5:3/8-16	4
33	742-04053A	Blade, 2 in 1, 17.9 Lg	3
34	747-1116	Rod, Deck Hanger	2
35	754-04044	Belt V, Type A Sec x 134	1
36	756-04129	Pulley, Idler, 4.25 Dia	3
37	783-04399	Cover, Belt LH	1
38	783-04400	Cover, Belt RH	1
39	783-04414	Skirt, Center	1
40	783-04415	Skirt, RH	1
41	731-3131A	Chute, Deflector	1
42	783-04470	Bracket, Chute Mounting	1
43	732-3070	Spring, Torsion	1
44	711-1762	Pin, Hinge	1


MODEL ZT42



MODEL ZT42

REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	703-05383A	Tube, Exhaust	1
2	703-05441A	Bracket, Muffler Mounting	1
3	703-05870	Shield, Muffler Tube Heat	1
4	710-0227	Screw, Hex Wash. Hd. Tapp	3
		#8-18 x .5	
5	710-04248	Screw, Hex Cap, 7/16-20 x 4.0 GR5	1
6	710-04261	Screw, Hex Wash. Hd. Tapp	2
		#12-16 x .5	
7	710-0599	Screw, Hex Wash. Hd. Tapp	4
		1/4-20 x .5	
8	710-0726	Screw, Hex Wash. Hd. Tapp	2
		5/16-12 x .75	
9	710-1007	Screw, Hex Sems Wash. Hd. Tapp ..	4
		3/8-16 x 1.5	
10	710-1314A	Screw, Socket Hd. 5/16-18 x .75	2
11	710-3008	Screw, Hex Cap, 5/16-18 x .75 GR5	4
12	710-3217	Screw, Truss Hd. Mach. #8-32 x .375	1
13	712-0142	Nut, Hex, #8-32	1
14	712-0271	Nut, Sems, 1/4-20	1
15	712-04063	Nut, Hx Insert Flange Lck, 5/16-18 GrF	4
16	717-04183	Clutch Assembly, Electric PTO	1
17	721-0348	Gasket, Exhaust (Tec	1
18	726-0197	Tie, Cable	1
19	726-0205	Clamp, Hose	2
20	726-3055	Clip, Cable Retainer	1
21	731-04914	Knob, Throttle Control	1
22	736-0171	Washer, Lock, 7/16	1
23	736-04131	Washer, Flat, .438 x 1.75 x .25	1
24	736-3008	Washer, Flat, .344 x .75 x .12	1
25	746-04161	Cable, Throttle, 39.0 Lg	1
26	747-04228A	Wire, Tank Mounting	1
27	750-04602	Spacer, PTO, 1.0 x 1.62 x .21	1
28	751-0564B	Deflector, Muffler	1
29	751-0617B	Muffler	1
30	751-10057C	Tank, Fuel, 3.0 Gal.	1
31	751-10286	Pipe, Exhaust	1
32	751-10349	Hose, Fuel Line	14in
33	751-3124C	Cap, Fuel	1
34	751-3140	Valve, Oil Drain	1
35	751-3141	Hose, Oil Drain Extension	1
36	751-3142	Cap, Oil Drain Valve	1
37	756-0978A	Pulley, Drive	1


MODEL ZT50



MODEL ZT50

REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	703-05441A	Bracket, Muffler Mounting	1
2	710-0227	Screw, Hex Wash. Hd. Tapp #8-18 x .5	3
3	710-04248	Screw, Hex Cap, 7/16-20 x 4.0 GR5	1
4	710-04261	Screw, Hex Wash. Hd. Tapp #12-16 x .5	2
5	710-0599	Screw, Hex Wash. Hd. Tapp 1/4-20 x .5	4
6	710-0726	Screw, Hex Wash. Hd. Tapp 5/16-12 x .75	2
7	710-1314A	Screw, Socket Hd. 5/16-18 x .75	4
8	710-1315	Screw, Hex Wash. Hd. Tapp 3/8-16 x 1.25	4
9	710-3008	Screw, Hex Cap, 5/16-18 x .75 GR5	2
10	710-3217	Screw, Truss Hd. Mach. #8-32 x .375	1
11	712-0142	Nut, Hex, #8-32	1
12	712-0271	Nut, Hex Sems, 1/4-20	1
13	712-04063	Nut, Hex Insert Lock, 5/16-18 GR5 ...	2
14	712-3005	Nut, Hex Flange Lock, 3/8-16 GR5 ...	1
15	717-04183	Clutch Assembly, Electric PTO	1
16	721-0460	Gasket, Exhaust	2
17	726-0197	Tie, Cable	1
18	726-0205	Clamp, Hose	2
19	726-3055	Clip, Cable Retainer	1
20	731-04914	Knob, Throttle Control	1
21	736-0171	Washer, Lock, 7/16	1
22	736-0300	Washer, Flat, .406 x .875 x .059	1
23	736-04131	Washer, Flat, .438 x 1.75 x .25	1
24	746-04235	Cable, Choke, 47 Lg	1
25	746-1086	Cable, Throttle, 39.0 Lg	1
26	747-04228A	Wire, Tank Mounting	1
27	751-0564B	Deflector, Muffler	1
28	751-0616B	Muffler	1
29	751-10057C	Tank, Fuel, 3.0 Gal.	1
30	751-10284	Pipe, Exhaust RH	1
31	751-10285	Pipe, Exhaust LH	1
32	751-10349	Hose, Fuel Line	14in
33	751-3124C	Cap, Fuel	1
34	751-3140	Valve, Oil Drain	1
35	751-3141	Hose, Oil Drain Extension	1
36	751-3142	Cap, Oil Drain Valve	1
37	756-0978A	Pulley, Drive	1

MODELS ZT42 AND ZT50



REF. NO.	PART NUMBER	DESCRIPTION	QTY.	REF. NO.	PART NUMBER	DESCRIPTION	QTY.
1	618-04326	Transmission Assembly, RH	1	8	712-04088	Nut, Hex Lock, 9/16-18 GRC	2
2	618-04327	Transmission Assembly, LH	1	9	712-0459	Nut, Hex Flange Lock, 7/16-20 GrB	2
3	634-04127	ZT42 Wheel Assembly, 18 x 6.5 x 8.	2	10	712-3050	Nut, Lug, 7/16-14	8
	734-0294	ZT42 Tire, 18 x 6.5 x 8	2	11	714-0507	Pin, Cotter, 3/32 x .75	2
	734-0255	Valve Assembly	2	12	726-04059	Clamp, Hose	2
	634-04171	ZT50 Wheel Assembly, 18 x 9.5 x 8	2	13	738-04192	Rod, .405 x 14.0	2
	734-1729	ZT50 Tire, 18 x 9.5 x 8	2	14	747-04217B	Rod, Bypass	2
	734-0255	Valve Assembly	2	15	748-04054	Hub, Wheel 42	2
4	710-0176	Screw, Hex Cap, 5/16-18 x 2.75 GR5	4		748-04055	Hub, Wheel 50	2
5	710-0395	Screw, Hex Cap, 5/16-18 x 2.25 GR5	2		750-04561	Tube, .45 x .69 x 10.2	2
6	710-0852	Stud, Rib Neck, 7/16-14 x 1.6	8	17	754-04043	V-Belt, Type A Sec x 57.7	1
7	711-04063	Nut, Hx Insert Flange Lck, 5/16-18 ..	6				