


SECTION 11: PARTS LIST FOR MODEL 995




IMPORTANT: For a proper working machine, use Factory Approved Parts. **V-BELTS** are specially designed to engage and disengage safely. A substitute (non OEM) V-Belt can be dangerous by not disengaging completely.

Model 995

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	647-04046	Control Handle	54.	748-0318	Wheel Ratchet
2.	731-0904A	Upper Control Handle	55.	736-0270	Bell Washer.265 ID x.75 OD
3.	16864	6 Sped. Rack Cable Bracket	56.	710-0751	Hex Cap Screw 1/4-20 x.620
4.	731-0620	Control Lever	57.	737-3000	Grease Fitting
5.	713-0397	Gear Insert	58.	736-0931	Flat Washer.203 ID x.403 OD
6.	732-0627	Shift Lever Spring	59.	747-0924	Wheel Pin Lock
7.	731-0924	6 Speed Shift Lever	60.	682-9020A	Caster Assembly RH
8.	731-0905A	Lower Control Housing		682-9021A	Caster Assembly LH
9.	710-1667A	C Sunk Tap Screw #10 x.75 Leg	61.	682-9024	Caster Bracket Assembly RH
10.	731-0906	Cable Mounting Cap		682-9026	Caster Bracket Assembly LH
11.	746-0711B	Drive Cable 51"	62.	710-1348	Screw 1/4-14 x.500
12.	712-0324	Top Lock Nut 1/4-20	63.	710-1652	Screw 1/4-14 x.625
13.	746-0883	Control Housing	64.	710-0654A	Hex Washer Screw 3/8-16 x 1.0
14.	710-1270	Oval C-Sunk Screw	65.	711-1146	Caster Axle
15.	746-0555	Control Cable 55"	66.	726-0233	Push Nut
16.	749-0439D	Upper Handle	67.	710-0703	Carriage Screw 1/4-20 x.75
17.	720-0284	Wing Nut	68.	682-3052	Handle Bracket Assembly - RH
18.	736-0451	Saddle Washer.320 ID x.830 OD		682-3053	Handle Bracket Assembly - LH
19.	710-1174	Carriage Bolt 5/16-18 x 2.0	69.	736-0232	Wave Washer.531 ID x.781 OD
20.	726-0240	Cable Tie	70.	712-0397	Wing Nut
21.	749-0907B	Lower Handle	71.	710-0260A	Carriage Bolt 5/16-18 x.62
27.	731-1901A	Trail Shield	72.	754-0460	Belt 3/8 x 39.24
28.	732-0842	Trail Shield Wire	73.	656-0613	Pulley Assembly
29.	631-0066	Chute Assembly	74.	750-1071	Sleeve Spacer.88 ID x 1.13 OD
30.	731-1832	Side-Discharge Chute	75.	750-1070	Sleeve Spacer.88 ID x 1.00 OD
31.	731-1833A	Mulch Cover	76.	782-7597	Pivot Bracket
32.	782-0078B	Deck 21"	77.	710-0654A	Screw 3/8-18 x 1.0
33.	712-0397	Wing Nut	78.	782-7596	Control Arm
34.	710-0703	Carriage Bolt 1/4-20 x.75	79.	732-0807	Torsion Spring
35.	746-0939A	6 Speed Cable	80.	711-1114	Pivot Shaft
36.	782-7574A	Cable Adjustment Bracket	81.	736-0526	Wave Washer 1.38 ID x.88 OD
37.	736-0270	Bell Washer.265 ID x.75 OD	82.	731-1828	Baffle
38.	712-3006	Hex Nut 1/4-20	83.	710-0653	Screw 1/4-20 x 3.75
39.	710-0167	Carriage Screw 1/4-20 x.50	84.	748-0377C	Blade Adapter Kit
40.	712-0138	Hex Nut 1/4-28	85.	742-0741	21" Mulching Blade
41.	782-7575A	Cable Mounting Bracket	86.	736-0524B	Blade Bell Support
42.	736-0329	Lock Washer 1/4	87.	710-1257	Hex Bolt 3/8-24 x 2.5
43.	756-0625	Roller Cable	88.	731-1874	Chute Door
44.	738-0924	Shoulder Screw.375 ID x 1/4-14	89.	732-0819	Torsion Spring
45.	736-0264	Flat Washer.330 ID x.630 OD	90.	726-0111	Push Cap
46.	714-0104	Cotter Pin	91.	747-0965	Pivot Rod
47.	732-0306	Compression Spring	92.	731-1713B	Discharge Chute
48.	734-2044	Wheel 9 x 2	94.	726-0214	Push Cap
49.	712-0414	Top Lock Tab Weld Nut 1/4-20	95.	736-0366	Flat Washer.640 ID x 1.12 OD
50.	16855	Ratchet Pawl Plate	96.	741-0685	Flange Bearing
51.	10622B	Plastic Spring Ratchet	97.	712-04063	Flange Lock Nut 5/16-18
52.	748-0381	Pawl RH	98.	734-1857	Wheel 7 x 2
	748-0188B	Pawl LH	99.	731-1887	Hubcap - Spoke w/ Hole
53.	738-0137A	Shoulder Screw.340 ID x.285 OD	100.	731-0981A	Hubcap - Radial Spoke

Model 995



Model 995

Ref. No.	Part No.	Part Description	Ref. No.	Part No.	Part Description
1.	720-0223	Grip	32.	736-3084	Flat Washer.510 ID x 1.120 OD
2.	732-0803A	Spring Lever	33.	712-0896	Hex Jam Nut 1/4-28
3.	738-0529	Shoulder Nut.825 x.165 Lg.	34.	782-7598	Belt Keeper
4.	710-0751	Cap Screw 1/4-20 x.620	35.	741-0124	Bearing
5.	736-0270	Bell Washer.285 ID x.75 OD	36.	732-0849A	Extension Spring
6.	748-0318	Wheel Ratchet	37.	750-1050	Flange Spacer
7.	736-0369	Flat Washer.508 ID x 1.0 OD	38.	682-0027A	Idler Bracket Assembly
8.	782-0566B	Pivot Arm Assembly	39.	710-0299	Hex Cap Screw 1/4-28 x 1.0
9.	750-0515	Spacer.510 ID x.70 OD	40.	741-0682A	Bearing Sleeve
10.	741-0978	Sleeve Bearing.504 ID x.830 OD	41.	736-0570	Flat Washer.885 ID x 1.45 OD
11.	750-1056	Shoulder Spacer	42.	721-0329	Oil Seal
12.	710-0653	Tap Screw 1/4-20 x.375	44.	618-0253	Upper Housing Assembly
13.	682-7528	Chain Cover Assembly	45.	782-7601A	Cable Bracket
14.	741-0324A	Flange Bearing.506 ID x.590 Lg	46.	741-0690	Bearing
15.	682-7526	Transmission Axle Assembly	47.	736-0616	Thrust Washer.504 ID x.70 OD
16.	618-0263A	Transmission Assembly	48.	782-7595	Pivot Bracket
17.	710-0604A	Hex Screw 5/16-18	49.	741-0324a	Flange Bearing
18.	713-0453	Chain	50.	711-1168	Output Shaft 6T
19.	638-0012	Rear Axle Assembly	51.	717-1469	Gear 34T
20.	741-0522	Flange Bearing.506 ID x.715 Lg	52.	741-0674	Bearing
21.	732-0832	Torsion Spring	53.	717-1487	Pinion Shaft 10T
22.	750-0151	Spacer.550 ID x.750 OD	54.	736-0314	Thrust Washer 3/8 x.70
23.	710-1315	Screw 3/8-16 x.25	55.	736-0569	Thrust Washer.388 x.625
24.	711-0835	Clevis Pin.50 Dia x 4.82 Lg.	56.	618-0252	Lower Housing Assembly
25.	750-0807	Spacer.385 ID x.624 OD	57.	710-0642	Hex Screw 1/2-20 x.75
26.	782-0568	Spring Bracket: Height Adjustment	58.	611-0066	Shaft Assembly (Incl. Ref. # 48-52)
27.	710-1652	Screw 1/4-14 x.825	59.	664-04036	Grassbag
28.	714-0474	Cotter Pin	60.	747-0940A	Support Rod w/ Rope Guide
29.	712-3025	Hex Jam Nut 5/16-24	61.	747-0939	Pivot Rod
30.	736-0425	Bell Washer.325 ID x.930 OD	62.	747-0937	Grassbag Frame
31.	756-0656	Pulley	63.	631-0071	Grassbag Cover

Safety & Decorative Labels

Some of the labels found on your mower are represented here with the corresponding part numbers. Please use these part numbers when ordering replacement labels.

777S30118



777I20291



777S30128



777S30116



777S30145

