


Illustrated Parts List



Handle, Frame & Wheel Assembly

Ref.	Part Number	Description
1	749-04282	Upper Handle
2	720-04072	Star Handle Knob
3	749-04281	Lower Handle
4	710-04398	Flange Screw: $\frac{5}{16}$ -18:7.5:GR5
5	754-04123	V-Belt
6	756-04163	Idler Pulley
7	748-04125	Shoulder Spacer
8	686-04080	Idler Bracket
9	712-04065	Flange Lock Nut: $\frac{3}{8}$ -16
10	710-0654A	TT Screw: $\frac{3}{8}$ -16:1.00
11	786-04303	Belt Cover
12	710-0514	HH Cap Screw: $\frac{3}{8}$ -16:1.00
13	732-0418	Extension Spring
14	738-04139	Stud: 33 x 1.5: $\frac{3}{8}$ -16
15	756-04217	Flywheel Pulley
16	710-0591	HH Cap Screw: $\frac{3}{8}$ -24:1.00
17	710-0520	HH Cap Screw: $\frac{3}{8}$ -16:1.55
18	786-04256	Tine Shield 61 cm
19	711-0415	Clevis Pin
20	642-0005	Outer Tine Assembly LH
21	642-0003	Inner Tine Assembly LH
22	714-0149B	Internal Cotter Pin
23	749-04266	Rear Wheel Tube

Ref.	Part Number	Description
24	714-3020	Cotter Pin
25	769-0299	Push Cap
26	734-0973	Wheel 5 x 1.38
27	749-04265	Depth Stake Tube
28	711-04520	Axle Shaft
29	710-1007	TT Screw: $\frac{3}{8}$ -16 x 1.50
30	711-0415	Clevis Pin
31	710-0809	TT Screw: $\frac{1}{4}$ -20:1.25
32	737-04202	Pipe Plug: $\frac{3}{8}$ NPT
33	642-0002	Inner Tine Assembly RH
34	642-0004	Outer Tine Assembly RH
35	618-04276A	Case Assembly
36	721-04157	Gasket
37	786-04296	Wheel Bracket
38	712-04063	Flange Lock Nut: $\frac{5}{16}$ -18
39	710-0487	Carriage Bolt
40	731-05385	Clutch Cable Fitting
41	746-04247	Clutch Cable
42	710-0599	TT Screw: $\frac{1}{4}$ -20:.50
43	786-04307	Cable Mount Bracket
44	747-04508	Clutch Bail
45	716-0208	Retaining Ring
46	736-0300	Flat Washer, .406 x .875 x .059