


REPLACEMENT PARTS - MODEL 316.791191

2-CYCLE TRIMMER




Item	Part No.	Description
1	753-06282	Rear Cover Assembly (includes 2 & 3)
2	791-181862	Starter Screw
3	753-06244	Starter Assembly Guard (includes 2)
4	753-06245	Rear Engine Cover (includes 5)
5	791-181345	Cover Screw
6	753-06104	Adapter
7	753-06091	Pawl Assembly
8	753-06499	Flywheel Assembly
9	753-06247	Washer
10	753-06248	Spacer
11	753-05860	Clutch Assembly
12	753-06285	Clutch Cover Assembly (includes 2, 13-15 & 21)
13	791-182519	Anti-Rotation Screw
14	753-04003	Clamp Screw
15	791-180217	Clamp Nut
16	753-06418	Muffler Assembly (includes 17 & 35)
17	753-06419	Muffler Gasket
18	753-06250	Fuel Tank Assembly (includes 19 & 20)

Item	Part No.	Description
19	791-181930	Tank Screw
20	753-05057	Fuel Cap
21	791-182366	U-Shaped Nut
22	753-05877	Lead Wires
23	753-06251	Throttle Cable
24	753-06303	Module Assembly
25	753-06440	Cylinder Gasket
26	753-05703	Cylinder Bolt
27	753-06193	Spark Plug
28	753-06189	Insulator Assembly (includes 29)
29	753-06184	Insulator O-Ring
30	753-06185	Carburetor O-Ring
31	753-06288	Carburetor
32	753-06253	Carburetor Gasket
33	753-06500	Aircleaner Assembly (includes 34)
34	753-06417	Aircleaner Filter
35	753-06294	Muffler Screw
36	753-06501	Short Block Assembly (includes Crankcase, Cylinder, Piston, 8-10 & 24-27)

REPLACEMENT PARTS - MODEL 316.791191

2-CYCLE TRIMMER



Item	Part No.	Description
1	753-04234	Throttle Housing Assembly (includes 2-4)
2	753-04119	Throttle Trigger
3	791-182690	Throttle Trigger Spring
4	791-182405	Switch
5	753-04344	Upper Drive Shaft Housing Assembly
6	753-05461	D-Handle Assembly (includes 7)
7	791-181587	D-Handle Hardware
8	753-1190	Split Boom Coupler (includes 9-12)
9	791-182057	Screw
10	791-181617	Bolt
11	791-181981	Adjustment Knob (includes 12)
12	753-04386	Knob Retaining Nut
13	753-06139	Lower Drive Shaft Housing Assembly
14	753-05267	Lower Flexible Drive Shaft
15	753-05698	Anti-Rotation Screw
16	753-06571	Gear Box Assembly (includes 15 & 20-24)
17	753-06125	Shield Mounting Screws
18	753-06123	Shield Assembly (includes 17 & 19)
19	753-06126	Blade Assembly
20	753-04284	Outer Spool Assembly (includes 21)
21	791-610660	Retainer
22	791-610317B	Spring
23	753-1155	Inner Reel
24	791-153066B	Bump Knob Assembly
25	791-610327	Shoulder Strap Clip
*	753-1156	.095 Line Reel & Line Assembly
*	791-682075B	Shoulder Strap

* Items Not Shown