




OPERATOR'S MANUAL




3-in-1 Battery Mower — TB E25

WARNING

**READ AND FOLLOW ALL SAFETY RULES AND INSTRUCTIONS IN THIS MANUAL
BEFORE ATTEMPTING TO OPERATE THIS MACHINE.
FAILURE TO COMPLY WITH THESE INSTRUCTIONS MAY RESULT IN PERSONAL INJURY.**

TROY-BILT LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019

Model TB E25



For a new battery pack, order part 725-05089.

Ref.	Part Number	Description
1	787-01839	Deck
2	731-08261	Shroud
3	731-07619	Side Discharge Door
4	731-07620	Side Discharge Chute
5	731-07621	Trail Shield
6	734-04610	Front Wheel
7	734-04611	Rear Wheel
8	731-08262	Wheel Cap
9	731-08263	Wheel Cap
10	731-07622	Rear Door
11	731-07623	Rear Baffle
12	731-07624	Mulching Plug
13	711-05358	Rear Shaft
14	732-04733	Spring
15	732-04734	Spring
16	787-01824	Left Bracket
17	787-08125	Right Bracket
18	711-05325	Trail Shield Pin
19	787-01813	Side Discharge Bracket
20	711-05326	Side Discharge Pin
21	732-04713	Spring
22	611-04176	Front Shaft Assembly
23	741-04464	Front Shaft Bushing
24	741-04474	Bearing
25	611-04177	Rear Shaft Assembly
26	741-04465	Rear Shaft Bushing
27	732-04735	Handle Adjust
28	732-04715	Handle Adjust Spring
29	720-04143	Handle Adjust Knob
30	787-01826	Link Bar
31	724-04095	Motor
32	731-07515	Fan
33	742-04321	Blade
34	736-04486	Flange
35	731-07598	Washer
36	736-04487	Washer
37	712-04237	Blade Nut
38	731-07672	Support
39	731-07673	Strain Relief
40	749-04670	Upper Handle
41	731-07522	Handle Grip
42	749-04688	Lower Handle
43	720-04145	Quick Release
44	736-04488	Washer
45	720-04146	Quick Release Knob

Ref.	Part Number	Description
46	710-05151	M8 Screw
47	715-04107	Quick Release Pin
48	712-04257	M8 Nut
49	712-04250	M6 Nut
50	720-04147	Wing Knob
51	710-05082	Screw
52	736-04489	Washer
53	731-07524	Cord Clip
54	714-04088	Pin
55	731-07513	Cap
56	625-04129	Switch Box
57	725-05156	Cord
58	747-05304	Clamp
59	764-04096	Grassbag
60	731-07674	Battery Pack Cover
61	731-07675	Battery Pack Housing
62	731-07676	Handle
63	787-01840	Hook
64	725-05157	Battery
65	725-05158	Connector
66	725-05159	PCB
67	725-05160	PCB Support
68	725-05161	Connector
69	725-05162	Safety Key
70	725-05163	Key Connector
71	725-05164	SA50 Connector
72	725-05165	Supporter
73	731-07678	Supporter
74	725-05170	Connector
75	725-05169	Connector
76	725-05168	Fuse
77	725-05167	Board
78	725-05068	Charger
79	736-04505	Spring Washer
80	736-04506	8mm Washer
81	712-04258	M8 Nut
82	710-05156	ST4.2x16 Screw
83	710-05155	ST4.2x25 Screw
84	710-05154	ST4.8x16 Screw
85	710-05153	M6x12 Screw
86	710-05118	M5 x 12 Screw
87	714-04086	Cotter Pin
88	716-04169	10mm Lock Ring
89	787-01841	Support