


REPLACEMENT PARTS - MODEL YM2BV

2-CYCLE GAS BLOWER

PPN 41AS2BVG901




Item	Part No.	Description
1	753-04620	Muffler Screws
2	753-06027	Muffler Assembly (includes 1 & 3)
3	753-05946	Muffler Gasket
4	753-05703	Screw
5	753-06193	Spark Plug
6	753-05704	Cylinder Gasket
7	753-05947	Shortblock Assembly (includes 4-6 & 8-11)
8	753-05948	Flywheel Assembly
9	753-04833	Washer
10	753-05687	Nut
11	753-05866	Module Assembly

Item	Part No.	Description
12	753-05949	Lead Wire
13	753-04595	Screw
14	753-05950	Fuel Tank Assembly (includes 13 & 15)
15	791-182529	Fuel Cap
16	753-05702	Insulator Gasket
17	753-05632	Insulator Assembly (includes 16)
18	791-181709	Carburetor Gasket
19	753-05951	Carburetor Assembly (includes 18)
20	753-05725	Aircleaner Assembly (includes 21)
21	791-181757	Air Filter
22	753-05952	Throttle Cable

REPLACEMENT PARTS - MODEL YM2BV

2-CYCLE GAS BLOWER

PPN 41AS2BVG901



Item	Part No.	Description
1	753-05937	Lower Tube
2	753-05936	Upper Tube
3	753-05377	Screw
4	791-181862	Screw
5	753-06657	Engine Cover Assembly (includes 3 & 4)
6	753-05944	Muffler Cover Assembly (includes 3)
7	753-05932	Outer Trigger Lock
8	753-05921	Impeller Housing (includes 9)
9	753-05919	Handle Grips
10	753-05924	Inner Trigger Lock
11	753-05925	Wavey Washer
12	791-182405	Switch
13	753-05930	Throttle Trigger
14	753-05928	Washer
15	753-05926	Latch Tube
16	753-05939	Latch Spring

Item	Part No.	Description
17	753-05929	Impeller
18	753-05927	Nut
19	753-05920	Impeller Housing (includes 9)
20	753-05917	Intake Cover
21	753-05918	Spring
22	753-04834	Lock Washer
23	753-06658	Elbow
24	753-06659	Bag
25	753-06660	Upper Vac Tube
26	753-06661	Lower Vac Tube