



Labels



PARTS LIST

Craftsman Model 247.288851



PARTS LIST


Craftsman Model 247.288851

Ref. No.	Part No.	Description
1	925-1649	Bulb Socket
2	683-04619-0691	Hood Assembly
3	710-04484	Screw, 5/16-18 x .750
4	710-0599	Hex Washer Screw, 1/4-20 x .500
5	712-0292	Tin Clip Nut, 1/4-20
6	710-0751	Hex Screw, 1/4-20 x .620
7	710-05108	Screw, 1/4 x .750
8	712-04064	Nut, Hex Flange Insert Lock, 1/4-20
9	931-07668	Grill
10	731-07458	Headlight Lens, RH
11	731-07459	Headlight Lens, LH
12	731-07460	Dash Collar
13	731-07711	Hood Scoop, LH
14	731-07712	Hood Scoop, RH
15	735-0271A	Bumper
16	738-04091A	Shoulder Screw, 5/16-18
17	783-05327B-0637	Left Support Pivot Bracket
18	783-05328A-0637	Right Support Pivot Bracket
19	783-06598-4043	Lower Grill
20	783-06610-0637	Lower Grill Bracket
21	983-04503	Speed Selector
22	710-05280	Self-Tap Screw, 1/4-20
23	710-3144	Hex Head Screw, 3/8-16
24	711-0736	Ferrule, 1/4-20 x 1.00
25	712-04065	Nut, Hex Flange Insert Lock, 3/8-16
26	714-04040	Cotter Pin

Ref. No.	Part No.	Description
27	783-06823	Speed Latch Support Tab
28	750-04465B	Flange Spacer
29	783-04903A	Speed latch
30	710-0604A	Self-Tap Screw, 5/16-18
31	710-05108	Hex Screw, 1/4 x .750
32	712-04063	Nut, Hex Flange Lock, 5/16-18
33	731-04945	Steering Support
34	783-04873B-0637	Dash
35	747-05371	Fuel Tank Support Rod
36	747-05326	Dash support Rod
37	747-04430	Speed Selector Control Rod
38	751-10782	Fuel Tank
39	751-12179	Fuel Cap
40	783-04584B-0637	Gas Tank Support Bracket
41	731-05265	Choke Plug
42	746-04364	Throttle/Choke Assembly
43	925-04659	Key Switch Module
44	625-04124	Key (2 pack)
45	725-0157	Cable Tie
46	925-0963	Headlight Bulb
47	726-04072A	Ratchet Clip: .250 x .500
48	936-0463	Flat Washer, .25 x .630 x .0515
49	735-04081	Rubber Grommet
50	751-12118	Fuel Rollover Valve
51	751-12089	Vent Hose
52	710-1652	Hex Washer Screw, 1/4-20 x .625

PARTS LIST

Craftsman Model 247.288851




PARTS LIST

Craftsman Model 247.288851

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	683-04334-0637	Shaft, Lift	24	756-04196A	Engagement Pulley
2	712-04065	Nut, Hex Flange Insert Lock, 3/8-16	25	683-04414-0637	Belt Keeper Rod Assembly
3	714-04040	Bow-Tie Pin, 91, RH	26	710-04484	Screw, Hd. Tapp, 5/16-18 x .75
4	716-0106A	E-ring, .625 Shaft	27	683-04195-0637	Support Bracket Assembly
5	720-0298	Grip, Handle	28	683-04601-0637	Rider Frame Assembly
6	732-04438	Spring, Lift Handle Torsion	29	710-0134	Carriage Screw, 1/4-20 x .62
7	938-0380	Bolt, Shoulder, .500 x .270: 3/8-16	30	710-3008	Screw, Hx. Hd., 5/16-18 x .75
8	941-0225	Bearing, Hex Flange,	31	712-04063	Nut, Flange Insert Lock 5/16-18
9	747-04653	Handle, Lift	32	712-04064	Nut, Hex Flange Insert Lock, 1/4-20
10	747-04393	Lift Rod, 13.68	33	912-0429	Hexlock Nut, 5/16-18
11	783-0678C-0637	Arm, Deck Lift RH	34	936-0140	Washer, Flat, .385 x .62 x .063
12	647-04096-0637	PTO Handle Assembly	35	736-0173	Flat Washer, .28 x .74 x .063
13	710-04608	Screw, Hx. Hd., 7/16-20 x 3.25	36	783-04548D-0637	Seat Bracket Frame
14	710-0599	Screw, Hd. Tapp, 1/4-20 x .5	37	783-04637-0637	Running Board Bracket
15	714-04040	Click Pin	38	783-04753-0637	Frame Support Bracket
16	720-04049A	Handle Grip	39	783-04869A-0637	Battery Bracket
17	732-04276A	PTO Spring, Extension	40	783-05389A-0637	Frame Brace Bracket
18	936-0171	Washer, Flat, 7/16	41	725-05090	Die Hard Battery
19	736-0322	Washer, Flat, .450 x .250 x .164	42	738-1132	Screw, Shoulder, .250 x .150
20	738-04237A	Shoulder Screw, #10-32 x .500	43	712-0271	Nut, Sems, 1/4-20
21	741-04119A	PTO Bearing	44	683-04448-0637	Battery Rod
22	946-04173C	Deck Engagement Cable	45	725-04363	Interlock Switch
23	725-04439	12v. Solenoid			

PARTS LIST

Craftsman Model 247.288851



PARTS LIST


Craftsman Model 247.288851

Ref. No.	Part No.	Description
1	617-04094	Gear Assembly, Steering
2	710-0643	Screw, 5/16-18, 1.00, Gr5, Lock
3	710-1309	Screw, Mach, 5/16-18, 0.750
4	710-3094A	Hex Head Screw, 3/8-16 x 1.00
5	710-3180	Screw, 5/16-18, 1.75, Gr5
6	912-0214	Nut, Jam Lock, 3/8-24
7	912-0240	Nut, Jam, 7/16-20, Gr2
8	712-04063	Nut, Flange Lock, 5/16-18, Grf
9	712-04065	Nut, Flange Lock, 3/8-16, Grf
10	923-0448A	Ball Joint, 7/16-20, Lock
11	736-0242	Washer, Bell, .340 x .872 x .060
12	731-04693	Hub Cap
13	738-04141	Shoulder Screw, 5/16-18
14	738-04162A	Shoulder Spacer, .8840 x .190
15	738-0919A	Steering Shaft, 5/8 Spline x 21.86
16	941-04124	Bearing, Flange, Hex 5/8
17	747-05385	Drag Link, Steering
18	948-0389	Cap, 1.25 x .16
19	748-04065-0637	Steering, Block
20	748-04068	Spacer, .710 ID x .125 OD x .56
21	719-04177A	Pivot Bar Axle Assembly

Ref. No.	Part No.	Description
22	710-04484	Screw, 5/16-18, 0.750
23	712-04065	Nut, Flange Lock, 3/8-16, GrF
24	714-04039A	Pin, Cotter, 5/32, 1.25
25	914-0474	Pin, Cotter, 1/8 x 0.75
26	726-04035	Push Cap, 3/4
27	936-0316	Washer, Flat, .78 x 1.59 x .060
28	736-04228A	Washer, Flat, .781 x 1.59
29	738-04128	Screw, Shlder, .500 x 2.380, 3/8-16
30	747-04299A	Tie Rod
31	748-04068	Spacer, .71 x .125 x .56
32	783-05326B-0637	Pivot Bar Bracket
33	938-04013	Axle Assembly LH
34	938-04014A-0637	Axle Assembly RH
35	631-04008A	Steering Wheel, Standard Grip
36	731-06825	Cap, Steering Wheel (Crafts. logo)
37	634-04639-0961	Wheel Assembly
38	934-04634-4042	Rim
39	734-1731-0901	Tire, 15 x 6 x 6 Sq. Shoulder
40	934-0255	Valve Stem
41	931-0484A	Hub Cap

PARTS LIST

Craftsman Model 247.288851




PARTS LIST

Craftsman Model 247.288851

Ref. No.	Part No.	Description
1	710-04482	Hex Flange Bolt, 3/8-16 x .875
2	710-04484	Screw, Hd. Tapp, 5/16-18 x .75
3	712-3004A	Flange Lock Nut, 5/16-18
4	925-05013	Seat Safety Switch
5	725-05277	Seat Jumper Harness <i>(not shown)</i>
6	926-0154	Push Mount Cable Tie
7	732-04035	Spring, Compress., 1.28 x 3.125
8	732-04563	Spring, Compress., .68 x 1.065 x .055
9	938-0296	Shoulder Screw, 5/16-18 x .437 x .268
10	783-06050	Seat Adjustment Lever
11	783-06088-0637	Seat Pivot Bracket
12	783-06448	Switch Retainer Clip
13	783-06840	Seat Mounting Bracket
14	735-04047	Rubber Foot Pad, LH
	735-04048	Rubber Foot Pad, RH
15	726-3046	Ratchet Clip, .250
16	710-05070	Tap Screw, 1/4-20 x .5
17	710-0599	Screw Pan Torx Head, 1/4-20 x .500
18	731-04591A	Cup Holder
19	783-04587D-0691	Fender
20	783-04843-0637	Lift Adjuster Bracket
21	710-0134	Carriage Screw, 1/4-20 x .62
22	757-04145	Seat

PARTS LIST

Craftsman Model 247.288851




PARTS LIST

Craftsman Model 247.288851

Ref.	Part No.	Description
1	683-04549-0637	Muffler Shield Assembly
2	710-0227	Screw, AB #8-18 0.500
3	710-04683	Tap Screw, 3/8-16 1.000
4	710-0642	Tap Screw, 1/4-20 0.750
5	710-1314A	Screw, Socket Head, 5/16-18 x .750
6	712-0271	Sems Nut, 1/4-20
7	BS-692236	Exhaust Gasket
8	725-0157	Cable Tie, 3/16 X .05 X 7.4
9	726-0205	Hose Clamp, .490 Dia.
10	731-05628	Oil Drain Sleeve
11	751-10349	Low Permeation Fuel Hose, 1/4
12	751-10448B	Briggs Single Muffler
13	751-10353	Long Muffler Deflector
14	331877-0869-G5	Engine

PARTS LIST

Craftsman Model 247.288851



PARTS LIST


Craftsman Model 247.288851

Ref.	Part No.	Description
1	918-04566	Dr Assembly, Autodrive Lt-5
2	683-04606	Auto-drive Bracket Assembly
3	683-04684	Idler Bracket Assembly
4	710-1260A	Tap Screw, 5/16-18 x 0.750
5	712-04065	Flange Lock Nut, 3/8-16
6	738-0322A	Shoulder Screw, .625 x .217
7	956-04015A	Pulley Assembly, Var. Spd. 4.75 Od
8	683-04522	Belt Keeper Assembly
9	683-04612-0637	Variable Bracket Assembly
10	710-0627	Hex Screw 5/16-24 .750
11	710-0778	Tap Screw, 1/4-20 1.500
12	718-04261	Bearing Cup
13	736-0362	Wash, Flat .330 X 1.25 X .06
14	941-0600	Ball Bearing, 17 x 40 x 12.6203
15	647-04035	Lvr Assembly, Shft
16	647-04201-0637	Ped Assembly, Drive, Autodrive
17	647-04203A-0637	Ped Assembly, Cont, Autodrive
18	683-04607	Bracket Assembly, Pedal, Autodrive
19	710-0227	Screw, Ab, #8-18, 0.500
20	710-04484	Screw, Tt, 5/16-18, .750
21	710-0604A	Screw, Tt, 5/16-18, 0.625
22	710-0809	Screw, Tt, 1/4-20, 1.250
23	710-0859	Hex Hd. Screw, 3/8-16, 2.50
24	710-1007	Screw, Ttsems, 3/8-16, 1.500
25	710-1266	Hex Hd. Screw, 5/16-18, 3.50
26	710-1325	Screw, Tt, 1/4-20, 1.625,
27	710-1858A	Screw, Tt, 3/8-16 x 1.75
28	710-3008	Hex Hd. Screw, 5/16-18, .75
29	912-0240	Nut, Jam, 7/16-20
30	712-0241	Nut, Hex, 3/8-24
31	712-04063	Nut, Flange Lock Nut, 5/16-18
32	912-0431	Nut, Flange Lock Nut, 3/8-16
33	712-0700	Nut, Flg, 9/16-18
34	914-0111	Pin, Cot, 3/32, 1.0
35	914-0209	Pin, Cotter Int- .125 Dia
36	714-04040	Pin, Cot, Bow-Tie 72
37	718-04407	Hub, Pulley, 5/8 Spline
38	720-04028	Knob, Shft
39	923-3018	Ball, Joint
40	725-0157	Cable, Tie, 3/16 X .05 X 7.4
41	725-1644	Switch, Spring, Short
42	726-0214	Cap, Push 5/8
43	926-0320	Plate, Insulator Nut
44	731-04602	Sleeve, .758 X .821 X 3.3125

Ref.	Part No.	Description
45	731-04604	Sleeve, .758 X .821 X 2.4375
46	731-06330	Plug, Deck Hole, 7/8
47	731-06894	Shift Plate Bearing
48	732-04488	Spring, Ext, .38 Od X 3.25 Lg
49	732-04612	Spring, Extn, .70 Dia X 12.00 Lg
50	732-04616B	Spring, Extn, .97 Od X 6.18 Lg
51	732-04764	Spring, Extn, .56 X 12.05 x .068
52	732-0716D	Spring, Extn, .59 Od X 4.00 Lg
53	735-0239	Pad, Foot, 4.0 Long
54	735-0662	Pad, Cont
55	936-0169	Wash, Lock, 3/8, Regular Duty
56	936-0185	Wash, Flat, .375 X .738 X .063
57	738-0372B	Spacer, Shoulder, 1.00 X .38 X .38
58	738-04091A	Screw, Shoulder, .43x.29, Tt, 5/16-18
59	741-0495	Bearing, Flg, .630 Idx .695 Od X .60
60	741-3065B	Bearing, Hex Flg, .628 Id, Split
61	747-05188	Rod, Brake, Lt-5 Trans
62	747-05243	Rod, Shift, Lt-5 Stretch 46"
63	747-05251A	Rod, Adj, Idlr, 3/8
64	747-05415	Rod, Trans, Footpedal Bypass
65	948-0334	Spacer, T-Axle .68
66	750-04456	Spacer, .260 X .372 X 1.420 Lg
67	750-0566A	Spacer, .260 X .375 X 1.030 Lg
68	954-04208	Belt, V Typ, 5l X 40.9 Lg Poly
69	954-0467A	Belt, V Typ, 5l, 90.80, Poly
70	956-04002	Pulley, Idlr, Flat 7.25 Od
71	756-04224	Pulley, Idlr, Flat 2.75 Od
72	756-04325	Pulley, Idlr, V-Type X 3.06
73	783-04536B-0637	Bracket, Ped, Support Lt-5
74	783-04595A	Bracket, Shft, Adj
75	783-06278	Plt, Bracket, Reinforcement
76	783-06562-0637	Bracket, Ped, Frame Rh
77	783-06592A	Bracket, Idlr, Dbl Autodrive
78	783-06641	Bracket, Supt, Pedal Stap
79	783-06769	Bracket, Idlr, Center Dbl
80	783-06807	Pedal Stop Plate
81	725-04363	Interlock Switch
82	17962	Switch Plate
83	634-04641-0961	Wheel Assembly, 18 x 9.5 x 8 Sq. Sh.
84	634-04369-4042	Rim Assembly
85	934-0255	Valve Stem
86	734-1729	Tire, 18 x 9.5 x 8 Sq. Sh.
87	736-0242	Bell Washer, .340 x .872 x .060
—	925-04082	Wiring Harness (Not Shown)

PARTS LIST

Craftsman Model 247.288851



PARTS LIST

Craftsman Model 247.288851

Ref. No.	Part No.	Description
1	618-04865A	Spdl Asm:Pul 6.93 Dia W/O Zerk
2	683-0254B	Brkt Asm:Deck:Hngr Lh Lt
3	631-04460	Chute Deflector Assembly
4	683-04511	Brake Asm:Deck:42/46
5	683-04525	Brake Asm:Deck:46"
6	683-04704	Deck Asm:46t:2w
7	710-0347	Hhcs:3/8-16:1.75:Gr5:Std
8	710-04484	Scr:Tt:5/16-18:.750:Hxindwsh
9	710-0514	Hhcs:3/8-16:1.00:Gr5:Std
10	710-0528	Hhcs:5/16-18:1.25:Gr5:Std
11	710-0599	Scr:Tt:1/4-20:0.500:Hxindwsh
12	710-0642	Scr:Tt:1/4-20:0.750:Hxindwsh
13	710-0778	Scr:Tt:1/4-20:1.500:Hxindwsh
14	710-1003	Scr:B:#10-16:0.625:Hxindwsh:Sp
15	710-3005	Hhcs:3/8-16:1.25:Gr5:Std
16	710-3178	Bolt:Crg:3/8-16:0.75:Gr1
17	712-0229	Nut:Push:3/8
18	712-04063	Nut:FlgIk:5/16-18:Grf:Nylon
19	712-04065	Nut:FlgIk:3/8-16:Grf:Nylon
20	712-0417A	Nut:Flg:5/8-18
21	712-04243	Nut:FlxIk:1/2-13
22	712-0641	Nut:Hex:M16-1.5 Din 936
23	714-04043	Pin:Cot:Bow-Tie 91
24	714-0470	Pin:Cot:Split:1/8x1.25
25	717-04074	Gear:Deck:Adj
26	721-04041	Adap:Water Nozzle
27	731-06496	Cvr:Belt:Universal
28	732-0384	Spr:Extn:.62 Dia X 6.12 Lg
29	732-04652	Spr:Comp:.70 Od X 2.06 Lg
30	732-04773	Spr:Torsn:.992 I.D X 1.17 O.D
31	732-04871	Spr:Extn:1.00 X 7.1175 X .183
32	734-04155	Whl:Deck:5.0 Dia Ball
33	735-0271A	Bmpr:.62 Dia X .3
34	736-0119	Wash:Lock:5/16:Splt:Reg

Ref. No.	Part No.	Description
35	736-0225	Wash:Lock:5/8:Int Tooth
36	736-0262	Wash:Flat:.385x.870x.092
37	736-0344	Wash:Flat:.385 X 1.0 X .030
38	736-0362	Wash:Flat:.330x1.250x.060:Hd
39	736-0371	Wash:Flat:.343 X .880 X .062
40	737-04003D	Noz:Deck:Water
41	738-04162A	Spcr:Shldr:.8840 X .190
42	738-0754	Scr:Shld:.437 Dia. X .54
43	738-3056	Shld-Scr - 1/2 Dia X 2.50 Lg.
44	742-04290	Blade:Cut:23.25" 2-In-1:Econ
45	747-05011	Rod:Keepr:Belt
46	747-05052	Rod:Cont:Brake 46"
47	747-05141A	Rod:Lift:Deck:Medium
48	747-05323	Rod:Keepr:Belt:42s 46t
49	747-1116	Rod:Hndl:Deck Rel .375 Dia
50	748-0234	Shoulder Spacer
51	748-04069	Cup:Pivot:Deck Lift
52	750-0258	Spcr:.315 X .750 X .375 Lg
53	750-0566A	Spcr:.260 X .372 X 1.030 Lg
54	751B221535	Clamp:Casing
55	754-04219	Belt:V Typ:A Sec X 106.62
56	756-04129B	Pul:Idlr:4.25"Dia
57	711-04847B	Hinge Pin
58	732-04372	Torsion Spring
59	783-05946	Brkt:Idlr:Piv:46
60	783-06243	Brkt:Cbl:Deck Engage
61	783-06368A	Brkt:Guard:Belt:4.25 Pulley
62	783-06981	Brkt:Idlr:46" Lh
63	783-06074A	Chute Bracket
64	756-04356	Deck Pulley, 6.93 DIA
65	941-0919	Ball Bearing, .787ID X 1.85 ODX.551
66	750-04936	Spacer, .792 X 1.060 X 1.860 LG
67	738-1186A	Spindle Shaft, 6.05 LG.

PARTS LIST


Craftsman Engine Model 331877-0869-G5 For Model 247.288851

48 SHORT BLOCK

1058 OPERATOR'S MANUAL




1329 REPLACEMENT ENGINE

1330 REPAIR MANUAL




PARTS LIST

Craftsman Engine Model 331877-0869-G5 For Model 247.288851



PARTS LIST






Craftsman Engine Model 331877-0869-G5 For Model 247.288851



PARTS LIST


Craftsman Engine Model 331877-0869-G5 For Model 247.288851

1036 EMISSIONS LABEL



PARTS LIST

Craftsman Engine Model 331877-0869-G5 For Model 247.288851



PARTS LIST

Craftsman Engine Model 331877-0869-G5 For Model 247.288851

121 CARBURETOR OVERHAUL KIT

51

104

634

217

633

105

617

51A

127

98



137




987


1266

358 ENGINE GASKET SET

3

12


868

7

20

943

617

1022

9

51

691


177

524


883

1266

1095 VALVE GASKET SET

7

51

1022

868

883

PARTS LIST

Craftsman Engine Model 331877-0869-G5 For Model 247.288851

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	794128	Cylinder Assembly	98	695408	Kit-Idle Speed
2	399265	Bushing/Seal Kit (Magneto Side)	104	694918	Pin-Float Hinge
3	391086s	Seal-Oil (Magneto Side)	105	696136	Valve-Float Needle
4	697188	Sump-Engine	108	695419	Valve-Choke
5	796026	Head-Cylinder	117	796251	Jet-Main (Standard)
7	794114	Gasket-Cylinder Head	118	791406	Jet-Main (High Altitude)
9	697109	Gasket-Breather	121	796184	Kit-Carburetor Overhaul
11	794683	Tube-Breather	125	796587	Carburetor
12	697110	Gasket-Crankcase	127	690727	Plug-Welch
13	793988	Screw (Cylinder Head)	130	792747	Valve-Throttle
15	690946	Plug-Oil Drain	131	792765	Kit-Throttle Shaft
16	797579	Crankshaft	133	694914	Float-Carburetor
20	795387	Seal-Oil (PTO Side)	135	698780	Tube-Fuel Transfer
22	692125	Screw (Crankcase Cover/Sump)	137	698781	Gasket-Float Bowl
23	698281	Flywheel	141	792777	Kit-Choke Shaft
24	796335	Key-Flywheel (Steel)	146	691639	Key-Timing
25	795858	Piston Assembly (Standard)	186	794873	Hose-Connector (Intake Manifold)
	795877	Piston Assembly (020" Oversize)	187	791805	Line-Fuel (Formed) (Cut to Length)
26	794126	Ring Set (Standard)	187A	791806	Line-Fuel (Formed) (21") (Cut to Length)
	794127	Ring Set (.020" Oversize)	187B	791744	Line-Fuel (Formed) (14") (Cut to Length)
27	698469	Lock-Piston Pin	188	691693	Screw (Control Bracket)
28	795861	Pin-Piston	192	691986	Adjuster-Rocker Arm
29	794122	Rod-Connecting	202	691841	Link-Mechanical Governor
32	791118	Screw (Connecting Rod)	209	692208	Spring-Governor (Green)
33	792868	Valve-Exhaust	216	691840	Link-Choke
34	791935	Valve-Intake	217	695409	Spring-Choke Return
35	691279	Spring-Valve (Intake)	222	694042	Bracket-Control
36	691279	Spring-Valve (Exhaust)	227	691374	Lever-Governor Control
37	699882	Guard-Flywheel	232	691842	Spring-Governor Link
42	499586	Keeper-Valve	238	691843	Cap-Valve
43	691968	Slinger-Governor/Oil	240	394358s	Filter-Fuel
45	690564	Tappet-Valve	265	691024	Clamp-Casing
46	793880	Camshaft	267	794904	Screw (Casing Clamp)
48	795446	Short Block	276	695410	Washer-Sealing
50	796180	Manifold-Intake	304	798670	Housing-Blower
51	692137	Gasket-Intake	305	697102	Screw (Blower Housing) (1/4-20x1.14)
51A	794312	Gasket-Intake	305A	793376	Screw (Blower Housing) (1/4-20x.68)
53	690227	Stud (Carburetor)			Screw (Blower Housing) (Blower Housing to Elbow)
54	691148	Screw (Intake Manifold)	305B	795891	
78	691693	Screw (Flywheel Guard)	306	794953	Shield-Cylinder
94	793610	Kit-Idle Mixture	307	691693	Screw (Cylinder Shield)
95	690718	Screw (Throttle Valve)	309	693551	Motor-Starter

PARTS LIST

Craftsman Engine Model 331877-0869-G5 For Model 247.288851

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
310	690323	Screw (Starter Motor)	759	697392	Pin-Counterweight
311	497608	Brush Set	773	796448	Retainer (Fuel Pump)
324	796309	Screen/Cup Assembly	783	693713	Gear-Pinion
333	795315	Armature-Magneto	789	698329	Harness-Wiring
334	691061	Screw (Magneto Armature)	797	693167	Nut (Brush Retainer)
337	491055s	Plug-Spark	801	691283	Cap-Drive
358	796187	Gasket Set-Engine	802	691286	Cap-End
404	691691	Washer (Governor Crank)	830	691095	Stud-Rocker Arm
415	794129	Plug (Cover/Retainer)	842	691031	Seal-O Ring (Dipstick Tube)
415A	794903	Plug (Intake Manifold)	847	790442	Dipstick/Tube Assembly
431	799043	Elbow-Intake	850	100106	Sealant-Liquid
445	793569	Filter-Air Cleaner Cartridge	851	692424	Terminal-Spark Plug
462	691261	Washer (Starter Cable)	868	690968	Seal-Valve
474	696459	Alternator	877	790544	Wire/Connector-Alternator
503	691532	Strap-Starter	883	692236	Gasket-Exhaust
505	691251	Nut (Governor Control Lever)	914	697551	Screw (Rocker Cover)
510	693699	Drive-Starter	943	690589	Seal-O Ring (Oil Pump Cover)
513	692024	Clutch-Drive	947	699915	Solenoid-Fuel
523	699908	Dipstick	964	799159	Cap-Connector
524	691032	Seal-Dipstick Tube	965	499613	Cover-Oil Pump
525	697184	Tube-Dipstick	967	793685	Filter-Pre Cleaner
552	697144	Bushing-Governor Crank	968	795757	Cover-Air Cleaner
562	691119	Screw (Governor Control Lever)	975	699502	Bowl-Fuel
579	691029	Nut (Starter Cable)	987	698777	Seal-Throttle Shaft
584	794682	Cover-Breather Passage	1005	796084	Fan-Flywheel
601	791850	Hose-Clamp (Green)	1017	796981	Screen-Oil Pump
614	691620	Pin-Cotter (Governor Crank)	1022	272475s	Gasket-Rocker Cover
616	692012	Crank-Governor	1023	797421	Cover-Rocker
617	692138	Seal-O Ring (Intake Manifold) (Red)	1024	794644	Pump-Oil
633	699813	Seal-Choke/Throttle (Choke Shaft)	1026	692003	Rod-Push (Intake)
634	698779	Spring/Seal Assembly		692011	Rod-Push (Exhaust)
635	691909	Boot-Spark Plug	1027	492932s	Filter-Oil
654	690958	Nut (Carburetor)	1029	691751	Arm-Rocker
684	697157	Screw (Breather Passage Cover)	1034	690822	Guide-Push Rod
691	692407	Seal-Governor Shaft	1036	Label-Emissions (Available from a Briggs & Stratton Authorized Dealer)	
697	791680	Screw (Drive Cap)	1040	698368	Plate-Trim
718	690959	Pin-Locating	1044	698139	Screw (Flywheel)
729	691224	Clip-Wire	1051	691265	Ring-Retaining
741	697128	Gear-Timing	1058	276344	Operator's Manual
750	790832	Screw (Oil Pump Cover)	1059	698516	Kit-Screw/Washer (Alternator)
757	793242	Link-Counterweight	1090	691293	Retainer-Brush
758	793763	Counterweight			

PARTS LIST

Craftsman Engine Model 331877-0869-G5 For Model 247.288851

Ref. No.	Part No.	Description
1091	691333	Cap-Limiter
1095	794152	Gasket Set-Valve
1119	691183	Screw (Alternator)
1127	695407	Screw (Float Bowl)
1139	796449	Washer (Fuel Pump)
1263	697124	Reed-Breather
1264	697104	Screw (Breather Reed)
1265	794151	Support-Blower Housing
1266	691917	Seal-O Ring (Intake Elbow) (Red)
1270	793243	Plug-AVS Counterweight
1329	331877-0869-G5	Replacement Engine
1330	276781	Repair Manual

Engine Gasket Set	Key No. 358
Valve Gasket Set	Key No. 1095
Carburetor Overhaul Kit	Key No. 121