


PARTS LIST

Steering and Axle — Model No. 247.289841



PARTS LIST


Steering and Axle — Model No. 247.289841

Ref. No.	Part No.	Description
1	710-04095	Hex Head Screw, 3/8-16:1.00
2	710-0514	Hex Head Screw, 3/8-16:1.00
3	710-0643	Hex Head Screw, 5/16-18:1.00
4	711-04998	LH Drag Link
5	711-04999	RH Drag Link
6	912-0240	Jam Nut, 7/16-20
7	712-04065	Flangelock Nut, 3/8-16
8	712-0459	Flangelock Nut, 7/16-20
9	712-3004A	Flangelock Nut, 5/16-18
10	717-1550F	Steering Gear
11	717-1554	Steering Pinion Gear
12	923-0448A	Ball Joint, 7/16-20
13	936-3004	Flat Washer, .406 x .875 x .105
14	736-3084	Flat Washer, .51 x 1.12 x .06
15	783-06043-0637	Steering Support Bracket
16	738-04263	Steering Shaft, .625 OD x 24.25 LG
17	738-04363	Shoulder Spacer, .385 x 1.25 x .3025
18	738-04364B	Spacer, .38 x 1.375
19	741-04237B	Hex Flange Bearing 5/8 PM
20	938-04040-0637	RH Axle Assembly

Ref. No.	Part No.	Description
21	938-04041-0637	LH Axle Assembly
22	710-0395	Hex Head Screw, 5/16-18:2.25
23	710-0859	Hex Head Screw, 3/8-16:2.50
24	710-3180	Hex Head Screw, 5/16-18:1.75
25	912-0214	Hexlock Nut, 3/8-24
26	712-04063	Flangelock Nut, 5/16-18
27	714-0162	Cotter Pin, 5/32:1.25
28	719-04413A	Pivot Bar Axle
29	748-04065-0637	Steering Block
30	748-04068	Spacer, .71 ID x .125 OD x .56LG
31	750-05280	Spacer, .385 x 1.00 x 1.5075
32	631-04415	Steering Wheel
33	731-06825	Steering Wheel Cap
34	731-05674	Bumper Cap
35	736-04228A	Flat Washer, .781ID x 1.590OD
36	634-04466-0961	Wheel Assembly
37	734-1727	Tire
38	934-04082-4042	Rim Assembly
39	934-0255	Tubeless Air Valve

PARTS LIST

Hood and Dash — Model No. 247.289841



PARTS LIST


Hood and Dash — Model No. 247.289841

Ref. No.	Part No.	Description
1	631-04353P	Dash Lever
2	710-04484	Taptite Screw, Lock Washer, 5/16-18:.750
3	710-0599	Taptite Screw, Lock Washer, 1/4-20:0.500
4	710-0895	Hi-Lo Screw, Lock Washer, 1/4-15:0.750
5	710-1017	Screw, 1/4-14:0.625
6	710-1611B	Taptite Screw, 5/16-18:0.750
7	710-1652	Taptite Screw, 1/4-20 x .625
8	710-3217	Machine Screw, #8-32:0.375
9	712-0142	Hex Nut, #8-32:GRA
10	714-04040	Bow-tie Cotter Pin
11	726-3046	Ratchet Clip:.250 DIA
12	731-07456	Dash
13	731-07550	Control Knob
14	732-04580	Extension Spring, .500 DIA x 2.733 LG
15	735-0271A	Bumper
16	735-04076	Accessory Net
17	747-05280	Control Rod Latch
18	747-1196	Lever Rod
19	783-04285F-0637	RH Dash Support Plate
20	783-04323F-0637	LH Dash Support Plate
21	625-04124	Key (Set of 2)
22	683-04618-0691	Hood Assembly
23	710-04187	Hi-lo Screw, Lock Washer, 1/4-15:0.50
24	710-05108	Screw, Lock Washer, 1/4 DIA:.750
25	931-07457	Grill

Ref. No.	Part No.	Description
26	731-07458	RH Lens
27	731-07459	LH Lens
28	931-07461	Hood Scoop
29	731-07467	Lower Grill
30	731-07711A	LH Hood Scoop
31	731-07712A	RH Hood Scoop
32	738-04091A	Shoulder Screw, .43 x .29:TT:5/16-18
33	710-0642	Taptite Screw, 1/4-20:0.750
34	747-05049	RH Tank Support Rod
35	747-05050	LH Tank Support Rod
36	951-12179	Fuel Cap
37	951-11650	Fuel Tank
38	925-1649	Lamp Socket
39	725-04992	Key Switch Module
40	735-04170	Fuel Tank Gasket
41	946-1100	Throttle Control
42	731-07495	P-Style Plen
43	725-04258	PTO Switch
44	925-04036C	Hour Meter
45	925-0963	Miniature Lamp, 12V
46	735-04081	Rubber Grommet
47	751-12118	Fuel Rollover Valve
—	777X44365	RH Reflector Label (Not Shown)
—	777X44366	LH Reflector Label (Not Shown)

PARTS LIST

Seat and Fender — Model No. 247.289841



PARTS LIST


Seat and Fender — Model No. 247.289841

Ref. No.	Part No.	Description
1	683-04301-0637	Lift Shaft Assembly
2	712-04063	Flangelock Nut, 5/16-18
3	712-04065	Flangelock Nut, 3/8-16
4	914-0104	Cotter Pin, .072 DIA. x 1.13 LG
5	714-04040	Bow-Tie Cotter Pin
6	716-0106A	E-Ring, .625 DIA. SHAFT
7	720-04150	Handle Grip
8	732-0874	Torsion Spring
9	736-0105	Spring Washer, .401 x .870 x .063
10	738-0138A	Shoulder Screw, .437 x .470:5/16-18
11	938-0380	Shoulder Bolt, .500 x .270:3/8-16
12	941-0225	Hex Flange Bearing
13	746-0968	Lift Cable, 16.16 LG
14	747-04962A	Lift Handle
15	756-04331	Pulley Roller Cable
16	783-05546A-0637	Lift Arm
17	710-04482	Hex Head Flange, 3/8-16:.875
18	710-04484	Taptite Screw, Lock Washer, 5/16-18:.750
19	712-3004A	Flangelock Nut, 5/16-18
20	725-0157	Cable Tie, 3/16 x .05 x 7.4
21	732-04849	Compression Spring, 1.71 x 3.735 x .238

Ref. No.	Part No.	Description
22	732-04563	Compression Spring, .68 x 1.065 x .055
23	938-0296	Shoulder Screw, .437 x .268:5/16-18
24	783-06049-0691	Seat Mounting Bracket
25	783-06050	Seat Adjustment Lever
26	783-06088-0691	Seat Pivot Bracket
27	783-06448	Switch Retainer Clip
28	710-04187	Hi-Lo Screw, Lock Washer, 1/4-15:0.50
29	710-0451	Carriage Bolt, 5/16-18:.750
30	710-0599	Taptite Screw, Lock Washer, 1/4-20:0.500
31	710-0895	Hi-Lo Screw, Lock Washer, 1/4-15:0.750
32	731-05837	LH Fender Cover
33	731-06754	RH Fender Cover
34	736-3078	Flat Washer, .344 x 1.00 x .063 HDN
35	783-06118-0691	Fender
36	726-3046	Ratchet Clip
37	735-04137	LH Foot Pad
—	735-04139	RH Foot Pad
38	757-04128	Seat
39	957-04134	Armrests
40	783-06181-0637	Lift Bracket
41	925-05013	Seat Switch

PARTS LIST

Drive and Rear Wheels — Model No. 247.289841



PARTS LIST


Drive and Rear Wheels — Model No. 247.289841

Ref. No.	Part No.	Description
1	918-04317	Wheel Assembly Hub
2	918-04917	Transmission
3	710-0189	Hex Screw, 5/16-18:3.00
4	710-0227	Screw, #8-18:0.500
5	710-04484	Taptite Screw, 5/16-18:.750
6	710-0599	Taptite Screw, 1/4-20:0.500
7	710-0909A	Taptite Screw, 5/16-18:1.750
8	710-1007	Taptite Sems Screw, 3/8-16:1.500
9	710-1008	Taptite Sems Screw, 3/8-16:1.875
10	710-1189	Screw, #12-24:0.625
11	710-1325	Taptite Screw, 1/4-20:1.625
12	710-3011	Hex Screw, 3/8-16:2.25
13	710-3119	Hex Screw, 3/8-16:.750
14	912-0240	Jam Nut, 7/16-20
15	712-04063	Flangelock Nut, 5/16-18
16	712-04065	Flangelock Nut, 3/8-16
17	914-0104	Cotter Pin, .072 DIA. x 1.13 LG
18	914-0111	Cotter Pin, 3/32:1.0
19	725-0157	Cable Tie, 3/16 x .05 x 7.4
20	725-04791A	Jumper Harness
21	725-1644	Short Spring Switch
22	926-0154	Push Mount Cable Tie 7.5 LG
23	926-0320	Insulator Nut Plate
24	931-1449A	Blade Fan
25	732-04528	Extension Spring, .50 DIA x 5.0 LG
26	732-04792	Extension Spring, 1.00 DIA x 4.75
27	732-0716D	Extension Spring, .59 OD x 4.00 LG
28	732-0932	Extension Spring, .38 DIA x 5.6
29	732-3118	Extension Spring, .375 OD x 1.44 LG
30	936-0227	Flat Washer, .390 x 1.500 x .134
31	936-0344	Flat Washer, .330 x .630 x .0635
32	936-3008	Flat Washer, .344 x .750 x .120
33	736-3010	Flat Washer, .407 x .812 x .135
34	647-04152B	Brake Control Assembly
35	738-04420	Shoulder Spacer, 1.375 x .380 x .183
36	747-04957A	Foot Pedal Bypass Transmission Rod

Ref. No.	Part No.	Description
37	747-05124	Brake Rod
38	747-05125A	Control Rod
39	747-05130	Disengage Rod
40	747-05181	Belt Keeper, 5/16
41	750-04456	Spacer, 260 x .372 x 1.420 LG
42	954-04244A	V Belt, 4L x 77.0
43	756-04224	Flat Idler Pulley, 2.75 OD
44	756-04325	V Idler Pulley, 3.06
45	783-05443A-0637	Torque Bracket
46	783-05841	Switch Bracket
47	783-06027A	Center Idler Bracket
48	783-06501A-0637	Deck Bracket
49	783-06503	Plate Bracket
50	783-0693A-0637	Axle Bracket
51	683-04571	Pedal Bracket Assembly
52	710-0604A	Taptite Screw, 5/16-18:0.625
53	711-05068	Clevis Pin, 5/16 x 3.985
54	714-04040	Bow-Tie Cotter Pin
55	726-0214	Push Cap
56	732-04587	Extension Spring, .63 DIA x 4.95 LG
57	735-04118A	Forward Pedal Pad
58	735-04135	Reverse Pedal Pad
59	735-04136	Brake Pedal Pad
60	938-0380	Shoulder Bolt, .500 x .270:3/8-16
61	741-0495	Flange Bearing, .630 ID x .695 OD x .60
62	748-04203	Cruise Latch
63	783-05914	Pedal Support Bracket
64	783-05940	Pedal Support Bracket, 5/8
65	783-06059-0637	Drive Pedal Bracket
66	783-06103A-0637	Brake Pedal Bracket
67	634-0202A-0961	Complete Wheel
68	712-3050	Lug Nut, 7/16-14
69	934-0255	Air Valve
70	734-04147-0901	Tire
71	634-04238-4042	Rim Assembly
72	738-1229A	Shldr. Screw, .625 x 2.50:1/2-13

PARTS LIST

Engine Accessories — Model No. 247.289841




PARTS LIST

Engine Accessories — Model No. 247.289841

Ref. No.	Part No.	Description
1	683-04549-0637	Muffler Shield Assembly
2	710-0227	Screw, Indented Washer, #8-18:0.500
3	710-04683	Taptite Screw, Indented Washer, 3/8-16:1.000
4	710-0599	Taptite Screw, Indented Washer, 1/4-20:0.500
5	710-1314A	Socket Head Screw, 5/16-18:.750
6	712-0271	Sems Nut, 1/4-20
7	721-0460	Exhaust Gasket
8	725-0157	Cable Tie, 3/16 x .05 x 7.4
9	726-0205	Hose Clamp, .490 DIA.
10	751-10542A	Muffler
11	783-06378A	Heat Shield
12	751-0564B	Muffler Deflector
13	751-10349	Fuel Hose
14	BS-49M777-0853-G5	Replacement Engine

PARTS LIST

PTO and Battery — Model No. 247.289841




PARTS LIST

PTO and Battery — Model No. 247.289841

Ref. No.	Part No.	Description
1	710-04379A	Hex Head Screw, 7/16-20:3.50
2	917-1774C	Electric PTO Clutch
3	725-0157	Cable Tie, 3/16 x .05 x 7.4
4	936-0171	Lock Washer, 7/16
5	736-0277	Flat Washer, 1.031 x 1.620 x .095
6	756-0978B	Electric PTO Engine Pulley
7	683-04469B-0691	Frame
8	710-04484	Taptite Screw, Indented Washer, 5/16-18:.750
9	710-3005	Hex Head Screw, 3/8-16:1.25
10	712-04065	Flangelock Nut, 3/8-16
11	738-04058	Shoulder Spacer, .38 x 1.0 x .70
12	747-04121A	Battery Holder Rod
13	783-0349-0637	Battery Tray
14	783-06089-0637	Seat Frame Bracket
15	725-05088	Battery
16	710-0653	Taptite Screw, 1/4-20:0.375
17	712-04064	Flangelock Nut, 1/4-20
18	725-04363	Interlock Switch
19	725-04439	Solenoid, 12 V
20	738-04237A	Shoulder Screw, #10-32:.500
21	710-04666	Hex Head Flange, 1/4-20:.75
22	712-0271	Sems Nut, 1/4-20
23	747-05195	Belt Keeper Rod
NS	925-04093	Wire Harness Assembly

PARTS LIST

Deck — Model No. 247.289841



PARTS LIST

Deck — Model No. 247.289841

Ref. No.	Part No.	Description
1	12650	Height Adjust Bracket
2	96606	Retainer Hook Bracket
3	918-04608A	Spindle Assembly
4	683-0254B-4028	Deck Hanger Bracket Assembly
5	983-04585-4028	Deck Assembly
6	683-0459-0637	Idler Assembly
7	703-2093-0637	Inner Baffle
8	703-3279-4028	Deflector Chute Stop
9	710-04095	Hex Screw, 3/8-16:1.00
10	710-04484	Taptite Screw, 5/16-18:.750
11	710-0521	Hex Screw, 3/8-16:3.00
12	710-0528	Hex Screw, 5/16-18:1.25
13	710-0597	Hex Screw, 1/4-20:1.00
14	710-0623	Taptite Screw, 3/8-16:0.750
15	710-0859	Hex Screw, 3/8-16:2.50
16	710-3103	Hex Screw, 5/16-18:2.00
17	710-3168	Carriage Bolt, 3/8-16:1.00
18	710-3178	Carriage Bolt, 3/8-16:0.75
19	911-0332	Clevis Pin, .50 DIA x .78 LG
20	911-3314	Roller Pin, 1/2 DIA x 7.31 LG
21	912-0206	Hex Nut, 1/2-13
22	712-0229	Push Nut, 3/8
23	712-04063	Flangelock Nut, 5/16-18
24	712-04065	Flangelock Nut, 3/8-16
25	712-0417A	Flange Nut, 5/8-18
26	912-0641	Hex Nut, M16-1.5 DIN 936
27	912-3010	Hex Nut, 5/16-18
28	712-3022	Hexlock Nut, Counterlock, 1/2-13
29	712-3083	Hexlock Nut, 1/2-13
30	914-0111	Cotter Pin, 3/32:1.0
31	914-0145	Click Pin, .092 x 1.64 LG
32	714-0162	Cotter Pin, 5/32:1.25
33	753-04070	Lynch Pin, .1875
34	750-1349A	Spacer, .79 x 1.82 x .55 LG
35	914-0470	Cotter Pin, 1/8 x 1.25
36	715-0108	Spring Pin, 1/4 DIA x 1.00 LG
37	917-04074	Deck Gear
38	921-04041	Water Nozzle Adaptor
39	731-0335	Deck Roller
40	731-05679	Front Roller

Ref. No.	Part No.	Description
41	732-04652	Compression Spring, .535 OD x 1.751 LG
42	732-04692	Extension Spring, .85 OD x 5.915 LG
43	732-0934	Extension Spring, 1.15 OD x 5.99 LG
44	734-04155	Deck Wheel
45	936-0119	Lock Washer, 5/16
46	936-0179	Flat Washer, .531 x 1.25 x .100
47	736-0225	Lock Washer, 5/8
48	936-0300	Flat Washer, .406 x .875 x .059
49	936-0921	Lock Washer, 1/2
50	737-04003D	Deck Water Nozzle
51	738-0295	Shaft, .750 x .4712
52	738-1229A	Shldr. Screw, .625 x 2.50:1/2-13
53	938-3056	Shoulder Bolt, .496 x 2.50:3/8-16
54	942-0677B	Blade
55	747-04938	Belt Keeper Rod
56	747-05141A	Deck Lift Rod
57	712-04064	Flangelock Nut, 1/4-20
58	747-05462	Anti-sway Rod
59	747-1116	Deck Release Handle Rod
60	950-0212	Spacer, .82 ID x 1.00 OD x .53
61	750-04597	Spacer, .380 x .900 x 1.313
62	750-0933	Spacer, .385 ID x .88 x .64
63	954-04083	V Belt
64	756-04129B	Idler Pulley, 4.25"DIA
65	783-04013A-0637	Pulley Stabilizer Bracket
66	783-04690B-0637	Deck Skirt
67	783-04726-0637	Stationary Idler Bracket
68	631-04070A	Chute Assembly
69	783-1470A-4028	RH Spindle Cover
70	783-1471-4028	LH Spindle Cover
71	711-04565	Hinge Pin
72	732-04372	Torsion Spring, .44 ID x 2.0
73	783-05030	Chute Bracket
74	756-04213	Deck Pulley
75	937-3000	Lube Fitting
76	738-1197	Spindle Shaft, 6.95 LG
77	941-0919	Ball Bearing, .787 ID x 1.85 OD x .551
78	748-0160A	Spacer, .790 ID x 1.25 OD x .175
79	750-1000	Spacer, .80 x 1.10 x 1.322 LG

LABELS

777I23379




777D14493



777I23356



777I23323



777X43688



777D14480




777S30503




777X44429



777I22265



777S33183



777S33660

777I23357



777D14486



777D14487

