










Component	Part Number and Description	
	759-3336	Spark Plug (Champion RC12YC)
	BS-793569	Air Filter Cartridge
	BS-492932S	Oil Filter
	BS-394358S	Fuel Filter
	954-04060B	Drive Belt (Mower Deck)
	942-04308 942-04308-X	2-in-1 Deck Blade Extreme Deck Blade
	918-04822A	Deck Spindle

Component	Part Number and Description
	734-04155 Deck Wheel (Front)
	925-1707D Battery
	751-12182 Fuel Tank Cap
	746-04364 Throttle Cable
	625-05002 Ignition Key
	631-04288 Discharge Chute Assembly

The following attachments and accessories are compatible for the Troy-bilt 2142 Lawn Tractor. See the retailer from which you purchased your tractor, an authorized Troy-bilt Service Dealer or phone (800) 828-5500 for information regarding price and availability.



CAUTION: This Troy-Bilt Lawn Tractor is NOT designed for use with any type of ground-engaging attachments (e.g. tiller or plow). Use of this type of equipment WILL void the tractor's warranty.

Model Number	Description
19A30006100	Mulch Plug, 42"
OEM-190-032	Snow Thrower, 42"
19A30003OEM	Twin Bagger, 42" Twin Blade
OEM-190-215	Wheel Weights
OEM-190-679	Bumper
OEM-190-833	46" Snow Blade
OEM-190-658	Tire Chains, 20" x 8"
OEM-19A-218	Rear Bracket with Weight Kit
490-850-0005	Blade Removal Tool
490-850-0008	Oil Siphon
490-900-M060	42 lb Rear Suit Case Weight Kit With Bracket
490-900-M059	42 Lb Rear Suit Case Weight
490-241-0023	Tire Chains 20X8
490-290-0013	Tractor Cover
OEM-190-607	Sun Shade
490-900-0045	Oil Filter Wrench
SPW-136	Spark Plug Wrench
490-325-0022	16 Oz Tire & Tube Sealant By Tire Science
490-325-0020	32 Oz Tire & Tube Sealant By Tire Science
490-850-0014	Tire Aid Deluxe Tire Plug Kit By Tire Science
490-328-0014	15" Tractor Tube With Sealant By Tire Science
490-328-0016	18" & 20" Tractor Tube With Sealant By Tire Science
22216	32 oz STA-BIL


Painted Parts

When ordering painted service parts, a four digit color suffix must be added to the part number (e.g. 783-XXXXX-0637). Please refer to the table below for current color codes:


0637	Black
0709	Dark Green (Bolens, Mastercraft, Yard-Man Domestic)
0662	Oyster Gray (MTD Gold)
0638	Red (Yard Machines, Huskee, Troy-Bilt, MTD)
0691	Black Jack (MTD Gold, MasterCut)
0674	Yellow (Yard-Man)

0650	Metallic Red (White Outdoor)
0665	Dark Green (Yard-Man Export)
0629	Silver Flake (MTD Platinum)
04038	Day Orange (Daedong)
04015	Fire Red (Massey Ferguson)
04033	Flint Mica (Troy-Bilt XP)

Electrical Schematic (Man. PTO)




Manual PTO and Battery



Ref.	Part Number	Description
1	647-04151	Handle Ass'y, PTO
2	710-04379A	Hex Screw, 7/16-20, 3.50, Gr5, Lock
3	710-0599	Screw, Self-tapping, 1/4-20, 0.50
4	714-04040	Pin, Cotter, Bow-Tie 72
5	720-04049A	Grip, Handle, 3/8
6	732-0932	Spring, Ext, .38 Dia x 5.6
7	747-05171A	Belt Keeper Rod
8	736-0322	Washer, Flat, .450 x 1.250 x .164
9	738-04237A	Screw, Shoulder, #10-32, .500
10	741-04119A	Bearing, PTO
11	946-04618B	Cable, Engag, Deck
12	750-0956	Spacer, 1.010 x 1.400 x .825
13	956-04067A	Pulley, Engine, 3.56 x 6.12 Dia.
14	683-04469C	Frame Ass'y, Lower
15	710-04484	Screw, Self-tapping, 5/16-18, .750,
16	710-3005	Hex Screw, 3/8-16, 1.25, Gr5, Std
17	712-04065	Nut, Flange Lock, 3/8-16, Grf,
18	738-04058	Spacer, Shoulder, .38 x 1.0 x .70
19	747-04121A	Rod, Battery
20	783-0349	Tray, Battery
21	783-06089	Bracket, Frame, Seat
22	925-1707D	Battery
23	710-04666	Hex Flange Screw, 1/4-20, .75, Gr5
24	712-0271	Nut, Sems, 1/4-20
25	710-0653	Screw, Self-tapping, 1/4-20, 0.375,
26	712-04064	Nut, Flange Lock, 1/4-20, Grf,
27	725-04232	Switch, 3-Pole
28	725-04363	Switch, Interlock
29	725-04439	Solenoid, 12V
30	725-04807	Switch, Plunger, Snap Mount
—	925-04105	Wire Harness, Main

Steering and Axle




Steering and Axle

Ref.	Part Number	Description
1	710-04095	Hex Screw, 3/8-16, 1.00, Gr5, Spec
2	710-0514	Hex Screw, 3/8-16, 1.00, Gr5, Std
3	710-0643	Hex Screw, 5/16-18, 1.00, Gr5, Lock
4	711-04998	Link, Drag LH
5	711-04999	Link, Drag RH
6	912-0240	Nut, Jam, 7/16-20, Gr2
7	712-04065	Nut, Flange Lock, 3/8-16, Grf,
8	712-0459	Nut, Flange Lock, 7/16-20, Grb, Lock
9	712-3004A	Nut, Flange Lock, 5/16-18, Gr5, Sd Lk
10	717-1550F	Gear, Steering, 11/90 Ratio
11	717-1554	Gear, Pinion, Steering
12	923-0448A	Ball Joint, 7/16-20, Lock
13	936-3004	Washer, Flat, .406 x .875 x .105
14	736-3084	Washer, Flat, .51 x 1.12 x .06
15	938-04034	Axle Ass'y, RH .750 Dia (46" Deck)
—	638-04032	Axle Ass'y, RH .750 Dia (42" Deck)
16	738-04263	Shaft, Steering, .625 OD x 24.25
17	738-04363	Spacer, Shoulder, .385 x 1.25 x .3025
18	738-04364B	Spacer, .38 x 1.375, Special, 46" Only
19	741-04237B	Bearing, Flange, Hex 5/8 Pm
20	783-06043	Bracket, Support, Steering
21	710-04484	Screw, Self-tapping, 5/16-18, .750,

Ref.	Part Number	Description
22	710-0395	Hex Screw, 5/16-18, 2.25, Gr5, Std
23	710-0859	Hex Screw, 3/8-16, 2.50, Gr5, Std
24	710-3180	Hex Screw, 5/16-18, 1.75, Gr5, Std
25	912-0214	Nut, Hex Lock, 3/8-24, Grb
26	712-04063	Nut, Flange Lock, 5/16-18, Grf
27	714-0162	Pin, Cotter, 5/32, 1.25
28	719-04413A	Axle, Pivot Bar, Cast
29	748-04278	Steering, Block
30	748-04068	Spacer, .71 ID x .125 OD x .56
31	750-05280	Spacer, .385 x 1.00 x 1.5075
32	631-04008A	Steering Wheel, Soft Grip
33	731-04681	Cap, Troy-Bilt
34	634-04406-0911	Wheel Assembly
35	734-1731-0901	Tire, 15 x 6 x 6
36	634-04405-0662	Rim Assembly, Plastic Bearing
37	934-0255	Tubeless Air Valve
38	741-0516B	Flange Bearing, .760 x 1.00 x 1.20
39	741-0990B	Flange Bearing, .760 ID
40	731-08049	Cap, Bumper
41	736-04228A	Washer, Flat, .350 x 1.559 x .062
42	638-04035P	Axle Ass'y, LH .750 Dia (46" Deck)
—	638-04033	Axle Ass'y, LH .750 Dia (42" Deck)


Seat and Fender



Ref.	Part Number	Description
1	683-04223	Shaft Ass'y, Lift
2	712-04063	Nut, Flange Lock, 5/16-18, Grf
3	712-04065	Nut, Flange Lock, 3/8-16, Grf
4	914-0104	Pin, Cotter, .072 Dia. x 1.13
5	714-04040	Pin, Cotter, Bow-Tie 72, 46"
—	914-0111	Bow-Tie Cotter Pin, 42"
6	716-0106A	Ring, E Type, .625 Dia. Shaft
7	720-0311	Grip, Handle, 1/2
8	732-0874	Spring, Torsion
9	736-0105	Washer, Spring, .401 x .870 x .063
10	738-0138A	Screw, Shoulder, .437 x .470, 5/16-18
11	938-0380	Bolt, Shoulder, .500, 3/8-16, 46"
—	738-04130	Shoulder Bolt, .625 x .175:3/8-16, 42"
12	941-0225	Bearing, Hex Flange
13	746-0968	Cable, Lift, 16.16
14	747-04962A	Handle, Lift,
15	756-04331	Pulley, Roller, Cable
16	783-05546A	Lift Link, 46"
—	783-04494C	Lift Arm, RH, 42"
—	783-04711C	Lift Arm, LH, 42"
17	710-04484	Screw, Self-tapping, 5/16-18, .750,
18	710-1260A	Taptite Screw, 5/16-18:.750
19	710-0599	Screw, Self-tapping, 1/4-20, 0.500,

Ref.	Part Number	Description
20	710-0895	Screw, HL, 1/4-15, 0.750,
21	731-06795	Cover, Lift Lever
22	731-1993A	Cover w/ Cup Holder
23	925-05013	Switch, Seat
24	736-3078	Washer, Flat .344 x 1.00 x .063
25	783-06443	Bracket, Lift, Man PTO, 6 Pos
26	783-06259	Fender
27	712-3004A	Nut, Flange Lock, 5/16-18, Gr5, Sd Lk
28	710-04482	Hex Head Flange, 3/8-16:.875
29	725-0157	Cable, Tie, 3/16 x .05 x 7.4
30	732-04849	Spring, Compr, 1.50 x 3.90 x .200
31	938-0296	Screw, Shoulder, .437 x .268, 5/16-18
32	783-06049	Bracket, Mounting, Seat
33	783-06088	Bracket, Pivot, Seat
34	732-04563	Comp. Spring, .68 x 1.065 x .055
35	783-06448	Clip, Retaining, Switch
36	726-3046	Clip, Ratchet, .250 Dia
37	735-04138	Pad, Foot, LH
38	735-04158	Pad, Foot, RH
39	757-04086	Seat, High Back
—	757-04081	Seat, Med Back, Black
40	783-06050	Seat Adjustment Lever

Drive and Rear Wheels




Drive and Rear Wheels

Ref.	Part Number	Description
1	918-0319	Hydro Transmission
2	710-0176	Hex Screw, 5/16-18:2.75
3	710-0227	Screw, #8-18:0.500
4	710-0351	Screw, #10-16:0.500
5	710-04484	Taptite Screw, 5/16-18:.750
6	710-0653	Taptite Screw, 1/4-20:0.375
7	710-1007	Screw, Sems, 3/8-16, 1.500
8	710-1325	Taptite Screw, 1/4-20:1.625
9	710-3011	Hex Screw, 3/8-16:2.25
10	912-0240	Jam Nut, 7/16-20
11	912-0346	Nut, Jamlock, 1/2-20
12	712-04063	Flangelock Nut, 5/16-18
13	912-0431	Flangelock Nut, 3/8-16
14	914-0111	Cotter Pin, 3/32:1.0
15	725-0157	Cable Tie, 3/16 X .05 X 7.4
16	725-04791A	Jumper Harness
17	725-1644	Short Spring Switch
18	926-0154	Push Mount Cable Tie 7.5 LG
19	926-0320	Insulator Nut Plate
20	731-05299A	Sleeve, .765 ID x 1.500 LG
21	731-06098	Hydro Fan
22	932-0209	Extension Spring, .48 OD X 2.03
23	732-04606	Extension Spring, .500 DIA X 12.6 LG
24	732-04624	Extension Spring, 1.00 DIA X 4.75
25	732-0716D	Extension Spring, .59 OD X 4.00 LG
26	732-0729	Wire Ring
27	732-3118	Extension Spring, .375 OD X 1.44 LG
28	936-0264	Washer, Flat, .330 X .630 X .0635
29	736-04263	Washer, Lock, TRANS HYDRO
30	936-3008	Washer, Flat, .344 X .750 X .120
31	736-3010	Washer, Flat, .407X.812X.135:HT
32	647-04152D	Brake Control Assembly
33	683-04488	Hydro Pedal Bracket Assembly
34	738-04420	Spacer, Shoulder, 1.375 X .380 X .183
35	747-04139	Rod, Brake, Hydro
36	747-04957A	Rod, Transmission, Footpedal Bypass
37	747-04979	Rod, Control, Hydro

Ref.	Part Number	Description
38	747-04991	Rod, Hydro Bypass
39	750-04456	Spacer, .260 X .372 X 1.420 LG
40	954-04207	Belt, V Type, Poly
41	756-04224	Pulley, Idler, Flat 2.75 OD
42	756-04308	Pulley, Input, 4.13 DIA
43	756-04325	Pulley, Idler, V-Type x 3.06
44	783-06027B	Bracket, Idler, Center Double
45	783-06133	Bracket, Mount, Hydro
46	783-06260	Bracket, Support, Belt Disengage
47	783-1019B	Switch Actuator Bracket
48	710-0604A	Taptite Screw, 5/16-18:0.625
49	711-05068A	Clevis Pin, 5/16 x 3.985
50	712-04065	Flangelock Nut, 3/8-16
51	714-04040	Bow-Tie Cotter Pin
52	719-0584B	Control Pedal
53	726-0214	Push Cap
54	732-04587	Extension Spring, .63 DIA x 4.95 LG
55	735-04136	Brake Pedal Pad
56	738-0430	Scr, Shldr, .50 x .685 3/8-16
57	938-0380	Shoulder Bolt, .500 x .270:3/8-16
58	741-0495	Flange Bearing, .630 ID x .695 OD x .60
59	748-04203	Cruise Latch
60	783-05914	Pedal Support Bracket
61	783-05940	Pedal Support Bracket, 5/8
62	783-06103A	Brake Pedal Bracket
63	731-2290A	Hub Cap
64	736-0430	Washer, Flat, .350 x 1.59 x .062
65	634-0104-0911	Wheel Assembly
66	710-05339	Screw, 5/16-24 x .750
67	634-04369-0662	Rim Assembly, Plastic Bead, 46"
68	934-0255	Tubeless Air Valve
69	734-1730-0901	Tire, 20 x 8 x 8
70	941-0490	Axle Hub
71	936-0344	Washer, Flat, .385 x 1.0 x .030
72	747-05444A	Belt Keeper Rod
73	710-1026	Screw, Self Tapping, 1/4-20 x 1.75


42" Deck



Ref.	Part Number	Description
1	918-04822A	Spindle Ass'y, Pulley, 6.3 Dia
2	683-0254B	Bracket Ass'y, Deck, Hanger LH
3	983-04511	Brake Ass'y, Deck, 42/46
4	983-04525	Brake Ass'y, Deck, 46"
5	983-04572A	Deck Ass'y, Offset, 42" W/O wheel
6	710-04484	Screw, Self-tapping, 5/16-18, .750
7	710-3005	Hex Screw, 3/8-16, 1.25, Gr5, Std
8	710-0528	Hex Screw, 5/16-18, 1.25, Gr5, Std
9	710-0599	Screw, Self-tapping, 1/4-20, 0.500
10	936-3039	Flat Washer, .406 x 1.500 x .105
11	710-0642	Screw, Self-tapping, 1/4-20, .750
12	710-3144	Hex Screw, 3/8-16, 2.00, Gr5, Std
13	710-3178	Bolt, Carriage, 3/8-16, 0.75, Gr1
14	712-0229	Nut, Push, 3/8
15	712-04063	Nut, Flange Lock, 5/16-18, Grf
16	712-04065	Nut, Flange Lock, 3/8-16, Grf
17	712-0417A	Nut, Flange, 5/8-18
18	712-04243	Nut, Lock, 1/2-13
19	731-07487	Deck Wash Nozzle
20	753-04070	Lynch Pin, .1875
21	783-06074A	Chute Bracket
22	917-04074	Gear, Deck, Adjustment
23	932-0384	Spring, Extension, .62 Dia x 6.12
24	783-07236	Pulley Cap
25	732-04840	Spring, Torsion, .992 ID X 1.17 OD
26	734-04155	Wheel, Deck, 5.0 Dia Ball
27	936-0119	Washer, Lock, 5/16, Regular Duty
28	941-0919A	Bearing, Ball, .787id x 1.85 Odx.551
29	936-0344	Washer, Flat, .385 X 1.0 X .030
30	710-0376	Hex Cap Screw, 5/16-18 x 1.00
31	720-05010	Cap, .290 x .500

Ref.	Part Number	Description
32	736-0262	Washer, Flat, .385 x .870 x .092
33	750-04936	Spacer, .792 x 1.060 x 1.860
34	783-06643	Bracket, Support, Stationary Idler
35	736-0317	Bell Washer, .63 X 1.25 X .18
36	738-04162C	Spacer, Shoulder, .8840 x .190
37	748-04272	Shoulder Spacer
38	938-3056	Bolt, Shoulder, .496 x 2.50, 3/8-16
39	942-04308	Blade, Cut, 21.23" 2-In-1, Econ
40	747-05323	Rod, Keepr, Belt 42 Idler
41	747-04944B	Deck Lift Rod
42	747-05105B	Rod, Control, Brake 42"
43	631-04288	Chut Assembly, 42" Deck
44	783-06424A	Deck Belt Cover, 42
45	936-0351	Washer, Flat, .760 ldx1.50 OD
46	738-1186A	Shift, Spindle, 6.11.
47	954-04060B	Belt, V Type, A Sec X 96.5
48	756-04129B	Pulley, Idler, 4.25"Dia
49	711-04847B	Pin, Hinge, Dia .3125 x 7.96
50	956-1227	Pulley, Deck, 6.3 Dia
51	732-04372	Spring, Torsion, .44 I.D. X 2.0
52	783-05946	Pivot idler Bracket, 46
53	783-06243	Bracket, Cable, Deck Engage
54	783-06368A	Bracket, Guard, Belt, 4.25 Pulley
55	921-04041	Water Nozzle Adapter
56	738-04278	Shoulder Screw, 1/4-20 x 0.50
57	914-0470	Cotter Pin, 1/8 X 1.25
58	732-04652	Comp. Spring, .535 OD X 1.751 LG
59	936-0179	Flat Washer, .531 X 1.25 X .100
60	747-1116	Deck Release Handle Rod
61	783-04740	Deck Engage Cable Bracket
62	783-06632	Deck Stop


46" Deck



Ref.	Part Number	Description
1	918-04865A	Spindle Ass'y, Pulley, 6.93 Dia
2	683-0254B	Bracket Ass'y, Deck, Hanger LH
3	983-04511	Brake Ass'y, Deck
4	983-04525	Brake Ass'y, Deck
5	983-04578B	Deck Ass'y, Offset, 46" 2W
6	710-04484	Screw, Self-tapping, 5/16-18, .750,
7	710-0514	Hex Screw, 3/8-16, 1.00
8	710-0528	Hex Screw, 5/16-18, 1.25
9	710-0599	Screw, Self-tapping, 1/4-20, 0.500,
10	783-07236	Pulley Cap
11	710-0642	Screw, Self-tapping, 1/4-20, .75,
12	710-1003	Screw, #10-16:.625
13	710-3144	Hex Screw, 3/8-16, 2.00
14	710-3178	Bolt, Carriage, 3/8-16, 0.75
15	712-0229	Nut, Push, 3/8
16	712-04063	Nut, Flange Lock, 5/16-18
17	712-04065	Nut, Flange Lock, 3/8-16
18	712-0417A	Nut, Flange, 5/8-18
19	712-04243	Nut, Lock, 1/2-13
20	710-0376	Hex Cap Screw, 5/16-18 x 1.00
21	753-04070	Pin, Lynch, .1875
22	714-04040	Bow-Tie Cotter Pin, 72
23	917-04074	Gear, Deck, Adjustment
24	731-06496	Belt Cover
25	932-0384	Spring, Extension, .62 Dia x 6.12
26	732-04652	Spring, Comp, .535 OD x 1.751
27	732-04840	Spring, Torsion, .992 I.D x 1.17 O.D
28	734-04155	Wheel, Deck, 5.0 Dia Ball
29	936-0119	Washer, Lock, 5/16, Regular Duty
30	921-04041	Water Nozzle Adaptor
31	936-0179	Washer, Flat, .531 x 1.25 x .100


Ref.	Part Number	Description
32	720-05010	Cap, .290 x .500
33	941-0919A	Ball Bearing, .787 ID x 1.85 OD x .551
34	736-0262	Washer, Flat, .385 x .870 x .092
35	736-0317	Washer, Bell, .63 x 1.25 x .18
36	936-0344	Washer, Flat, .385 x 1.0 x .030
37	748-04272	Spacer, Shoulder, .50 x .145
38	750-04936	Spacer, .792 x 1.060 x 1.860
39	738-04162C	Spacer, Shoulder, .8840 x .190
40	711-04847B	Hinge Pin
41	938-3056	Bolt, Shoulder, .496 x 2.50, 3/8-16
42	942-04290	Blade
43	747-05323	Rod, Keeper, Belt
44	747-04944B	Rod, Lift, Deck, Frt, 13.7
45	747-05011	Rod, Keeper, Belt
46	747-05052A	Rod, Control, Brake
47	756-04356	Pulley, Deck, 6.93 Dia
48	747-1116	Rod, Handle, Deck Release
49	731-07487	Deck Wash Nozzle
50	738-04278	Shoulder Screw, 1/4-20 x 0.50
51	751B221535	Clamp, Casing
52	954-04219	Belt, V-Type
53	756-04129B	Pulley, Idler, 4.25"Dia
54	937-3000	Fitting, 3/16, Lnc#70, Drive Lube
55	738-1186A	Shift, Spindle, 6.11.
56	783-05946	Bracket, Idler, Pivot
57	783-06243	Bracket, Cable, Deck Engage
58	783-06368A	Bracket, Guard, Belt, 4.25 Pulley
59	783-06643	Bracket, Support, Deck Stationary Idler
60	783-06074A	Bracket, Chute
61	631-04288	Chute Ass'y, Deflector
62	732-04372	Torsion Spring, .44 ID x 2.0

Hood and Dash, K Style




Ref.	Part Number	Description
1	931-04663	Dash Assenbly
2	710-0599	Taptite Screw ,1/4-20:0.500
3	710-04484	Taptite Screw ,5/16-18:.750
4	710-0895	Hi-Lo Screw, 1/4-15:0.750
5	710-1017	Screw, 1/4-14:0.625
6	710-1611B	Taptite Screw ,5/16-18:0.750
7	714-04040	Bow Tie Cotter Pin
8	731-06639	Dash Lever
9	731-06642	Cruise Cover
10	931-06212	Plenum
11	735-0271A	Bumper
12	747-05008	Control Rod
13	747-1196	Lever
14	783-04285F	RH Support Plate
15	783-04323F	LH Support Plate
16	710-1652	Tap Screw, 1/4-20, 0.625
17	683-04441A	Hood Assembly
18	710-05108	Screw, 1/4 DIA:.750
19	731-06095	LH Lens
20	731-06096	RH Lens
21	738-04091A	Shoulder Screw, .43 x .29
22	747-04161	LH Tank Support Rod
23	747-04946	RH Tank Support Rod
24	951-04309	Fuel Tank
25	951-12182	Fuel Cap
26	925-0963	Lamp
27	925-1649	Lamp Socket
28	731-1999	Choke Plug
29	946-04542	Throttle/Choke Cable, 46.5"
—	746-04364	Throttle/Choke Cable, 25"
30	925-04227B	Key Switch Module
31	925-04036C	Hour Meter
32	712-04064	Flangelock Nut, 1/4-20
33	625-05002	Key, Assembly
34	631-04272	Grill
35	710-0751	Hex Screw, 1/4-20:.620
—	726-04096	Choke Hole Plug (Not Shown)

Engine Accessories, Single



Ref.	Part Number	Description
1	683-04549	Muffler Shield Assembly
2	710-0227	Screw, Indented Washer, #8-18:0.500
3	710-04683A	Taptite Screw, 3/8-16:1.000
4	710-0642	Taptite Screw, 1/4-20:0.750, Briggs
5	710-1314A	Socket Head Screw, 5/16-18:0.750
6	BS-692236	Gasket, Exhaust, Briggs
7	712-0271	Sems Nut, 1/4-20
8	751-3141-14	Extension Hose, Oil Drain
9	725-0157	Cable Tie, 3/16 x .05 x 7.4
10	726-0205	Hose Clamp, .490 DIA.
11	751-11053A	Long Muffler Deflector
12	751-10448D	Muffler, Briggs
13	951-10517A	Oil Drain
14	751-10349	Fuel Hose



Ref.	Part Number	Description
1	683-04549	Shield Ass'y, Muffler
2	710-0227	Screw, Ab, #8-18, 0.500,
3	710-04683A	Screw, Self-tapping, 3/8-16, 1.000,
4	710-0599	Screw, Self-tapping, 1/4-20, 0.500,
5	710-1314A	Screw, Socket Head, 5/16-18, .750
6	712-0271	Nut, Sems, 1/4-20
7	751-3141-14	Hose, Extension, Oil Drain
8	721-0460	Gasket, Exhaust, Briggs
9	725-0157	Cable, Tie, 3/16 x .05 x 7.4
10	726-0205	Clamp, Hose, .490 Dia.
11	951-10517A	Drain, Oil
12	751-10542A	Muffler, Briggs Twin
13	751-12089-28	Hose, Vent
14	751-10349-28	Hose, Fuel, Low Permeation, 1/4
15	751-11053A	Deflector, Muffler, Long