


Model 844



Model 844

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	731-1433	Hood Assy.	43	783-0351	Rear Fender
2	738-0141	Sold. Bolt.437" Via. x.35"	44	17223	Light Bracket
3	726-0233	Bolt Retainer 1/4" I.D.	45	710-0167	Carriage Bolt 1/4-20 x .50" Lg.*
4	17762	Hood Reinforcement Spacer	46	736-0278	Fl-Wash. .328" I.D. x .68" O.D.
5	783-0462	Switch Retainer Brat. ††	48	725-1657A	Safety Switch †
6	710-0351	Truss Mach. B-Tap Scr.#10 x.5" Lg.	49	712-0121	Hex Nut #10-24 Thd. †
7	17782	Retainer Clip	54	712-0158	Hex Cent. L-Nut 5/16-18 Thd.
8	783-0121	Hood Reinforcement	55	731-1434	Side Cover-R.H.
9	725-1716	PTO Switch ††		731-1435	Side Cover-L.H. (Not Shown)
11	746-0614A	Choke Control	56	710-1005	Hx Wash. Hd. B-Tap Scr.1/4 x .5" Lg.
12	17294B	Dash Support Brat.-L.H.	58	736-0222	Ext. L-Wash. 1/4" I.D.
14	783-0123	Hood Hinge	59	831-0823A	Throttle Control Box Ass'y.
15	725-0963	Lamp	62	731-0948	Lens-R.H.
16	725-1650	Twist Lock-Lamp Socket	63	725-0201	Ignition Key
17	731-0705	Headlight Housing	64	725-1717	Ignition Switch
19	731-1774	7-Speed Selector Plate	65	731-0962	Dash Panel †
21	731-1442A	Grille		731-1772	Dash Panel ††
22	17293B	Dash Support Bracket-R.H.	67	725-0925	Ammeter
23	736-0119	L-Wash. 5/16" I.D.*	68	731-0949	Lens-L.H.
24	712-3010	Hex Nut 5/16-18 The. (Or. 5)	69	725-1347	Ignition Switch Cap
25	736-0176	Fl-Wash. 1/4" I.D. x .93" O.D.	71	730-3000	Reflector (Optional)
27	710-0286	Truss Mach. Sir. 1/4-20 x.5" Lg. †	72	746-0630A	Throttle Wire 39" Lg.
28	747-0708A	Deck Control Rod †	73	725-1346	Ignition Switch Nut
29	720-0232	Knob-Blade Clutch †	74	710-0779A	Truss Mach. AB-Tap Scr.#10 x .5" Lg.
30	712-0271	Hex Seems Nut 1/4-20 The.* †	75	710-0936	Truss Hd. AB-Tap Scr. #6 x.62" Lg.
31	726-0106	Push Cap †	77	710-0642	Hex Wash. Hd. Tap Scr.1/4 x .75" Lg.
32	710-0726	Hex Wash. Had. AB-Tap Scr.5/16 x .75"	88	17406	Fender Bracket-R.H.
33	747-0513A	PTO Lever †		17407	Fender Bracket-L.H.
34	783-0460	Deck Clutch Count. Brat. †	97	726-0211	U-Nut 5/16-18 Thd.
35	710-0106	Hex Bolt 1/4-20 x 1.25" Lg.* †	105	710-0599	Hex Tap Scr. 1/4-20 x .5" Lg.
36	712-0271	Hex Seems Nut 1/4-20 The.	111	712-0185	Speed Nut 1/4-20 Thd.
37	736-0329	L-Wash. 1/4" I.D.*	114	725-1426	Solenoid
38	735-0126	Rubber Washer †	115	712-0271	Hex Sems Nut 1/4-20 Thd.
39	710-0924	Truss Mach. Sir. 1/4-20 x.75"Lg.	116	710-3013	Hex Bolt 1/4-20 x .5" Lg.*
40	736-0173	Fl-Wash. .281" I.D. x .73" †	117	720-0218	Shift Knob
41	712-0324	Hex L-Nut 1/4-20 Thd. †	118	783-0430	Shift Cover
42	710-0224	Truss Mach. Scr. #10-24 x .5"Lg. †			

† Used with Manual PTO

†† Used with Electric PTO


NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Oyster Gray, the part number to order would be 700-xxxx-062.

Yard-Man Green: 0665

Yard-Man Yellow: 0674

Powder Black: 0637


Model 844



Model 844

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	738-0963	Steering Shaft Ass'y.	41	736-0188	Fl-Wash. .76" I.D. x 1.49" O.D.
2	723-0448A	Ball Joint 7/16-20 Thd.	42	638-0007A	Front Axle Ass'y.—L.H.
3	712-0240	Hex Jam Nut 7/16-20 Thd.	43	638-0008A	Front Axle Ass'y.—R.H.
4	741-0656	Hex Flange Brg.	44	736-0267	Flat Washer 3/8 x .870
5	712-0318	Hex Jam Nut 5/8-18 Thd.	45	710-0538	Hex L-Scr. 5/16-18 x .62" Lg.
6	717-0943C	Steering Gear Segment	46	710-1257	Hex Bolt 3/8-24 x 2.50" Lg.
7	736-0317	Bell-Wash. 5/8" I.D. x 1.25" O.D.	47	712-0431	Hex L-Nut 3/8-16 Thd.*
8	712-3054	Hex Nut 3/8-24 Thd.	48	741-0516	Flange Brg. .75" I.D.
9	712-0711	Hex Jam Nut 3/8-24 Thd.	49	736-0316	Fl-Wash. .71" I.D. x 1.5" O.D.
10	736-0169	L-Wash. 3/8" I.D.*	50	634-0084	Wheel Ass'y. Comp.
11	738-0768	Steering Gear Segment Shaft		734-1727	Tire Only
12	736-0187	Fl-Wash. .64" I.D. x 1.24" O.D.	51	634-0067	Rim Only
13	748-0227A	Hex Flange Brg. .63" I.D.	53	711-0222A	Battery Hold Down Rod
14	723-3018	Ball Joint Ass'y.	54	783-0346A	Battery Plate
15	710-0599	Hx Wash. Hd. TT-Tap Scr. 1/4-20 x .5"	55	710-3015	Hex Bolt 1/4-20 x .75" Lg. (Gr. 5)
16	16888A	Deck Idler Support Brkt.	56	736-0343	Fl-Wash. .33" I.D. x 1.25" O.D.
17	748-0389	Cap	58	725-1706	Battery
19	736-0119	L-Wash. 5/16" I.D.*	59	731-1683	Battery Cover
20	712-0123	Hex Nut 5/16-24 Thd.*	60	712-3087	Wing Nut Plastic 1/4-20 Thd.
21	736-0242	Bell-Wash. .345" I.D. x .88" O.D.	61	731-0954	Steering Bellow
22	16894	Bearing Retainer Brkt.	62	783-0465	Steering Brace
23	710-0157	Hex Bolt 5/16-24 x .75" Lg.	63	738-0966	Shld. Bolt .5" Dia. x .925" Lg.
24	710-0793	Ribbed Neck Bolt 3/8-24 x .8" Lg.	64	631-0027	Steering Wheel
25	710-0604	Hex Wash. TT-Tap Scr. 5/16-18 x .62"	65	731-0955	Steering Wheel Insert
26	711-1106A	Steering Drag Link	66	710-0643	Hex L-Bolt 5/16-18 x 1" Lg.
27	783-0338	Pivot Bar Side Plate—R.H.	67	17359C	Lower Frame
28	783-0337	Pivot Bar Side Plate—L.H.	68	736-0452	Bell-Wash. .396" I.D. x 1.14" O.D.
29	710-1309	Pan Hd. Scr. 5/16-18 x .62" Lg.	70	714-0149B	Internal Cotter Pin
30	683-0061A	Steering Arm Ass'y.	71	734-1788A	Hub Cap (Yellow)
31	738-0777A	Deck Connecting Rod	72	727-0425A	Spring Clip
32	738-0527	Shld. Bolt .498" Dia. x 2.45" Lg.	73	712-3017	Hex Nut 3/8-16 Thd.
33	731-0484A	Cap	74	741-0587	Flange Bearing (Style A)
34	714-0121	Cotter Pin 5/32" Dia.	76	710-0896	Hex Wash. B-Tap Scr. 1/4 x .62" Lg.
35	736-0316	Flat Washer	77	712-0262	Hex Jam L-Nut 3/8-24 Thd.
36	741-0660	Flange Brg. .757" I.D.	78	737-0280	Grease Fitting
37	747-0753	Tie Rod (Adjustable)	79	734-0255	Air Valve
38	683-0128A	Pivot Bar Ass'y. (Steel)	94	712-0291	Hex L-Nut 1/4-20 Thd.
39	16889A	Pivot Bar Support Brkt.—Front	96	726-0341	Cap
40	16890A	Pivot Bar Support Brkt.—Rear	97	731-1291A	End Cap


Model 844



Model 844

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	720-0233	Grip	46	726-0273	Mounting Clamp
2	97282	Lift Handle Ass'y.	47	731-1789A	Hub Cap (Yellow)
3	710-0805	Hex Bolt 5/16-18 x 1.5" Lg.*	48	710-0599	Hx Wash Hd. TT-Tap Scr. 1/4-20
4	748-0274A	Lift Shaft Drive	50	714-0111	Cotter Pin .09 Dia. x 1.0" Lg.
5	741-0225	Plastic Hex Brg. 5/8" I.D.	51	714-0149B	Int. Cotter Pin
6	14231	Index Brkt. Deck Lift	52	736-0231	FI Wash. .34" I.D.x 1.12" O.D. x
7	751-3141	Oil Drain Extension Hose	53	710-0600	Hx Wash Hd AB-Tap Scr 5/16-24
8	751-3140	Oil Drain	54	712-0206	Hex Nut 1/2-13 Thd.
9	750-0956	Spacer	55	14399	Deck Link
11	736-0171	L-Wash. 7/16" I.D.	56	736-0264	FI-Wash. .344" I.D.
12	710-1002	Hex Scr. 7/16-20 x 2" Lg. (Gr. 5)	57	736-0219	Bell-Wash. .4" I.D. x 1.13" O.D.
14	983-0101	Lift Shaft Ass'y.	60	710-3008	Hex Bolt 5/16-18 x .75" Lg.*
15	13895	Lift Pivot Brkt. Ass'y.	63	736-0329	L-Wash. 1/4" I.D.*
16	17303	Adj. Deck Lift Link	65	751-0535-46	Fuel Line 46" Lg.
17	736-0192	FI-Wash. 1/2" I.D. x 1.00" O.D.	66	726-0205	Hose Clamp
18	714-0101	Hairpin Cotter	67	710-0776A	Hex AB-Tap Scr. 1/4 x .62" Lg.
19	741-0295	Nyliner 5/8" I.D. x .88" Lg.	68	17424	Fuel Tank Strap
20	738-0445	Shld. Bolt 5/8" Dia. x .96" Lg. 3/8-16	69	751-0566	Gas Tank
21	13790	Connecting Link	70	751-0531B	Gas Gauge
23	736-0322	Flat Wash. .44" I.D. x 1.25" O.D.	71	683-0108A	Seat Plate
24	756-0989	Engine Pulley	72	783-0419	Hitch Plate
25	710-0502A	Hx Wash Hd. Scr. 3/8-16 x 1.25"	73	738-0482	Hitch Rod
26	710-0726	Hex Thd. Rolling Scr. 5/16-18 x .75"	74	726-0272	Hose Clamp
27	738-0435	Running Board Rod	75	727-0425A	Spring Clip
28	726-0272	Clamp	77	683-0098	Pivot Brkt. Ass'y.—R.H.
29	734-0255	Air Valve	78	683-0097	Pivot Brkt. Ass'y.—L.H.
30	634-0132	Rear Wheel Ass'y. Comp.	79	712-3050	Lug Nut 7/16-14 Thd.
	734-1728	Tire Only	81	710-0148	Hex Hd. F-Tap Scr. #8-32 x .38" Lg.
31	634-3178	Rear Wheel Rim Only	82	710-0604	Hex TT-Tap Scr 5/16-18 x .62" Lg.
32	736-0345	Flat Washer	83	751-0650	Exhaust Tube—R.H.
33	710-0751	Hex Bolt 1/4-20 x .62" Lg.	84	751-0651	Exhaust Tube—L.H.
34	711-0817	Eye Bolt Adj. Link 1/2-13 Thd.	85	751-0616	Muffler
36	712-0158	Hex Cent. L-Nut 5/16-18 Thd.	88	721-0460	Exhaust Gasket
37	710-0237	Hex Bolt 5/16-24 x .62" Lg.*	89	751-0564	Muffler Deflector
38	736-0119	L-Wash. 5/16" I.D.*	90	710-3014	Hex Bolt 5/16-18 x .625" Lg.
39	712-0181	Hex Top L-Nut 3/8-16 Thd.	91	783-0023A	Heat Shield
40	732-0369	Compression Spring	92	17958	Muffler Mounting Brkt.
41	738-0777A	Deck Connecting Rod	93	710-0751	Hex Bolt 1/4-20 x .62" Lg.
42	712-0271	Hex Sems Nut 1/4-20 Thd.*	97	783-0626	Front Heat Shield
43	14170	Index Brkt. Reinforcement Plate	99	751-3142	Oil Drain Cap

Model 844



Model 844

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	738-0296	Shld. Bolt .437" Dia. x .162"		16921	Running Board—L.H.
3	732-0581B	Ext. Spring 5.31" Lg.	32	712-0123	Hex Nut 5/16-24 Thd.
4	736-0270	Bell Washer .265 x .75	33	726-0139	Speed Nut #10Z
5	712-3010	Hex Nut 5/16-18 Thd. (Gr. 5)	34	17360C	R.H. Side Frame
6	710-0650	Hex Wash. Hd. Tap Scr. 5/16 -18 x .7"	35	17361D	L.H. Side Frame
7	736-0159	Fl-Wash. .344" I.D.	36	17359C	Lower Frame
8	722-0160	Bushing	37	731-1052	Rubber Foot Pad
9	732-0588	Compression Spring	38	757-0372	Seat 14-1/4" High (Yellow)
11	710-0726	Hex Wash. Hd. AB-Tap Scr. 5/16 x .75"	42	746-0630A	Throttle Control Wire 39" Lg.
12	710-0227	Hx Wash. Hd. AB-Tap Scr. #8 x .5" Lg.	43	17239A	Seat Lift Bracket
14	725-1303	Spring Switch	44	725-1439	Seat Spring Switch
15	726-0279	Insulator Plate	45	726-0278	Insulator Boss Plate
18	683-0108A	Seat Plate	46	726-0320	Insulator Nut Plate
19	710-0351	Truss Mach. B-Tap Scr.	75	710-1007	Hex Bolt 3/8-16 x .5" Lg.
20	731-0405	Snap Bushing	76	710-1268	Hex Wash. Hd. B-Tap Scr. #10-16 x .38"
21	725-1713	Reverse Safety Switch	77	712-3027	Hex Flanged L-Nut 1/4-20 Thd.
22	783-0430	Shift Cover	78	720-0309A	Seat Adjustable Grip
24	712-0271	Hex Sems Nut 1/4-20	79	731-1989	Spacer
25	710-3008	Hex Bolt 5/16-18 x .75" Lg.	80	732-0499	Compression Spring 1.5" Lg.
26	17406	Fender Bracket—R.H.	81	736-0175	Spring Wash. .265" I.D. x .56" O.D.
	17407	Fender Bracket—L.H.	82	736-0204	Fl-Wash. .344" I.D. x .62" O.D.
27	736-0242	Bell-Wash. .345" I.D. x .88" O.D.	84	738-0137A	Shld. Bolt .34" x 1/4 -20 Thd.
28	710-0323	Truss Mach. Scr. 5/16-18 x .75" Lg.	85	783-0607A	Seat Pivot Bracket
29	710-1012	Rib Neck Bolt 5/16-24 x .75" Lg.	86	783-0609	Seat Lever
30	738-0435	Running Board Rod	87	783-0753	Seat Selector
31	16922	Running Board—R.H.	88	783-0611	Seat Stop


NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Oyster Gray, the part number to order would be 700-xxxx-062.

Yard-Man Green: 0665

Yard-Man Yellow: 0674

Powder Black: 0637

Model 844



Model 844


REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	17347	Deck Stabilizer	63	738-0347	Shld. Spacer .625" I.D.
2	17264	Diagonal Brace	64	748-0234	Shld. Spacer †
6	683-0052	46" Deck Ass'y. Comp.	65	750-0214	Spacer .34" I.D.
7	710-0167	Hex Bolt 1/4-20 x .50" Lg.	66	750-0470	Spacer .326" I.D. †
8	711-0792	Hinge Pin	67	754-0349	V-Belt
9	712-3006	Hex Nut 1/4-20 Thd. (Gr. 5)	68	754-0350	V-Belt
10	714-0149B	Hairpin Clip	69	756-0627	FI-Idler Pulley 3.5" O.D.
12	736-0270	Bell-Wash. 1/4" I.D.	70	756-0969	Pulley 5.0" Dia.
13	738-0392	Deck Connecting Rod	71	756-0977	Double Pulley 5.0" Dia.
22	618-0240	Spindle Ass'y. (R.H. & Center)	72	711-0701	Clevis Pin 1/4" Dia. x .53" Lg.
23	618-0241	Spindle Ass'y. (L.H.) †	73	712-0798	Hex Nut 3/8-16 Thd.
29	736-0119	Lock Wash. 5/16" I.D.*	74	714-0104	Intern. Cotter Pin 5/16" Dia.
31	742-0645	Blade 14.88" Lg. (Middle)	75	714-0145	Intern. Cotter Pin 3/8 Dia.
32	742-0644	Blade 16.28" Lg. (R.H. & L.H.)	76	734-0973	Deck Wheel 5" Dia.
35	17116	Deck Brake Brkt. Ass'y. †	77	734-3058B	Deck Wheel w/Insert 5" Dia.
36	17213	Idler Bracket	78	736-0169	L-Wash. 3/8" I.D.*
37	17258B	Belt Cover Brkt.—R.H.	79	736-0192	FI-Wash. .531" I.D.
38	783-0066A	Belt Cover—L.H.	80	738-0533	Shoulder Bolt .498" Dia. x 1.64" Lg.
39	710-1039	Hex Bolt 3/8-24 x 1.0" Lg.	81	738-3056	Shoulder Bolt
40	710-0151	Hex Bolt 3/8-24 x 2" Lg.	83	732-0602	Torsion Spring
41	710-0559	Hex Bolt 1/4-28 x 1.75" Lg. †	84	703-1693	Hinge Mtg. Brkt.
42	710-0599	Hex Wash. Hd. Tap-Scr. 1/4-20 x .5" †	85	726-0106	Push Nut
43	710-0624	Hex Bolt 5/16-24 x 1.5" Lg. (Grade 5) †	86	731-1032	Chute Ass'y. (Incl. Ref. 8, 83, 84, 85, 86)
44	710-0698	Hex Bolt 1/4-28 x 1.5" Lg.	87	750-0932A	Spacer 5/8" I.D. x 7/8" O.D.
46	711-0993	Belt Guard Pin 1/4" Dia.	88	17982	Spindle Reinforcement Plate
47	712-0117	Hex Cent. L-Nut 1/4-28 Thd. †	89	710-0650	Hex Wash. Hd. Scr. 5/16-18 x 1" Lg.
48	712-0123	Hex Nut 5/16-24 Thd.	90	710-1260	Hex Wash. Hd. Scr. 5/16-18 x .75" Lg.
49	712-0138	Hex Nut 1/4-28 Thd.	91	712-0417A	Hex Flange Nut 5/8-18 Thd.
50	712-0241	Hex Nut 3/8-24 Thd.	92	711-0242	Spacer .38" I.D.
51	712-3006	Hex Nut 1/4-20 Thd. (Gr. 5)	93	710-3013	Hex Bolt 1/4-20 x .5" Lg.
53	727-0426	Brake Cable Ass'y. †	94	783-0141	Skirt—Center
54	732-0594A	Extension Spring 6.17" Lg.	95	783-0142	Skirt—Right Hand
55	732-0429A	Extension Spring 3.97" Lg. †	96	712-0271	Hex Sems Nut 1/4-20 Thd.
56	736-0105	Bell-Wash. .38" I.D. x .88" O.D.	97	710-0703	Carriage Bolt 1/4-20 x .75
57	736-0331	Bell-Wash. .39" I.D. x 1.13" O.D.	98	16606	Retainer Hook Bracket
61	736-0329	L-Wash. 1/4" I.D.*	99	712-3027	Hex Lock Nut 1/4-20
62	736-0416	FI-Wash. 5/16" I.D. x 3" O.D. †	100	710-0751	Hex Cap Screw 1/4-20 x .620

† Not used on units with Electric P.T.O.

IMPORTANT: For a proper working machine, use Factory Approved Parts.

V-BELTS are specially designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.

Model 844



Model 844


REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	754-0280A	"V"-Belt	49	710-0726	Hex Wash. AB-Tap Scr. 5/16-18 Thd.
2	741-0495	Flange Brg.	50	710-0642	Hex Wash. TT-Tap. Scr. 1/4-20 x .75"
3	741-0419	Flange Nyliner Brg.	51	710-0599	Hex Wash. TT-Tap Scr. 1/4-20 x .5" Lg
4	741-0405	Thrust Brg.	52	710-0501	Hex Bolt 1/4-20 x 2" Lg. (Gr. 5)
5	738-0956	Shaft	53	710-0347	Hex Bolt 3/8-16 x 1.75" Lg. (Gr. 5)
6	738-0779	Shld. Bolt 3/8-24 Thd.	54	710-0189	Hex Bolt 5/16-18 x 3" Lg. (Gr. 5)
7	736-0452	Bell-Wash. .396" I.D. x 1.14" O.D.	55	683-0154	Idler Brkt. Ass'y.
8	736-0414	FI-Wash. .56" I.D. x 1.12" O.D.	56	656-0046	Trans. Pulley
9	736-0355	FI-Wash. .5" I.D. x 1" O.D.	57	650-0006	Cross Brkt. Tube Ass'y.
10	736-0329	L-Wash. 1/4" I.D.*	58	16924A	Clutch Ass'y. Mtg. Bracket
11	736-0169	L-Wash. 3/8" I.D.*	59	16980A	Brake Lockout Brkt.
12	736-0119	L-Wash. 5/16" I.D.*	60	17962	Switch Plate
13	732-0568	Ext. Spring 2.54" Lg.	61	647-0021	Pedal Ass'y.
14	732-0459	Ext. Spring 6.96" Lg.	62	710-3008	Hex Bolt 5/16-18 x .75" Lg.*
15	717-0800A	Variable Speed Pulley	63	710-0528	Hx Bolt 5/16-18 x 1.25" Lg. (Gr. 5)
16	712-3061	Hex L-Nut 3/8-24 Thd.	64	710-0589	Hex Hd. Tap Scr. #10-16 x .75" Lg.
17	712-3057	Hex Nut 5/16-24 Thd. (Gr. 5)	65	711-0832	Ferrule
18	712-3017	Hex Nut 3/8-16 Thd. (Gr. 5)	66	712-3010	Hex Nut 5/16-18 Thd.
19	712-3006	Hex Nut 1/4-20 Thd. (Gr. 5)	67	714-0111	Cotter Pin 1" Lg.
20	712-0241	Hex Nut 3/8-24 Thd.	68	714-0115	Cotter Pin 1/8" Dia. x 1" Lg.
21	711-1000	Belt Keeper	69	720-0166	Ball Knob
22	710-3005	Hex Bolt 3/8-16 x 1.25" Lg.	70	732-0395	Ext. Spring 2.51" Lg.
23	710-0157	Hex Bolt 5/16-24 x .75" Lg. (Gr. 5)	71	735-0196	Foot Pad
24	683-0115	Variable Speed Torque Brkt. Ass'y.	72	736-0117	FI-Wash. 3/8" I.D. x .62" O.D.
25	683-0114	Variable Speed Brkt.	73	741-0225	Hex Flange Bearing
26	17485	Retainer Cup	74	747-0644	Pedal Lock Rod
27	17180	Support Brkt.	75	747-0724A	Brake Link Rod
28	783-0402A	Trans. Torque Brkt.	76	747-0726A	Speed Control Link
29	756-0981	Flat Idler	77	748-0234	Shld. Spacer
30	754-0446	"V"-Belt	78	750-0214	Spacer .34" I.D. x .87" O.D.
31	747-0998	Brake Rod	79	647-0011	Speed Selector Lever Ass'y.
32	747-0981	Shift Lever	80	711-0723A	Ferrule
33	741-0491	Flange Nyliner Brg.	81	712-0429	Hex L-Nut 5/16-18 Thd.
34	738-0967	Shld. Bolt 3/8-16 Thd.	82	714-0104	Hairpin Clip
35	736-3068	FI-Wash. .5" I.D. x .875" O.D.	83	732-0429A	Ext. Spring 3.97" Lg.
36	736-0407	Bell-Wash. .45" I.D. x 1" O.D.	84	736-0117	FI-Wash. 3/8" I.D. x .62" O.D.
37	736-0275	FI-Wash. 5/16" I.D.	85	736-0141	Spr. Wash. 7/16" I.D.
38	736-0242	Bell-Wash. .345" I.D. x .88" O.D.	86	736-0192	FI-Wash. .531" I.D. x .93" O.D.
39	732-0716	Ext. Spring 4.1" Lg.	87	736-0267	FI-Wash. 3/8" I.D. x .87" O.D.
40	732-0384	Ext. Spring 6.12" Lg.	88	738-0296	Shld. Bolt .437" x .286"
42	721-0450	Boot Shifter	89	747-0729	Speed Control Link Rod
43	718-0505	Shifter Cover	90	747-0750A	Deck Control Rod
44	718-0504	Shifter Insert	91	618-0312	Transmission Complete
45	714-0111	Cotter Pin 1" Lg.	92	13833A	Parking Brake Mtg. Brkt.
46	712-0378	Hex Nut 7/16-20 Thd.	93	712-0158	Hex L-Nut 5/16-18 Thd.
47	712-3010	Hex Nut 5/16-18 Thd. (Gr. 5)	94	736-0105	Bell-Wash. .38" I.D. x .88" O.D.
48	711-1155	Ferrule	95	732-0308	Extension Spring 6.37" Lg.

Model 844

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
96	731-0483	Conduit 4" Lg.	111	714-0128	Sq. Key 1/4" x 1" Lg.†
97	712-0214	Hex Cent. L-Nut 3/8-24 Thd.	112	17418	Torque Bracket†
98	14076A	Idler Brkt. Deck Ass'y.	113	710-3008	Hex Bolt 5/16-18 x .75" Lg.†
99	756-0293A	"V"-Belt Idler	114	736-0242	Bell-Wash. .345" I.D. x .88" O.D.
100	710-0459	Hex Bolt 3/8-24 x 1.5" Lg.	115	710-0833	Hex Bolt 5/16-18 x 5.25" Lg.
101	748-0278	Spacer	116	720-0232	Knob
102	738-0129	Shld. Bolt .498" Dia. x 2.05"	117	720-0218	Shift Knob
103	732-0478	Extension Spring 6.12" Lg.	118	16888A	Deck Idler Support Brkt.
104	710-1002	Hex Bolt 7/16-20 x 2.75" Lg.	119	712-0375	Hex Cent. L-Nut 3/8-16 Thd.
	710-1049	Hex Bolt 7/16-20 x 3.75" Lg.†	120	736-0329	L-Wash. 1/4" I.D.
105	736-0171	L-Wash. 7/16" I.D.*	121	710-0501	Hex Bolt 1/4-20 x 2" Lg.
106	736-0322	Fl-Wash. .44" I.D. x 1.25" Lg.	122	710-0726	Hex AB-Tap Scr. 5/16 x .75" Lg.
	738-0785	Shld. Spacer†	123	13887A	Deck Control Pivot Brkt.
107	756-0989	Engine Pulley	124	712-3004A	Hex L-Nut 5/16-18 Thd.
	756-0990	Engine Pulley†	125	710-3083	Hex Bolt 5/16-18 x 1.375" Lg.
108	17358D	Belt Guard	126	736-0355	Fl-Wash. .58" I.D. x 1" O.D.
109	750-0956	Spacer	127	710-0604	Hex TT-Tap Scr. 5/16-18 x .625" Lg.
110	717-1434	Electric PTO†			

† Models with Electric PTO only.


Model 844



TRANSMISSION COMPLETE 618-0301A

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	618-0225	Collar Ass'y.—Reverse	20	713-0448	Chain Endless
2	618-0226	Collar Ass'y.—Hi-Lo	21	716-0131	Ext. Snap Ring
3	618-0227A	Shift Fork Ass'y.	22	717-0678	Brake Pad
4	618-0365	Wheel Hub Ass'y.	23	717-1438	Bevel Gear 41T
5	618-0284	Drive Shaft Blk. Ass'y.	24	717-1439	Spur Gear 20T
6	618-0285	Output Brg. Blk. Ass'y.	25	717-1440	Spur Gear 10T
7	618-0286	Output Brg. Blk. Ass'y. Seal	26	717-1441	Spur Gear 27T
8	618-0287	Inboard Axle Blk. Ass'y.	27	717-1442	Spur Gear 37T
9	618-0368	Differential Axle Ass'y.	28	718-0537	Shifter Brg. Blk.
10	618-0302	Inboard Axle Blk. Ass'y.	29	718-0500	Inner Axle Blk. Brg.
11	619-0034	Upper Housing Ass'y.	30	719-0385	Lower Housing
12	641-0002A	Axle Brg. Blk. Ass'y.	31	721-0468	Main Gasket
13	661-0012	Bracket Ass'y. —R.H.	32	721-0469	Axle Gasket —L.H.
14	710-0788	Hex Wash. TT-Tap Scr. 1/4-20 x 1" Lg.	33	721-0470	Axle Gasket —R.H.
15	711-1051A	Drive Shaft	34	731-1898	Shipping Plug
16	711-1216	Output Shaft —R.H.	35	736-0337	Fl-Wash. 5/8" I.D. x 1" O.D.
17	712-1329	Hex Nut 3/4-16	37	750-1033A	Spacer 1.13" I.D. x 1.38" O.D.
18	713-0446	Sprocket 9T	38	761-0215	Disc Brake
19	713-0447	Sprocket 16T	39	777X4001	Model I.D. Label (Not Shown)

Model 844



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	710-1206	Hex Wash. Hd. Scr. 1/4-20 x 2.37	18	721-0213	Seal
2	712-0273	Nylon L-Nut 5/16-24 Thd.	19	719-0337	Upper Housing
3	717-0678	Brake Puck	20	718-0300	Lockout Plate
4	717-0682	Puck Plate	21	717-1463	Bevel Gear
5	717-0772A	Brake Arm	22	716-0231	Retainer Ring
6	732-0925	Torsion Spring	23	716-0114	Retainer Ring
7	736-0371	Fl-Wash. .343" I.D. x .88" O.D.	24	736-3046	Fl-Wash. 1" I.D. x 1.8" O.D.
9	741-0343	Brake Pin	25	719-0340	Differential Housing
10	761-0207	Brake Yoke	26	717-1446	10T Miter Gear
11	761-0208	Brake Anti Rotation Brkt.	27	717-1443	Spur Gear 60T
12	711-1235	Input Shaft	28	712-3054	Hex L-Nut 3/8-24 Thd.
13	710-0788	Hex Wash. Hd. AB-Tap Scr.	29	711-1052A	Cross Shaft
14	741-0335	Needle Brg. .625" I.D.	30	710-1642	Hex Bolt 3/8-24 x 2" Lg.(Gr. 5)
15	736-0336	Fl-Wash. 5/8" I.D. x 1" O.D.	31	611-0052A	Axle Ass'y.—L.H.
16	736-0335	Thrust Wash. .635" I.D. x 1.25" O.D	32	611-0051A	Axle Ass'y.—R.H.
17	732-0614	Wire Ring			

Model 844

