


Style 0




Style 0

REF. NO.	PART NO.	DESCRIPTION
1.	783-0250	Hood
2.	738-0952A	Shld. Bolt .375" Dia. x .125" Lg.
4.	710-0924	Pan Hd. Scr. 1/4-20 x .75" Lg.
6.	712-3006	Hex Sems Nut 1/4-20 Thd.
7.	749-0812	Grille Support Rod
8.	731-1099A	Headlight Lens w/o Logo
	731-1767	Headlight Lens w/ Logo
9.	712-3027	Flange Lock Nut 1/4-20 Thd.
10.	731-1097E	Grille
13.	725-0963	Lamp
14.	725-1649	Socket
15.	710-0703	Carriage Bolt 1/4-20 x .75" Lg.
16.	710-0599	Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5"
17.	736-0173	Flat Washer .281" I.D. x .73" O.D.
18.	726-0233	Bolt Retainer 1/4" I.D.
19.	712-0185	Speed Nut 1/4-20 Thd.
20.	710-3008	Hex Bolt 5/16-18 x .75" Lg. (Gr.5)
21.	17632A	Gas Tank Support Brkt.
22.	731-1096B	Dash w/Ammeter Hole
	731-1337A	Dash w/o Ammeter Hole
23.	725-0267	Ignition Switch
24.	725-0201	Ignition Key
25.	746-0616A	Choke Control 23" Lg.
	746-0614A	Choke Control 38" Lg.
	746-0720	Choke Control 20" Lg.
	746-3021	Choke Control 29" Lg.
26.	725-0634	Light Switch**
27.	725-0925	Ammeter**
32.	710-0286	Truss Mach. Scr. 1/4-20 x .5" Lg.
35.	17871B	Fender w/Cutout
38.	710-0726	Hex Wash. Hd. AB-Tap Scr. 5/16 x .75"
41.	831-0823A	Throttle Box Assembly
42.	710-0779A	Truss Mach. AB-Tap Scr. #10 x .5" Lg.
43.	746-0776	Throttle Control Wire 18.5" Lg.
	746-0634	Throttle Control Wire 35" Lg.
	746-0638	Throttle Control Wire 22" Lg.
44.	777-9206	Grille Reflector Label
45.	710-0603	Hex Wash. Hd. B-Tap Scr. 5/16-18 x .5"
46.	17782	Choke Retainer
47.	710-0642	Hex TT-Tap Scr. 1/4-20 x .75" Lg.
48.	726-0201	U-Nut 5/16-18 Thd.
49.	736-3078	Flat Washer .34" I.D. x 1" O.D.
50.	736-0119	Lock Washer 5/16" I.D.
51.	712-3010	Hex Nut 5/16-18 Thd. (Gr.5)
—	629-0309	Headlight Harness (Not Shown)

** Optional Parts

NOTE: For faster service, obtain the standard fasteners locally. If these are not available locally, call 1(800) 800-7310 or 1(330) 220-4MTD to order by part number and size as shown here.

Style 3




Style 3

REF. NO.	PART NO.	DESCRIPTION
1.	783-0250	Hood
2.	738-0952	Shld. Bolt .375" Dia. x .125" Lg.
6.	712-0271	Hex Sems Nut 1/4-20 Thd.
9.	712-3027	Flange Lock Nut 1/4-20 Thd.
10.	783-0156A	Grille
13.	725-0963	Lamp
14.	725-1651	Socket
15.	710-0703	Carriage Bolt 1/4-20 x .75" Lg.
16.	710-0599	Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5"
17.	736-0173	Flat Washer .281" I.D. x .73" O.D.
18.	726-0233	Bolt Retainer 1/4" I.D.
19.	712-0185	Speed Nut 1/4-20 Thd.
20.	710-0376	Hex Bolt 5/16-18 x .1" Lg.
21.	17632A	Gas Tank Support Brkt.
22.	731-1096B	Dash w/Ammeter Hole
	731-1337A	Dash w/o Ammeter Hole
23.	725-0267	Ignition Switch
24.	725-0201	Ignition Key
25.	746-0616A	Choke Control 23" Lg.
	746-0614A	Choke Control 38" Lg.
	746-3021	Choke Control 29" Lg.
	746-0720	Choke Control 20" Lg.
26.	725-0634	Light Switch**
27.	725-0925	Ammeter**
32.	710-0924	Pan Hd. Scr. 1/4-20 x .75" Lg.
35.	17871B	Fender
38.	710-0726	Hex Wash. Hd. AB-Tap Scr. 5/16 x .75"
41.	831-0823A	Throttle Box Assembly
42.	710-0779A	Truss Mach. AB-Tap Scr. #10 x .5" Lg.
43.	746-0776	Throttle Control Wire 18.5" Lg.
	746-0634	Throttle Control Wire 35" Lg.
	746-0638	Throttle Control Wire 22" Lg.
45.	710-0603	Hex Wash. Hd. B-Tap Scr. 5/16-18 x .5"
46.	17782	Choke Retainer
47.	710-0642	Hex TT-Tap Scr. 1/4-20 x .75" Lg.
49.	731-1503A	Lens
50.	783-0151A	Side Panel—LH
51.	783-0150A	Side Panel—RH
71.	726-0211	U-Nut 5/16-18 Thd.
-	629-0309	Headlight Harness (Not Shown)

** Optional Parts

NOTE: For faster service, obtain the standard fasteners locally. If these are not available locally, call 1(800) 800-7310 or 1(330) 220-4MTD to order by part number and size as shown here.

Style 4




Style 4

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
9.	710-3008	Hex Bolt 5/16-18 x .75" Lg. (Gr.5)	82.	726-0233	Push Nut Fastener
10.	712-3010	Hex Nut 5/16-18 Thd. (Gr.5)	83.	736-0176	Flat Washer .27" I.D. x .948"
11.	736-0119	Lock Washer 5/16" I.D.	84.	725-0925	Ammeter
12.	736-3078	Flat Washer .34" I.D. x 1" O.D.	85.	712-0185	Speed Nut 1/4-20 Thd.
13.	712-0271	Hex Sems Nut 1/4-20 Thd.	86.	731-0961A	Dash Panel
26.	710-0726	Hex Wash. Hd. AB-Tap Scr.5/16 x .75"	87.	710-0599	Hex Wash. Hd. B-Tap Scr.1/4 x .75" Lg.
27.	736-0142	Flat Washer .218" I.D. x .5" O.D.	88.	783-0121	Hood Reinforcement
32.	731-0911	Rubber Foot Pad—LH **	89.	783-0123	Hood Hinge
	731-0912	Rubber Foot Pad—RH**	90.	17762	Hood Reinforcement Spacer
33.	710-3008	Hex Bolt 5/16-18 x .75" Lg.	92.	17223	Light Bracket
38.	710-0258	Hex Bolt 1/4-20 x .62" Lg.	93.	712-0158	Hex Lock Nut 5/16-18 Thd.
51.	712-0265	Hex Sems Nut 5/16-18 Thd.	94.	712-0107	Hex Lock Nut 1/4-20 Thd.
65.	783-0041A	Pivot Bar Brkt.	95.	712-3007	Hex Jam Nut 5/16-18 Thd.
66.	783-0350	Fender	96.	710-0874	Hex Bolt 5/16-18 x 7/8" Lg.
67.	710-0167	Carriage Bolt 1/4-20 x .62" Lg.	97.	710-0351	Truss Mach. B-Tap Scr. #10 x .5" Lg.
70.	746-0776	Throttle Wire 18.5" Lg.	98.	731-1434	Side Cover—RH - Red
	746-0634	Throttle Wire 35" Lg.		731-2256	Side Cover—RH - Black
	746-0636	Throttle Wire 28" Lg.		731-1435	Side Cover—LH (Not Shown) - Red
71.	831-0823A	Throttle Control Box Assembly		731-2255	Side Cover—LH (Not Shown) - Black
72.	725-1341B	Ignition Key	99.	731-1442A	Grille - Red
73.	725-1346	Ignition Switch Nut		731-2254	Grill - Black
74.	725-1347	Ignition Switch Cap	100.	731-0949	Lens—LH
75.	725-1396	Ignition Switch		731-0948	Lens—RH
76.	731-1433	Hood - Red	101.	725-1650	Twist Lock-Lamp Socket
	731-2253	Hood - Black	102.	725-0963	Lamp
77.	710-0779A	Truss Mach. AB-Tap Scr. #10 x .5" Lg.	103.	731-0705	Headlight Housing
78.	725-0634	Light Switch	104.	17300D	Dash Support Brkt.
79.	746-3021	Choke Control 29" Lg.	105.	17633A	Support Brkt.
	746-0614A	Choke Control 38" Lg.	106.	17782	Choke Retainer
80.	710-0642	Hex Wash. Hd. Tap Scr. 1/4 x .75" Lg.	—	629-0309	Headlight Harness (Not Shown)
81.	710-0599	Hex Tap Scr. 1/4-20 x .5" Lg.			

** Optional Parts

NOTE: For faster service, obtain the standard fasteners locally. If these are not available locally, call 1(800) 800-7310 or 1(330) 220-4MTD to order by part number and size as shown here.

Style 5




Style 5

REF. NO.	PART NO.	DESCRIPTION
1.	783-0250	Hood
2.	738-0952	Shld. Bolt .375" Dia. x .125" Lg.
3.	736-0119	Lock Washer 5/16" I.D.
4.	712-3010	Hex Nut 5/16-18 Thd.
6.	712-0271	Hex Sems Nut 1/4-20 Thd.
8.	731-1099A	Headlight Lens w/o Logo
	731-1767	Headlight Lens w/ Logo
9.	712-3027	Flange Lock Nut 1/4-20 Thd.
10.	731-1097E	Grille
11.	736-3078	Flat Washer .344" I.D. x 1" O.D.
12.	712-0267	Hex Nut 5/16-18 Thd.
13.	725-0963	Lamp
14.	725-1649	Socket
15.	710-0703	Carriage Bolt 1/4-20 x .75" Lg.
16.	710-0599	Hex Wash. Hd. TT-Tap Scr.1/4-20 x .5" Lg.
17.	736-0173	Flat Washer .281" I.D. x .73" O.D.
18.	726-0233	Bolt Retainer 1/4" I.D.
19.	712-0185	Speed Nut 1/4-20 Thd.
20.	710-3008	Hex Bolt 5/16-18 x .75" Lg. (Gr.5)
21.	17632A	Gas Tank Support Brkt.
22.	731-1096B	Dash w/Ammeter Hole
	731-1337A	Dash w/o Ammeter Hole
23.	725-0267	Ignition Switch
24.	725-0201	Ignition Key
25.	746-0616A	Choke Control 23" Lg.
	746-0614A	Choke Control 38" Lg.
	746-3021	Choke Control 29" Lg.
	746-0720	Choke Control 20" Lg.
26.	725-0634	Light Switch**
27.	725-0925	Ammeter**
32.	710-0924	Pan Hd. Scr. 1/4-20 x .75" Lg.
35.	17871B	Fender w/Cutout
38.	710-0726	Hex Wash. Hd. AB-Tap Scr.5/16 x .75" Lg.
41.	831-0823A	Throttle Box Assembly
42.	710-0779A	Truss Mach. AB-Tap Scr.#10 x .5" Lg.
43.	746-0776	Throttle Control Wire 18.5" Lg.
	746-0634	Throttle Control Wire 35"Lg.
	746-0638	Throttle Control Wire 22" Lg.
44.	777-9206	Grille Reflector Label
45.	710-0603	Hex Wash. Hd. B-Tap Scr.5/16-18 x .5" Lg.
46.	17782	Choke Retainer
47.	710-0642	Hex TT-Tap Scr. 1/4-20 x .75" Lg.
49.	783-0150A	Side Panel-RH
50.	783-0151A	Side Panel-LH
72.	710-0286	Truss Mach. Scr. 1/4-20 x .5" Lg.
73.	736-0342	Flat Washer .283" I.D. x .75" Lg.
74.	732-0835	Hood Latch **
75.	712-0272	Hex Sems Nut 10-24 Thd. **
76.	710-0473	Truss Mach. Scr. 10-24 x .5" Lg. **
—	629-0309	Headlight Harness (Not Shown)

** Optional Parts

NOTE: For faster service, obtain the standard fasteners locally. If these are not available locally, call 1(800) 800-7310 or 1(330) 220-4MTD to order by part number and size as shown here.

Style 8




Style 8

REF NO.	PART NO.	DESCRIPTION
1.	783-0551	Hood Brkt.
2.	783-0477A	Grille
3.	783-0476B	Side Panel -RH
4.	783-0475A	Side Panel - LH
5.	738-0255	Shld. Bolt .375" Dia.
6.	736-0413	Spr. Wash. .39" I.D. x .62" O.D.
7.	731-1854A	Lens
8.	726-0233	Retainer Nut
9.	726-0211	U - Nut 5/16-18 Thd
10.	725-1651	Socket
11.	712-0292	Tinn. Nut 1/4-20 Thd.
12.	712-0271	Hex Sems Nut 1/4-20 Thd.
13.	710-0924	Pan Hd. Mach. Scr. 1/4-20 x .75" Lg.
14.	710-0599	Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5"
15.	710-0751	Hex Bolt
16.	710-0376	Hex Bolt 5/16-18 x .1" Lg. (Gr.5)
17.	683-0168	Hood Pivot Brkt. Assembly
18.	783-0478A	Hood
19.	629-0309	Headlight Harness
20.	17782	Choke Retainer
21.	725-0157	Cable Tie
22.	710-0607	Hex Wash. Hd. Tap Scr. 5/16-18 x .5"
23.	725-0963	Lamp
24.	17632B	Gas Tank Support Brkt.
25.	710-0703	Carriage Bolt 1/4-20 x .75" Lg.
26.	731-1852	Dash Panel
27.	783-0350	Fender
28.	710-0726	Hex Wash. Hd. Tap Scr. 5/16 x .75"
29.	710-0286	Truss Mach. Scr. 1/4-20 x .5" Lg.
30.	725-0925	Ammeter
31.	725-0634	Light Switch
32.	725-0201	Ignition Key
33.	725-0267	Ignition Switch
34.	831-0823A	Throttle Box Assembly
35.	710-0779A	Truss Mach. AB-Tap Scr. #10 x .5"
36.	746-0776	Throttle Control Wire 18.5" Lg.
	746-0638	Throttle Control Wire 22" Lg.
	746-0634	Throttle Control Wire 35" Lg.
37.	746-0720	Choke Control 20" Lg.
	746-0616A	Choke Control 23" Lg.
	746-3021	Choke Control 29" Lg.
	746-0614A	Choke Control 38" Lg.
40.	16988A	Engine Baffle †
41.	783-0553A	Hood Brkt. Support
42.	710-0351	Pan Hd. Scr. #10-16 x .5" Lg.
43.	726-0293	Retainer Nut
44.	710-0896	Hex Wash. AB-Tap Scr. 1/4-14 x .625"
45.	710-0166	Pan Hd. Scr. 1/4-20 x 1" Lg.†
46.	731-0511-18	Trim Strip †

† B&S Twin Cylinder Engine Only.

NOTE: For faster service, obtain the standard fasteners locally. If these are not available locally, call 1(800) 800-7310 or 1(330) 220-4MTD to order by part number and size as shown here.

Style 9




Style 9

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
3.	710-0376	Hex Bolt 5/16-18 x .1" Lg.	37.	750-0218	Spacer .262" I.D. x .31"
5.	710-0603	Hex Wash. Hd. Scr. 5/16" x .5" Lg.	39.	16903A	Hood Plate
7.	710-0286	Truss Mach. Scr. 1/4-20 x .5" Lg.	40.	710-1005	Hex Wash. Hd. Tap Scr. 1/4-20 x .5" Lg.
8.	710-0726	Hex Wash. Hd. Tap Scr. 5/16 x .75" Lg.	41.	731-1048B	Dash
9.	17633A	Support Bracket	42.	725-0925	Ammeter
10.	17300D	Dash Support Bracket	43.	831-0823A	Throttle Control Box Assembly
11.	783-0350	Rear Fender	44.	710-0919	Mach. Scr. #10 x .44" Lg.
12.	730-3000	Reflector **	45.	746-0616A	Choke Control 23" Lg.
14.	16725	Side Panel—RH †		746-0614A	Choke Control 38" Lg.
	17458A	Side Panel w/Foam—RH		746-3021	Choke Control 29" Lg.
	17459A	Side Panel Assembly w/Foam—LH(Not Shown)		746-0720	Choke Control 20" Lg.
	17309B	Side Panel-LH (Not Shown)	46.	746-0776	Throttle Control Wire 18.5" Lg.
15.	710-0286	Truss Mach. Scr. 1/4-20 x .5" Lg.		746-0634	Throttle Control Wire 35" Lg.
16.	710-0166	Truss Mach. Scr. 1/4-20 x 1.0" Lg.		746-0638	Throttle Control Wire 22" Lg.
17.	710-1026	Hex Wash. TT-Tap Scr. 1/4-20 x 1.75"	47.	725-0267	Ignition Switch
18.	750-0768	Spacer .26" I.D. x 1.32"	48.	725-0201	Ignition Key
19.	710-0642	Hex Rolling Tap Scr. 1/4-20 x .75" Lg.	49.	731-1491A	Hood-Red
21.	731-0511-18	Trim Strip-18" Lg.		731-1531A	Hood-Charcoal
22.	736-0329	Lock Washer 1/4" I.D.		731-1497A	Hood-Oyster Gray
23.	712-0271	Hex Sems Nut 1/4-20 Thd.		731-1704A	Hood-Evergreen
24.	726-0201	Speed Nut 5/16" Thd.		731-1893A	Hood-Black
27.	17410	Grille Assembly	71.	749-0814	Grille Support Tube
28.	731-1044	Headlight Lens	73.	736-0607	External Lock Washer 5/16" I.D.
29.	731-0705	Headlamp Housing	76.	17782	Choke Retainer
30.	725-0963	Headlamp	77.	725-0634	Light Switch
31.	725-1650	Twist Lock Lamp Socket	78.	736-3010	Flat Washer .406" I.D. x .812" O.D.
32.	736-0242	BelLock Washer .345" I.D. x .88"	79.	710-0206	Hex Bolt 1/4-20 x .88" Lg.
33.	712-0429	Hex Lock Nut 5/16-18 Thd.	80.	783-0013	Dash Fastening Tab
34.	735-0126	Rubber Washer	81.	725-0157	Cable Tie
35.	783-0190	Hood Hinge	82.	777-8568A	Chrome Label
36.	710-0599	Hex Wash.Hd.B-Tap Scr.1/4-20 x.5"	83.	726-0211	U-Nut 5/16-18 Thd.

** Optional Parts

NOTE: For faster service, obtain the standard fasteners locally. If these are not available locally, call 1(800) 800-7310 or 1(330) 220-4MTD to order by part number and size as shown here.

Model Series 690 thru 699




Model Series 690 thru 699

REF NO.	PART NO.	DESCRIPTION	REF NO.	PART NO.	DESCRIPTION
1.	731-0220	Steering Wheel Cap	30.	747-0753	Tie Rod (Adjustable)
	731-1459A	Steering Wheel Cap (Sq.—MTD)		747-0861	Tie Rod (Non-Adjustable)
	731-1460	Steering Wheel Cap (Sq.—No logo)	31.	712-0711	Hex Jam Nut 3/8-24 Thd.
2.	710-0643	Hex Bolt 5/16-18 x 1" Lg.	32.	—	Front Axle Assembly—RH
3.	736-0242	Belleville Wash. .345" I.D.	33.	—	Wheel Assembly Comp.
4.	731-1693	Steering Wheel (3 Spoke)†	34.	—	Front Wheel Rim Only
	731-1687	Steering Wheel (3 Spoke)††	35.	—	Bearing
	631-0027	Steering Wheel (4 Spoke)	36.	736-0285	Flat Washer .635 I.D. x 1.59" O.D.
5.	731-0559A	Steering Bellow—4.5" (Style A)	37.	731-0484A	Front Wheel Hub Cap
	731-0954	Steering Bellow—9" (Style 0, 1, 3, 4, 5, 6, 8, 9)		734-1787A	Spoked Hub Cap (Yellow—Opt.)
	731-1542	Steering Bellow—3.25" (Style 7)		734-1613A	Spoked Hub Cap (Gray—Opt.)
6.	712-0240	Hex Jam Nut 7/16-20 Thd.		734-1612A	Spoked Hub Cap (Beige—Opt.)
7.	741-0587	Flange Bearing .628" I.D. x 1.36 O.D.	38.	714-0470	Cotter Pin 1/8" Dia. x 1.25"
8.	723-0448	Ball Joint 7/16-20 Thd.	39.	736-0162	Flat Washer .640" I.D. x 1.20" O.D.
9.	17198A	Retainer Plate	40.	726-0214	Push Cap 5/8" Dia. Rod
10.	738-0141	Shoulder Bolt .437 x .35 Lg. 5/16-18	42.	712-0262	Hex Jam Nut 3/8-24 Thd.
11.	710-0152	Hex Bolt 3/8-24 x 1.0" Lg. (Gr. 5)	43.	710-1309	Hex Patch Bolt 5/16-18 x .62"
13.	750-0535	Spacer .380" I.D. x .625" O.D.x	46.	748-0389	Cap
14.	736-0217	Lock Washer 3/8" I.D. (H.D.)	47.	712-0214	Hex Cent. Lock Nut 3/8-24 Thd.
15.	710-0726	Hex Wash. Hd. Self-Tap Scr.	48.	736-0169	Lock Washer 3/8" I.D.
16.	711-1107	Steering Drag Link	49.	712-0158	Hex Cent. Lock Nut 5/16-18 Thd.
17.	783-0041B	Front Pivot Brkt.	50.	736-0119	Lock Washer 5/16" I.D.
18.	738-0527	Shoulder Bolt	51.	717-0622A	Steering Gear Segment
19.	712-0431	Flanged L- Nut 3/8-16 Thd.	52.	741-0656	Hex Flg. Brg. .634 I.D.
21.	712-0411	Hex Lock Nut 5/16-24 Thd.	53.	736-0187	Flat Washer (Hardened)
22.	16481A	Steering Arm Front Axle	54.	738-0919	Steering Shaft
23.	710-0593	Hex Bolt 5/16-24 x 2.25" Lg.	57.	710-0837	Oval Hd. C.Sunk Scr. (Style A)
24.	741-0659	Hex Flg. Brg. .632 I.D.	58.	736-0271	Wave-Wash. .32" I.D. x .62" O.D.
25.	683-0128A	Pivot Bar Assembly (Steel)	59.	736-0187	Flat Washer (Hardened)
	719-0342A	Pivot Bar Assembly (Cast Iron)	60.	723-0448	Drag Link Ball Joint 7/16-20 Thd.
	—	Grease Fitting (Cast Iron)	63.	727-0425A	Spring Clip (Used w/Spoked Hub Cap)
26.	—	Front Axle Assembly—LH	64.	736-0356	Washer .39" I.D. x 1.38" O.D.
27.	712-0241	Hex Nut 3/8-24 Thd.	65.	731-1291A	Pivot Bar End Cap (If equipped)
28.	736-0169	Lock Washer 3/8" I.D.	66.	710-0459	Hex Bolt 3/8-24 x 1.5" Lg. (Gr. 5)
29.	723-3018	Ball Joint 3/8-24 Thd.	69.	731-1649	Axle Cap
			70.	731-0955	Steering Wheel Insert (If equipped)

**FRONT WHEEL CHART


† Uses Round Steering Wheel Cap
 †† Uses Square Steering Wheel Cap



NOTE: For faster service, obtain the standard fasteners locally. If these are not available locally, call 1(800) 800-7310 or 1(330) 220-4MTD to order by part number and size as shown here.

Description	15" x 6" (Round Shoulder)	15" x 6" (Square Shoulder)
Wheel Assembly Comp.	634-0056A	634-0105
Tire Only	734-0864	734-1731
Rim Only	634-0172	634-0024
Bearing	741-0487A	741-0487A
	741-0706 (in kit	753-0845)
Air Valve	734-0255	734-0255
Grease Fitting (If equipped)	737-0211A	737-0211A
Grease Plug	737-0212A	737-0212A
Front Axle Assembly—LH	683-0127	683-0127
Front Axle Assembly—RH	683-0126	683-0126
Front Axle Assembly—LH (46" Deck)	683-0124	683-0124
Front Axle Assembly—RH (46" Deck)	683-0125	683-0125


Model Series 690 thru 699



Model Series 690 thru 699

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1.	710-0604A	Hex Washer Screw 5/16-18 x .625	44.	783-0093	Offset Scissors
2.	712-3004A	Flange Lock Nut 5/16-18	45.	747-0887	Neutral Return Rod
3.	17840	Transaxle Mounting Bracket	46.	738-1170	Friction Stud
4.	731-1734	Hydro Bracket Indicator	47.	750-0918	Spacer
5.	710-0924	Machine Screw 1/4-20 x .75	48.	761-0196	Friction Washer .385 ID x 1.13 OD
6.	736-0329	Lock Washer 1/4	49.	736-0219	Bell Washer .39 ID x 1.13 OD
7.	710-0227	Hex Washer Screw #8-18 x .50	50.	736-3008	Flat Washer .344 ID x .750 OD
8.	726-0320	Insulator Nut Plate	51.	710-0859	Hex Cap Screw 3/8-16 x 2.50
9.	725-1713	Spring Switch	52.	756-0981A	Flat Idler Pulley
10.	712-3006	Hex Nut 1/4-20	53.	712-0431	Flange Lock Nut 3/8-16
11.	725-1399	Wire Assembly	54.	710-0520	Hex Cap Screw 3/8-16 x 1.5
12.	647-0008A	Control Speed Lever Assembly	55.	738-0347	Shoulder Spacer .625 OD
13.	783-0122	Speed Bracket Control	56.	783-1313	Flat Idler Bracket
14.	712-3010	Hex Nut 5/16-18	57.	783-0095	Return Neutral Mounting Bracket
15.	732-0433	Spring Extension	58.	783-1315	Idler Bracket
16.	712-0241	Hex Nut 3/8-24	59.	710-0642	Hex Washer Screw 1/4-20 x .75
17.	736-0169	Lock Washer 3/8	60.	756-0116	Idler Pulley
18.	714-0104	Cotter Pin	61.	754-0338	Belt
19.	738-0296	Shoulder Screw	62.	720-0166	Ball Knob
20.	736-0141	Spring Washer 7/16 x .740	63.	783-1312	Hydro Trans Bracket
21.	736-0119	Lock Washer 5/16	64.	732-0716	Extension Spring .59 OD x 4.0
22.	748-0234	Shoulder Spacer	65.	747-0608A	Lockout Brake Rod
23.	710-3008	Hex Cap Screw 5/16-18 x .75	66.	747-1274	Brake Rod 22.25 Lg
24.	747-1276	Engage Rod 12.75 Lg	67.	17755A	Hydro Bracket
25.	711-0832	Ferrule	68.	710-0599	Hex Washer Screw 1/4-20 x .5
26.	736-0413	Spring Washer	69.	735-0196	Foot Pad
27.	736-0185	Flat Washer .375 ID x .738 OD	70.	747-1216	Stop Rod 3/8
28.	783-1314	Return Neutral Bracket	71.	683-0123	Brake Clutch Pedal Assembly
29.	712-3027	Hex Lock Nut 1/4-20	72.	710-1238	Hex Washer Screw 5/16-18 x .875
30.	783-0096	Neutral Return Lever	73.	712-0265	Nut 5/16-18
31.	748-0368	Shoulder Spacer	74.	736-0140	Flat Washer .385 ID x .62 OD
32.	712-0431	Flange Lock Nut 3/8-16	75.	714-0470	Cotter Pin
33.	712-0273	Hex Lock Nut 5/16-24	76.	683-0049	Lockout Bracket Assembly
34.	732-0727	Neutral Return Spring	77.	736-0406	Flat Washer .442 ID x 1.38 OD
35.	731-1449A	Blade Fan	78.	738-0296	Shoulder Screw .437 x .286 Lg
36.	747-1277	Hydro Bypass Rod	79.	732-0728	Extension Spring 4.31 Lg
37.	17994	Transaxle Spring Retainer Bracket	80.	714-0111	Cotter Pin
38.	710-0176	Hex Cap Screw 5/16-18 x 2.75	81.	736-3008	Flat Washer .344 ID x .750 OD
39.	783-0092	Flat Scissor	82.	750-0802	Spacer .640 ID x .760 OD
40.	710-0299	Hex Cap Screw 1/4-28 x 1.0	83.	17860	Pedal Mounting Bracket
41.	736-0159	5/16 Washer	84.	736-0256	Flat Washer .635 ID x .930 OD
42.	750-0808	Spacer .340 ID x .560 OD	85.	710-1012	Bolt 5/16-24
43.	736-0414	Flat Washer .570 ID x 1.20 OD	86.	732-0384	Extension Spring .62 Dia x 6.12 Lg

Model Series 690 thru 699




REF NO.	PART NO.	DESCRIPTION
1.	618-0587	Transmission Comp.

Description	20" x 8" (Round Shoulder)	20" x 8" (Square Shoulder)
Wheel Assembly Comp.	734-1675	634-0104
Tire Only	734-1596	734-1730
Rim Only	634-0070	634-0070

Round Shoulder	Square Shoulder
	


Model Series 690 thru 699



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1.	783-0103	Connecting Rod	27.	710-3007	Hex Wash. Hd. Tap Scr.
2.	683-0029A	Pivot Link Assembly—LH	28.	14802A	Link Deck Lift Assembly
3.	683-0028A	Pivot Link Assembly.—RH	29.	711-0723A	Adj. Ferrule 3/8-24 Thd.
4.	17710	Deck Hanger Link Assembly	30.	17712	Adj. Deck Lift Link
5.	14800A	Deck Hanger Link Assembly	31.	712-3066	Hex Nut 1/2-20 Thd.
6.	14804A	Deck Hanger Link Assembly	32.	711-0841	Lift Link Adjuster
7.	748-0331	Shld. Spacer .318" I.D.	33.	17637A	Lift Shaft Assembly
8.	736-0231	Flat Washer .344" I.D. x 1.125" O.D.	34.	725-1657A	Safety Switch (Deck)
9.	736-0119	Lock Washer 5/16" I.D.	35.	714-0145	Inter. Cotter Pin 3/8" Dia.
10.	712-3010	Hex Nut 5/16-18 Thd.	36.	732-0637	Extension Spring
12.	714-0470	Cotter Pin 1/8" Dia.	37.	17636C	Stabilizer Bracket
13.	736-0256	Flat Washer .635" I.D. x 1.0" O.D.	38.	738-0670A	Shaft 1/2" Dia. x 10.28" Lg.
14.	683-0003	Hgt Adj. Stop Lever Assembly**	39.	732-0638	Extension Spring
15.	08540	Knob**	40.	720-0233	Grip (Lift Handle)
16.	710-0604A	Hex Washer Screw 5/16-18 x .625"	41.	97675A	Deck Lift Handle Assembly.
17.	748-0176	Flange Bearing .63" I.D.**	42.	738-0669	Shaft 3/8" Dia. x 9.34" Lg.
18.	710-1238	Hex Wash. Hd. Scr. 5/16-18x .875"	43.	747-0598	Disengagement Rod
19.	710-3008	Hex Bolt 5/16-18 x .75" Lg.	44.	97624	Stabilizer Shaft Assembly.
20.	17730	Index Brkt.	45.	732-0556	Extension Spring 7.58" Lg.
21.	783-0042D	Upper Frame—RH	46.	783-0043B	Upper Frame—LH
23.	736-0267	Flat Washer .385" I.D. x .87" O.D.	47.	741-0487A	Flange Brg. .632" I.D.
24.	736-0160	Flat Washer .531" I.D. x .93" O.D.	48.	17128A	Spring Retainer Brkt.
25.	726-0272	Clamp	49.	716-0104	"E"-Ring
26.	738-0526	Running Board Rod	50.	736-0425	Washer .325" I.D.

** Optional Parts

Model Series 690 thru 699




Model Series 690 thru 699

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
2.	710-1208	Hex Tap Scr. 5/16-18 x 3.25"	53.	17239A	Seat Lift Brkt.
6.	783-0039A	Seat Pivot Bracket	54.	757-0363A	Seat 8-7/8" High
7.	751-0603	Fuel Cap		757-0364A	Seat 8-7/8" High (Yellow)
8.	751-0555	Fuel Tank (1.5 Gal)		757-0360A	Seat 10-5/8" High
	751-0657	Fuel Tank (3 Gal.)		757-0365	Seat 10-5/8" High (Yellow)
9.	726-0209	Tie Strap		757-0348A	Seat 14-1/4" High
10.	751-0535-15	Fuel Line		757-0372	Seat 14-1/4" High (Yellow)
11.	726-0205	Hose Clamp		757-0350	Seat 14-1/4" High w/ Drain Holes
13.	712-0287	Hex Nut 1/4-20 Thd.	55.	17950A	Seat Pivot Brkt. Support—RH
14.	736-0329	Lock Washer 1/4" I.D.	56.	738-0296	Shld. Bolt .437" Dia. x .268"
16.	732-0735	Compression Spring	57.	725-1303	Spring Switch (Seat—Outer)
21.	738-0526	Running Board Rod	59.	710-0650	Hex TT-Tap Scr. 5/16-18 x 7/8"
22.	710-0227	Hex AB-Tap Scr. #8 x .50" Lg.	63.	725-1439	Safety Switch (Seat—Inner)
23.	726-0139	Speed Nut #10Z	65.	783-0345	Battery Tray
24.	783-0041A	Front Pivot Brkt.	66.	710-0351	Truss Mach. B-Tap Scr.#10 x .5" Lg.
25.	710-0870	Hex Tap Scr. 3/8-16 x .62" Lg.	67.	748-0347	Spring Spacer
26.	710-0726	Hex Wash. Hd. AB-Tap Scr.5/16 x .75"	68.	710-0323	Truss Mach. Scr. 5/16-18 x .75"
28.	710-0134	Carriage Bolt 1/4-20 x .62"	69.	710-3008	Hex Bolt 5/16-18 x .75" Lg.
29.	17770D	Running Board (RH & LH)	70.	731-0405	Snap Bushing
30.	761-0168B	Blade Brake Assembly	71.	723-3064	Battery Retainer Strap
32.	731-0909	Rubber Foot Pad—LH**	72.	712-3010	Hex Nut 5/16-18 Thd.
	731-0910	Rubber Foot Pad—RH**	73.	712-0265	Hex Sems Nut 5/16-18 Thd.
	723-0422	Abrasive Foot Pad**	74.	712-0271	Hex Sems Nut 1/4-20 Thd.
34.	783-0310C	Lower Frame	75.	738-1007	Shouler Screw 3/8-16 x .5**
36.	726-0278	Insulator Boss Plate	76.	710-1268	Hex Wash. B-Tap Scr. #10-16 x .38" **
37.	736-0264	Flat Washer .344" I.D. x .625" O.D.	77.	712-3027	Hex Flanged Lock Nut 1/4-20 Thd. **
38.	710-3008	Hex Bolt 5/16-18 x .75" Lg.	78.	720-0309A	Seat Adjustable Grip **
39.	783-0042A	Upper Frame—RH	79.	731-1989	Spacer **
42.	732-0581B	Extension Spring 5.31" Lg.	80.	732-0499	Compression Spring 1.5" Lg. **
44.	725-1706	12-V Battery	81.	736-0175	Spring Washer .265" I.D. x .56" O.D. **
45.	783-0043	Upper Frame—LH	82.	736-0204	Flat Washer .344" I.D. x .62" O.D. **
46.	783-0133B	Shift Cover	84.	738-0137A	Shld. Bolt .34" x 1/4 -20 Thd. **
48.	726-0279	Insulator Plate	85.	783-0607A	Seat Pivot Bracket **
49.	1795A	Seat Pivot Brkt. Support—LH	86.	783-0609	Seat Lever **
50.	783-0355A	Hitch Plate	87.	783-0753	Seat Selector **
51.	712-0267	Hex Nut 5/16-18 Thd.	88.	783-0611	Seat Stop **
52.	736-0119	Lock Washer 5/16" I.D.			

** Optional Parts

NOTE: For faster service, obtain the standard fasteners locally. If these are not available locally, call 1(800) 800-7310 or 1(330) 220-4MTD to order by part number and size as shown here.

Deck F



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
2	710-1260A	Hex Wash. TT-Tap Scr. 5/16-18 x .75"	26	754-0329A	V-Belt
3	683-0129A	38" Deck Ass'y. **	27	736-0270	Bell-Wash. 1/4" I.D.
	753-0694	38" Deck Ass'y. Complete **	28	783-0342	Brake Disc
4	783-0343A	Belt Guard Deck	35	712-0417A	Hex Flange Nut 5/8-18 Thd.†
5	710-0599	Hex Wash. Hd. TT- Tap Scr.1/4-20 Thd.	39	618-0138A	Blade Spdl Assembly
6	710-0134	Carriage Screw 1/4-20 Thd. Gr. 2	42	756-0969	5" Dia. Pulley†
8	710-0751	Hex Bolt 1/4-20 x .62"	52	703-1693A	Hinge Mtg. Brkt.
10	711-0792	Hinge Pin	53	732-0602A	Torsion Spring
12	783-1297	Deck Skirt 38"	54	726-0106	Push Nut
13	712-0181	Hex Top L-Nut 3/8-16 Thd.	55	731-1032B	Chute Assembly
14	712-3006	Hex Nut 1/4-20 Thd. (Gr. 5)	57	712-3087	Wing Nut 1/4-20 Thd. ††
17	734-0973	Deck Wheel—5"	58	731-2363	Mulching Plug ††
18	736-0105	Bell-Wash. .40" I.D. x .88" O.D.	59	16606	Retainer Hook Brkt.
22	738-0373	Shld. Bolt .498" Dia. x 1.53"	60	712-3027	Hex Flange Nut 1/4-20 Thd.
23	742-0610	3 in 1 Blade			

† Deck pulleys and blade nuts must be torqued to 100 ft. lbs. if removed or replaced.


†† If equipped

** Must be ordered with 4 digit color code.

IMPORTANT: For a proper working machine, use Factory Approved Parts.

V-BELTS are specially designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.

Deck G



Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
2	710-1260A	Hex Wash. TT-Tap Scr. 5/16-18 x .75"	26	754-0371A	V-Belt
3	683-0141B	42" Deck Ass'y. **	27	736-0270	Bell-Wash. 1/4" I.D.
	753-0698	42" Deck Ass'y. Complete **	28	783-0342	Brake Disc
4	783-0149B	Belt Guard Deck	35	712-0417A	Hex Flange Nut 5/8-18 Thd.†
5	710-0599	Hex Wash. Hd. TT-Tap Screw 1/4-20 Thd.	39	618-0142A	Blade Spindle Assembly
6	710-0134	Carraige Screw 1/4-20 Thd.	42	756-0980	5.75" Dia. Pulley†
8	710-0751	Hex Bolt 1/4-20 x .62"	52	703-1693A	Hinge Mtg. Brkt.
10	711-0792	Hinge Pin	53	732-0602A	Torsion Spring
12	783-1146A	Deck Skirt 42"	54	726-0106	Push Nut
13	712-0181	Hex Top L-Nut 3/8-16 Thd.	55	731-1032B	Chute Assembly
14	712-3006	Hex Nut 1/4-20 Thd. (Gr. 5)	57	712-3087	Wing Nut 1/4-20 Thd.††
17	734-0973	Deck Wheel—5"	58	731-2363	Mulching Plug ††
18	736-0105	Bell-Wash. .40" I.D. x .88" O.D.	59	16606	Retainer Hook Brkt.
22	738-0373	Shld. Bolt .498" Dia. x 1.53"	60	712-3027	Hex Flange Nut 1/4-20 Thd.
23	742-0616	3 in 1 Blade			

† Deck pulleys and blade nuts must be torqued to 100 ft. lbs. if removed or replaced.


†† If equipped

** Must be ordered with 4 digit color code.

IMPORTANT: For a proper working machine, use Factory Approved Parts.

V-BELTS are specially designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.

Deck H



Deck H

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	618-0240	Blade Spindle Assembly	32.	742-0644	Blade 16.28" Lg.
2.	983-0120A	46" Deck Assembly **	33.	748-0234	Shoulder Spacer
	913-06921	46" Deck Ass'y. Comp. (For Service) **	34.	750-0932A	Spacer .635" I.D. x .088" O.D.
3.	710-3151	Hex Bolt 5/8-18 x 4.25" Lg.	36.	754-0440	V-Belt
4.	710-0428	Hex Bolt 1/4-28 x 1.25" Lg.	37.	754-0439	V-Belt
5.	710-0459A	Hex Bolt 3/8-24 x 1.5" Lg.	38.	756-0638	Pulley Double Deck 5" O.D.
6.	710-1039	Hex Bolt 3/8-24 x 1" Lg.	39.	756-0627	Flat Idler Pulley 3.5 O.D.
8.	710-0599	Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5"	40.	783-0046	Idler Deck Bracket
9.	710-0151	Hex Bolt 3/8-24 x 2" Lg.	41.	783-0063A	Belt Cover—LH
10.	710-1260A	Hex Flange Bolt 5/16-24 x .75" Lg.	42.	17116	Deck Brake Brkt. Assembly
11.	712-0417A	Hex Flange Lock Nut 5/8-18 Thd.	43.	17258A	Belt Cover Brkt.—RH
12.	711-0993	Belt Guard Pin	44.	710-0751	Hex Bolt 1/4-20 x .62" Lg.
13.	712-0138	Hex Nut 1/4-28 Thd.	45.	711-0792	Hinge Pin
14.	712-0429	Hex Ins. Lock Nut 5/16-18 Thd.	46.	736-0270	BelLock Washer 1/4" I.D.
15.	712-0241	Hex Nut 3/8-24 Thd.	47.	732-0602	Torsion Spring
16.	712-3006	Hex Nut 1/4-20 Thd. (Gr. 5)	48.	703-1693	Hinge Mtg. Brkt.
17.	712-0181	Hex Top Jam Nut 3/8-16 Thd.	49.	726-0106	Push Nut
18.	712-0158	Hex Center Lock Nut 5/16-18 Thd.	50.	731-1032	Chute Assembly Complete
19.	716-3020	Int. Snap Ring	51.	750-0960	Spacer .635" I.D. x 1" O.D.
20.	732-0594A	Ext. Spring .88" O.D. x 6.17"	52.	736-0158	Lock Washer 5/8" I.D.
21.	732-0723	Ext. Spring .788" O.D. x 15.5"	53.	712-0337	Hex Nut 5/8-18 Thd.
22.	734-0973	Deck Wheel	54.	710-0167	Carriage Bolt 1/4-20 x .5" Lg.
23.	736-0290	Flat Washer .635" I.D. x 1" O.D. x .06"	55.	712-0271	Hex Sems Nut 1/4-20 Thd.
24.	736-0329	Lock Washer 1/4" I.D.	57.	736-3088	Flat Washer .635" I.D.
25.	736-0331	BelLock Washer 3/8" x 1.125" x .062"	58.	783-0141	Center Deck Skirt
26.	736-0105	BelLock Washer 3/8" x .87" x .064"	59.	783-0142	Deck Skirt—RH
28.	738-0347	Shoulder Spacer .625" I.D. x .169"	60.	738-0999	Return Spring Stud
29.	738-0373	Shld. Bolt .498" x 1.525"	61.	16606	Retainer Hook Bracket
30.	741-0524	Ball Brg. .625" I.D. x 1.574" O.D. x .47"	62.	712-3027	Hex Lock Nut 1/4-20
31.	742-0645	Blade 14.88" Lg.			


** Must be ordered with 4-digit color code.

IMPORTANT: For a proper working machine, use Factory Approved Parts.

V-BELTS are specially designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.


Harness Assembly

Briggs & Stratton Single Cylinder




Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	629-0207	Harness Adapter (Mag.)	6.	725-0963	Bulb (Headlight)
2.	629-0302B	Wire Harness w/Light Switch and Amp	7.	725-1426	Solenoid
	629-0301B	Wire Harness w/o Light Switch and Amp	8.	725-1643	Safety Switch (Reverse)
3.	725-0267	Ignition Switch	9.	725-1657A	Safety Switch Ratchet
4.	725-0634	Light Switch (If equipped)			
5.	725-0925	Ammeter (If equipped)			

Briggs & Stratton Overhead Valve




Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
2.	629-0305B	Wire Harness w/Light Switch and Amp	7.	725-1426	Solenoid
	629-0304B	Wire Harness w/o Light Switch and Amp	8.	725-1643	Safety Switch (Reverse)
3.	725-0634	Light Switch (If equipped)	9.	725-1657A	Safety Switch Ratchet
4.	725-0925	Ammeter (If equipped)	11.	726-3046	
5.	725-0963	Bulb (Headlight)			
6.	725-1396	Ignition Switch			

Briggs & Stratton Twin Cylinder




Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
2.	629-0208	Harness Adapter	8.	725-1426	Solenoid
3.	629-0302B	Wire Harness w/Light Switch & Amp	9.	725-1643	Safety Switch (Reverse)
	629-0301B	Wire Harness w/o Light Switch & Amp	10.	725-1657A	Safety Switch
4.	725-0267	Ignition Switch	11.	629-0125	Harness Adapter (Alt.)
5.	725-0634	Light Switch	13.	726-3046	Ratchet
6.	725-0925	Ammeter			
7.	725-0963	Bulb			

Tecumseh




Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	629-0302B	Wire Harness w/Light Switch & Amp	6.	725-1426	Solenoid
	629-0301B	Wire Harness w/o Light Switch & Amp	7.	725-1643	Safety Switch (Reverse)
2.	725-0267	Ignition Switch	8.	725-1657A	Safety Switch
3.	725-0634	Light Switch (If equipped)	10.	726-3046	Ratchet
4.	725-0925	Ammeter (If equipped)			
5.	725-0963	Bulb (Headlight)			

Kohler



Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	726-3046	Ratchet	6.	725-0634	Light Switch
2.	725-1657A	Safety Switch	7.	725-0267	Ignition Switch
3.	725-1426	Solenoid	8.	629-0303B	Wire Harness
4.	725-0963	Bulb (Headlight)	9.	629-0209	Wire Harness Adapter
5.	725-0925	Ammeter	10.	629-0132	Wire Harness (Monitor)


Intek Twin



Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	726-3046	Ratchet	6.	725-0925	Ammeter
2.	725-1657A	Safety Switch	7.	725-0634	Light Switch
3.	725-1426	Solenoid	8.	629-0305B	Wire Harness w/Lt./Amp
4.	725-1396	Ignition Switch		629-0306B	Wire Harness w/Lt./Amp/Mon.
5.	725-0963	Bulb (Headlight)			


Engine

Briggs & Stratton Single Cylinder




Ref. No.	Part No.	Description
1.	783-0615	Muffler Bracket
2.	751-0618	Exhaust Pipe
3.	751-0617	Muffler
4.	751-0564	Muffler Deflector
5.	736-0119	Lock Washer 5/16" I.D.
6.	726-0272	Clamp
7.	721-0208	Exhaust Gasket
8.	710-1314	Socket Hd. Bolt 5/16-18 x .62" Lg.
9.	710-0604	Hex Wash Hd. TT-Tap Scr. 5/16-18 x .62"
10.	710-0599	Hex Wash. TT-Tap Scr. 1/4-20 x .5" Lg.
11.	710-0148	Hex Slot Scr. #8-32 x .38" Lg.

Briggs & Stratton Overhead Valve




Ref. No.	Part No.	Description
1.	710-0148	Hex Tap Scr. #8-32 x .38" Lg.
2.	710-0599	Hex TT-Tap Scr. 1/4-20 x .5" Lg.
3.	710-0604	Hex TT-Tap Scr. 5/16-18 x .62"
4.	710-1237	Hex Wash. Scr. #10-32 x .62"
5.	710-1314	Socket Head Scr. 5/16-18 x .62"
6.	710-1315	Hex TT-Tap Scr. 3/8-16 x 1.25"
7.	712-0271	Hex Sems Scr. 1/4-20 Thd.
8.	721-0208	Gasket
9.	726-0205	Hose Clamp
10.	726-0272	Clamp
11.	731-1682A	Oil Drain Sleeve
12.	736-0119	Lock Washer 5/16" I.D.
14.	751B213146	Casing Clamp
15.	751-0535-12	Fuel Line 12" Lg.
16.	751-0564	Muffler Deflector
17.	751-0617	Muffler
18.	751-0619	Exhaust Pipe
19.	783-0615	Muffler Brkt.

Briggs & Stratton Twin Cylinder




Ref. No.	Part No.	Description
1.	710-0148	Hex Tap Scr. #8-32 x .38" Lg.
2.	710-0599	Hex Wash. TT-Tap Scr. 1/4-20 x5" Lg.
3.	710-0604	Hex Wash. TT-Tap Scr. 5/16-18 x .62"
4.	710-0779A	Truss Mach. Scr. #10 x .5" Lg.
5.	710-1315	Hex Hd. Tap Scr. 3/8-16 x 1.25"Lg.
6.	710-3015	Hex Bolt 1/4-20 x .75"Lg.
7.	712-0271	Hex Sems Nut 1/4-20 Thd.
9.	721-0346	Exhaust Gasket
10.	726-0205	Hose Clamp
11.	726-0272	Clamp
12.	736-0329	Lock Washer 1/4" I.D.
13.	736-3067	Flat Washer .188" I.D. x .438" O.D.
14.	737-0143	Oil Drain Cap
15.	737-0164	Pipe Nipple 3/8 x 18 NPT.
17.	751-0535-26	Fuel Line 26" Lg.
18.	751-0564	Deflector: Muffler
19.	751-0616	Muffler
20.	751-0623	Exhaust Pipe—LH
21.	751-0624	Exhaust Pipe—RH
22.	783-0357	Heat Shield
23.	783-0615	Muffler Bracket

Tecumseh




Ref. No.	Part No.	Description
1.	710-0148	Hex Bolt #8-32 x .38" Lg.
2.	710-0599	Hex Wash. Hd. TT-Scr. 1/4-20 x .5" Lg.
3.	710-0604	Hex Wash. Hd. TT-Scr. 5/16-18 x .62"
4.	710-1314	Socket Hd. Bolt 5/16-18 x .62" Lg.
5.	710-1315	Hex Wash. Hd. TT-Scr. 3/8-16 x 1.25"
6.	712-0271	Hex Sems Nut 1/4-20 Thd.
8.	721-0348	Exhaust Gasket
9.	726-0205	Hose Clamp
10.	726-0272	Clamp
11.	736-0119	Lock Washer 5/16" I.D.
13.	737-0286	Pipe 3/8 NPT x 3.8" Lg. (16/17 HP)
	737-0199	Pipe 3/8 NPT x 2" Lg. (12/13 HP)
14.	751-0535-12	Fuel Line
15.	751-0564	Muffler Deflector
16.	751-0572	Hex Pipe Plug (16/17 HP)
	737-0143	Oil Drain Cap (12/13 HP)
17.	751-0617	Muffler
18.	751-0620	Exhaust Pipe (16/17 HP)
	751-0622	Exhaust Pipe (12/13 HP)
19.	783-0378A	Heat Shield (16/17 HP)
20.	783-0615	Muffler Bracket

Kohler



Ref. No.	Part No.	Description
1.	710-0148	Hex Tap Scr. #8-32 x .38" Lg.
2.	710-0599	Hex Wash. TT-Tap Scr. 1/4-20 x5" Lg.
3.	710-0604	Hex Wash. TT-Tap Scr. 5/16-18 x .62"
4.	710-3206A	Hex Bolt M8 x 1.25
5.	712-3086	Hex Flange Nut M8 Thd.
7.	721-0375	Exhaust Gasket
8.	726-0205	Hose Clamp
9.	726-0272	Clamp
10.	736-0607	External Lock Washer 5/16" I.D.
12.	751-0535-12	Fuel Line 12" Lg.
13.	751-0564	Muffler Deflector
14.	751-0617	Muffler
15.	751-0621	Exhaust Pipe
16.	751-3140	Oil Drain
17.	751-3141	Oil Drain Hose
18.	783-0615	Muffler Bracket.

Intek Twin



Ref. No.	Part No.	Description
1.	710-0148	Hex Tap Scr. #8-32 x .38" Lg.
2.	710-0599	Hex Wash. TT-Tap Scr. 1/4-20 x5" Lg.
3.	710-0604	Hex Wash. TT-Tap Scr. 5/16-18 x .62"
4.	710-1314	Socket Head Scr. 5/16-18 x .62"
5.	710-1315	Hex TT-Tap Scr. 3/8-16 x 1.25"
7.	721-0460	Exhaust Gasket
8.	726-0205	Hose Clamp
9.	726-0272	Clamp
10.	736-0119	Lock Washer 5/16" I.D.
12.	751-0535-12	Fuel Line 12" Lg.
13.	751-0564	Muffler Deflector
14.	751-0616	Muffler
15.	751-0650	Exhaust Pipe—RH
16.	751-0651	Exhaust Pipe—LH
17.	751-3140	Oil Drain
18.	751-3141	Oil Drain Hose
19.	783-0615	Muffler Bracket
20.	783-0625	Heat Shield