



Model 390



Model 390

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1.	712-0442	Acorn Lock Nut 1/4-20	26.	786-0004	Tail Piece Bracket (R.H.)
2.	736-3020	Flat Washer .271" I.D. x .630" O.D.	27.	711-0415	Clevis Pin
3.	720-0270A	Reverse Handle Grip	28.	710-0805	Hex Bolt 5/16-18 x 1.5" Lg.
4.	731-1600	Handle Cover w/o throttle	29.	710-0189	Hex Bolt 5/16-18 x 3" Lg.
5.	710-0779A	Truss Mach. Scr. #10 x 1/2" Lg.	30.	736-0242	Wash. Bell. .340" I.D. x .872" O.D.
6.	720-0274	Grip-Handle	31.	711-1036	Spec. Hex Nut
7.	712-0287	Hex Nut 1/4-20 Gr.2	32.	736-0119	L-Wash. 5/16" I.D.
8.	726-0135	Cap Speed Nut	33.	710-3008	Hex Bolt 5/16-18 Gr. 5
9.	686-0083	Clutch Handle Assembly	34.	786-0129	Cable Guide Bracket
10.	720-0269	Grip-Clutch	35.	710-0604A	Hex Washer Screw 5/16-18 x .62" Lg.
11.	710-0641	Hex Bolt 1/4-20 x 2.25" Lg. Gr.5	36.	710-0602	Hex Wash. Hd. TT-Tap Scr.
12.	731-1645A	Clutch Handle Holder	37.	738-0934	Shdl. Bolt 5/16-18
13.	736-0140	Flat Washer .385" I.D. x .62" O.D.	38.	786-0138A	Frame (R.H.)
14.	686-0014A	Reverse Handle Ass'y	39.	786-0139A	Frame (L.H.)
15.	736-0264	Flat Washer .344" I.D. x .62" O.D.	40.	736-0171	Lock Washer 7/16
16.	649-0022B	Handle Assembly Comp.	41.	712-0240	Jam Nut 7/16-20 Gr. 2
17.	710-1236	Carr. Bolt 5/16-18 x 1	42.	710-0176	Hex Bolt 5/16-18 x 2.75" Lg.
18.	720-0195	Hand Knob	43.	712-0429	Hex Nylon Nut 5/16-18 Thd.
19.	749-1082	Engine Tube Brace	44.	711-0415	Clevis Pin
20.	712-3004A	Hex Flange L-Nut 5/16-18 Thd.	45.	714-0149B	Cotter Pin
21.	736-0242	Bell. Wash. .34" I.D.	46.	686-0081A	Wheel Hanger Bracket Assembly
22.	786-0005	Depth Bar	47.	734-1566	Wheel Ass'y 8" x 1.75"
23.	714-0149B	Cotter Pin	48.	738-0929	Shoulder Screw .496 I.D. x 1.445 O.D.
24.	712-3004A	Hex Flange L-Nut 5/16-18 Thd. Gr.5	49.	750-0890	Spacer
25.	786-0003	Tail Piece Bracket (L.H.)			

Model 390



Model 390

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1.	712-0392	Hex L-Stop nut 1/4-28	25.	750-0892	Spacer .64" Dia. x 2.4" Lg.
2.	736-3020	Flat Wash. .266" I.D. x .625" O.D.	26.	748-0350	Pulley Mounting Adapter
3.	710-0599	Hex Washer TT-Tap Scr. 1/4-20 x .5"	27.	736-0112	Bell-Wash. .525" I.D. x 1.5" O.D.
4.	711-0920	Belt Cover Bolt	28.	712-3029	Hex Jam Nut 1/2-20 Thd. (Gr. 5)
5.	712-3004A	Hex Flange Top L-Nut 5/16-18 (Gr.5)	29.	732-0697	Return Spring
6.	710-0723	Hex Hd. Scr. 3/8-16 x 1.25" Lg. (Gr.5)	30.	786-0040B	Reverse Bracket
7.	756-0313	FI-Idler 2.12" O.D.	31.	736-0119	Lock Washer 5/16
8.	786-0149	Idler Belt Keeper	32.	710-0107	Hex Bolt 5/16-24 x .5"
9.	786-0144	Idler Bracket	33.	756-0971	Inner Engine Pulley Half
10.	712-0266	Hex Cent. Jam Nut 3/8-16 Thd.	34.	756-0600	Outer Engine Pulley Half
11.	786-0057	Belt Cover	35.	736-0452	Bell Washer .396" I.D. x 1/14" O.D.
12.	710-0599	Hex Wash. TT-Tap Scr. 1/4-20 x .5" Lg.	36.	710-0191	Hex Bolt 3/8-24 x 1.25"
13.	786-0043A	Tiner Shield	38.	686-0013	Reverse Arm Assembly
14.	710-3008	Hex Hd. Cap Scr. 5/16-18 x .75" Lg	39.	712-0266	Hex Cent. Jam Nut 3/8-16 Thd.
15.	712-3004A	Hex Flange Top L-Nut 5/16-18 (Gr. 5)	40.	710-0723	Hex Cap Bolt 3/8-16 x 1.25" Lg. (Gr. 5)
16.	686-0091	Chain Case Assembly Complete	41.	756-0313	FI-Idler 2.12" O.D.
17.	686-0106	Tine Disc Ends	42.	786-0041	Keeper Plate
18.	714-0149B	Internal Cotter Pin	43.	710-0502A	Hex L-Wash. TT-Tap 3/8-16 x 1.25"
19.	711-0415	Clevis Pin	44.	786-0145A	Engine Plate
20.	642-0023	Outer Tine Assembly L.H.	45.	786-0053	Tine Shield Bracket
	642-0024	Outer Tine Assembly R.H.	46.	736-0171	L-Wash. 7/16" I.D.
21.	642-0003	Inner Tine Assembly L.H.	47.	712-0240	Hex Nut 7/16-20 Thd.
	642-0002	Inner Tine Assembly R.H.	48.	754-0428	V-Belt (Forward)
22.	746-0918	Forward Clutch Cable	49.	754-0429	V-Belt (Reverse)
23.	746-0953	Reverse Clutch Cable	50.	738-0102	Shld. Bolt
24.	756-0585	FI-Pulley 6" Dia.	51.	738-0930	Shld. Bolt