


SECTION 3: PARTS LIST



Ref. No.	Part No.	Description
1.	16587D	Support Bracket: Bagger
2.	16592	Support Tube Assembly
3.	664-04017	Grasscatcher Cover Assembly
4.	710-0623	Self-tapping Screw 3/8-16 x 0.75"
5.	710-0751	Hex Screw 1/4-20 x 0.620
6.	710-3008	Hex Screw 5/16-18 x 0.75"
7.	711-0309A	Clevis Pin
	711-0310	Clevis Pin (on older model tractors)
9.	711-04069	Grasscatcher Pin
10.	711-1421	Clevis Pin
11.	712-0459	Lock Nut 7/16-20
12.	712-3004A	Lock Nut 5/16-18
13.	712-3027	Flange Lock Nut 1/4-20
14.	714-0117	Hairpin Clip
15.	714-0145	Click Pin
16.	723-04008	Chute Strap
17.	731-04159	Discharge Chute 46"
	731-04153	Discharge Chute 38"/42" Bag
18.	731-0926B	Catcher Tube
	731-0899E	Chute Tube (model 190-180)
19.	736-0331	Bell Washer
20.	736-0407	Bell Washer
21.	736-3092	Flat Washer
22.	738-1020	Shoulder Screw
23.	742-0644	Blade 16.28" Lg. (model 190-182)
24.	742-0645	Blade 14.88" Lg. (model 190-182)
25.	783-04132	Supt. Bracket (model 190-180) LH
26.	783-04137	Supt. Bracket (model 190-180) RH
27.	783-04138	Support Bracket (model 190-182)
28.	783-0601	Mounting Bracket
29.	783-0673	Hook: Mounting Bracket
30.	783-0764	Mounting Bracket LH
31.	783-0765	Bracket: Cross Support
32.	764-0221	Catcher Bag
33.	749-0701A	Grass Bag Frame
34.	712-0272	Hex Sems Nut, #10-24
35.	710-0604A	Self-tapping Screw, 5/16-18 x .625
36.	710-0473	Machine Screw, , #10-24 x .5
37.	16591A	Bag Hanger Bracket