



## SECTION 12: PARTS LIST FOR MODEL GT 954H



# Model GT 954H

| REF. NO. | PART NO.  | DESCRIPTION                           | REF. NO. | PART NO.   | DESCRIPTION                                  |
|----------|-----------|---------------------------------------|----------|------------|----------------------------------------------|
| 1        | 683-0305  | Bracket Assembly, Hood                | 26       | 712-0142   | Nut, Hex, #8-32                              |
| 2        | 710-0376  | Hex Screw, 5/16-18, 1.00, Gr5         | 27       | 731-04213  | Brake Lever                                  |
| 3        | 710-1652  | Screw, 1/4-20, 0.625                  | 28       | 731-04214  | Cruise Control Lever                         |
| 4        | 710-0642  | Screw, 1/4-20, 0.750                  | 29       | 731-05037  | Dash Panel                                   |
| 5        | 710-0895  | Screw, 1/4-15, 0.750                  | 30       | 731-1857   | Control Knob                                 |
| 6        | 710-0924  | Screw, Machine, 1/4-20, 0.750         | 31       | 746-1085A  | Choke Knob w/ Cable, 37.5"                   |
| 7        | 710-3015  | Hex Screw, 1/4-20, .75, Gr5           | 32       | 747-1155   | Rod, Brake / Cruise Pivot                    |
| 8        | 712-0292  | Nut, Clip, 1/4-20                     | 33       | 783-04285D | Support Plate, Dash, RH                      |
| 9        | 712-04063 | Nut, Flange Lock, 5/16-18, Grf, Nylon | 34       | 783-04323D | Support Plate, Dash, LH                      |
| 10       | 712-04064 | Nut, Flange Lock, 1/4-20, Grf, Nylon  | 35       | 725-1752   | Electric PTO Switch                          |
| 11       | 726-0201  | Nut, Speed,.3125 ID                   | 36       | 751-0658E  | Fuel Tank, 3 Gal.                            |
| 12       | 731-2283A | Hood                                  | 37       | 751-0603   | Fuel Cap                                     |
| 13       | 731-2286A | Lens                                  | 38       | 746-1086   | Throttle Cable, 39"                          |
| 14       | 731-05473 | Side Panel, LH                        | 39       | 725-1744   | Key, Ignition                                |
| 15       | 731-2308B | Side Panel, RH                        |          | 725-1745   | Key w/ Plastic Cover, Ignition               |
| 16       | 731-2284  | Hood Plenum                           | 40       | 683-04219  | Bumper                                       |
| 17       | 736-0173  | Washer, Flat,.28 x.74 x.063           | 41       | 731-2234A  | Bellow                                       |
| 18       | 731-05598 | Bumper Cap                            | 42       | 725-04227A | Ignition Switch Module                       |
| 19       | 736-3078  | Washer, Flat,.344 x 1.0 x.063         | 43       | 725-04036B | Systems Indicator Monitor w/ Hour Meter      |
| 20       | 747-04301 | Support, Side Panel                   | 44       | 725-0963   | Miniature Lamp, 12V                          |
| 21       | 747-2127  | Rod, Hood Latch                       | 45       | 725-1649   | Socket, Lamp                                 |
| 22       | 710-0726  | Screw, 5/16-12, 0.750                 | —        | 629-04083  | Headlight Wire Harness <i>(not pictured)</i> |
| 23       | 710-1017  | Screw, 1/4-14, 0.625                  | —        | 725-04336  | Tractor Wire Harness <i>(not pictured)</i>   |
| 24       | 710-1611B | Screw, 5/16-18, 0.750                 | —        | 735-04023  | Cargo Net <i>(not pictured)</i>              |
| 25       | 710-3217  | Screw, Machine, #8-32, 0.375          | —        | 726-04029  | Ratchet Clip <i>(not pictured)</i>           |


# Model GT 954H



# Model GT 954H

| REF. NO. | PART NO.  | DESCRIPTION                       | REF. NO. | PART NO.   | DESCRIPTION                      |
|----------|-----------|-----------------------------------|----------|------------|----------------------------------|
| 1        | 710-0227  | Screw, #8-18 x.500                | 31       | 731-1993A  | Cover w/ Cup Holder              |
| 2        | 683-04079 | Lift Shaft Assembly               | 32       | 736-3078   | Flat Washer,.349 x 1.0 x.063     |
| 3        | 711-0332  | Clevis Pin,.5 x.78                | 33       | 783-0677B  | Lift Adjustment Bracket          |
| 4        | 736-0607  | Lock Washer, 5/16                 | 34       | 783-04459A | Fender 4 Sty Hydro w/ Flares     |
| 5        | 712-04065 | Flange Lock Nut, 3/8-16           | 35       | 783-1489B  | Seat Mounting Bracket            |
| 6        | 712-04063 | Flange Lock Nut, 5/16-18          | 36       | 710-1268   | Screw, #10-16 x.375              |
| 7        | 725-1439  | Inner Seat Spring Switch          | 37       | 712-04064  | Flange Lock Nut, 1/4-20          |
| 8        | 714-0104  | Hairpin Clip                      | 38       | 720-0309A  | Seat Adjuster Grip               |
| 9        | 714-04023 | Hairpin Clip                      | 39       | 731-04074  | Spacer                           |
| 10       | 716-0106A | E-Ring                            | 40       | 732-0499   | Compression Spring,.41 x 1.5     |
| 11       | 720-0311  | Handle Grip                       | 41       | 725-1303   | Outer Seat Spring Switch         |
| 12       | 732-0874  | Torsion Spring                    | 42       | 710-0932   | Carriage Screw 1/4-20 x 1.00     |
| 13       | 732-1184  | Extension Spring,.84 x 4.6        | 43       | 738-0137A  | Shoulder Screw,.340 x.285,1/4-20 |
| 14       | 736-0275  | Flat Washer, 5/16                 | 44       | 738-0966A  | Shoulder Screw,.50 x.50, 3/8-16  |
| 15       | 726-0278  | Insulator Boss Plate              | 45       | 783-0611   | Seat Stop                        |
| 16       | 736-3019  | Flat Washer,.31 x 1.062 x.134     | 46       | 783-0738C  | Seat Pivot Bracket               |
| 17       | 710-0599  | Screw, 1/4-20 x.500               | 47       | 783-0739A  | Seat Adjustment Lever            |
| 18       | 738-0138A | Hex Cap Screw, 5/16-18 x.62       | 48       | 783-0753   | Seat Adjustment Selector         |
| 19       | 738-0380  | Shoulder Screw, 3/8-16            | 49       | 757-04015  | High Back Seat, Black            |
| 20       | 741-0225  | Hex Flange Bearing                | 50       | 735-0656   | RH Foot Pad                      |
| 21       | 712-0271  | Sems Nut 1/4-20                   | 51       | 735-0657   | LH Foot Pad                      |
| 22       | 746-0968  | Lift Cable, 16.16                 | —        | 726-3046   | Foot Pad Clips                   |
| 23       | 747-04155 | Lift Handle                       | 52       | 714-0111   | Cotter Pin                       |
| 24       | 756-1154  | Roller Pulley                     | 53       | 726-0279   | Insulator Plate                  |
| 25       | 783-0678A | Arm Lift                          | 54       | 783-0209D  | Seat Lift Bracket                |
| 26       | 783-0720A | Deck Stabilizer Bracket           | 55       | 726-0201   | Speed Clip                       |
| 27       | 710-0451  | Carriage Bolt, 5/16-18 x.750      | 56       | 731-2618   | RH Fender Flare                  |
| 28       | 710-0604A | Self-tapping Screw, 5/16-18 x.625 | 57       | 731-2619   | LH Fender Flare                  |
| 29       | 710-0895  | Self-tapping Screw, 1/4-15 x.75   | 58       | 738-0296   | Shoulder Screw,.437 x.286        |
| 30       | 731-1990  | Lift Lever Cover                  |          |            |                                  |


# Model GT 954H



# Model GT 954H

| REF.<br>NO. | PART<br>NO. | DESCRIPTION                          |
|-------------|-------------|--------------------------------------|
| 1           | 710-04095   | Hex Screw, 3/8-16, 1.00, Gr5         |
| 2           | 710-0514    | Hex Screw, 3/8-16, 1.00, Gr5         |
| 3           | 710-0643    | Hex Screw, 5/16-18, 1.00, Gr5        |
| 4           | 711-1408    | Link, Drag, RH                       |
| 5           | 711-1409A   | Link, Drag, LH                       |
| 6           | 712-0214    | Nut, Hex Lock, 3/8-24                |
| 7           | 712-04065   | Nut, Flange Lock, 3/8-16, Grf, Nylon |
| 8           | 712-0459    | Nut, Flange Lock, 7/16-20            |
| 9           | 712-3004A   | Nut, Flange Lock, 5/16-18, Gr5       |
| 10          | 712-0240    | Nut, Jam, 7/16-20, Gr2               |
| 11          | 717-1550E   | Gear, Steering, 11/90 Ratio          |
| 12          | 717-1554    | Gear, Pinion, Steering               |
| 13          | 723-0448A   | Ball Joint, 7/16-20, Lock            |
| 14          | 736-3004    | Washer, Flat,.406 x.875 x.105        |
| 15          | 736-3084    | Washer, Flat,.51 x 1.12 x.06         |
| 16          | 710-1260A   | Screw, 5/16-18, 0.750                |
| 17          | 738-04154   | Spacer, Shoulder,.38 x 1.00 x.31     |
| 18          | 738-1001A   | Shaft, Steering,.625 OD x 24.25 Lg   |
| 19          | 741-0475    | Plastic Bushing.380 ID               |
| 20          | 741-0656A   | Hex Flange Bearing 5/8 PM            |
| 21          | 783-0726E   | Pivot Bracket, Support RH            |
| 22          | 783-0727D   | Pivot Bracket, Support LH            |
| 23          | 783-0728    | Pivot Bracket, Bar                   |
| 24          | 631-04008A  | Steering Wheel, 13.25                |
| 25          | 731-04065   | Steering Wheel Cover                 |
| 26          | 738-1011A   | Shoulder Screw,.5 x 2.2, 3/8-16      |
| 27          | 734-2290A   | Deluxe Hub Cap                       |
| 28          | 736-0316    | Flat Washer,.78 x 1.589 x.06         |
| 29          | 714-04039   | Cotter Pin, 5/32 x 1.25              |
| 30          | 719-04105   | Cast Iron Pivot Bar                  |
| 31          | 726-0341    | Push Cap                             |
| 32          | 638-04003   | LH Axle Assembly,.750                |
| 33          | 638-04004   | RH Axle Assembly,.750                |
| 34          | 711-0332    | Pin, Clevis,.50 x.78                 |
| 35          | 714-04023   | Cotter Pin, Internal,.080 x 1.5625   |
| 36          | 783-0720A   | Adjustment Bracket, Front            |
| 37          | 634-04088A  | Wheel Assembly Complete,             |
|             | 734-04148   | Tire Only 16 x 7.5 x 8               |
|             | 634-04082   | Rim Only w/ Valve Stem               |
| 38          | 738-0143    | Screw, Shoulder,.498 x.340, 3/8-16   |
| 39          | 712-0431    | Flange Lock Nut, 3/8-16              |

# Model GT 954H




# Model GT 954H

| REF. NO. | PART NO.   | DESCRIPTION                         | REF. NO. | PART NO.   | DESCRIPTION                                   |
|----------|------------|-------------------------------------|----------|------------|-----------------------------------------------|
| 1        | 712-3050   | Lug Nut, 3/4-16                     | 43       | 710-0650   | Self-tapping Screw, 5/16-18 x.875             |
| 2        | 629-0949A  | Reverse/Ground Wire Harness Adapter | 44       | 710-1260A  | Self-tapping Screw, 5/16-18 x.75              |
| 3        | 783-04442  | Double Idler Bracket                | 46       | 711-04159B | Pin, 3/8-16 x 2.43                            |
| 4        | 710-0176   | Hex Cap Screw, 5/16-18 x 2.75       | 47       | 732-0335   | Compression Spring,.40 OD x 1.17              |
| 5        | 710-0216   | Hex Cap Screw, 3/8-16 x.75          | 48       | 732-0955   | Extension Spring,.50 OD x 1.41                |
| 6        | 710-0227   | Screw, #8-18 x.5                    | 49       | 732-0963   | Extension Spring,.50 OD x 6.37                |
| 7        | 710-1007   | Hex Cap Screw, 3/8-16 x 1.5         | 50       | 735-0662   | Drive Pedal Pad                               |
| 8        | 710-0599   | Self-tapping Screw, 1/4-20 x.50     | 51       | 735-3049   | Brake Pedal Pad                               |
| 9        | 710-0726   | Self-tapping Screw, 5/16-12 x.75    | 54       | 736-0187   | Flat Washer,.64 x 1.24 x.06                   |
| 10       | 710-3011   | Hex Cap Screw, 3/8-16 x 2.25        | 56       | 736-0262   | Flat Washer,.385 x.870 x.092                  |
| 12       | 711-0832   | Ferrule, 3/8-24                     | 57       | 738-0155   | Shoulder Screw,.437 x 1.62                    |
| 13       | 712-3004A  | Flange Lock Nut, 5/16-18            | 59       | 741-0225   | Hex Flange Bearing                            |
| 14       | 712-04063  | Flange Lock Nut, 5/16-18            | 60       | 741-3065B  | Split Hex Flange Bearing                      |
| 15       | 712-3017   | Hex Nut, 3/8-16                     | 61       | 747-04096  | Cruise Control Rod                            |
| 16       | 714-0104   | Internal Cotter Pin                 | 62       | 747-04093  | Brake Lock Control Rod                        |
| 17       | 714-0111   | Cotter Pin                          | 63       | 748-04039B | Cruise Latch                                  |
| 18       | 725-0157   | Cable Tie                           | 64       | 748-0415B  | Spacer, 5/16 x 1.54                           |
| 19       | 725-1644   | Short Spring Switch                 | 65       | 783-04612  | Steering Support Bracket                      |
| 20       | 726-0154   | Push-mount Cable Tie                | 66       | 783-0663E  | Drive Lockout Bracket                         |
| 21       | 726-0320   | Insulator Nut Plate                 | 67       | 747-04521  | Brake Pedal                                   |
| 22       | 732-0716C  | Extension Spring,.59 x 4.0          | 68       | 783-0693   | Transmission Axle Bracket                     |
| 23       | 732-04323B | Extension Spring,.770 x 3.72 Lg.    | 69       | 634-0202A  | Wheel Assembly Comp., 23 x 9.5 x 12           |
| 24       | 732-3118   | Extension Spring, 3/8 x 1.44        |          | 634-3178   | Rim Only 12.0 x 7.0                           |
| 26       | 736-0169   | Lock Washer, 3/8                    |          | 734-0255   | Air Valve (Not Shown)                         |
| 27       | 736-3008   | Flat Washer,.344 x.750 x.120        |          | 734-04147  | Tire Only 23.0 x 10.5 x 12 Sq. Shoulder       |
| 28       | 736-3010   | Flat Washer,.407 x.812 x.135        | 70       | 734-2290A  | Hub Cap                                       |
| 29       | 738-0372B  | Shoulder Spacer,.38                 | 71       | 710-1611B  | Self-tapping Screw, 5/16-18 x.75              |
| 30       | 747-1119   | Hydrostatic Control Rod             | 72       | 736-0119   | Lock Washer, 5/16                             |
| 31       | 747-1121   | Hydrostatic Bypass Rod              | 73       | 712-04065  | Flange Lock Nut 3/8-16                        |
| 32       | 747-04140  | Hydrostatic Brake Rod               | 74       | 710-0520   | Hex Cap Screw, 3/8-16 x 1.5                   |
| 34       | 754-0349   | Drive Belt                          | 75       | 736-0258   | Flat Washer.385 x 1.00 x.135                  |
| 35       | 756-04209  | V-idler Pulley, 3.06                | 76       | 738-0380   | Shoulder Screw 3/8-16.50 x.27                 |
| 36       | 756-04224  | Flat Idler Pulley, 2.75             | 77       | 618-04317  | Wheel Hub Assembly                            |
| 37       | 783-0667B  | Transmission Torque Bracket         | 78       | 712-0240   | Jam Nut, 7/16-20                              |
| 38       | 783-0745   | Speed Control Bracket               | 79       | 710-3119   | Screw, 3/8-16 x.750                           |
| 39       | 783-0782   | Switch Actuator Bracket             | 80       | 714-0507   | Cotter Pin                                    |
| 40       | 647-0031B  | Brake Control Assembly              | 81       | 736-0227   | Flat Washer,.390 x 1.500 x.134                |
| 41       | 647-0049A  | Drive Control Assembly              | —        | 618-04329  | Hydrostatic Transmission Assembly (Not Shown) |
| 42       | 683-0267C  | Hydro Pedal Assembly                |          |            |                                               |




# Model GT 954H



# Model GT 954H

| REF.<br>NO. | PART<br>NO. | DESCRIPTION                          |
|-------------|-------------|--------------------------------------|
| 1           | 710-1260A   | Screw, 5/16-18 x 0.75                |
| 2           | 710-0859    | Screw, 3/8-16, 2.50, Gr5             |
| 3           | 710-04379A  | Screw, 7/16-20, 3.50, Gr5, Lock      |
| 4           | 712-04065   | Nut, Flange Lock, 3/8-16, GrF, Nylon |
| 5           | 717-1744B   | PTO Clutch, Electric                 |
| 6           | 736-0277    | Washer, Flat, 1.031 x 1.620 x .095   |
| 7           | 748-0415B   | Spacer, .385 ID x .635 OD x 1.54     |
| 8           | 756-0978A   | Pulley, Engine, 3.56 Diameter        |
| 9           | 783-04419B  | Clutch Bracket                       |
| 10          | 783-04467   | Deck Bracket, Up-Stop                |
| 11          | 725-04039   | Switch                               |
| 12          | 712-0271    | Nut, Sems, 1/4-20                    |
| 13          | 17962       | Switch Plate                         |
| 14          | 725-1750A   | Battery, 235 CCA                     |
| 15          | 710-0224    | AB Screw, #10-16 x .500              |
| 16          | 683-04173   | Frame Assembly, Lower                |
| 17          | 710-0607    | Screw, 5/16-18, 0.500                |
| 18          | 710-0642    | Screw, 1/4-20, 0.750                 |
| 19          | 710-3005    | Screw, 3/8-16, 1.25, Gr5             |
| 20          | 712-04064   | Nut, Flange Lock, 1/4-20, GrF, Nylon |
| 21          | 783-0693    | Axle Bracket                         |
| 22          | 732-04035   | Spring, Compression, 1.28 OD x 3.125 |
| 23          | 736-0222    | Washer, Lock, 1/4, External          |
| 24          | 710-0726    | Screw, 5/16-12, 0.75                 |
| 25          | 738-04058   | Spacer, Shoulder, .38 x 1.0 x .70    |
| 26          | 747-04121A  | Hold Rod, Battery                    |
| 27          | 783-0349    | Battery Tray                         |
| 28          | 783-04329A  | Seat Bracket, Frame                  |
| 29          | 783-04811   | Frame, Upper                         |
| 30          | 710-0599    | Screw, 1/4-20, 0.50                  |
| 31          | 725-1426A   | Solenoid, 12V, 100 Amp               |
| 32          | 738-1132    | Screw, Shoulder, .250 x .15, 1/4-20  |
| 33          | 710-0703    | Screw, Carriage, 1/4-20, .75         |
| 34          | 712-3087    | Nut, Wing, 1/4-20                    |
| 35          | 783-04612   | Support Bracket, Steering            |
| 36          | 736-0171    | Lock Washer, 7/16                    |

# Model GT 954H




# Model GT 954H

| REF. NO. | PART NO.  | DESCRIPTION                          | REF. NO. | PART NO.   | DESCRIPTION                           |
|----------|-----------|--------------------------------------|----------|------------|---------------------------------------|
| 1.       | 12650     | Bracket, Adjustment, Height          | 40.      | 717-04074  | Adjustment, Deck, Gear                |
| 2.       | 16606     | Bracket, Hook, Retainer              | 41.      | 721-04041  | Water Nozzle Adaptor                  |
| 3.       | 618-0671  | Spindle Assembly, Pulley             | 42.      | 747-1324   | Rod, Deck Adjust                      |
| 4.       | 683-0254B | Bracket Assembly, Deck, Hanger LH    | 43.      | 731-0335   | Roller, Deck                          |
| 5.       | 683-0459  | Idler Assembly, 54"                  | 44.      | 731-3005   | Front Roller                          |
| 6.       | 683-0608A | Bracket Assembly, Lift, 54"          | 45.      | 731-05559  | Deflector, Chute                      |
| 7.       | 17255A    | Bracket Assembly, LH-Front           | 46.      | 732-0306A  | Spring, Compression,.406 x.531 x 1.75 |
| 8.       | 783-04394 | Bracket Assembly, RH-Front           | 47.      | 732-0459B  | Spring, Extension,.94 Dia x 6.74      |
| 9.       | 703-3511  | Guard, Finger                        | 48.      | 732-0971   | Spring, Extension, 1.010 Dia x 6.500  |
| 10.      | 703-2093  | Baffle, RR, Inner                    | 49.      | 732-3070   | Torsion Spring.44 l.d. x 2.10         |
| 11.      | 710-0521  | Screw, 3/8-16 x 3.00                 | 50.      | 734-04155  | Deck Wheel, 5" Dia.                   |
| 12.      | 710-0599  | Screw, 1/4-20 x.500                  | 51.      | 736-0119   | Lock Washer                           |
| 13.      | 710-0216  | Hex Screw 3/8-16 x 0.75              | 52.      | 703-3279   | Deflector Chute Stop                  |
| 14.      | 710-04095 | Hex Screw 3/8-16 x 1.0               | 53.      | 783-04462  | Lift Bracket                          |
| 15.      | 710-0528  | Hex Screw, 5/16-18 x 1.25            | 54.      | 736-0760   | Lock Washer                           |
| 16.      | 710-1260A | LD Screw 5/16-18 x 0.75              | 55.      | 736-0921   | Lock Washer                           |
| 17.      | 710-0607  | Screw, 5/16-18 x 0.500               | 56.      | 750-04597  | Spacer,.380 x.900 x 1.313             |
| 18.      | 710-0623  | Screw, 3/8-16 x.750                  | 57.      | 736-0300   | Washer, Flat.406 x.875 x.059          |
| 19.      | 712-0206  | Hex Nut, 1/2-13                      | 58.      | 737-04003C | Water Nozzle: Deck Wash-Out System    |
| 20.      | 710-3011  | Hex Screw, 3/8-16 x 2.25             | 59.      | 738-0295   | Shaft,.750 x.47.12                    |
| 21.      | 710-3103  | Hex Screw, 5/16-18 x 2.00            | 60.      | 738-1229A  | Shoulder Screw                        |
| 22.      | 710-3168  | Bolt, Carriage, 3/8-16 x 1.0         | 61.      | 738-3056   | Shoulder Screw                        |
| 23.      | 710-3178  | Short Neck Carriage Bolt 3/8-16 x.75 | 62.      | 742-0677   | Blade, 18.50"                         |
| 24.      | 711-0332  | Pin, Clevis,.50 Dia x.78             | 63.      | 747-1116   | Deck Release Handle Rod,.375 Dia      |
| 25.      | 711-1737  | Pin, Roller,.5" Dia x 10.06.         | 64.      | 750-0151   | Spacer.550 ID x.755 OD x 1.1          |
| 26.      | 711-04565 | Pin, Hinge, Dia.3125                 | 65.      | 750-0212   | Spacer,.82 ID x 1.00 OD x.53          |
| 27.      | 712-0229  | Push Nut Retainer                    | 67.      | 754-0642   | Belt, V-Type, B Section               |
| 28.      | 712-0417A | Nut, Hex Flange, 5/8-18              | 68.      | 756-04129  | Pulley, Idler, 4.25 Dia.              |
| 29.      | 712-04065 | Nut, Lock, Flange, 3/8-16            | 69.      | 783-04013A | Bracket, Stabilizing                  |
| 30.      | 712-0641  | Hex Nut M16                          | 70.      | 683-04113A | Deck Assembly                         |
| 31.      | 712-04063 | Nut, Flange Lock, 5/16-18            |          | 783-04982  | Deck Shell                            |
| 32.      | 712-3010  | Nut, Hex, 5/16-18, Gr5               | 71.      | 783-04534  | Bracket, Mounting, 54" Roller         |
| 33.      | 712-3022  | Nut, Hex Lock, 1/2-13                | 72.      | 783-1454B  | Bracket, Roller, Front                |
| 34.      | 712-3083  | Hex Lock Nut, 1/2-13                 | 73.      | 783-04726  | Bracket, Idler                        |
| 35.      | 714-0145  | Pin, Click,.092 x 1.64               | 74.      | 783-1470A  | Cover, Spindle RH                     |
| 36.      | 714-0470  | Pin, Cotter, 1/8 x 1.25              | 75.      | 783-1471   | Cover, Spindle LH                     |
| 37.      | 714-0111  | Pin, Cotter, 3/32 x 1.00             | 76.      | 783-04690  | Deck Skirt                            |
| 38.      | 715-0108  | Pin, Spring 1/4 Dia x 1.00           | 77.      | 783-05030  | Bracket, Deflector Chute              |
| 39.      | 714-0162  | Cotter Pin                           | 78.      | 750-0933   | Spacer,.385 ID x.88 x.64              |

**IMPORTANT:** For a proper working machine, use Factory Approved Parts. **V-belts** are designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.

## Model GT 954H



| REF. NO. | PART NO.  | DESCRIPTION                       | REF. NO. | PART NO.  | DESCRIPTION                  |
|----------|-----------|-----------------------------------|----------|-----------|------------------------------|
| 1        | 710-0227  | Screw, #8-18 x.50                 | 10       | 725-0157  | Cable Tie                    |
| 2        | 710-0599  | Screw, 1/4-20 x.50                | 11       | 736-0300  | Lock Washer,.406 x.875 x.059 |
| 3        | 710-0726  | Screw, 5/16-18 x.750              | 12       | 751-3140  | Oil Drain Valve              |
| 4        | 783-0615D | Muffler Bracket                   | 13       | 751-10349 | Fuel Line Hose               |
| 5        | 751-3142  | Oil Drain Cap                     | 14       | 751-0564A | Muffler Deflector            |
| 6        | 710-0654A | Self-tapping Screw, 3/8-16 x 1.00 | 15       | 751-0805A | Muffler, Twin Inlet          |
| 7        | 712-3005  | Flange Lock Nut, 3/8-16           | 16       | 751-0645A | RH Exhaust Pipe              |
| 8        | 751-3141  | Oil Drain Hose                    | 17       | 751-0644  | LH Exhaust Pipe              |
| 9        | 726-0205  | Hose Clamp                        |          |           |                              |

# Model GT 954H

(MODEL PLATE)



777D03399  
Center On Rear Fender



777S32522



(QTY 2) 777D03126



777I20881  
Right Side  
Of Dash




777I20809




777X42332  
Place Under Hood

| REPLACEMENT PARTS |                            |             |                           |
|-------------------|----------------------------|-------------|---------------------------|
| Part Number       | Part Name                  | Part Number | Part Name                 |
| 777D03399         | Center On Rear Fender      | 777D03126   | Red and Black Oval        |
| 777S32522         | Safety Warning Label       | 777I20881   | Right Side Of Dash        |
| 777I20809         | Transmission Bypass Label  | 777X42332   | Place Under Hood          |
| 777D09742         | Operator's Right Hood Side | 777D09743   | Operator's Left Hood Side |
| 777X40219         | Reflective Insert          | 777D07778   | 54 INCH CUT               |
| 877S30036         | Deck Wash System           | 777S30015   | Keep Off Curve            |
| 777I22265         | Deck Wash System Label     | 777S30503   | Danger Label              |
| 777D09788         | Deck Wash System Label     | 777S30584   | Danger Label              |

777D09742  
Operator's Right Hood Side



777X40219  
Reflective Insert Placed On Grill  
Behind Headlight Lens



777D07778



877S30036

777I22265



777S30503



777D09788



777S30015  
KEEP OFF CURVE  
VERTICALLY ON DECK.



777S30584 REF.  
IN MOLDED AREA

