



SECTION 12: PARTS LIST FOR MODEL Z814K



Model Z814K

REF. NO.	PART NO.	DESCRIPTION
1.	710-0227	Self-tapping Screw, #8-18 x .50"
2.	710-0599	Self-tapping Screw, 1/4-20 x .50"
3.	712-0726	AB Screw 5/16-12 x 0.75"
4.	710-1237	Screw, #10-32 x .625
5.	710-1314A	Socket Cap Screw, 5/16-18 x .625
6.	710-1315	TT Screw 3/8-16 x 1.250"
7.	712-3017	Hex Nut 3/8-16
8.	721-0331	Sealant
9.	721-0460	Exhaust Gasket
10.	722-0263	Foam
11.	726-0205	Hose Clamp
12.	736-0119	Lock Washer
13.	736-0300	Flat Washer
15.	751B221535	Casing Clamp
16.	751-0535	Fuel Line Hose
17.	751-0564	Deflector: Muffler
18.	751-0616	Muffler: Dual Inlet
19.	751-0650	Exhaust Pipe RH
20.	751-0651	Exhaust Pipe LH
21.	751-3140	Oil Drain
22.	751-3141	Hose: Oil Drain Extension
23.	751-3142	Oil Drain Cap
24.	783-0615B	Heat Shield: Muffler
25.	783-0625C	Heat Shield

Model Z814K




Model Z814K

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	710-3015	Hex Cap Screw, 1/4-20 x .75	24	710-3217	Torx Screw, #8-32 x .375
2	710-0599	Self-tapping Screw, 1/4-20 x .5	25	712-0142	Hex Nut, 8-32
3	712-3027	Hex Flange Lock Nut, 1/4-20	26	731-0071C	Dash Panel, 4-style
4	710-0895	Self-Tapping Screw, 1/4-15 x .75	27	731-0072	Parking Brake Button
5	710-0924	Pan Phillips Screw, 1/4-20 x .75	28	731-1857	Throttle Control Lever
6	710-0528	Hex Cap Screw, 5/16-18 x 1.25	29	731-2106	Cruise Control Button
7	712-0292	U-type Speed Nut, 1/4-20	30	747-1155	Brake/Cruise Pivot Rod
8	712-3004A	Flange Lock Nut, 5/16-18	31	749-1087B	Dash Support Tube
9	726-0201	Speed Nut	32	731-2232	Intake Bellow (Model T614H)
10	747-2127	Hood Latch Rod	33	751-0658D	Fuel Tank, 3-gallon
11	731-1978	RH Head Light Lens	34	751-0603	Fuel Cap
	731-1979	LH Head Light Lens	35	725-1745	Ignition Key w/ plastic cover
12	747-1132A	Hood Support Rod		725-1744	Ignition Key w/o plastic cover
13	731-1980A	Hood	37	783-1000A	Grille Support Bracket
14	731-1981C	LH Side Panel	38	725-1976	Systems Indicator Monitor
15	731-1982C	RH Side Panel	39	725-1741	Ignition Switch
17	736-0342	Flat Washer, .283 x .75 x .030	40	625-0051	Headlight Assembly
18	736-0173	Flat Washer, .28 x .74 x .063	41	725-1752	Electric PTO Switch
19	736-3078	Flat Washer, .349 x 1.0 x .063	42	731-1995	RH Headlight Reflector
20	710-0642	Self-tapping Screw, 1/4-20 x 0.75		731-1996	LH Headlight Reflector
21	783-0808A	Hood Heat Shield w/o Intake Bellow	—	629-0469B	Headlight Wire Harness
22	710-0726	AB Screw, 5/16-12 x .75	—	629-0404B	PTO Wire Harness
23	710-0599	Self-tapping Screw, 1/4-20 x .50			

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665
Yard-Man Yellow: 0674
Powder Black: 0637

Model Z814K




Model Z814K

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	747-1324	Deck Stabilizer Rod	31	731-1993	Cover w/ Cup Holder
2	683-0462	Lift Shaft Assembly	32	736-3078	Flat Washer, .349 x 1.0 x .063
3	711-0332	Clevis Pin, .5 x .78	33	783-0677	Lift Adjustment Bracket
4	712-0206	Hex Nut, 1/2-13	34	783-1279	Fender
5	712-0431	Flange Lock Nut, 3/8-16	35	783-1489	Seat Mounting Bracket
6	712-3004A	Flange Lock Nut, 5/16-18	36	710-1268	Screw, #10-16 x .375
7	712-3083	Hex Nut, 1/2-13	37	712-3027	Hex Flange Lock Nut, 1/4-20
8	714-0104	Internal Cotter Pin	38	720-04026	Seat Adjuster Grip
9	714-0145	Internal Cotter Pin	39	731-04074	Spacer
10	716-0106	E-Ring	40	732-0499	Compression Spring, .41 x 1.5
11	720-0311	Handle Grip	41	736-0175	Spring Washer, .265 x .562 x .025
12	732-0874	Torsion Spring	42	736-0204	Flat Washer, .344 x .62 x .03
13	732-1184	Extension Spring	43	738-0137A	Shoulder Screw, .340 x .285, 1/4-20
14	736-0275	Flat Washer, 5/16	44	738-0966	Shoulder Screw
15	736-0921	Lock Washer, 1/2	45	783-0611	Seat Stop
16	736-3019	Flat Washer, .31 x 1.062 x .134	46	783-0738A	Seat Pivot Bracket
17	736-3084	Flat Washer, .51 x 1.12 x .06	47	783-04246	Seat Adjustment Lever
18	738-0138A	Hex Cap Screw, 5/16-18 x .62	48	783-0753	Seat Adjustment Selector
19	738-0143	Shoulder Screw, 3/8-16	49	757-0372	Seat, Yellow
20	741-0225	Hex Flange Bearing	50	735-0656	RH Foot Pad
21	741-0715	Snap Flange Bearing	51	735-0657	LH Foot Pad
22	746-0968	Lift Cable, 16.16		726-3046	Foot Pad Clips (Not Shown)
23	747-1111A	Lift Handle	52	714-0111	Cotter Pin
24	756-1154	Roller Pulley	53	731-0511	Trim Strip
25	783-0678A	Arm Lift	54	783-0209A	Seat Lift Bracket
26	783-0720A	Deck Stabilizer Bracket	55	783-1478	Fender Clip
27	710-0260A	Carriage Bolt, 5/16 x .62	56	731-2618	Fender Flare RH
28	710-0726	AB Screw, 5/16-12 x .75	57	731-2619	Fender Flare LH
29	710-0895	Self-tapping Screw, 1/4-15 x .75	59	710-0932	Carriage Screw 1/4-20 x 1.0"
30	731-1990	Lift Lever Cover			

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665
Yard-Man Yellow: 0674
Powder Black: 0637

Model Z814K




Model Z814K

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	710-1260A	Self-tapping Screw, 5/16-18 x .75	24	731-04065	Steering Wheel Cap
2	710-0604A	Self-tapping Screw, 16-18 x .625	25	638-0021A	LH Axle Assembly, .75 Diameter
3	783-0726B	RH Pivot Support Bracket	26	638-0022A	RH Axle Assembly, .75 Diameter
4	783-0727A	LH Pivot Support Bracket	27	719-0525B	Cast Iron Pivot Bar w/ Fittings, .75
5	783-0728	Pivot Bar Bracket	28	712-0431	Flange Lock Nut, 3/8-16
6	710-0514	Hex Cap Screw, 3/8-16 x 1	29	714-0162	Cotter Pin
7	711-1408	RH Drag Link	30	726-0341	Push Cap, .750
8	711-1409A	LH Drag Link	31	736-0242	Bell Washer, .34 x .872
9	712-0240	Jam Nut, 7/16-20	32	736-0285	Flat Washer, .635 x 1.589 x .06
10	712-0241	Hex Nut, 3/8-24	33	736-0331	Bell Washer, .39 x 1.13 x .062
11	712-0431	Flange Lock Nut, 3/8-16	34	738-1011	Shoulder Screw, .5 x 2.2, 3/8-16
12	712-0459	Flange Lock Nut, 7/16-20	35	710-0643	Hex Bolt, 5/16-18 X 1
13	712-3004A	Flange Lock Nut, 5/16-18	36	634-0105A	Wheel Assembly Complete, 15 x 6 x 6
14	717-1550D	Steering Gear, 11/90 Ratio		634-0172	Rim Only w/ Plastic Bearing
15	717-1554	Steering Pinion Gear		734-0255	Air Valve (Not Shown)
16	723-0448A	Ball Joint, 7/16-20		734-1731	Tire Only, Square Shoulder
17	736-0169	Lock Washer, 3/8	37	731-2290A	Hub Cap
18	736-3084	Flat Washer, .51 x 1.12 x .06	38	783-0653E	Steering Support Bracket
19	738-1001A	Steering Shaft, .625 OD x 24.4	39	738-0143	Shoulder Screw, 3/8-16
20	741-0475	Plastic Bushing, .38 ID	40	710-04095	Hex Screw 3/8-16 x 1.0
21	741-0656	Hex Flange Bearing, 5/8	41	17962	Switch Plate
22	738-0372B	Shoulder Spacer, .38 ID	42	710-0224	AB Screw #10-16 x 0.5
23	631-04008	Steering Wheel: 3 Spoke			

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665
Yard-Man Yellow: 0674
Powder Black: 0637

Model Z814K



Model Z814K

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	712-3050	Lug Nut, 3/4-16	40	647-0031B	Brake Control Assembly
2	629-0949A	Reverse/Ground Wire Harness Adapter	41	647-0049	Drive Control Assembly
3	683-0251	Double Idler Bracket Assembly	42	683-0267C	Hydro Pedal Assembly
4	710-0176	Hex Cap Screw, 5/16-18 x 2.75	43	710-0650	Self-tapping Screw, 5/16-18 x .875
5	710-0216	Hex Cap Screw, 3/8-16 x .75	44	710-1260A	Self-tapping Screw, 5/16-18 x .75
6	710-0227	Screw, #8-18 x .5	45	711-0736	Ferrule, 1/4-20
7	710-0344	Hex Cap Screw, 3/8-16 x 1.5	46	711-1363	Pin, 3/8-16 x 2.43
8	710-0599	Self-tapping Screw, 1/4-20 x .50	47	732-0335	Compression Spring, .40 OD x 1.17
9	710-0604A	Self-tapping Screw, 5/16-18 x .625	48	732-0955	Extension Spring, .50 OD x 1.41
10	710-3011	Hex Cap Screw, 3/8-16 x 2.25	49	732-0963	Extension Spring, .50 OD x 6.37
11	711-0677	Ferrule, 5/16-18	50	735-0662	Drive Pedal Pad
12	711-0832	Ferrule, 3/8-24	51	735-3049	Brake Pedal Pad
13	712-0431	Flange Lock Nut, 3/8-16	52	736-0133	Flat Washer, .411 x 1.25 x 1.0
14	712-3004A	Flange Lock Nut, 5/16-18	53	736-0142	Flat Washer, .281 x .50 x .063
15	712-3017	Hex Nut, 3/8-16	54	736-0187	Flat Washer, .64 x 1.24 x .06
16	714-0104	Internal Cotter Pin	55	736-0204	Flat Washer, .344 x .062 x .03
17	714-0111	Cotter Pin	56	736-3004	Flat Washer, .406 x .875 x .105
18	725-0157	Cable Tie	57	738-0155	Shoulder Screw, .437 x 1.62
19	725-1644	Short Spring Switch	58	738-0507B	Shoulder Screw, .5 x .434
20	726-0154	Push-mount Cable Tie	59	741-0225	Hex Flange Bearing
21	726-0320	Insulator Nut Plate	60	741-3065B	Split Hex Flange Bearing
22	732-0716	Extension Spring, .59 x 4.0	61	747-1137	Cruise Control Rod
23	732-0429A	Extension Spring, .5 x 3.97	62	747-1138	Brake Lock Control Rod
24	732-3118	Extension Spring, 3/8 x 1.44	63	748-0413	Cruise Latch
25	736-0140	Flat Washer, .385 x .62 x .063	64	748-0415B	Spacer, 5/16 x 1.54
26	736-0169	Lock Washer, 3/8	65	783-0653F	Steering Support Bracket
27	736-3008	Flat Washer, .344 x .750 x .120	66	783-0663C	Drive Lockout Bracket
28	736-3010	Flat Washer, .407 x .812 x .135	67	783-0773	Brake Pedal
29	738-0372B	Shoulder Spacer, .38	68	783-0693	Transmikssion Axle Bracket
30	747-1119	Hydrostatic Control Rod	69	634-0132	Wheel Assy. Complete, 23 x 9.5 x 12
31	747-1121	Hydrostatic Bypass Rod		634-0194	Rim Only
32	747-1122	Hydrostatic Brake Rod		734-0255	Air Valve (Not Shown)
33	750-0535	Spacer, .376 x .625 x .22		734-1728	Tire Only, Square Shoulder
34	754-0349	Drive Belt	70	731-2290	Hub Cap
35	756-0116	V-idler Pulley, 3.06	71	736-0316	Flat Washer, .780 x 1.59 x .062
36	756-0981A	Flat Idler Pulley, 2.75	72	712-3026	Jam Nut, 3/4-16
37	783-0667A	Transmission Torque Bracket	73	710-1611B	Self-tapping Screw, 5/16-18 x .75
38	783-0745	Speed Control Bracket	74	756-0978A	Engine Pulley
39	783-0782	Switch Actuator Bracket	—	618-0379	Hydrostatic Transmission Assembly


NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665

Yard-Man Yellow: 0674

Powder Black: 0637

Model Z814K



Model Z814K

Ref. No.	Part No.	Description
1.	710-0604A	TT Screw 5/16-18 x 0.625"
2.	732-04035	Compression Spring
3.	738-1020	Shoulder Screw 0.625 x 0.5
4.	736-0407	Bell Washer
5.	712-0459	Flange Lock Nut
6.	736-0222	Lock Washer, 1/4
7.	725-1426	Solenoid: 12 V., 100 amp.
8.	710-0599	TT Screw 1/4-20 x 0.5"
9.	736-0329	Lock Washer, 1/4
10.	723-0444	Battery Strap
11.	712-0271	Hex Sems Nut 1/4-20
12.	712-3087	Wing Nut
13.	783-1033A	Hitch Plate
14.	725-1706	Battery: 12 V., 270 CCA
15.	738-1132	Shoulder Screw
16.	710-0703	Carriage Screw 1/4-20 x 0.75"
17.	712-3006	Hex Nut 1/4-20
18.	783-0349	Battery Tray
19.	683-0304C	Lower Frame Assembly
20.	712-0431	Flange Lock Nut 3/8-16
21.	710-3025	Hex Screw 5/16-18 x 0.625
22.	712-3004A	Flange Lock Nut 5/16-18
23.	756-0978A	Engine Pulley: Electric PTO
24.	683-0618	Clutch Bracket Assembly: 54" Deck
26.	710-1652	Hex Head Washer Screw
27.	783-0891B	Deck Stop
28.	748-0415B	Spacer
29.	783-0653E	Steering Support Bracket
30.	710-0859	Hex Screw 3/8-16 x 2.5"
31.	717-1774	Electric PTO Clutch
32.	736-0322	Flat Washer
33.	736-0171	Lock Washer
34.	710-3157	Hex Bolt 7/16-20 x 3.25"
—	629-0469B	Harness Assembly: Headlight
—	629-04048	Harness Assembly: PTO


NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665

Yard-Man Yellow: 0674

Powder Black: 0637

Model Z814K



Model Z814K

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1.	12650	Bracket, Adjustment, Height	40.	717-1553B	Adjustment, Deck, Gear
2.	16606	Bracket, Hook, Retainer	41.	721-04041	Water Nozzle Adaptor
3.	618-0671	Spindle Assembly, Pulley, 5.39 Dia x .5625	43.	731-0335	Roller, Deck
4.	683-0254	Bracket Assembly, Deck, Hanger LH	44.	731-3005	Front Roller
5.	683-0459	Idlr Assembly, 54"	45.	731-3131A	Deflector, Chute
6.	683-0608	Bracket Assembly, Lift, 54"	46.	732-0306	Spring, Compression, .406 x .531 x 1.75
7.	683-0609	Bracket Assembly, LH-Front	47.	732-0459	Spring, Extension, .94 Dia x 6.74
8.	683-0610	Bracket Assembly, RH-Front	48.	732-0934	Spring, Extension, 1.15 Dia x 5.99
9.	683-0617	Stop Assembly, Chute	49.	732-3070	Torsion Spring .44 I.d. x 2.10
10.	703-2093	Baffle, RR, Inner	50.	734-3058B	Deck Wheel, 5" Dia.
11.	703-2392	Bracket	51.	736-0119	Lock Washer
12.	703-3511	Guard, Finger	52.	736-0134	Flat Washer, .812 ID x 1.38 OD x .1
13.	710-0216	Hex Screw 3/8-16 x 0.75	53.	736-0208	Flat Washer, .51 ID x 1.5 OD x .07
14.	710-0514	Hex Screw 3/8-16 x 1.0	54.	736-0760	Lock Washer
15.	710-0528	Hex Screw, 5/16-18 x 1.25	55.	736-0921	Washer, Lock, 1/2 , Regular Duty
16.	710-0602	Screw, Self-tapping, 5/16-18 x 1.000	56.	736-3039	Flat Washer .406 ID X 1.5 x 11ga
17.	710-0726	Screw, AB, 5/16-12 x 0.75	57.	736-3072	Washer, Flat .38 ID x.93 OD x.110
18.	710-0751	Hex Screw, 1/4-20 x .620	58.	737-04003	Water Nozzle: Deck Wash-Out System
19.	710-1644	Screw, Carriage, 3/8-16 x 5.00	59.	738-0295	Shoulder Screw, .750 x .47.12
20.	710-3011	Hex Screw, 3/8-16 x 2.25	60.	738-1229A	Shoulder Screw
21.	710-3073	Hex Screw, 5/16-18 x 2.25	61.	738-3056	Shoulder Screw, 1/2 Dia x 2.50 .
22.	710-3168	Bolt, Carriage, 3/8-16 x 1.0	62.	742-0677	Blade, 18.50"
23.	710-3178	Short Neck Carriage Bolt 3/8-16 x .75	63.	747-1116	Deck Release Handle Rod, .375 Dia
24.	711-0332	Pin, Clevis, .50 Dia x .78	64.	750-0151	Spacer .550 ID x .755 OD x 1.1
25.	711-1737	Pin, Roller, .5" Dia x 10.06 .	65.	750-0212	Spacer, .82 ID x 1.00 OD x .53
26.	711-1762	Pin, Hinge, Dia .375 x 14.06	66.	750-3213	Spacer, .405 x .75 x 3.875
27.	712-0229	Push Nut Retainer	67.	754-0642	Belt, V-Type, B Section
28.	712-0417A	Nut, Hex Flange, 5/8-18	68.	756-3105	Pulley, Idler, 5.0 Dia.
29.	712-0431	Nut, Flange Lock, 3/8-16	69.	783-04013A	Bracket, Stabilizing
30.	712-0641	Hex Nut M16	70.	783-04232	Deck: SD w/Water Nozzle Ftg.
31.	712-3004A	Nut, Flange Lock, 5/16-18, Gr5	71.	783-1453	Bracket, Mounting, 54" Roller
32.	712-3010	Nut, Hex, 5/16-18, Gr5	72.	783-1454	Bracket, Roller, Front
33.	712-3022	Nut, Hex Lock, 1/2-13	73.	783-1455	Bracket, Idler
34.	712-3027	Nut, 1/4-20, Hexflg, Lock	74.	783-1470	Cover, Spindle RH
35.	714-0145	Pin, Click, .092 x 1.64	75.	783-1471	Cover, Spindle LH
36.	714-0470	Pin, Cotter, 1/8 x 1.25	76.	783-1482	RH Skirt
37.	714-3004	Pin, Cotter, 3/32 x 1.25	77.	783-1483	LH Skirt
38.	715-0108	Pin, Sprg, 1/4 Dia x 1.00	78.	783-1484	LH Extension Skirt
39.	715-0246	Pin, Spring, 3/16 x 1.25			