


# Illustrated Parts List



## **Pedal Drive Garden Tractor**

**Model Series  
808H & 808K**


**IMPORTANT:** Read safety rules and instructions carefully before operating equipment.

**Warning:** This unit is equipped with an internal combustion engine and should not be used on or near any unimproved forest-covered, brush-covered or grass-covered land unless the engine's exhaust system is equipped with a spark arrester meeting applicable local or state laws (if any). If a spark arrester is used, it should be maintained in effective working order by the operator. In the State of California the above is required by law (Section 4442 of the California Public Resources Code). Other states may have similar laws. Federal laws apply on federal lands. A spark arrester for the muffler is available through your nearest engine authorized service dealer or contact the service department, P.O. Box 361131 Cleveland, Ohio 44136-0019.

**MTD LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019**

(12/2002)


# SECTION 12: PARTS LIST FOR MODELS 808H & 808K



## Models 808H & 808K

| REF.<br>NO. | PART<br>NO. | DESCRIPTION                       |
|-------------|-------------|-----------------------------------|
| 1           | 710-0227    | Self-tapping Screw, #8-18 x .5    |
| 2           | 710-0599    | Self-tapping Screw, 1/4-20 x .5   |
| 3           | 710-0726    | AB Screw, 5/16-12 x .75           |
| 4           | 710-1237    | Screw, #10-32 x .625              |
| 5           | 710-1314A   | Socket Cap Screw, 5/16-18 x .625  |
| 6           | 710-1315    | Self-tapping Screw, 3/8-16 x 1.25 |
| 7           | 712-3017    | Hex Nut, 3/8-16                   |
| 8           | 721-0460    | Exhaust Gasket                    |
| 9           | 726-0205    | Hose Clamp                        |
| 10          | 736-0119    | Lock Washer, 5/16                 |
| 11          | 736-0300    | Flat Washer                       |
| 12          | 751B221535  | Casing Clamp                      |
| 13          | 751-0535    | Fuel Line Hose                    |
| 14          | 751-0564    | Muffler Deflector                 |
| 15          | 751-0616    | Muffler, Twin Inlet               |
| 16          | 751-0650    | RH Exhaust Pipe                   |
| 17          | 751-0651    | LH Exhaust Pipe                   |
| 18          | 751-3140    | Oil Drain Valve                   |
| 19          | 751-3141    | Oil Drain Hose                    |
| 20          | 751-3142    | Oil Drain Cap                     |
| 21          | 783-0615B   | Muffler Heat Shield               |
| 22          | 783-0625C   | Engine Heat Shield                |
| 23          | 722-0263    | Foam (fits over fuel line)        |
| 24          | 746-1086    | Throttle Cable                    |

# Models 808H & 808K




## Models 808H & 808K

| REF. NO. | PART NO.  | DESCRIPTION                   |
|----------|-----------|-------------------------------|
| 1.       | 726-3046  | Ratchet Clip                  |
| 2.       | 731-2247A | Hood Shield                   |
| 3.       | 747-1184  | Support Rod: Air Duct         |
| 4.       | 783-0478A | Hood: 8 Style                 |
| 5.       | 683-0195  | Bracket Assembly              |
| 6.       | 710-0351  | Pan Head B Screw #10-16 x 0.5 |
| 7.       | 710-0376  | Hex Screw 5/16-18 x 1.0       |
| 8.       | 710-0456  | Hex Screw #10-16 x 0.5        |
| 9.       | 710-0599  | TT Screw 1/4-20 x 0.5         |
| 10.      | 710-0751  | Hex Screw 1/4-20 x 0.620      |
| 11.      | 710-0896  | AB Screw 1/4-14 x 0.625       |
| 12.      | 710-0924  | Machine Screw 1/4-20 x 0.75   |
| 13.      | 712-0271  | Sems Nut                      |
| 14.      | 712-0292  | Nut: Clip                     |
| 15.      | 712-0431  | Flange Lock Nut               |
| 16.      | 726-0211  | U-Nut 5/16-18                 |
| 17.      | 731-1854A | Lens: 8 Style                 |
| 18.      | 735-0126  | Rubber Washer                 |
| 19.      | 735-0199A | Rubber Bumper                 |
| 20.      | 736-3039  | Flat Washer                   |
| 21.      | 783-0475B | LH Panel: SD, 8 Style         |
| 22.      | 783-0476C | RH Panel: SD, 8 Style         |
| 23.      | 783-0477A | Grill: 8 Style                |
| 24.      | 783-0553A | Support Bracket: Hood         |
| 25.      | 783-1495  | Hinge Bracket: Hood           |
| 26.      | 710-0726  | AB Screw 5/16-20 x 0.750      |
| 27.      | 751-0603  | Fuel Cap                      |
| 28.      | 751-06580 | Fuel Tank                     |
| 29.      | 710-0599  | TT Screw 1/4-20 x 0.5         |
| 30.      | 710-0642  | TT SCrew 1/4-20 x 0.75        |
| 31.      | 710-0650  | TT Screw 5/16-18 x 0.875      |
| 33.      | 710-0895  | Hi-lo Screw 1/4-15 x 0.75     |
| 34.      | 710-1611B | TT Screw 5/16-18 x 0.75       |
| 35.      | 710-3217  | Machine Screw #8-32 x 0.375   |
| 36.      | 712-0142  | Nut 8-32                      |
| 37.      | 731-04215 | Cruise Lever                  |
| 38.      | 731-04217 | Brake Lever                   |
| 39.      | 731-1857  | Control Knob                  |
| 40.      | 731-2122C | Dash Panel                    |
| 41.      | 736-0142  | Flat Washer                   |
| 42.      | 736-0270  | Bell Washer                   |
| 43.      | 736-3078  | Flat Washer                   |
| 44.      | 747-1196  | Bent Rod: Lever               |
| 45.      | 749-1087C | Support Tube: Dash            |
| 46.      | 768-0010  | Bumper Assembly*              |
| 47.      | 714-0145  | Internal Cotter Pin*          |
| 48.      | 710-1611B | TT Screw 5/16-18 x 0.75*      |
| —        | 629-0469A | Headlight Wire Harness        |
| —        | 629-1067  | Tractor Wire Harness          |

\*Not standard on all tractors.


# Models 808H & 808K



## Models 808H & 808K

| REF. NO. | PART NO.  | DESCRIPTION                      | REF. NO. | PART NO.  | DESCRIPTION                         |
|----------|-----------|----------------------------------|----------|-----------|-------------------------------------|
| 1        | 747-1130B | Deck Stabilizer Rod (Model 808H) | 31       | 731-1993  | Cover w/ Cup Holder                 |
|          | 747-1324  | Deck Stabilizer Rod (Model 808K) | 32       | 736-3078  | Flat Washer, .349 x 1.0 x .063      |
| 2        | 683-0197B | Lift Shaft Assembly (Model 808H) | 33       | 783-0677  | Lift Adjustment Bracket             |
|          | 683-0462  | Lift Shaft Assembly (Model 808K) | 34       | 783-1280  | Fender                              |
| 3        | 711-0332  | Clevis Pin, .5 x .78             | 35       | 783-1489  | Seat Mounting Bracket               |
| 4        | 712-0206  | Hex Nut, 1/2-13                  | 36       | 710-1268  | Screw, #10-16 x .375                |
| 5        | 712-0431  | Flange Lock Nut, 3/8-16          | 37       | 712-3027  | Hex Flange Lock Nut, 1/4-20         |
| 6        | 712-3004A | Flange Lock Nut, 5/16-18         | 38       | 720-0309A | Seat Adjuster Grip                  |
| 7        | 712-3083  | Hex Nut, 1/2-13                  | 39       | 731-1989  | Spacer                              |
| 8        | 714-0104  | Internal Cotter Pin              | 40       | 732-0499  | Compression Spring, .41 x 1.5       |
| 9        | 714-0145  | Internal Cotter Pin              | 41       | 736-0175  | Spring Washer, .265 x .562 x .025   |
| 10       | 716-0106  | E-Ring                           | 42       | 736-0204  | Flat Washer, .344 x .62 x .03       |
| 11       | 720-0311  | Handle Grip                      | 43       | 738-0137A | Shoulder Screw, .340 x .285, 1/4-20 |
| 12       | 732-0874  | Torsion Spring                   | 44       | 738-1007  | Shoulder Screw, .50 x .50, 3/8-16   |
| 13       | 732-1184  | Extension Spring, .84 x 4.6      | 45       | 783-0611  | Seat Stop                           |
| 14       | 736-0275  | Flat Washer, 5/16                | 46       | 783-0738  | Seat Pivot Bracket                  |
| 15       | 736-0921  | Lock Washer, 1/2                 | 47       | 783-0739  | Seat Adjustment Lever               |
| 16       | 736-3019  | Flat Washer, .31 x 1.062 x .134  | 48       | 783-0753  | Seat Adjustment Selector            |
| 17       | 736-3084  | Flat Washer, .51 x 1.12 x .06    | 49       | 757-04010 | High Back Seat, Black               |
| 18       | 738-0138A | Hex Cap Screw, 5/16-18 x .62     | 50       | 735-0656  | RH Foot Pad                         |
| 19       | 738-0143  | Shoulder Screw, 3/8-16           | 51       | 735-0657  | LH Foot Pad                         |
| 20       | 741-0225  | Hex Flange Bearing               | —        | 726-3046  | Foot Pad Clips                      |
| 21       | 741-0715  | Snap Flange Bearing              | 52       | 714-0111  | Cotter Pin                          |
| 22       | 746-0968  | Lift Cable, 16.16                | 54       | 783-0209A | LH Seat Lift Bracket                |
| 23       | 747-1111A | Lift Handle                      | —        | 17239A    | RH Seat Lift Bracket                |
| 24       | 756-1154  | Roller Pulley                    | 55       | 710-0924  | Phillips Pan Screw, 1/4-20 x .75    |
| 25       | 783-0678A | Arm Lift                         | 56       | 712-0292  | U-type Speed Nut, 1/4-20            |
| 26       | 783-0720A | Deck Stabilizer Bracket          | 57       | 731-2480  | Shift Lever Cover                   |
| 27       | 710-0260A | Carriage Bolt, 5/16 x .62        | 58       | 738-0296  | Shoulder Screw, .437 x .286         |
| 28       | 710-0726  | AB Screw, 5/16-12 x .75          | 59       | 731-2618  | RH Fender Flare                     |
| 29       | 710-0895  | Self-tapping Screw, 1/4-15 x .75 | 60       | 731-2619  | LH Fender Flare                     |
| 30       | 731-1990  | Lift Lever Cover                 | 61       | 783-1478  | Fender Clips                        |


# Models 808H & 808K



## Models 808H & 808K

| REF.<br>NO. | PART<br>NO. | DESCRIPTION                            |
|-------------|-------------|----------------------------------------|
| 1           | 710-1260A   | Self-tapping Screw, 5/16-18 x .75      |
| 2           | 710-0604A   | Self-tapping Screw, 16-18 x .625       |
| 3           | 783-0726B   | RH Pivot Support Bracket               |
| 4           | 783-0727A   | LH Pivot Support Bracket               |
| 5           | 783-0728    | Pivot Bar Bracket                      |
| 6           | 710-0514    | Hex Cap Screw, 3/8-16 x 1 (Grade 5)    |
| 7           | 711-1408    | RH Drag Link                           |
| 8           | 711-1409A   | LH Drag Link                           |
| 9           | 712-0240    | Jam Nut, 7/16-20 (Grade 2)             |
| 10          | 712-0241    | Hex Nut, 3/8-24 (Grade 2)              |
| 11          | 712-0431    | Flange Lock Nut, 3/8-16                |
| 12          | 712-0459    | Flange Lock Nut, 7/16-20               |
| 13          | 712-3004A   | Flange Lock Nut, 5/16-18               |
| 14          | 717-1550D   | Steering Gear, 11/90 Ratio             |
| 15          | 717-1554    | Steering Pinion Gear                   |
| 16          | 723-0448A   | Ball Joint, 7/16-20                    |
| 17          | 736-0169    | Lock Washer, 3/8                       |
| 18          | 736-3084    | Flat Washer, .51 x 1.12 x .06          |
| 19          | 738-1001A   | Steering Shaft, .625 OD x 24.4         |
| 20          | 741-0475    | Plastic Bushing, .38 ID                |
| 21          | 741-0656    | Hex Flange Bearing, 5/8                |
| 22          | 738-0372B   | Shoulder Spacer, .38 ID                |
| 23          | 631-04008   | Steering Wheel, Three Spoke, Soft Grip |
|             | 631-04028   | Steering Wheel, Three Spoke            |
| 24          | 731-04040   | Steering Wheel Cap, Round w/logo       |
|             | 731-04039   | Steering Wheel Cap, Round              |
| 25          | 638-0017    | LH Axle Assembly, .75 Diameter         |
| 26          | 638-0018    | RH Axle Assembly, .75 Diameter         |
| 27          | 719-0525B   | Cast Iron Pivot Bar w/ Fittings, .75   |
| 28          | 712-0431    | Flange Lock Nut, 3/8-16                |
| 29          | 714-0162    | Cotter Pin                             |
| 30          | 726-0341    | Push Cap, .750                         |
| 31          | 736-0242    | Bell Washer, .34 x .872                |
| 32          | 736-0316    | Flat Washer, .78 x 1.59 x .06          |
| 33          | 736-0285    | Flat Washer, .635 x 1.589 x .06        |
| 34          | 738-1011    | Shoulder Screw, .5 x 2.2, 3/8-16       |
| 35          | 710-0643    | Hex Bolt, 5/16-18 X 1                  |
| 36          | 634-0183    | Wheel Assembly Complete, 16 x 6.5 x 8  |
|             | 634-0182    | Rim Only w/ Plastic Bearing            |
|             | 734-0255    | Air Valve (Not Shown)                  |
|             | 734-1727    | Tire Only, Square Shoulder             |
| 37          | 734-2290    | Hub Cap                                |
| 38          | 783-0653E   | Steering Support Bracket               |
| 39          | 738-0143    | Shoulder Screw, 3/8-16                 |
| 40          | 736-0331    | Bell Washer, .39 x 1.13 x .062         |
| 41          | 710-04095   | Hex Bolt 3/8-16 x 1.0 Special          |

# Models 808H & 808K




## Models 808H & 808K

| REF. NO. | PART NO.  | DESCRIPTION                       | REF. NO. | PART NO.  | DESCRIPTION                            |
|----------|-----------|-----------------------------------|----------|-----------|----------------------------------------|
| 1        | 618-0375  | Variable-speed Bracket Assembly   | 45       | 783-0669  | Idler Bracket                          |
| 2        | 618-0376  | Two-speed Transmission Assembly   | 46       | 647-0031B | Brake Control Shaft Assembly           |
| 3        | 631-0009A | Shifter Knob                      | 47       | 647-0032  | Speed Control Shaft Assembly           |
| 4        | 647-0037  | Shift Lever                       | 48       | 683-0266  | Drive Pedal Assembly                   |
| 5        | 656-0050  | Variable-speed Pulley Assembly    | 49       | 710-1135  | Self Tapping Screw, 5/16-18 x 2.5      |
| 6        | 756-0665  | Transmission Pulley, 8.5          | 50       | 711-0736  | Ferrule, 1/4-20                        |
| 7        | 683-0251  | Double-Idler Bracket              | 51       | 711-1363  | Pin, 3/8-16 x 2.43                     |
| 8        | 710-0176  | Hex Cap Screw, 5/16-18 x 2.75     | 52       | 714-0104  | Cotter Pin                             |
| 9        | 710-0227  | Self Tapping Screw, #8-18 x .5    | 53       | 732-0437  | Compression Spring, .34 OD x 1.0       |
| 10       | 710-0347  | Hex Cap Screw, 3/8-16 x 1.75      | 54       | 732-0955  | Extension Spring, .5 OD x 1.41         |
| 11       | 710-0805  | Hex Cap Screw, 5/16-18 x 1.5      | 55       | 735-0662  | Drive Pedal Pad                        |
| 12       | 710-0809  | Self-tapping Screw, 1/4-20 x 1.25 | 56       | 735-3049  | Brake Pedal Pad                        |
| 13       | 710-0726  | AB Screw, 5/16-12 x .75           | 57       | 736-0140  | Flat Washer, .281 x .5 x .0625         |
| 14       | 710-3011  | Hex Cap Screw, 3/8-16 x 2.25      | 59       | 736-0187  | Flat Washer, .64 x 1.24 x .06          |
| 15       | 711-0677  | Ferrule, 5/16 x .312 Dia.         | 60       | 736-0204  | Flat Washer, .344 x .062 x .03         |
| 16       | 712-0181  | Hex Jam Nut, 3/8-16               | 61       | 738-0155  | Shoulder Screw, .437 x 1.62            |
| 17       | 712-0702  | Hex Flange Nut, 7/16-20           | 62       | 738-0507B | Shoulder Screw, .5 x .434              |
| 18       | 712-0431  | Flange Lock Nut, 3/8-16           | 63       | 741-0225  | Hex Flange Bearing                     |
| 19       | 712-0798  | Hex Nut, 3/8-16                   | 64       | 741-3065B | Split Hex Flange Bearing               |
| 20       | 712-3004A | Flange Lock Nut, 5/16-18          | 65       | 747-04096 | Cruise Control Rod                     |
| 21       | 712-3008  | Hex Jam Nut, 3/8-16               | 66       | 747-04093 | Brake Lock Control Rod                 |
| 22       | 714-0111  | Cotter Pin                        | 67       | 748-0413  | Cruise Latch                           |
| 23       | 723-3018  | Ball Joint, 3/8-24                | 68       | 748-0415B | Spacer, 5/16 x 1.54                    |
| 24       | 710-1260A | LD Screw 5/16-18 x 0.75           | 69       | 783-0653F | Steering Support Bracket               |
| 25       | 710-0650  | TT Screw 5/16-18 x 0.875          | 70       | 783-0732  | Drive Lockout Bracket                  |
| 26       | 732-0384  | Extension Spring, .62 Dia. x 6.12 | 71       | 783-0773  | Brake Pedal                            |
| 27       | 732-0716  | Extension Spring, .59 OD x 4.0    | 72       | 736-3008  | Flat Washer, .344 x .750 x .120        |
| 28       | 736-0105  | Bell Washer, .401 x .870 x .063   | 73       | 783-0693  | Axle Bracket                           |
| 29       | 736-0169  | Lock Washer, 3/8                  | 74       | 683-0304A | Lower Frame Assembly                   |
| 30       | 736-0275  | Flat Washer, 5/16                 | 75       | 732-0963  | Extension Spring, .5 OD x 6.37         |
| 31       | 718-0771  | Pulley Hub, 1/2 Spline            | 76       | 731-2290  | Hub Cap                                |
| 32       | 736-0642  | Flat Washer, .44 x .75 x .06      | 77       | 712-3050  | Lug Nut, 7/16-14                       |
| 33       | 736-3010  | Flat Washer, .407 x .812 x .135   | 78       | 634-0132  | Wheel Assembly Complete, 23 x 9.5 x 12 |
| 34       | 738-0322  | Shoulder Screw, .625 Dia. x .21   |          | 634-3178  | Rim Only                               |
| 35       | 747-1122  | Brake Rod                         |          | 734-0255  | Air Valve                              |
| 36       | 747-1123A | Belt Guard                        |          | 734-1728  | Tire Only, Square Shoulder             |
| 37       | 747-1127  | Idler Adjustment Rod, 3/8         | 79       | 750-0768  | Split Spacer, .25 x .37 x 1.32         |
| 38       | 710-1026  | Self-tapping Screw, 1/4-20 x 1.75 | 80       | 750-0566A | Spacer, .372 x .26 x 1.03              |
| 39       | 747-1185  | Transmission Belt Guard Rod       | 81       | 712-3026  | Jam Nut, 3/4-16                        |
| 40       | 738-0372B | Shoulder Spacer, .380 ID          | 82       | 736-0316  | Flat Washer, .78 x 1.59 x .06          |
| 41       | 754-0468  | Variable-speed Belt               | 83       | 710-1611B | TT Screw, 5/16-18 x .75                |
| 42       | 754-0467  | Drive Belt                        | 84       | 747-1185  | Transmission Belt Guard Rod            |
| 43       | 756-0981A | Flat Idler, 2.75 OD               | 85       | 710-0599  | Self Tapping Screw, 1/4-20 x .5        |
| 44       | 783-0667B | Transmission Torque Bracket       | 86       | 756-0639A | Engine Pulley, 3.56"                   |

**IMPORTANT:** For a proper working machine, use Factory Approved Parts. **V-belts** are designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.

Models 808H & 808K



## Models 808H & 808K


| REF. NO. | PART NO.  | DESCRIPTION                        |
|----------|-----------|------------------------------------|
| 1        | 618-0225  | Reverse Collar Assembly            |
| 2        | 618-0226  | Hi-Lo Collar Assembly              |
| 3        | 618-0227A | Shift Fork Assembly                |
| 4        | 618-0284  | Detent Block Assembly              |
| 5        | 618-0285  | Output Bearing Block Assembly      |
| 6        | 618-0286  | Output Seal Bearing Block Assembly |
| 7        | 618-0287  | Inboard Sealed Axle Block Assembly |
| 8        | 618-0302  | Inboard Sealed Axle Block Assembly |
| 9        | 618-0365  | Wheel Hub Assembly                 |
| 10       | 618-0368  | Differential Axle Assembly         |
| 11       | 719-0379A | Upper Housing                      |
| 12       | 641-0002A | Axle Bearing Block Assembly        |
| 13       | 661-0012  | Brake Assembly                     |
| 14       | 710-0642  | Self-tapping Screw, 1/4-20 x .75   |
| 15       | 710-0788  | Self-tapping Screw, 1/4-20 x 1.0   |
| 16       | 711-1051A | Drive Shaft                        |
| 17       | 711-1216  | Output Shaft                       |
| 18       | 712-1329  | Nut, 3/4-16                        |
| 19       | 713-0446  | 9-tooth Sprocket                   |
| 20       | 713-0447  | 16-tooth Sprocket                  |
| 21       | 713-0448  | 22-link Chain, .625                |
| 22       | 716-0131  | External Snap Ring                 |
| 23       | 717-0678  | Brake Pad                          |
| 24       | 717-1438  | 41-tooth Bevel Gear                |
| 25       | 717-1439  | 20-tooth Spur Gear                 |
| 26       | 717-1440  | 10-tooth Spur Gear                 |
| 27       | 717-1441  | 27-tooth Spur Gear                 |
| 28       | 717-1442  | 37-tooth Spur Gear                 |
| 29       | 718-0500  | Inner Axle Bearing Block           |
| 30       | 718-0504  | Shifter Insert                     |
| 31       | 718-0505  | Shifter Cover                      |
| 32       | 718-0537  | Shifter Bearing Block              |
| 33       | 719-0385  | Lower Housing                      |
| 34       | 718-0540  | Lockout Plate                      |
| 35       | 736-0337  | Flat Washer, 5/8 x 1.0             |
| 36       | 736-3046A | Flat Washer, 1.01 x 1.86 x .060    |
| 37       | 711-1235  | Input Shaft                        |
| 38       | 747-1140  | Shift Lever                        |
| 39       | 750-1033A | Spacer, 1.13 x 1.38 x 1.968        |
| 40       | 761-0215  | Disc Brake                         |
| 41       | 716-0114  | Retaining Ring, .56                |
| 42       | 717-1463  | 13-tooth Bevel Gear                |
| 43       | 736-0335  | Flat Washer                        |
| 44       | 736-0336  | Flat Washer, 5/8 x 1.0 x .030*     |
|          | 736-0337  | Flat Washer, 5/8 x 1.0 x .040*     |
|          | 736-0349  | Flat Washer, 5/8 x 1.0 x .020*     |
| 46       | 741-0335  | Needle Bearing                     |
| 47       | 741-0696  | Needle Bearing                     |
| 48       | 716-0231  | E-ring, .75                        |
| 49       | 618-0376  | Transmission Assembly Complete     |

**NOTE:** Transmission has a grease capacity of 32 oz. Order part number 737-0148.

**NOTE:** Upon reassembling transmission input shaft for any reason, refill its cavity with approximately 2/3 oz. of grease. Order part number 737-0289.

\*Use applicable flat washer (12a, 12b or 12c) in this application allowing proper end-play as instructed in Service Manual.


# Model 808H



# Model 808H

| REF. NO. | PART NO.  | DESCRIPTION                           | REF. NO. | PART NO.  | DESCRIPTION                   |
|----------|-----------|---------------------------------------|----------|-----------|-------------------------------|
| 1.       | 783-0653E | Steering Support Bracket              | 36.      | 736-0407  | Bell Washer, .45 x 1.0 x .062 |
| 2.       | 647-0064  | PTO Lever Engagement Assembly         | 37.      | 738-1132  | Shoulder Screw                |
| 3.       | 683-04060 | Engagement Plate Assembly             | 38.      | 754-0228  | PTO Belt (shown on next page) |
| 4.       | 710-1002  | Hex Bolt 7/16-20 x 2.0                | 40.      | 783-0693  | Axle Bracket                  |
| 5.       | 710-0276  | Carriage Screw 5/16-18 x 1.0          | 41.      | 712-3006  | Hex Nut 1/4-20                |
| 6.       | 710-0344  | Hex Screw 3/8-16 x 1.5                | 42.      | 736-0329  | Lock Washer                   |
| 7.       | 710-1238  | Hex Head Washer Screw, 5/16-18 x .875 | 43.      | 710-0607  | TT Screw 5/16-18 x 0.5        |
| 8.       | 710-3261  | Hex Screw 3/8-16 x 7.0                | 44.      | 710-0642  | TT Screw 1/4-20 x 0.75        |
| 10.      | 712-0431  | Flange Lock Nut                       | 45.      | 725-1657A | Switch                        |
| 11.      | 712-3004A | Flange Lock Nut                       | 46.      | 17962     | Switch Plate                  |
| 12.      | 712-3010  | Hex Nut                               | 47.      | 710-0224  | AB Screw #10-16 x 0.5         |
| 13.      | 714-0470  | Cotter Pin                            | 48.      | 683-0304C | Lower Frame Assembly          |
| 14.      | 726-0201  | Speed Nut                             | 49.      | 711-1428  | Belt Guard Pin                |
| 15.      | 710-3025  | Hex Cap Screw 5/16-18 x .625          | 50.      | 712-0229  | Push Nut Retainer             |
| 16.      | 732-0944  | Extension Spring                      | 51.      | 731-2111A | PTO Knob                      |
| 17.      | 732-0991A | Belt Guard                            | 52.      | 736-0108  | Flat Washer                   |
| 18.      | 732-1013  | Belt Guard                            | 53.      | 736-0119  | Lock Washer                   |
| 19.      | 725-1706  | 12 V Battery                          | 54.      | 736-0140  | Flat Washer                   |
| 20.      | 710-0751  | Hex Cap Screw, 1/4-20 x .62           | 55.      | 736-0242  | Bell Washer                   |
| 21.      | 712-0271  | Hex Sems Nut, 1/4-20                  | 56.      | 736-0258  | Flat Washer                   |
| 22.      | 712-3087  | Wing Nut, 1/4-20                      | 57.      | 736-0275  | Flat Washer                   |
| 23.      | 725-1426  | Solenoid, 12-Volt, 100 Amp            | 58.      | 736-0300  | Flat Washer                   |
| 24.      | 710-0599  | Self Tapping Screw, 1/4-20 x .5       | 59.      | 736-3072  | Flat Washer                   |
| 25.      | 736-0222  | Lock Washer, 1/4                      | 60.      | 738-0372B | Shoulder Spacer               |
| 26.      | 783-1033A | Hitch Plate                           | 61.      | 747-1112D | Deck Engagement Handle        |
| 27.      | 748-0415B | Spacer                                | 62.      | 747-1243  | Belt Keeper Rod               |
| 28.      | 741-0708  | Hex Split Flange Bearing              | 63.      | 756-0487  | Idler Pulley                  |
| 29.      | 783-0349  | Battery Tray                          | 64.      | 756-0627B | Idler Pulley                  |
| 30.      | 712-0459  | Flange Lock Nut, 7/16-20              | 65.      | 783-0744A | Bracket                       |
| 31.      | 783-0891B | Deck Stop                             | 66.      | 736-0119  | Lock Washer                   |
| 32.      | 710-0604A | Self Tapping Screw, 5/16-18 x .625    | 67.      | 736-0171  | Lock Washer                   |
| 33.      | 732-3080  | Compression Spring, 1.28 x 3.5        | 68.      | 736-0322  | Flat Washer                   |
| 34.      | 723-0444  | Battery Strap                         | 69.      | 750-0956  | Spacer                        |
| 35.      | 738-1020  | Shoulder Screw, .625 x .5, 7/16-20    | 70.      | 756-1182A | Engine Pulley                 |

# Model 808K




# Model 808K

| REF. NO. | PART NO.  | DESCRIPTION                           | REF. NO. | PART NO.  | DESCRIPTION                           |
|----------|-----------|---------------------------------------|----------|-----------|---------------------------------------|
| 1        | 783-0653E | Steering Support Bracket              | 25       | 736-0222  | Lock Washer, 1/4                      |
| 2        | 754-0476  | PTO Belt                              | 26       | 783-1033A | Hitch Plate                           |
| 3        | 717-1774  | Elec. PTO Clutch                      | 27       | 748-0415B | Spacer, 3/8 x 1.54                    |
| 4        | 783-1487  | PTO Clutch Anti-rot. Brakt.           | 28       | 756-0627B | Idler Pulley, 3.5                     |
| 5        | 710-0859  | Hex Cap Screw, 3/8-16 x 2.5           | 29       | 783-0349  | Battery Tray                          |
| 6        | 710-1238  | Hex Head Washer Screw, 5/16-18 x .875 | 30       | 712-0459  | Flange Lock Nut, 7/16-20              |
| 7        | 712-0431  | Flange Lock Nut, 3/8-16               | 31       | 783-0891B | Deck Stop                             |
| 8        | 732-0978  | Extension Spring, .62 x 5.62          | 32       | 710-0604A | Self Tapping Screw, 5/16-18 x .625    |
| 9        | 712-3004A | Flange Lock Nut, 5/16-18              | 33       | 732-3080  | Compression Spring, 1.28 x 3.5        |
| 10       | 710-3180  | Hex Cap Screw, 5/16-18 x 1.75         | 34       | 723-0444  | Battery Strap                         |
| 11       | 712-3010  | Hex Nut, 5/16-18                      | 35       | 738-1020  | Shoulder Screw, .625 x .5, 7/16-20    |
| 12       | 683-0294  | Idler Bracket Assembly                | 36       | 736-0407  | Bell Washer, .45 x 1.0 x .062         |
| 13       | 738-3056  | Shoulder Screw, 1/2 x 2.5             | 37       | 738-1132  | Shoulder Screw, 1/4-20, .25 x .15     |
| 14       | 710-3144  | Hex Cap Screw, 3/8-16 x 2.0           | 38       | 736-0322  | Flat Washer, .45 x 1.25 x .164        |
| 15       | 710-3025  | Hex Cap Screw, 5/16-18 x .625         | 39       | 629-04047 | Harness Assembly, Electric PTO Clutch |
| 16       | 738-0785  | Shoulder Spacer, 1.38 x .445 x .36    | 40       | 783-0693  | Axle Bracket                          |
| 17       | 736-0171  | Lock Washer, 7/16                     | 41       | 712-3006  | Hex Nut 1/4-20                        |
| 18       | 710-3157  | Hex Cap Screw, 7/16-20 x 3.25         | 42       | 736-0329  | Lock Washer                           |
| 19       | 725-1706  | 12-volt Battery, 270 CCA              | 43       | 710-0607  | TT Screw 5/16-18 x 0.5                |
| 20       | 710-0751  | Hex Cap Screw, 1/4-20 x .62           | 44       | 710-0642  | TT Screw 1/4-20 x 0.75                |
| 21       | 712-0271  | Hex Sems Nut, 1/4-20                  | 45       | 725-1657A | Switch                                |
| 22       | 712-3087  | Wing Nut, 1/4-20                      | 46       | 17962     | Switch Plate                          |
| 23       | 725-1426  | Solenoid, 12-Volt, 100 Amp            | 47       | 710-0224  | AB Screw #10-16 x 0.5                 |
| 24       | 710-0599  | Self Tapping Screw, 1/4-20 x .5       | 48       | 683-0304C | Lower Frame Assembly                  |

**IMPORTANT:** For a proper working machine, use Factory Approved Parts. **V-belts** are designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.

# Model 808H




# Model 808H

| REF. NO. | PART NO.  | DESCRIPTION                            | REF. NO. | PART NO.  | DESCRIPTION                     |
|----------|-----------|----------------------------------------|----------|-----------|---------------------------------|
| 1.       | 17116     | Brake Assembly: Deck                   | 35.      | 732-0594A | Extension Spring, .91 x 7.3     |
| 2.       | 17258C    | Deck Belt Cover                        | 36.      | 732-0934  | Extension Spring                |
| 3.       | 17982     | Spindle Reinforcement Plate            | 37.      | 732-1165  | Extension Spring                |
| 4.       | 618-0430A | Spindle Assembly, 5.0 Dia.             | 38.      | 734-0973  | Deck Wheel                      |
|          | 756-1187  | Pulley Only                            | 39.      | 734-3058B | Deck Wheel                      |
| 5.       | 618-0595  | Double Pulley Spindle Assembly         | 40.      | 736-0119  | Lock Washer, 5/16               |
|          | 756-0603  | Double Pulley Only                     | 41.      | 736-0140  | Flat Washer                     |
| 6.       | 683-0199C | SD Deck Assembly: 46 inch              | 42.      | 736-0270  | Bell Washer, .265 x .75 x .062  |
| 7.       | 683-0254  | Deck Adjustment Bracket Assembly       | 43.      | 736-0418A | Flat Washer                     |
| 8.       | 710-0167  | Carriage Screw, 1/4-20 x .50           | 44.      | 738-0347  | Shoulder Spacer                 |
| 9.       | 710-0344  | Hex Cap Screw, 3/8-16 x 1.5            | 45.      | 738-0373  | Shoulder Screw                  |
| 10.      | 710-0501  | Hex Cap Screw, 1/4-20 x 2.0            | 46.      | 738-3056  | Shoulder Screw                  |
| 11.      | 710-0514  | Hex Cap Screw, 3/8-16 x 1.0            | 47.      | 746-1107  | Bracket Cable                   |
| 12.      | 710-0528  | Hex Cap Screw, 5/8-18 x 1.25           | 48.      | 747-1116  | Deck Release Pin                |
| 13.      | 710-0599  | Self-tapping Screw, 1/4-20 x .5        | 49.      | 748-0234  | Shoulder Spacer                 |
| 14.      | 710-0650  | Self-tapping Screw, 15/16-18 x .875    | 50.      | 750-1320  | Spacer                          |
| 15.      | 710-0703  | Hex Screw, 1/4-20 x .75                | 51.      | 754-0228  | V-Belt                          |
| 16.      | 710-0751  | Hex Cap Screw, 1/4-20 x .62            | 52.      | 754-0349  | Deck Belt, Poly                 |
| 17.      | 710-0805  | Hex Bolt 5/16-18 x 1.5                 | 53.      | 756-0627B | Idler Pulley, 3.5               |
| 18.      | 710-1260A | Self-tapping Screw, 5/16-18 x .75      | 55.      | 783-0139A | Idler Bracket                   |
| 19.      | 710-3180  | Hex Bolt 5/16-18 x 1.75                | 56.      | 783-0141  | Center Deck Skirt               |
| 20.      | 711-04069 | Grasscatcher Pin                       | 57.      | 783-0142  | RH Deck Skirt                   |
| 21.      | 711-0993  | Belt Guard Pin                         | 58.      | 783-1025  | Chute Stop                      |
| 22.      | 711-1554  | Pin                                    | 59.      | 783-1347A | LH Belt Cover                   |
| 23.      | 712-0271  | Hex Sems Nut, 1/4-20                   | 60.      | 731-1032B | Chute Deflector: Side Discharge |
| 24.      | 712-0417A | Hex Flange Nut, 5/8-18                 | 61.      | 726-0106  | Speed Nut                       |
| 25.      | 712-0431  | Flange Lock Nut, 3/8-16                | 62.      | 711-0792  | Hinge Pin                       |
| 26.      | 712-3004A | Flange Lock Nut                        | 63.      | 703-1693A | Mounting Bracket                |
| 27.      | 712-3006  | Hex Nut, 1/4-20                        | 64.      | 732-0602  | Torsion Spring                  |
| 28.      | 712-3010  | Hex Nut 5/16-18                        | 65.      | 742-0611  | Blade: 16.28" Star              |
| 29.      | 712-3027  | Hex Flange Lock Nut, 1/4-20            | 66.      | 742-0612  | Blade: 14.88" Star              |
| 30.      | 714-0470  | Cotter Pin, 1/8 x 1.25                 | 67.      | 731-1636  | Mulch Plug†                     |
| 31.      | 717-1553B | Deck Adjustment Gear                   | 68.      | 712-3087  | Wing Nut†                       |
| 32.      | 726-0233  | Push Nut. .25 x .5                     | 69.      | 712-3006  | Hex Nut†                        |
| 33.      | 732-0306  | Compression Spring, .406 x .531 x 1.75 | 70.      | 710-0578  | Machine Screw†                  |
| 34.      | 732-0429A | Extension Spring                       | 71.      | 736-0173  | Flat Washer†                    |

† If equipped

**IMPORTANT:** For a proper working machine, use Factory Approved Parts. **V-belts** are designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.

# Model 808K



# Model 808K

| REF. NO. | PART NO.  | DESCRIPTION                                | REF. NO. | PART NO.   | DESCRIPTION                             |
|----------|-----------|--------------------------------------------|----------|------------|-----------------------------------------|
| 1.       | 12650     | Bracket, Adjustment, Height                | 40.      | 717-1553B  | Adjustment, Deck, Gear                  |
| 2.       | 16606     | Bracket, Hook, Retainer                    | 41.      | 721-04041  | Water Nozzle Adaptor                    |
| 3.       | 618-0671  | Spindle Assembly, Pulley, 5.39 Dia x .5625 | 43.      | 731-0335   | Roller, Deck                            |
| 4.       | 683-0254  | Bracket Assembly, Deck, Hanger LH          | 44.      | 731-3005   | Front Roller                            |
| 5.       | 683-0459  | Idlr Assembly, 54"                         | 45.      | 731-3131A  | Deflector, Chute                        |
| 6.       | 683-0608  | Bracket Assembly, Lift, 54"                | 46.      | 732-0306   | Spring, Compression, .406 x .531 x 1.75 |
| 7.       | 683-0609  | Bracket Assembly, LH-Front                 | 47.      | 732-0459   | Spring, Extension, .94 Dia x 6.74       |
| 8.       | 683-0610  | Bracket Assembly, RH-Front                 | 48.      | 732-0934   | Spring, Extension, 1.15 Dia x 5.99      |
| 9.       | 683-0617  | Stop Assembly, Chute                       | 49.      | 732-3070   | Torsion Spring .44 I.d. x 2.10          |
| 10.      | 703-2093  | Baffle, RR, Inner                          | 50.      | 734-3058B  | Deck Wheel, 5" Dia.                     |
| 11.      | 703-2392  | Bracket                                    | 51.      | 736-0119   | Lock Washer                             |
| 12.      | 703-3511  | Guard, Finger                              | 52.      | 736-0134   | Flat Washer, .812 ID x 1.38 OD x .1     |
| 13.      | 710-0216  | Hex Screw 3/8-16 x 0.75                    | 53.      | 736-0208   | Flat Washer, .51 ID x 1.5 OD x .07      |
| 14.      | 710-0514  | Hex Screw 3/8-16 x 1.0                     | 54.      | 736-0760   | Lock Washer                             |
| 15.      | 710-0528  | Hex Screw, 5/16-18 x 1.25                  | 55.      | 736-0921   | Washer, Lock, 1/2 , Regular Duty        |
| 16.      | 710-0602  | Screw, Self-tapping, 5/16-18 x 1.000       | 56.      | 736-3039   | Flat Washer .406 ID X 1.5 x 11ga        |
| 17.      | 710-0726  | Screw, AB, 5/16-12 x 0.75                  | 57.      | 736-3072   | Washer, Flat .38 ID x.93 OD x.110       |
| 18.      | 710-0751  | Hex Screw, 1/4-20 x .620                   | 58.      | 737-04003  | Water Nozzle: Deck Wash-Out System      |
| 19.      | 710-1644  | Screw, Carriage, 3/8-16 x 5.00             | 59.      | 738-0295   | Shoulder Screw, .750 x .47.12           |
| 20.      | 710-3011  | Hex Screw, 3/8-16 x 2.25                   | 60.      | 738-1229A  | Shoulder Screw                          |
| 21.      | 710-3073  | Hex Screw, 5/16-18 x 2.25                  | 61.      | 738-3056   | Shoulder Screw, 1/2 Dia x 2.50 .        |
| 22.      | 710-3168  | Bolt, Carriage, 3/8-16 x 1.0               | 62.      | 742-0677   | Blade, 18.50"                           |
| 23.      | 710-3178  | Short Neck Carriage Bolt 3/8-16 x .75      | 63.      | 747-1116   | Deck Release Handle Rod, .375 Dia       |
| 24.      | 711-0332  | Pin, Clevis, .50 Dia x .78                 | 64.      | 750-0151   | Spacer .550 ID x .755 OD x 1.1          |
| 25.      | 711-1737  | Pin, Roller, .5" Dia x 10.06 .             | 65.      | 750-0212   | Spacer, .82 ID x 1.00 OD x .53          |
| 26.      | 711-1762  | Pin, Hinge, Dia .375 x 14.06               | 66.      | 750-3213   | Spacer, .405 x .75 x 3.875              |
| 27.      | 712-0229  | Push Nut Retainer                          | 67.      | 754-0642   | Belt, V-Type, B Section                 |
| 28.      | 712-0417A | Nut, Hex Flange, 5/8-18                    | 68.      | 756-3105   | Pulley, Idler, 5.0 Dia.                 |
| 29.      | 712-0431  | Nut, Flange Lock, 3/8-16                   | 69.      | 783-04013A | Bracket, Stabilizing                    |
| 30.      | 712-0641  | Hex Nut M16                                | 70.      | 783-04232  | Deck: SD w/Water Nozzle Ftg.            |
| 31.      | 712-3004A | Nut, Flange Lock, 5/16-18, Gr5             | 71.      | 783-1453   | Bracket, Mounting, 54" Roller           |
| 32.      | 712-3010  | Nut, Hex, 5/16-18, Gr5                     | 72.      | 783-1454   | Bracket, Roller, Front                  |
| 33.      | 712-3022  | Nut, Hex Lock, 1/2-13                      | 73.      | 783-1455   | Bracket, Idler                          |
| 34.      | 712-3027  | Nut, 1/4-20, Hexflg, Lock                  | 74.      | 783-1470   | Cover, Spindle RH                       |
| 35.      | 714-0145  | Pin, Click, .092 x 1.64                    | 75.      | 783-1471   | Cover, Spindle LH                       |
| 36.      | 714-0470  | Pin, Cotter, 1/8 x 1.25                    | 76.      | 783-1482   | RH Skirt                                |
| 37.      | 714-3004  | Pin, Cotter, 3/32 x 1.25                   | 77.      | 783-1483   | LH Skirt                                |
| 38.      | 715-0108  | Pin, Sprg, 1/4 Dia x 1.00                  | 78.      | 783-1484   | LH Extension Skirt                      |
| 39.      | 715-0246  | Pin, Spring, 3/16 x 1.25                   |          |            |                                         |

**IMPORTANT:** For a proper working machine, use Factory Approved Parts. **V-belts** are designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.