


MODELS W814H & R814K



Models W814H & R814K

REF. NO.	PART NO.	DESCRIPTION
1	710-0227	Self-tapping Screw, #8-18 x .5
2	710-0599	Self-tapping Screw, 1/4-20 x .5
3	710-0604A	Self-tapping Screw, 5/16-18 x .625
4	710-1237	Screw, #10-32 x .625
5	710-1314A	Socket Cap Screw, 5/16-18 x .625
6	710-1315	Self-tapping Screw, 3/8-16 x 1.25
7	712-3017	Hex Nut, 3/8-16
8	721-0460	Exhaust Gasket
9	726-0205	Hose Clamp
10	736-0119	Lock Washer, 5/16
11	736-0300	Flat Washer
12	751B221535	Casing Clamp
13	751-0535	Fuel Line Hose
14	751-0564	Muffler Deflector
15	751-0616	Muffler, Twin Inlet
16	751-0650	RH Exhaust Pipe
17	751-0651	LH Exhaust Pipe
18	751-3140	Oil Drain Valve
19	751-3141	Oil Drain Hose
20	751-3142	Oil Drain Cap
21	783-0615B	Muffler Heat Shield
22	783-0625C	Engine Heat Shield
23	722-0263	Foam (fits over fuel line)
24	746-1086	Throttle Cable (Model R814K)
	746-1100	Throttle Cable (Model W814H)
25	746-1100	Throttle Cable (Model W814H)
26	751-0645	RH Exhaust Pipe (Model W814H)
27	751-0644A	LH Exhaust Pipe (Model W814H)
28	751-0805	Muffler, Twin Inlet (Model W814H)
29	783-0881	Engine Heat Shield (Model W814H)
30	721-0377	Exhaust Gasket (Model W814H)
31	712-3086	Flange Nut, M8 x 1.25-6 (Model W814H)

NOTE: Engine accessory parts are applicable to both Models W814H and R814K except where otherwise noted.


NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665

Yard-Man Yellow: 0674

Powder Black: 0637


Models W814H & R814K



Models W814H & R814K

REF. NO.	PART NO.	DESCRIPTION
1	710-3015	Hex Cap Screw, 1/4-20 x .75
2	710-0599	Self-tapping Screw, 1/4-20 x .5
3	712-3006	Hex Nut, 1/4-20
4	710-0895	Self-tapping Screw, 1/4-15 x .75
5	710-0924	Pan Phillips Screw, 1/4-20 x .75
6	710-0528	Hex Cap Screw, 5/16-18 x 1.25
7	712-0292	U-type Speed Nut, 1/4-20
8	712-3004A	Flange Lock Nut, 5/16-18
9	726-0201	Speed Nut
10	747-2127	Hood Latch Rod
11	731-1978	RH Head Light Lens
	731-1979	LH Head Light Lens
12	747-1132A	Hood Support Rod
13	731-1980A	Hood
14	731-1981B	LH Side Panel
15	731-1982B	RH Side Panel
16	736-0329	Lock Washer, 1/4
17	736-0342	Flat Washer, .283 x .75 x .030
18	736-0173	Flat Washer, .28 x .74 x .063
19	736-3078	Flat Washer, .349 x 1.0 x .063
20	710-0809	Self-tapping Screw, 1/4-20 x 1.25
21	783-0808A	Hood Heat Shield w/o Intake Bellow
22	710-0604A	Self-tapping Screw, 5/16-18 x .625
23	710-1017	Torx Self-tapping Screw, 1/4-14 x .625
24	710-3217	Torx Screw, #8-32 x .375
25	712-0142	Hex Nut, 8-32
26	731-0071C	Dash Panel, 4-style
27	731-0072	Parking Brake Button
28	731-1857	Throttle Control Lever
29	731-2106	Cruise Control Button
30	747-1155	Brake/Cruise Pivot Rod
31	749-1087A	Dash Support Tube
32	731-2234	Intake Bellow
33	751-0658C	Fuel Tank, 3-gallon
34	751-0603	Fuel Cap
35	725-1745	Ignition Key w/ plastic cover
	725-1744	Ignition Key w/o plastic cover
36	731-2272	Heat Shield
37	783-1000A	Grille Support Bracket
38	725-1976	Systems Indicator Monitor
39	725-1741	Ignition Switch
40	625-0051	Headlight Assembly
41	725-1752	Electric PTO Switch
42	747-1303	LH Rod
43	747-1304	RH Rod
44	731-1995	RH Headlight Reflector
	731-1996	LH Headlight Reflector
—	629-0469A	Headlight Wire Harness
—	629-1067	Tractor Wire Harness (Model R814K)
	629-1069	Tractor Wire Harness (Model W814H)

Models W814H & R814K



Models W814H & R814K

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	747-1130B	Deck Stabilizer Rod (Model W814H)	30	731-1990	Lift Lever Cover
	747-1324	Deck Stabilizer Rod (Model R814K)	31	731-1993	Cover w/ Cup Holder
2	683-0197A	Lift Shaft Assembly (Model W814H))	32	736-3078	Flat Washer, .349 x 1.0 x .063
	683-0642	Lift Shaft Assembly (Model R814K)	33	783-0677	Lift Adjustment Bracket
3	711-0332	Clevis Pin, .5 x .78	34	783-1279	Fender
4	712-0206	Hex Nut, 1/2-13	35	783-1489	Seat Mounting Bracket
5	712-0431	Flange Lock Nut, 3/8-16	36	710-1268	Screw, #10-16 x .375
6	712-3004A	Flange Lock Nut, 5/16-18	37	712-3027	Hex Flange Lock Nut, 1/4-20
7	712-3083	Hex Nut, 1/2-13	38	720-0309A	Seat Adjuster Grip
8	714-0104	Internal Cotter Pin	39	731-1989	Spacer
9	714-0145	Internal Cotter Pin	40	732-0499	Compression Spring, .41 x 1.5
10	716-0106	E-ring	41	736-0175	Spring Washer, .265 x .562 x .025
11	720-0311	Handle Grip	42	736-0204	Flat Washer, .344 x .62 x .03
12	732-0874	Torsion Spring	43	738-0137A	Shoulder Screw, .340 x .285, 1/4-20
13	732-1184	Extension Spring, .84 x 4.6	44	738-1007	Shoulder Screw, .50 x .50, 3/8-16
14	736-0275	Flat Washer, 5/16	45	783-0611	Seat Stop
15	736-0921	Lock Washer, 1/2	46	783-0738	Seat Pivot Bracket
16	736-3019	Flat Washer, .31 x 1.062 x .134	47	783-0739	Seat Adjustment Lever
17	736-3084	Flat Washer, .51 x 1.12 x .06	48	783-0753	Seat Adjustment Selector
18	738-0138A	Hex Cap Screw, 5/16-18 x .62	49	757-0372	Seat, Yellow
19	738-0143	Shoulder Screw, 3/8-16	50	735-0656	RH Foot Pad
20	741-0225	Hex Flange Bearing	51	735-0657	LH Foot Pad
21	741-0715	Snap Flange Bearing	—	726-3046	Foot Pad Clips
22	746-0968	Lift Cable, 16.16	52	714-0111	Cotter Pin
23	747-1111A	Lift Handle	53	731-0511	Trim Strip
24	756-1154	Roller Pulley	54	783-0209A	LH Seat Lift Bracket
25	783-0678A	Arm Lift	—	17239A	RH Seat Lift Bracket
26	783-0720A	Deck Stabilizer Bracket	55	783-1478	Fender Clips
27	710-0260A	Carriage Bolt, 5/16 x .62	56	731-2618	RH Fender Flare
28	710-0604A	Self-tapping Screw, 5/16-18 x .625	57	731-2619	LH Fender Flare
29	710-0895	Self-tapping Screw, 1/4-15 x .75	58	738-0296	Shoulder Screw, .437 x .286


NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665

Yard-Man Yellow: 0674

Powder Black: 0637

Models W814H & R814K



Models W814H & R814K

REF. NO.	PART NO.	DESCRIPTION
1	710-1260A	Self-tapping Screw, 5/16-18 x .75
2	710-0604A	Self-tapping Screw, 16-18 x .625
3	783-0726B	RH Pivot Support Bracket
4	783-0727A	LH Pivot Support Bracket
5	783-0728	Pivot Bar Bracket
6	710-0514	Hex Cap Screw, 3/8-16 x 1 (Grade 5)
7	711-1408	RH Drag Link
8	711-1655	LH Drag Link
9	712-0240	Jam Nut, 7/16-20 (Grade 2)
10	712-0241	Hex Nut, 3/8-24 (Grade 2)
11	712-0431	Flange Lock Nut, 3/8-16
12	712-0459	Flange Lock Nut, 7/16-20
13	712-3004A	Flange Lock Nut, 5/16-18
14	717-1550D	Steering Gear, 11/90 Ratio
15	717-1554	Steering Pinion Gear
16	723-0448A	Ball Joint, 7/16-20
17	736-0169	Lock Washer, 3/8
18	736-3084	Flat Washer, .51 x 1.12 x .06
19	738-1001A	Steering Shaft, .625 OD x 24.4
20	741-0475	Plastic Bushing, .38 ID
21	741-0656	Hex Flange Bearing, 5/8
22	738-0372B	Shoulder Spacer, .38 ID
23	731-2624	Steering Wheel, Soft Grip, Three Spoke
24	731-2625	Steering Wheel Cap, Round
25	638-0017	LH Axle Assembly, .75 Diameter
26	638-0018	RH Axle Assembly, .75 Diameter
27	719-0525B	Cast Iron Pivot Bar w/ Fittings, .75
28	712-0431	Flange Lock Nut, 3/8-16
29	714-0162	Cotter Pin
30	726-0341	Push Cap, .750
31	736-0242	Bell Washer, .34 x .872
32	736-0316	Flat Washer, .78 x 1.59 x .06
33	736-0285	Flat Washer, .635 x 1.589 x .06
34	738-1011	Shoulder Screw, .5 x 2.2, 3/8-16
35	710-0643	Hex Bolt, 5/16-18 X 1
36	634-0183	Wheel Assembly Complete, 16 x 6.5 x 8
	634-0182	Rim Only w/ Plastic Bearing
	734-0255	Air Valve (Not Shown)
	734-1727	Tire Only, Square Shoulder
37	734-2290	Hub Cap
38	783-0653E	Steering Support Bracket
39	738-0143	Shoulder Screw, 3/8-16
40	736-0331	Bell Washer, .39 x 1.13 x .062


NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665

Yard-Man Yellow: 0674

Powder Black: 0637

Models W814H & R814K




Models W814H & R814K

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	712-3050	Lug Nut, 3/4-16	39	783-0782	Switch Actuator Bracket
2	629-0949A	Reverse/Ground Wire Harness Adapter	40	647-0031	Brake Control Assembly
3	683-0251	Double Idler Bracket Assembly	41	647-0049	Drive Control Assembly
4	710-0189	Hex Cap Screw, 5/16-18 x 3.00	42	683-0267C	Hydro Pedal Assembly
5	710-0216	Hex Cap Screw, 3/8-16 x .75	43	710-1650	Self-tapping Screw, 5/16-18 x .875
6	710-0227	Screw, #8-18 x .5	44	710-1260A	Self-tapping Screw, 5/16-18 x .75
7	710-0344	Hex Cap Screw, 3/8-16 x 1.5	45	711-0736	Ferrule, 1/4-20
8	710-0599	Self-tapping Screw, 1/4-20 x .50	46	711-1363	Pin, 3/8-16 x 2.43
9	710-0604A	Self-tapping Screw, 5/16-18 x .625	47	732-0335	Compression Spring, .40 OD x 1.17
10	710-3011	Hex Cap Screw, 3/8-16 x 2.25	48	732-0955	Extension Spring, .50 OD x 1.41
11	711-0677	Ferrule, 5/16-18	49	732-0963	Extension Spring, .50 OD x 6.37
12	711-0832	Ferrule, 3/8-24	50	735-0662	Drive Pedal Pad
13	712-0431	Flange Lock Nut, 3/8-16	51	735-3049	Brake Pedal Pad
14	712-3004A	Flange Lock Nut, 5/16-18	52	736-0133	Flat Washer, .411 x 1.25 x 1.0
15	712-3017	Hex Nut, 3/8-16	53	736-0142	Flat Washer, .281 x .50 x .063
16	714-0104	Internal Cotter Pin	54	736-0187	Flat Washer, .64 x 1.24 x .06
17	714-0111	Cotter Pin	55	736-0204	Flat Washer, .344 x .062 x .03
18	725-0157	Cable Tie	56	736-3004	Flat Washer, .406 x .875 x .105
19	725-1644	Short Spring Switch	57	738-0155	Shoulder Screw, .437 x 1.62
20	726-0154	Push-mount Cable Tie	58	738-0507B	Shoulder Screw, .5 x .434
21	726-0320	Insulator Nut Plate	59	741-0225	Hex Flange Bearing
22	732-0716	Extension Spring, .59 x 4.0	60	741-3065B	Split Hex Flange Bearing
23	732-0965	Extension Spring, .5 x 3.5	61	747-1137	Cruise Control Rod
24	732-3118	Extension Spring, 3/8 x 1.44	62	747-1138	Brake Lock Control Rod
25	736-0140	Flat Washer, .385 x .62 x .063	63	748-0413	Cruise Latch
26	736-0169	Lock Washer, 3/8	64	748-0415B	Spacer, 5/16 x 1.54
27	736-0275	Flat Washer, .344 x .688 x .065	65	783-0653E	Steering Support Bracket
28	736-3010	Flat Washer, .407 x .812 x .135	66	783-0663C	Drive Lockout Bracket
29	738-0372	Shoulder Spacer, .38	67	783-0773	Brake Pedal
30	747-1119	Hydrostatic Control Rod	68	783-0693	Transmiksion Axle Bracket
31	747-1121	Hydrostatic Bypass Rod	69	634-0132	Wheel Assembly Complete, 23 x 9.5 x 12
32	747-1122	Hydrostatic Brake Rod		634-0194	Rim Only
33	750-0535	Spacer, .376 x .625 x .22		734-0255	Air Valve (Not Shown)
34	754-0349	Drive Belt		734-1728	Tire Only, Square Shoulder
35	756-0116	V-idler Pulley, 3.06		734-2290	Hub Cap
36	756-0981A	Flat Idler Pulley, 2.75	70	736-0316	Flat Washer, .780 x 1.59 x .062
37	783-0667A	Transmission Torque Bracket	71	712-3026	Jam Nut, 3/4-16
38	783-0745	Speed Control Bracket	72	618-0379	Hydrostatic Transmission Assembly
			—		

IMPORTANT: For a proper working machine, use Factory Approved Parts. **V-belts** are designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.
Yard-Man Green: 0665
Yard-Man Yellow: 0674
Powder Black: 0637

Models W814H & R814K



* Found on Model R814K only.


Models W814H & R814K

REF. NO.	PART NO.	DESCRIPTION
1	783-0653E	Steering Support Bracket
2	754-0476	PTO Belt
3a	717-1709	Electric PTO Clutch (Model W814H)
3b	717-1774	Electric PTO Clutch (Model R814K)
4a	783-1003	PTO Clutch Anti-rotation Bracket (Model W814H)
4b	783-1487	PTO Clutch Anti-rotation Bracket (Model R814K)
5	710-0859	Hex Cap Screw, 3/8-16 x 2.5
6	710-1238	Hex Head Washer Screw, 5/16-18 x .875
7	712-0431	Flange Lock Nut, 3/8-16
8	732-0978	Extension Spring, .62 x 5.62
9	712-3004A	Flange Lock Nut, 5/16-18
10	710-3180	Hex Cap Screw, 5/16-18 x 1.75
11	712-3010	Hex Nut, 5/16-18
12	683-0294	Idler Bracket Assembly
13	738-3056	Shoulder Screw, 1/2 x 2.5
14	710-3144	Hex Cap Screw, 3/8-16 x 2.0
15	710-3025	Hex Cap Screw, 5/16-18 x .625
16	738-0785	Shoulder Spacer, 1.38 x .445 x .36
17	736-0171	Lock Washer, 7/16
18	710-3157	Hex Cap Screw, 7/16-20 x 3.25 (Grade 5)
19	725-1706	12-volt Battery, 270 CCA
20	710-0751	Hex Cap Screw, 1/4-20 x .62
21	712-0271	Hex Sems Nut, 1/4-20
22	712-3087	Wing Nut, 1/4-20
23	725-1426	Solenoid, 12-Volt, 100 Amp
24	710-0599	Self Tapping Screw, 1/4-20 x .5
25	736-0222	Lock Washer, 1/4
26	783-1033A	Hitch Plate
27	748-0415B	Spacer, 3/8 x 1.54
28	756-0627B	Idler Pulley, 3.5
29	783-0349	Battery Tray
30	712-0459	Flange Lock Nut, 7/16-20
31	783-0891B	Deck Stop
32	710-0604A	Self Tapping Screw, 5/16-18 x .625
33	732-3080	Compression Spring, 1.28 x 3.5
34	723-0444	Battery Strap
35	738-1020	Shoulder Screw, .625 x .5, 7/16-20
36	736-0407	Bell Washer, .45 x 1.0 x .062
37	738-1132	Shoulder Screw, 1/4-20, .25 x .15
38	736-0322	Flat Washer, .45 x 1.25 x .164

IMPORTANT: For a proper working machine, use Factory Approved Parts. **V-belts** are designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.
Yard-Man Green: 0665
Yard-Man Yellow: 0674
Powder Black: 0637


Model W814H



REF. NO.	PART NO.	DESCRIPTION
1	16606	Retainer Hook
2	17982	Spindle Reinforcement Plate
3	618-0430A	Spindle Assembly, 5.0 Dia.
	756-1187	Pulley Only
4	618-0431	Double Pulley Spindle Assembly
	756-0603	Double Pulley Only
5	683-0254	Deck Adjustment Bracket Assembly
6	683-0199C	46-inch Deck Shell
7	710-0167	Carriage Screw, 1/4-20 x .50
8	710-0344	Hex Cap Screw, 3/8-16 x 1.5
9	710-0501	Hex Cap Screw, 1/4-20 x 2.0
10	710-0514	Hex Cap Screw, 3/8-16 x 1.0
11	710-0528	Hex Cap Screw, 5/8-18 x 1.25
12	710-0599	Self-tapping Screw, 1/4-20 x .5
13	710-0650	Self-tapping Screw, 15/16-18 x .875
14	710-0703	Hex Screw, 1/4-20 x .75
15	710-0751	Hex Cap Screw, 1/4-20 x .62
16	710-1260A	Self-tapping Screw, 5/16-18 x .75
17	712-0271	Hex Sems Nut, 1/4-20
18	712-0417A	Hex Flange Nut, 5/8-18
19	712-0431	Flange Lock Nut, 3/8-16
20	712-3006	Hex Nut, 1/4-20
21	712-3027	Hex Flange Lock Nut, 1/4-20
22	714-0470	Cotter Pin, 1/8 x 1.25
23	717-1553A	Deck Adjustment Gear
24	726-0233	Push Nut. .25 x .5
25	731-1032B	Side Discharge Chute Assembly
26	732-0306	Compression Spring, .406 x .531 x 1.75
27	732-0594A	Extension Spring, .91 x 7.3
28	710-0578	Screw, 1/4-20 x 1.5
29	734-0973	Deck Wheel, 5 x 1.38
30	736-0105	Bell Washer, .401 x .87 x .063
31	736-0119	Lock Washer, 5/16
32	736-0270	Bell Washer, .265 x .75 x .062
33	738-0347	Shoulder Spacer, .625 x 1.16
34	738-0373	Shoulder Screw
35	742-0611	Three-in-one Blade, Star Center, 16.28"
36	742-0612	Three-in-one Blade, Star Center, 14.88"
37	747-1116	Deck Release Pin
38	754-0349	Deck Belt, Poly
39	738-3056	Shoulder Screw, 1/2-2.5
40	756-0627B	Idler Pulley, 3.5
41	734-3058B	Deck Wheel, 5.0
42	783-0139A	Idler Bracket
43	783-0141	Center Deck Skirt
44	783-0142	RH Deck Skirt
45	783-0747	LH Belt Cover
46	783-0805A	RH Belt Cover
47	753-0875	46-inch Deck Assembly Complete

IMPORTANT: For a proper working machine, use Factory Approved Parts. **V-belts** are designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.

Model R814K



Model R814K

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	12650	Bracket, Adjustment, Height	38	731-0335	Roller, Deck
2	16606	Bracket, Hook, Retainer	39	731-3005	Front Roller
3	618-0671	Spindle Assembly, Pulley, 5.39 Dia x .5625	40	731-3131A	Deflector, Chute
4	683-0254	Bracket Assembly, Deck, Hanger LH	41	732-0306	Spring, Compression, .406 x .531 x 1.75
5	683-0459	Idlr Assembly, 54"	42	732-0459	Spring, Extension, .94 Dia x 6.74
6	683-0608	Bracket Assembly, Lift, 54"	43	732-0934	Spring, Extension, 1.15 Dia x 5.99
7	683-0609	Bracket Assembly, LH-Front	44	732-3070	Torsion Spring .44 l.d. x 2.10
8	683-0610	Bracket Assembly, RH-Front	45	734-3058B	Deck Wheel, 5" Dia.
9	683-0617	Stop Assembly, Chute	46	736-0105	Washer, Bell, .375 x .870 x .063
10	703-2093	Baffle, RR, Inner	47	736-0119	Washer, Lock, 5/16, Regular Duty
11	703-2392	Bracket	48	736-0134	Flat Washer, .812 ID x 1.38 OD x .1
12	703-3511	Guard, Finger	49	736-0171	Washer, Lock, 7/16, Regular Duty
13	710-0528	Hex Screw, 5/16-18, 1.25, Gr5,	50	736-0208	Flat Washer, .51 ID x 1.5 OD x .07
14	710-0602	Screw, Self-tapping, 5/16-18, 1.000	51	736-0921	Washer, Lock, 1/2, Regular Duty
15	710-0604A	Screw, Self-tapping, 5/16-18, 0.625	52	736-3027	Flat Washer, .531 x 1.75 x .090
16	710-0751	Hex Screw, 1/4-20, .620, Gr5,	53	736-3039	Flat Washer .406 ID X 1.5 x 11ga
17	710-1644	Screw, Carriage, 3/8-16, Gr5, 5.00	54	736-3072	Washer, Flat .38 ID x .93 OD x .110
18	710-3011	Hex Screw, 3/8-16, 2.25, Gr5,	55	738-0295	Shoulder Screw, .750 x .47.12
19	710-3073	Hex Screw, 5/16-18, 2.25, Gr5,	56	738-1229	Shoulder Screw, 5/8 Dia x 2.50 .
20	710-3168	Bolt, Carriage, 3/8-16 x 1.0	57	738-3056	Shoulder Screw, 1/2 Dia x 2.50 .
21	710-3178	Short Neck Carriage Bolt 3/8-16 x .75	58	742-0677	Blade, 18.50"
22	711-0332	Pin, Clevis, .50 Dia x .78	59	747-1116	Deck Release Handle Rod, .375 Dia
23	711-1737	Pin, Roller, .5" Dia x 10.06 .	60	750-0151	Spacer .550 ID x .755 OD x 1.1
24	711-1762	Pin, Hinge, Dia .375 x 14.06	61	750-0212	Spacer, .82 ID x 1.00 OD x .53
25	712-0417A	Nut, Hex Flange, 5/8-18	62	750-3213	Spacer, .405 x .75 x 3.875
26	712-0431	Nut, Flange Lock, 3/8-16	63	754-0642	Belt, V-Type, B Section
27	712-3004A	Nut, Flange Lock, 5/16-18, Gr5	64	756-3105	Pulley, Idler, 5.0 Dia.
28	712-3010	Nut, Hex, 5/16-18, Gr5	65	783-1453	Bracket, Mounting, 54" Roller
29	712-3019	Nut, Hex, 7/16-14, Gr2	66	783-1454	Bracket, Roller, Front
30	712-3022	Nut, Hex Lock, 1/2-13	67	783-1455	Bracket, Idler
31	712-3027	Nut, 1/4-20, Hexflg, Lock	68	783-1470	Cover, Spindle RH
32	714-0145	Pin, Click, .092 x 1.64	69	783-1471	Cover, Spindle LH
33	714-0470	Pin, Cotter, 1/8 x 1.25	70	783-1479	Deck Shell Assembly, 54"
34	714-3004	Pin, Cotter, 3/32 x 1.25	71	783-1482	RH Skirt
35	715-0108	Pin, Sprg, 1/4 Dia x 1.00	72	783-1483	LH Skirt
36	715-0246	Pin, Spring, 3/16 x 1.25	73	783-1484	LH Extension Skirt
37	717-1553A	Adjustment, Deck, Gear	74	753-04000	54-inch Deck Assembly Complete

IMPORTANT: For a proper working machine, use Factory Approved Parts. **V-belts** are designed to engage and disengage safely. A substitute (non OEM) V-belt can be dangerous by not disengaging completely.

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.
Yard-Man Green: 0665
Yard-Man Yellow: 0674
Powder Black: 0637