
Upper Handle Assembly



Upper Handle Assembly

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	657940	Clutch handle R.H.	35	645655	Clutch cable
2	657932	Clutch handle L.H.	36	150250	5/16-18 x 1-1/2 bolt
3	713180	Cam lock	37	312280	5/16-18 x 1-3/4 bolt
4	657361	Clutch handle bracket	38	715177	5/16-18 locknut
5	666644	Bracket light	39	456780	3/8-16 x 3 bolt
6	657411	Pin latch	40	150185	3/8 lockwasher
7	152926	3/8 cap retainer	41	715391	3/8-16 hex nut
8	664755	Console bracket remote	42	657270	Spacer
9	657312	Bracket console support	43	645622	Spring auger clutch
10	315085	5/16-18 x 1/2 self tapping screw	44	707612	Spring drive clutch
11	715052	1/4-20 x 1/2 bolt	45	657254	Lower handle
12	715094	1/4 lockwasher	46	312066	5/16-18 x 3/4 bolt
13	310052	1/4-20 hex nut	47	310045	5/16-18 hex nut
14	153007	1/4-20 x 1/2 self tapping screw	48	672253	Handle crank
15	657353	Console Remote	49	663278	Crank
16	112169	Control knob	50	313510	5/16-18 x 3/4 carriage bolt
17	657288	Speed control lever	51	672220	Grommett
18	312322	3/8-16 x 1-3/4 bolt	52	697664	Bracket chute rotate L.H.
19	645630	Spring	53	697672	Bracket chute rotate R.H.
20	715417	3/8 flat washer	54	151472	3/32 x 1 cotter pin
21	451195	3/8-16 locknut	55	672956	Plastic cap
22	657304	Deflector lever remote	56	664771	Rod chute control
23	645648	Spring washer	57	157339	1/2-20 jam nut
24	150169	1/4-20 x 1 bolt	58	672964	Plastic stop
25	150391	1/4 x 20 locknut	59	311035	1/2 lockwasher
26	645697	Remote chute cable	60	663252	Bracket crank
27	715029	3/32 x 3/4 cotter pin	61	663260	Bracket clamp crank
28	715185	5/16 flat washer	62	457523	5/16-18 x 3/4 self tapping screw
29	657296	Rod speed control	63	673483	Rubber pad
30	152934	5/16-24 hex nut	64	666651	Spring cam assist
31	664763	Adaptor	65	715524	3/8 - 16 Hex jam nut
32	707372	Ball joint	66	156505	10-24 x 3/4 Screw
33	311118	5/16 lockwasher		630160	(Not shown) Light kit with out alternator
34	697656	Upper handle	1	630137	with alternator


Motor Mount Assembly

2246 Belt cover (black) 7771 Motor mount frame	54	419713	Auger pulley 8.4"
7771 Motor mount frame			Lyanger barrey o
	55	707687	Belt auger drive
2999 Engine riser	56	663245	Rear panel
5300 1/4 flat washer	57	663054	Bottom panel
3007 1/4-20 x 1/2 self tapping screw	58	664813	Spring auger brake
5085 5/16-18 x 1/2 self tapping	59	729905	Friction disc assembly
screw	60	152959	Race thrust
7789 End plate	61	707562	Needle bearing
2261 Plastic bushing	62	423228	Needle bearing
0824 1/2 flat washer	63	707711	Spindle housing
3106 5/32 x 7/8 roll pin	64	707729	Grease fitting
2973 Lever auger clutch	65	707760	Seal
2981 Lever clutch cable	66	707570	Spindle housing
0045 5/16-18 hex nut	67	461830	Race thrust
1118 5/16 lockwasher	68	153296	3/4 ring retainer
5185 5/16 flat washer	69	313510	5/16-18 x 3/4 carriage bolt
2916 Bracket clutch adjustment	70	312082	5/16-18 x 1/2 bolt
3510 5/16-18 x 3/4 carriage bolt	· 71	707737	Drive bushing
0185 3/8 lockwasher	72	423475	Drive shaft hex bearing
7347 3/8-16 x 1 self tapping screw	73	428425	Clutch plate
7644 5/16-18 x 2-1/2 bolt GR 5	74	763342	Yoke speed
8 HP Tecumseh engine	74 75	715029	3/32 x 3/4 cotter pin
	75 76	790709	Retainer
10 HP Tecumseh engine	77	707984	Chain
3005 Belt guide plate	77 78	707976	Drive sprocket
3569 Spacer	76 79		Bearing clutch
3064 5/16-24 x 1 bolt		664821	
4146 5/16-18 x 3 bolt	80	415737	Grease fitting
6669 Belt guide	81	664342	Shaft gear assembly
2066 5/16-18 x 1-3/4 bolt	82	446690	1/8 key
3845 Rod spindle support	83	461822	Washer
5094 1/4 lockwasher	84	707950	Hub friction wheel
0052 1/4-20 hex nut	85	707968	Friction wheel
5177 5/16-18 locknut	86	153510	5/16 external tooth lockwashe
7695 Spring drive idler	87	150185	3/8 lockwasher
7362 5/16-18 x 3/4 shoulder bolt	88	310029	3/8-24 hex nut
1996 7/16 flat washer	89	663369	Hex shaft
1246 Idler bracket	90	664839	Retainer
9762 3'' idler pulley	91	664326	Axle
3015 3/8-16 x 1-1/4 bolt	92	707802	Chain
5524 3/8-16 jam nut	93	663476	Retainer
4797 Spindle plate	94	153619	Click pin
4805 Engine pulley spacer	95	042853	Wheel
7745 Pulley traction drive	96	153239	Washer
7752 Pulley auger drive	97	664334	Axle bracket
3031 Washer	98	313510	5/16-18 x 3/4 carriage bolt
3023 3/8 lockwasher	99	312090	1/4-20 x 1-1/2 bolt GR 5
7370 3/8-24 x 1-1/4 bolt	100~	152967	1/4-20 locknut
2965 Auger clutch rod	101	663286	(Not shown) Tire chain kit
2272 3/8-16 x 1-1/2 bolt			(8280 & 1032)
5417 3/8 flat washer	102	763417	Yoke drive
5524 3/8-16 jam nut	103	775684	Spring clutch yoke return
0048 5/16-18 x 5/8 bolt	104	707638	Bushing
7596 Belt traction drive	105	645648	Spring washer
	106	657403	3/8 cap retainer
			(Not shown) Electric start
,	107	457523	5/16-18 x 3/4 self tapping
g i	ı i	1	screw
9648 3080	Traction pulley 7" 3/16 key	Traction pulley 7" 106 3/16 key	Traction pulley 7" 106 657403 3/16 key 630129

Auger Housing Assembly

Reference No.	Part No.	Description	
1	310045	5/16-18 hex nut	
2	311118	5/16 lockwasher	
3	715185	5/16 flatwasher	
4	313510	5/16-18 x 3/4 carriage bolt	
5	458232	8-32 x 1/2 bolt	
6	154096	8-32 locknut	
7	790659	Retainer	
8	698753	Flange	
9	677682	Decal - Danger	
10	677690	Decal - Danger	
11A	697730	Auger housing 28''	
11B	697748	Auger housing 32"	
12	457523	5/16-18 x 3/4 self tapping scre	
13	662569	Height adjustor	
14	150169	1/4-20 x 1 bolt	
15	708222	7/8 bearing	
16	707943	3/16 key	
17A	663096	28" scraper bar	
17B	663088	32'' scraper bar	
18	312058	5/16-18 x 1 bolt	
19	697763	Gear box brace	
20A	707653	28" gear box assembly	
20B	707646	32" gear box assembly	
21A	663120	28'' serrated auger L.H.	
21B	663112	32'' serrated auger L.H.	
22A	663146	28'' serrated auger R.H.	
22B	663138	32'' serrated auger R.H.	
23	380055	Shear bolt	
24	452615	1/4-20 locknut	
25	715177	5/16-18 locknut	
26	415687	Grease fitting	
27	707661	Bushing auger shaft	
28	153700	Washer	
29	153718	Spacer	
30	380048	5/16-18 x 5/8 bolt	
31	419713	Auger pulley 8.4"	
32	664698	Chute extension remote (See Remote Chute Assembly)	


Remote Chute Assembly



Remote Chute Assembly

Duai Stage	Showthrower	Hemote Chute Assembly
Reference No.	Part No.	Description
1	663203	Chute deflector remote
2	663518	Spring
3	157321	5/16-18 x 3/4 pan head slotted bolt
4	310151	5/16-18 locknut
5	672972	Plastic washer
6	664698	Chute extension remote
7	664706	Bracket cable
8	312082	5/16-18 x 1/2 bolt
9	715177	5/16-18 locknut
10	120048	10-24 x 3/8 bolt
11	452318	10-24 locknut
12	150169	1/4-20 x 1 bolt
13	150391	1/4 x 20 locknut
14	664714	Remote wire form
15	156463	5/16-18 x 3 bolt GR5
16	645697	Remote cable
17	707927	Skirt snow chute
18	707935	6/16 rivet
19	462424	#10 - flat washer
20	715185	5/16 flat washer
		,

Gear Box Assembly



Section 1. Company

Gear Box Assembly

		age Showin	Hower Geal Box Assembly
	Ref. No.	Part No.	Description
J	1	707471	Seal
	2	707547	Housing L.H.
	3	707463	Bearing
	4	707455	Housing assembly L.H.
	5	707430	Race thrust
	6	153353	Key Woodruff #91
	7	707422	Worm gear
	8	707448	Gasket
	9	707489	Housing assembly R.H.
	10A	663328	28'' auger shaft
	10B	663336	32" auger shaft
	11	153486	5/16-24 x 1-3/4 bolt
	12	153346	Ring quad
	13	153338	Bearing impeller shaft
	14	153320	Race thrust
	15	153312	Bearing needle
.	16	153304	Race thrust
,	17	153080	Key 3/16''
	18	707513	Worm
	19	152959	Race thrust
	20	153296	Ring retainer
	21	707505	Bearing impeller shaft
	22	153288	Grease plug
	23	663344	Impeller shaft
	24	663104	Impeller
	25	707539	Housing R.H.
	26	153064	5/16-24 x 1 bolt
	27	153189	5/16-24 flange locknut
	28	153148	1/4-20 x 2-1/4 bolt
	29	715300	1/4 flat washer
	30	152967	1/4-20 locknut
	31	707943	3/16 key
		707653	28" gear box assembly (complete)
		707646	32" gear box assembly (complete)
			į
*****	D/I 6900E		