


Model Series D449R401




Model Series D449R401

Ref. No	Part No.	Description	Ref. No	Part No.	Description
1.	747-2133	Bail Handle	54.	618-04006	Transmission Assembly Compl.
2.	731-2628	Handle Panel	55.	710-1650	Shld. Screw
3.	749-1507	Upper Handle	56.	731-1937A	Front Drive Cover: Yellow
4.	764-0310	Rear Grass Catcher Frame	57.	711-1293	Belt Keeper Pin
5.	764-0311	Front Grass Catcher Frame	58.	736-0331	Bell Washer
6.	664-0176	Grass Bag-Half Sail	59.	748-0355	Bearing Support
7.	746-1252	Control Cable	60.	736-0447	Wave Washer
8.	749-0907B	Lower Handle	61.	782-0511A	Height Adj. Plate LH†
9.	746-1250	Drive Cable		782-0512B	Height Adj. Plate RH
10.	736-0524A	Blade Bell Support	62.	682-0509	Pivot Plate Assembly
11.	710-1174	Carriage Bolt	63.	756-1146A	Drive Pulley
12.	720-0284	Handle Knob	64.	748-0377C	Blade Adapter
13.	736-0451	Saddle Washer	65.	742-0741	Mulching Blade w/ Star: 21"
14.	720-0279	Wing Nut		742-0641	Standard Blade 21"
15.	710-1205	Rope Guide	66.	736-0526	Wave Washer
18.	631-0075B	Engine Spacer Assembly	67.	710-0216	Hex Screw 3/8-16
23.	714-0104	Hairpin Clip	68.	715-0221	Dowel Pin
24.	731-1236	Rear Trail Shield	69.	717-1762	Gear 14T RH
25.	732-0700	Wire: Trail Shield		717-1761	Gear 14T LH †
26.	720-0275	Knob	70.	714-0101	Hairpin Clip
27.	710-0192	Scr. Tr. Mach. #10-24 x 0.380"	71.	736-3013	Flat Washer
28.	732-0677	Torsion Spring LH	72.	716-0865	Snap Ring
29.	782-5003	Rear Baffle LH	73.	782-7551	Wheel Dust Cap
30.	710-1017	Scr. AB 1/4-14 x 0.625"	74.	716-0102	Snap Ring
31.	732-0678	Torsion Spring RH	75.	736-0474	Washer DD 1.5" O.D.
32.	710-0896	Hex Scr. w/ Wash. 1/4-14 x 0.62"	76.	712-0271	Hex Nut 1/4-20
33.	720-0426	Knob	77.	710-1257	Hex Bolt
34.	736-0105	Bell Washer .375 x .870	78.	750-04010	Sleeve Spacer, .88 x 1.19 O.D.
35.	734-2042	Rear Wheel: Disk Bar Gray	80.	782-5004	Rear Baffle RH
36.	738-0102	Shoulder Screw	82.	750-1166	Slev. Spacer LH †
37.	731-1426	Hubcap: Radial Spoke Yellow		750-1165	Slev. Spacer RH
38.	682-3067	Handle Bracket Assembly LH †	83.	682-0516A	Handle Bracket Assembly RH Compl.
	682-3066	Handle Bracket Assembly RH	84.	682-0515A	Handle Bracket Assembly LH Compl.
39.	14766	Pivot Bar LH†	85.	782-7000	RD Chute Door
	14765	Pivot Bar RH	86.	731-2634	Bail Stop
40.	732-0706	Front Lever RH	87.	732-0708	Bearing Retainer
	732-0707	Front Lever LH†	88.	732-0417A	Spring Lever
41.	738-0507B	Shoulder Screw	89.	710-1008	TT Screw
42.	726-0240	Cable Tie	90.	682-0512A	Height Adj. Assembly RH Compl.
43.	731-2629	Drive Handle	91.	682-0511A	Height Adj. Assembly LH Compl.
44.	712-0798	Hex Nut 3/8-16	93.	734-2004A	Wheel, 8x2 x 1.75
45.	736-0356	Flat Washer	94.	747-2132	Control Rod
46.	710-0817	TT-Scr. 5/16-18	95.	732-04001	Extension Spring
47.	782-0080A	Rear Discharge Deck: 21"	96.	741-0604A	Bearing Sleeve .50 I.D.
48.	754-0465	V-Belt		737-0476	Bottle of Oil (Not shown)
49.	782-5007A	Mulch Plug	97.	756-0613	Half Pulley
53.	782-5002	Front Baffle	98.	756-0612A	Half Pulley
			99.	750-1071	Sieve Spacer .88 I.D. x 1.130 O.D.

† Not shown

Model Series D449R401



Ref No.	Part No.	Description
1.	712-0896	L-Nut 1/4-28
2.	782-7598	Belt Keeper
3.	741-0124	Ball Bearing
4.	750-1050	Flange Bearing
5.	712-3025	Hex Jam Nut 5/16-24
6.	736-0425	Bell Washer .325 x .930 x .45
7.	656-0047	Pulley, 3.82 x .313 x .68
8.	736-0406	Flat Washer .422 x 1.38 x .060
9.	682-0028	Idler Bracket Pulley
10.	732-04001	Extension Spring
11.	741-0682A	Bearing Sleeve
12.	736-0570	FI-Wash. .865 x 1.145 x .030
13.	711-1492	Pinion Shaft 10T
14.	741-0699	Needle Bearing .438 x .625 x .500
15.	736-0520	FI-Wash. .504 x .700 x .030
16.	717-1492	Pinion Shaft
17.	682-0030	Cable Idler Brkt.
18.	721-0329	Oil Seal .500 x .687 x .094
19.	741-0673	Flange Bearing
20.	611-0105	Output Shaft
21.	736-0314	Thrust Washer .375 x .070 x .030
22.	736-0569	Thrust Washer .388 x .625 x .062
23.	618-0300A	Upper Housing
24.	618-0299A	Lower Housing
25.	710-1276	Hex Screw w/Washer 1/4-20 x .750
26.	618-04006	Transmission Assembly Comp.