


PARTS LIST

HOUSING PARTS - MODEL TB320BV 2-CYCLE GAS MULCHING BLOWER VACUUM




Item	Part No.	Description
1	753-04810	Muffler Cover Assembly (includes 2 & 30)
2	791-180350B	Air Cleaner Filter
3	791-180351	Carburetor Mounting Screw
4	753-04227	Choke Knob
5	753-1194	Choke Plate
6	753-04331	Carburetor Assembly (includes 7 & 18)
7	791-610675	Carburetor Gasket
8	791-181860	Carb Mount Screw
9	791-683974B	Primer & Hose Assembly
10	753-1196	Carb Mount Assembly (includes 8, 11 & 12)
11	791-684451	Reed Assembly
12	753-1208	Carburetor Mount Gasket
13	753-04747	Crankcase Service Assembly (includes 8)
14	791-612134	Rear Mounting Pad
15	753-04310	Fuel Tank Assembly (includes 16-18)
16	753-04084	Fuel Cap
17	791-181086	Fuel Return Line
18	753-04886	Fuel Line Assembly
19	791-145308	Front Mounting Pad
20	753-04409	Shroud Extension (includes 30)
21	791-182736	Flywheel Assembly
22	753-04748	Spacer
23	753-04705	Pulley Retainer
24	753-04459	Recoil Pulley Assembly (includes 25 & 28)
25	753-04286	Recoil Spring
26	791-611061	Rope Guide

Item	Part No.	Description
27	791-181079	Pull Handle
28	791-613103	Rope
29	791-181862	Housing Screw
30	791-181345	Cover Screw
31	753-04749	Starter Housing Assembly (includes 23-30)
32	791-182402	Wire Lead
33	753-04336	Module Assembly
34	791-610311B	Spark Plug
35	753-04618	Muffler Assembly (includes 36-41)
36	753-04619	Exhaust Gasket
37	753-04689	Spark Arrestor Screen
38	753-04690	Plate
39	753-04691	Hood
40	753-04315	Screw
41	753-04620	Muffler Mounting Bolts
42	753-04323	Cylinder Assembly (includes 44 & 45)
43	753-04367	Piston and Rod Assembly
44	753-04182	Cylinder Gasket
45	791-182723	Cylinder Bolt
46	791-181524	Crankshaft Extension
47	791-182396	Washer
*	753-1209	Piston Ring
*	753-04750	Short Block Assembly (includes 8, 13, 34, 42-45)

* Items Not Shown

PARTS LIST

HOUSING PARTS - MODEL TB320BV 2-CYCLE GAS MULCHING BLOWER VACUUM



Item	Part No.	Description
1	753-04452	Engine Cover Assm (includes 2)
2	791-181345	Screw
3	753-04451	Handle Assm (includes 2)
4	753-04756	Throttle control Assm (includes 5-9)
5	791-182420	Upper Throttle Control Plate
6	791-00048	Throttle Control Lever
7	791-182423	Screw
8	791-182405	Rocker Switch Assm
9	791-182422	Lower Throttle Control Plate
10	791-00049	Throttle Cable
11	753-048109	Engine Mount Plate (includes 12 & 13)
12	791-182409	Washer
13	753-04755	Screw
14	753-04596	Impeller Blade
15	753-04482	Impeller Hardware (includes 16-18)
16	753-04833	Washer
17	753-04834	Lock Washer
18	791-182414	Bolt

Item	Part No.	Description
19	753-04456	Vacuum Door Spring
20	753-04455	Vacuum Door Lock
21	753-04454	Vacuum Door
22	791-182424	Mounting Plate Hardware
23	791-182647	Blower Tube
24	753-04457	Vacuum Bag Adaptor
25	791-180466	Upper Vacuum Tube
26	791-180467	Lower Vacuum Tube
*	791-612930	Cable Tie
*	753-04458	Vacuum Bag Assm (includes Bag & Cable Tie)
*	791-682075B	Shoulder Strap

Items Not Shown