




Illustrated Parts List



Hydrostatic Lawn Tractor

Models Z614H & T614H

IMPORTANT: Read safety rules and instructions carefully before operating equipment.


Warning: This unit is equipped with an internal combustion engine and should not be used on or near any unimproved forest-covered, brush-covered or grass-covered land unless the engine's exhaust system is equipped with a spark arrester meeting applicable local or state laws (if any). If a spark arrester is used, it should be maintained in effective working order by the operator. In the State of California the above is required by law (Section 4442 of the California Public Resources Code). Other states may have similar laws. Federal laws apply on federal lands. A spark arrester for the muffler is available through your nearest engine authorized service dealer or contact the service department, P.O. Box 361131 Cleveland, Ohio 44136-0019.

MTD LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019

PRINTED IN U.S.A.

FORM NO. 770-10589B
(11/2002)

SECTION 12: PARTS LIST FOR MODELS Z614H & T614H




REF. NO.	PART NO.	DESCRIPTION
1.	710-0227	Self-tapping Screw, #8-18 x .50"
2.	710-0599	Self-tapping Screw, 1/4-20 x .50"
3.	712-0726	AB Screw 5/16-12 x 0.75"
4.	710-1237	Screw, #10-32 x .625
5.	710-1314A	Socket Cap Screw, 5/16-18 x .625
6.	710-1315	TT Screw 3/8-16 x 1.250"
7.	712-3017	Hex Nut 3/8-16
8.	721-0331	Sealant
9.	721-0460	Exhaust Gasket
10.	722-0263	Foam
11.	726-0205	Hose Clamp
12.	736-0119	Lock Washer
13.	736-0300	Flat Washer
15.	751B221535	Casing Clamp
16.	751-0535	Fuel Line Hose
17.	751-0564	Deflector: Muffler
18.	751-0616	Muffler: Dual Inlet
19.	751-0650	Exhaust Pipe RH
20.	751-0651	Exhaust Pipe LH
21.	751-3140	Oil Drain
22.	751-3141	Hose: Oil Drain Extension
23.	751-3142	Oil Drain Cap
24.	783-0615B	Heat Shield: Muffler
25.	783-0625C	Heat Shield

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665
Yard-Man Yellow: 0674
Powder Black: 0637

Models Z614H & T614H




Models Z614H & T614H

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	710-3015	Hex Cap Screw, 1/4-20 x .75	24	710-3217	Torx Screw, #8-32 x .375
2	710-0599	Self-tapping Screw, 1/4-20 x .5	25	712-0142	Hex Nut, 8-32
3	712-3006	Hex Nut, 1/4-20	26	731-0071C	Dash Panel, 4-style
4	710-0895	Self-tapping Screw, 1/4-15 x .75	27	731-0072	Parking Brake Button
5	710-0924	Pan Phillips Screw, 1/4-20 x .75	28	731-1857	Throttle Control Lever
6	710-0528	Hex Cap Screw, 5/16-18 x 1.25	29	731-2106	Cruise Control Button
7	712-0292	U-type Speed Nut, 1/4-20	30	747-1155	Brake/Cruise Pivot Rod
8	712-3004A	Flange Lock Nut, 5/16-18	31	749-1087B	Dash Support Tube
9	726-0201	Speed Nut	32	731-2232	Intake Bellow (Model T614H)
10	747-2127	Hood Latch Rod		731-2234	Intake Bellow (Model Z614H)
11	731-1978	RH Head Light Lens	33	751-0658D	Fuel Tank, 3-gallon
	731-1979	LH Head Light Lens	34	751-0603	Fuel Cap
12	747-1132A	Hood Support Rod	35	725-1745	Ignition Key w/ plastic cover
13	731-1980A	Hood		725-1744	Ignition Key w/o plastic cover
14	731-1981C	LH Side Panel	37	783-1000A	Grille Support Bracket
15	731-1982C	RH Side Panel	38	725-1976	Systems Indicator Monitor
16	736-0329	Lock Washer, 1/4	39	725-1741	Ignition Switch
17	736-0342	Flat Washer, .283 x .75 x .030	40	625-0051	Headlight Assembly
18	736-0173	Flat Washer, .28 x .74 x .063	41	731-1995	RH Headlight Reflector
19	736-3078	Flat Washer, .349 x 1.0 x .063		731-1996	LH Headlight Reflector
20	710-0642	Self-tapping Screw, 1/4-20 x 0.75	—	629-0469B	Headlight Wire Harness
21	783-0808A	Hood Heat Shield w/o Intake Bellow	—	629-1071	Tractor Wire Harness (Model T614H)
22	710-0726	AB Screw, 5/16-12 x .75	—	629-1067	PTO Wire Harness (Model Z614H)
23	710-0599	Self-tapping Screw, 1/4-20 x .50			

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665
Yard-Man Yellow: 0674
Powder Black: 0637

Models Z614H & T614H




Models Z614H & T614H

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	747-1130	Deck Stabilizer Rod	29	710-0895	Self-tapping Screw, 1/4-15 x .75
2	683-0197	Lift Shaft Assembly	30	731-1990	Lift Lever Cover
3	711-0332	Clevis Pin, .5 x .78	31	731-1993	Cover w/ Cup Holder
4	712-0206	Hex Nut, 1/2-13	32	736-3078	Flat Washer, .349 x 1.0 x .063
5	712-0431	Flange Lock Nut, 3/8-16	33	783-0677	Lift Adjustment Bracket
6	712-3004A	Flange Lock Nut, 5/16-18	34	783-1279	Fender
7	712-3083	Hex Nut, 1/2-13	35	783-1489	Seat Mounting Bracket
8	714-0104	Internal Cotter Pin	36	710-1268	Screw, #10-16 x .375
9	714-0145	Internal Cotter Pin	37	712-3027	Hex Flange Lock Nut, 1/4-20
10	716-0106	E-ring	38	720-0309A	Seat Adjuster Grip
11	720-0311	Handle Grip	39	731-04074	Spacer
12	732-0874	Torsion Spring	40	732-0499	Compression Spring, .41 x 1.5
13	732-1184	Extension Spring	41	736-0175	Spring Washer, .265 x .562 x .025
14	736-0275	Flat Washer, 5/16	42	736-0204	Flat Washer, .344 x .62 x .03
15	736-0921	Lock Washer, 1/2	43	738-0137A	Shoulder Screw, .340 x .285, 1/4-20
16	736-3019	Flat Washer, .31 x 1.062 x .134	44	738-0966	Shoulder Screw
17	736-3084	Flat Washer, .51 x 1.12 x .06	45	783-0611	Seat Stop
18	738-0138A	Hex Cap Screw, 5/16-18 x .62	46	783-0738	Seat Pivot Bracket
19	738-0143	Shoulder Screw, 3/8-16	47	783-0739	Seat Adjustment Lever
20	741-0225	Hex Flange Bearing	48	783-0753	Seat Adjustment Selector
21	741-0715	Snap Flange Bearing	49	757-04012	High Back Seat, Yellow (Model Z614H)
22	746-0968	Lift Cable, 16.16		757-04011	Med. Back Seat, Yellow (Model T614H)
23	747-1111A	Lift Handle	50	735-0656	RH Foot Pad
24	756-1154	Roller Pulley	51	735-0657	LH Foot Pad
25	783-0678A	Arm Lift		726-3046	Foot Pad Clips (Not Shown)
26	783-0720A	Deck Stabilizer Bracket	52	714-0111	Cotter Pin
27	710-0260A	Carriage Bolt, 5/16 x .62	53	731-0511	Trim Strip
28	710-0604A	Self-tapping Screw, 5/16-18 x .625	54	783-0209A	Seat Lift Bracket

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665
Yard-Man Yellow: 0674
Powder Black: 0637

Models Z614H & T614H




Models Z614H & T614H

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	710-1260A	Self-tapping Screw, 5/16-18 x .75	24	731-04065	Steering Wheel Cap
2	710-0604A	Self-tapping Screw, 16-18 x .625	25	638-0021A	LH Axle Assembly, .75 Diameter
3	783-0726B	RH Pivot Support Bracket	26	638-0022A	RH Axle Assembly, .75 Diameter
4	783-0727A	LH Pivot Support Bracket	27	719-0399B	Cast Iron Pivot Bar w/ Fittings, .75
5	783-0728	Pivot Bar Bracket	28	712-0431	Flange Lock Nut, 3/8-16
6	710-0514	Hex Cap Screw, 3/8-16 x 1 (Grade 5)	29	714-0162	Cotter Pin
7	711-1408	RH Drag Link	30	726-0341	Push Cap, .750
8	711-1409A	LH Drag Link	31	736-0242	Bell Washer, .34 x .872
9	712-0240	Jam Nut, 7/16-20 (Grade 2)	32	736-0285	Flat Washer, .635 x 1.589 x .06
10	712-0241	Hex Nut, 3/8-24 (Grade 2)	33	736-0331	Bell Washer, .39 x 1.13 x .062
11	712-0431	Flange Lock Nut, 3/8-16	34	738-1011	Shoulder Screw, .5 x 2.2, 3/8-16
12	712-0459	Flange Lock Nut, 7/16-20	35	710-0643	Hex Bolt, 5/16-18 X 1
13	712-3004A	Flange Lock Nut, 5/16-18	36	634-0105A	Wheel Assembly Complete, 15 x 6 x 6
14	717-1550D	Steering Gear, 11/90 Ratio		634-0172	Rim Only w/ Plastic Bearing
15	717-1554	Steering Pinion Gear		734-0255	Air Valve (Not Shown)
16	723-0448A	Ball Joint, 7/16-20		734-1731	Tire Only, Square Shoulder
17	736-0169	Lock Washer, 3/8	37	734-2290	Hub Cap
18	736-3084	Flat Washer, .51 x 1.12 x .06	38	783-0653E	Steering Support Bracket
19	738-1001A	Steering Shaft, .625 OD x 24.4	39	738-0143	Shoulder Screw, 3/8-16
20	741-0475	Plastic Bushing, .38 ID	40	710-04095	Hex Screw 3/8-16 x 1.0
21	741-0656	Hex Flange Bearing, 5/8	41	17962	Switch Plate
22	738-0372B	Shoulder Spacer, .38 ID	42	710-0224	AB Screw #10-16 x 0.5
23	631-04008	Steering Wheel: 3 Spoke			

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665
Yard-Man Yellow: 0674
Powder Black: 0637

Models Z614H & T614H



Models Z614H & T614H

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	17840	Transaxle Mounting Bracket	42	747-1151	Hydrostatic Control Rod
2	618-0319	Hydrostatic Transmission	43	750-0535	Spacer, .376 x .625 x .22
3	629-0949A	Reverse Wire Harness Adapter & Ground	44	754-0349	Drive Belt
4	736-0242	Bell Washer, .34 x .872	45	756-0116	V-idler Pulley, 3.06
5	683-0251	Double Idler Bracket Assembly	46	756-0981A	Flat Idler Pulley, 2.75
6	710-0176	Hex Cap Screw, 5/16-18 x 2.75	47	756-1166	Input Pulley, 5.0
7	710-0227	Screw, #8-18 x .5	48	783-0810	Transmission Torque Bracket
8	710-0344	Hex Cap Screw, 3/8-16 x 1.5	49	783-1019	Switch Actuator Bracket
9	710-0726	AB Screw, 5/16-12 x .75	50	647-0031B	Brake Control Assembly
10	710-0599	Self-tapping Screw, 1/4-20 x .375	51	647-0049	Drive Control Assembly
11	710-3007	Screw, #12-24 x .375	52	683-0267C	Hydro Pedal Assembly
12	710-3011	Hex Cap Screw, 3/8-16 x 2.25	53	710-0650	Self-tapping Screw, 5/16-18 x .875
13	710-3103	Hex Cap Screw, 5/16-18 x 2.0	54	710-1260A	Self-tapping Screw, 5/16-18 x .75
14	711-0677	Ferrule, 5/16-18	55	711-0736	Ferrule, 1/4-20
15	711-0832	Ferrule, 3/8-24	56	711-1363	Pin, 3/8-16 x 2.43
16	712-0333	Hex Nut, 1/2-20	57	732-0335	Compression Spring, .405 OD x 1.17
17	712-0431	Flange Lock Nut, 3/8-16	58	756-0978A	Engine Pulley
18	712-3006	Flange Lock Nut, 1/4-20	59	732-0963	Extension Spring, .50 OD x 6.37
19	712-3010	Hex Nut, 5/16-18	60	735-0662	Drive Pedal Pad
20	712-3017	Hex Nut, 3/8-16	61	735-3049	Brake Pedal Pad
21	714-0104	Internal Cotter Pin	62	736-0133	Flat Washer, .411 x 1.25 x 1.0
22	714-0111	Cotter Pin	63	736-0187	Flat Washer, .64 x 1.24 x .06
23	725-0157	Cable Tie	64	736-0222	Ext. Lock Washer
24	725-1644	Short Spring Switch	65	710-1611B	TT Screw 5/16-18 x 0.75
25	726-0320	Insulator Nut Plate	66	738-0155	Shoulder Screw, .437 x 1.62
26	731-1449A	10-inch Fan	67	710-0627	Hex Cap Screw, 5/16-24 x .75
27	732-0209	Extension Spring, .48 x 2.03	68	741-0225	Hex Flange Bearing
28	732-0716	Extension Spring, .59 x 4.0	69	741-3065B	Split Hex Flange Bearing
29	732-0729	Wire Ring	70	747-1137	Cruise Control Rod
30	732-0429A	Extension Spring, .5 x 3.97	71	747-1138	Brake Lock Control Rod
31	732-0994	Extension Spring, .5 x 7.0	72	748-0413	Cruise Latch
32	732-3118	Extension Spring, 3/8 x 1.44	73	736-3008	Flat Washer, .344 x .750 x .120
33	736-0140	Flat Washer, .385 x .62 x .063	74	783-0653E	Steering Support Bracket
34	736-0329	Lock Washer	75	783-0663C	Drive Lockout Bracket
35	736-0169	Lock Washer, 3/8	76	783-0773	Brake Pedal
36	736-0275	Flat Washer, .344 x .688 x .065	77	634-0104	Wheel Assembly Complete 20 x 8 x 8
37	736-0921	Lock Washer, 1/2		634-0070	Square Shoulder
38	736-3010	Flat Washer, .407 x .812 x .135		734-0255	Rim Assembly Only
39	738-0372B	Shoulder Spacer, .38		734-1730	Air Valve (Not Shown)
40	747-1149	Hydrostatic Bypass Rod		734-2290A	Tire Only, 20 x 8 x 8, Square Shoulder
41	747-1150	Hydrostatic Brake Rod	78		Deluxe Hub Cap (Ref. 79 Required)
			79	736-0430	Flat Washer, .350 x 1.59 x .062


NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665


Yard-Man Yellow: 0674

Powder Black: 0637

Models Z614H & T614H



Model Z614H




Models Z614H & T614H

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	647-0064	PTO Engage Lever Assembly	39	783-0349	Battery Tray
2	683-0450	PTO Engage Plate Assembly	40	725-1426	Solenoid, 12-Volt, 100 Amp
3	710-0276	Carriage Screw, 5/16-18 x 1.00	41	710-0599	Self-Tapping Screw, 1/4-20 x .5
4	710-0520	Hex Cap Screw, 3/8-16 x 1.5	42	736-0222	Lock Washer, 1/4
5	710-0831	Hex Cap Screw, 3/8-16 x 5.5	43	683-0304C	Lower Frame Assembly
6	710-1238	Hex Head Washer Screw, 5/16-18 x .875	44	725-1706	12-Volt Battery, 270 CCA
7	712-0229	Push Nut, 3/8	45	710-0751	Hex Cap Screw, 1/4-20 x .62
8	712-0431	Flange Lock Nut, 3/8-16	46	712-0271	Hex Sems Nut, 1/4-20
9	712-3004A	Flange Lock Nut, 5/16-18	47	712-3044	Wing Nut, 1/4-20
10	712-3010	Hex Nut, 5/16-18	48	732-1165	Extension Spring, .50 x 5.0
11	714-0470	Cotter Pin, 1/8 x 1.25	49	710-3180	Hex Cap Screw, 5/16-18 x 1.75
12	726-0201	Speed Nut, .3125	50	750-0596	Spacer Cup
13	731-2111A	PTO Knob	51	710-3029	Hex Head Cap Screw, 7/16-20 x 1.25
14	732-1170	Extension Spring, .75 x 6.75	52	736-0171	Lock Washer, 7/16
15	732-0991A	Belt Guard	53	736-0322	Flat Washer, .450 x 1.25
16	736-0108	Flat Washer, .510 x .750 x .033	54	756-0983B	Engine Pulley, 3.56 OD x 5.56
17	736-0119	Lock Washer, 5/16	55	754-0497	PTO Belt
18	736-0140	Flat Washer, .385 x .62 x .063	56	783-0653E	Steering Support Bracket
19	736-0275	Flat Washer, 5/16	57	711-1044	Keeper Pin, 5/16 x 4.75
20	736-0300	Flat Washer, .406 x .875 x .059	58	732-1013	Belt Guard
21	736-0242	Bell Washer, .39 x 1.13 x .062	59	736-0329	Lock Washer
22	736-3010	Flat Washer, .407 x .812 x .135	60	712-3006	Hex Nut
23	738-0372A	Shoulder Spacer, .380	61	683-0297/	Idler Bracket Assembly
24	741-0708	Hex Split Flange Bearing, .5		0251	
25	747-1112D	PTO Engagement Handle	62	738-3056	Shoulder Screw 1/2 x 2.50
26	747-1286	Belt Keeper Rod	63	710-3144	Hex Screw 3/8-16 x 2.5
27	748-0415B	Spacer, 3/8 x 1.54	64	710-0859	Hex Screw 3/8-16 x 2.5
28	756-0627B	Idler Pulley, 3.5	65	732-0978	Extension Spring
29	756-1208	Idler Pulley, 4.0	66	754-0474	PTO Belt (Model Z614H)
30	783-0744A	Engagement Stop	67	717-1708	Electric PTO Clutch (Model Z614H)
31	783-0891B	Deck Stop	68	738-0785	Shoulder Spacer
32	710-0604A	Self-Tapping Screw, 5/16-18 x .625	69	710-3157	Hex Cap Screw
33	732-04035	Compression Spring, 1.28 x 3.25	70	725-1657A	Switch
34	723-0444	Battery Strap	71	17962	Switch Plate
35	738-1020	Shoulder Screw, .625 x .5, 7/16-20	72	710-024	Screw #10-16 x 0.5
36	736-0407	Bell Washer, .45 x 1.0 x .062	73	710-3144	Hex Cap Screw 3/8-16 x 2.0
37	712-0459	Flange Lock Nut, 7/16-20	74	783-1003	Anti-Rotation Bracket (Model Z614H)
38	783-1031A	Hitch Plate	75	710-3025	Hex Cap Screw 5/16-18 x 0.625

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665
Yard-Man Yellow: 0674
Powder Black: 0637

Cutting Deck: Model Z614H




Cutting Deck: Model Z614H

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1.	683-0265C	Deck Assembly	29.	711-04069	Grass Catcher Pin
2.	17982	Spindle Plate	30.	736-0119	Lock Washer
3.	618-0240A	Spindle Assembly	31.	736-0270	Bell Washer
4.	618-0241	Spindle Assembly: Double Pulley	32.	738-0347	Shoulder Spacer
5.	683-0254	Deck Hanger Bracket Assembly LH	33.	738-0373	Shoulder Screw
7.	710-0167	Carriage Screw 1/4-20 x 0.50	34.	747-1116	Deck Release Handle
8.	710-0344	Hex Screw 3/8-16 x 1.5	35.	754-0349	V-Belt
9.	710-0501	Hex Screw 1/4-20 x 2.0	36.	754-0474	V-Belt
10.	710-0514	Hex Screw 3/8-16 x 1.0	37.	756-0627B	Idler Pulley
11.	710-0528	Hex Screw 5/16-18 x 1.25	39.	783-0139A	Idler Bracket
12.	710-0599	TT Screw 1/4-20 x 0.5	40.	783-0141	Deck Skirt: Center
13.	710-0650	TT Screw 5/16-18 x 0.875	41.	783-0142	Deck Skirt RH
14.	710-0703	Carriage Screw 1/4-20 x 0.75	42.	783-0747	Belt Cover LH
15.	710-0751	Hex Screw 1/4-20 x 0.620	43.	783-0805A	Belt Cover RH
16.	710-1260A	LD Screw 5/16-18 x 0.75	44.	783-1025	Chute Stop
17.	712-0271	Sems Nut 1/4-20	45.	710-0578	Machine Screw
18.	712-0417A	Flange Nut	46.	736-0173	Flat Washer
19.	712-0431	Lock Nut 3/8-16	47.	712-3006	Hex Nut
20.	712-3006	Hex Nut 1/4-20	48.	712-3087	Wing Nut
21.	712-3027	Lock Nut 1/4-20	49.	731-1636	Mulch Plug
22.	714-0470	Cotter Pin	50.	731-1032B	Chute Deflector: Side Discharge
23.	717-1553B	Gear Adjustment	51.	726-0106	Speed Nut
24.	726-0233	Push Nut	52.	711-0792	Hinge Pin
25.	732-0306	Compression Spring	53.	703-1693A	Mounting Bracket
26.	732-0594A	Extension Spring	54.	732-0602	Torsion Spring
27.	732-0934	Extension Spring	55.	742-0611	Blade: 16.28" Star
28.	734-0973	Deck Wheel	56.	742-0612	Blade: 14.88" Star

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665
Yard-Man Yellow: 0674
Powder Black: 0637

Cutting Deck: Model T614H



Cutting Deck: Model T614H

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	17116	Brake Assembly: Deck	41.	736-0270	Bell Washer
2.	17258C	Belt Cover	42.	736-0418A	Flat Washer
3.	17982	Spindle Plate	43.	738-0347	Spacer
4.	618-0240A	Spindle Assembly	44.	738-0373	Shoulder Screw
5.	618-0594	Spindle Assembly: Double Pulley	45.	746-1107	Cable Bracket
6.	683-0254	Bracket: Deck Hanger LH	46.	747-1116	Deck Release Handle Rod
7.	683-0265C	Deck Assembly	47.	748-0234	Shoulder Spacer
8.	710-0167	Carriage Screw 1/4-20 x 0.50"	48.	750-1320	Spacer
9.	710-0344	Hex Screw 3/8-16 x 1.5"	49.	754-0349	V Belt
10.	710-0501	Hex Screw 1/4-20 x 2.0"	50.	754-0486A	V Belt
11.	710-0514	Hex Screw 3/8-16 x 1.0"	51.	756-0627B	Idler Pulley
12.	710-0528	Hex Screw 5/16-18 x 1.25"	53.	783-0139A	Idler Bracket
13.	710-0599	TT Screw 1/4-20 x 0.5"	54.	783-0141	Deck Skirt: Center
14.	710-0650	TT Screw 5/16-18 x 0.875"	55.	783-0142	Deck Skirt: RH
15.	710-0703	Carriage Screw 1/4-20 x 0.75"	56.	783-1025	Chute Stop
16.	710-0751	Hex Screw 1/4-20 x 0.620"	57.	783-1348	Belt Cover
17.	710-0805	Hex Screw 5/16-18 x 1.5"	58.	742-0611	Blade: 16.28" Star
18.	710-1260A	LD Screw 5/16-18 x 0.75"	59.	742-0612	Blade: 14.88" Star
19.	710-3180	Hex Screw 5/16-18 x 1.75"	60.	731-1032B	Chute Deflector: Side Discharge
20.	711-04069	Grass Catcher Pin	61.	731-1636	Mulch Plug
21.	711-0993	Belt Guard Pin	62.	712-3087	Wing Nut
22.	711-1554	Pin	63.	712-3006	Hex Nut
23.	712-0271	Hex Sems Nut 1/4-20	64.	710-0578	Machine Screw
24.	712-0417A	Flange Nut	65.	736-0173	Flat Washer
25.	712-0431	Flange Lock Nut	66.	703-1693A	Mounting Bracket
26.	712-3004A	Flange Lock Nut	67.	726-0106	Speed Nut
27.	712-3006	Hex Nut 1/4-20	68.	732-0602	Torsion Spring
28.	712-3010	Hex Nut 5/16-18	69.	711-0792	Hinge Pin
29.	712-3027	Hex Flange Nut 1/4-20	70.	712-0417A	Flange Nut
30.	714-0470	Cotter Pin	71.	756-1187	Deck Pulley
31.	717-1553B	Gear Adjustment	72.	750-0952	Spacer
32.	726-0233	Push Nut	73.	741-0919	Ball Bearing
33.	732-0306	Compression Spring	74.	748-0434	Spacer
34.	732-0429A	Extension Spring	75.	619-0011	Spindle Housing
35.	732-0594A	Extension Spring	77.	17983	Shoulder Bearing
36.	732-0934	Extension Spring	78.	738-0927	Spindle Shaft
37.	732-1165	Extension Spring	79.	712-0417A	Flange Lock Nut
38.	734-0973	Deck Wheel	80.	756-0603	Pulley
39.	736-0119	Lock Washer	81.	750-1304	Spacer
40.	736-0140	Flat Washer	82.	738-1010	Spindle Shaft