




Illustrated Parts List



Hydrostatic Lawn Tractor

Model Z814K

IMPORTANT: Read safety rules and instructions carefully before operating equipment.


Warning: This unit is equipped with an internal combustion engine and should not be used on or near any unimproved forest-covered, brush-covered or grass-covered land unless the engine's exhaust system is equipped with a spark arrester meeting applicable local or state laws (if any). If a spark arrester is used, it should be maintained in effective working order by the operator. In the State of California the above is required by law (Section 4442 of the California Public Resources Code). Other states may have similar laws. Federal laws apply on federal lands. A spark arrester for the muffler is available through your nearest engine authorized service dealer or contact the service department, P.O. Box 361131 Cleveland, Ohio 44136-0019.

MTD LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019

PRINTED IN U.S.A.

(1/2003)

SECTION 12: PARTS LIST FOR MODEL Z814K



Model Z814K

REF. NO.	PART NO.	DESCRIPTION
1.	710-0227	Self-tapping Screw, #8-18 x .50"
2.	710-0599	Self-tapping Screw, 1/4-20 x .50"
3.	712-0726	AB Screw 5/16-12 x 0.75"
4.	710-1237	Screw, #10-32 x .625
5.	710-1314A	Socket Cap Screw, 5/16-18 x .625
6.	710-1315	TT Screw 3/8-16 x 1.250"
7.	712-3017	Hex Nut 3/8-16
8.	721-0331	Sealant
9.	721-0460	Exhaust Gasket
10.	722-0263	Foam
11.	726-0205	Hose Clamp
12.	736-0119	Lock Washer
13.	736-0300	Flat Washer
15.	751B221535	Casing Clamp
16.	751-0535	Fuel Line Hose
17.	751-0564	Deflector: Muffler
18.	751-0616	Muffler: Dual Inlet
19.	751-0650	Exhaust Pipe RH
20.	751-0651	Exhaust Pipe LH
21.	751-3140	Oil Drain
22.	751-3141	Hose: Oil Drain Extension
23.	751-3142	Oil Drain Cap
24.	783-0615B	Heat Shield: Muffler
25.	783-0625C	Heat Shield

This exploded perspective view illustrates the assembly of a vehicle seat. The components are numbered as follows:

- 1:** Multiple screws used for securing the seat backrest and base.
- 2:** A large, curved metal spring or support structure.
- 3:** A small, rectangular component, possibly a switch or sensor.
- 4:** A small, rectangular component, possibly a switch or sensor.
- 5:** A small, rectangular component, possibly a switch or sensor.
- 6:** A small, rectangular component, possibly a switch or sensor.
- 7:** A small, rectangular component, possibly a switch or sensor.
- 8:** A small, rectangular component, possibly a switch or sensor.
- 9:** A small, rectangular component, possibly a switch or sensor.
- 10:** A small, rectangular component, possibly a switch or sensor.
- 11:** A small, rectangular component, possibly a switch or sensor.
- 12:** A small, rectangular component, possibly a switch or sensor.
- 13:** A small, rectangular component, possibly a switch or sensor.
- 14:** A small, rectangular component, possibly a switch or sensor.
- 15:** A small, rectangular component, possibly a switch or sensor.
- 16:** A small, rectangular component, possibly a switch or sensor.
- 17:** A small, rectangular component, possibly a switch or sensor.
- 18:** A small, rectangular component, possibly a switch or sensor.
- 19:** A small, rectangular component, possibly a switch or sensor.
- 20:** A small, rectangular component, possibly a switch or sensor.
- 21:** A small, rectangular component, possibly a switch or sensor.
- 22:** A small, rectangular component, possibly a switch or sensor.
- 23:** A small, rectangular component, possibly a switch or sensor.
- 24:** A small, rectangular component, possibly a switch or sensor.
- 25:** A small, rectangular component, possibly a switch or sensor.
- 26:** A small, rectangular component, possibly a switch or sensor.
- 27:** A small, rectangular component, possibly a switch or sensor.
- 28:** A small, rectangular component, possibly a switch or sensor.
- 29:** A small, rectangular component, possibly a switch or sensor.
- 30:** A small, rectangular component, possibly a switch or sensor.
- 31:** A small, rectangular component, possibly a switch or sensor.
- 32:** A small, rectangular component, possibly a switch or sensor.
- 33:** A small, rectangular component, possibly a switch or sensor.
- 34:** A small, rectangular component, possibly a switch or sensor.
- 35:** A small, rectangular component, possibly a switch or sensor.
- 36:** A small, rectangular component, possibly a switch or sensor.
- 37:** A small, rectangular component, possibly a switch or sensor.
- 38:** A small, rectangular component, possibly a switch or sensor.
- 39:** A small, rectangular component, possibly a switch or sensor.
- 40:** A small, rectangular component, possibly a switch or sensor.
- 41:** A small, rectangular component, possibly a switch or sensor.
- 42:** A small, rectangular component, possibly a switch or sensor.


Model Z814K

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	710-3015	Hex Cap Screw, 1/4-20 x .75	24	710-3217	Torx Screw, #8-32 x .375
2	710-0599	Self-tapping Screw, 1/4-20 x .5	25	712-0142	Hex Nut, 8-32
3	712-3027	Hex Flange Lock Nut, 1/4-20	26	731-0071C	Dash Panel, 4-style
4	710-0895	Self-Tapping Screw, 1/4-15 x .75	27	731-0072	Parking Brake Button
5	710-0924	Pan Phillips Screw, 1/4-20 x .75	28	731-1857	Throttle Control Lever
6	710-0528	Hex Cap Screw, 5/16-18 x 1.25	29	731-2106	Cruise Control Button
7	712-0292	U-type Speed Nut, 1/4-20	30	747-1155	Brake/Cruise Pivot Rod
8	712-3004A	Flange Lock Nut, 5/16-18	31	749-1087B	Dash Support Tube
9	726-0201	Speed Nut	32	731-2232	Intake Bellow (Model T614H)
10	747-2127	Hood Latch Rod	33	751-0658D	Fuel Tank, 3-gallon
11	731-1978	RH Head Light Lens	34	751-0603	Fuel Cap
	731-1979	LH Head Light Lens	35	725-1745	Ignition Key w/ plastic cover
12	747-1132A	Hood Support Rod		725-1744	Ignition Key w/o plastic cover
13	731-1980A	Hood	37	783-1000A	Grille Support Bracket
14	731-1981C	LH Side Panel	38	725-1976	Systems Indicator Monitor
15	731-1982C	RH Side Panel	39	725-1741	Ignition Switch
17	736-0342	Flat Washer, .283 x .75 x .030	40	625-0051	Headlight Assembly
18	736-0173	Flat Washer, .28 x .74 x .063	41	725-1752	Electric PTO Switch
19	736-3078	Flat Washer, .349 x 1.0 x .063	42	731-1995	RH Headlight Reflector
20	710-0642	Self-tapping Screw, 1/4-20 x 0.75		731-1996	LH Headlight Reflector
21	783-0808A	Hood Heat Shield w/o Intake Bellow	—	629-0469B	Headlight Wire Harness
22	710-0726	AB Screw, 5/16-12 x .75	—	629-0404B	PTO Wire Harness
23	710-0599	Self-tapping Screw, 1/4-20 x .50			

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665
Yard-Man Yellow: 0674
Powder Black: 0637

Model Z814K




Model Z814K

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	747-1324	Deck Stabilizer Rod	31	731-1993	Cover w/ Cup Holder
2	683-0642	Lift Shaft Assembly	32	736-3078	Flat Washer, .349 x 1.0 x .063
3	711-0332	Clevis Pin, .5 x .78	33	783-0677	Lift Adjustment Bracket
4	712-0206	Hex Nut, 1/2-13	34	783-1279	Fender
5	712-0431	Flange Lock Nut, 3/8-16	35	783-1489	Seat Mounting Bracket
6	712-3004A	Flange Lock Nut, 5/16-18	36	710-1268	Screw, #10-16 x .375
7	712-3083	Hex Nut, 1/2-13	37	712-3027	Hex Flange Lock Nut, 1/4-20
8	714-0104	Internal Cotter Pin	38	720-04026	Seat Adjuster Grip
9	714-0145	Internal Cotter Pin	39	731-04074	Spacer
10	716-0106	E-Ring	40	732-0499	Compression Spring, .41 x 1.5
11	720-0311	Handle Grip	41	736-0175	Spring Washer, .265 x .562 x .025
12	732-0874	Torsion Spring	42	736-0204	Flat Washer, .344 x .62 x .03
13	732-1184	Extension Spring	43	738-0137A	Shoulder Screw, .340 x .285, 1/4-20
14	736-0275	Flat Washer, 5/16	44	738-0966	Shoulder Screw
15	736-0921	Lock Washer, 1/2	45	783-0611	Seat Stop
16	736-3019	Flat Washer, .31 x 1.062 x .134	46	783-0738A	Seat Pivot Bracket
17	736-3084	Flat Washer, .51 x 1.12 x .06	47	783-04246	Seat Adjustment Lever
18	738-0138A	Hex Cap Screw, 5/16-18 x .62	48	783-0753	Seat Adjustment Selector
19	738-0143	Shoulder Screw, 3/8-16	49	757-0372	Seat, Yellow
20	741-0225	Hex Flange Bearing	50	735-0656	RH Foot Pad
21	741-0715	Snap Flange Bearing	51	735-0657	LH Foot Pad
22	746-0968	Lift Cable, 16.16		726-3046	Foot Pad Clips (Not Shown)
23	747-1111A	Lift Handle	52	714-0111	Cotter Pin
24	756-1154	Roller Pulley	53	731-0511	Trim Strip
25	783-0678A	Arm Lift	54	783-0209A	Seat Lift Bracket
26	783-0720A	Deck Stabilizer Bracket	55	783-1478	Fender Clip
27	710-0260A	Carriage Bolt, 5/16 x .62	56	731-2618	Fender Flare RH
28	710-0726	AB Screw, 5/16-12 x .75	57	731-2619	Fender Flare LH
29	710-0895	Self-tapping Screw, 1/4-15 x .75	59	710-0932	Carriage Screw 1/4-20 x 1.0"
30	731-1990	Lift Lever Cover			

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665
Yard-Man Yellow: 0674
Powder Black: 0637

Model Z814K




Model Z814K

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	710-1260A	Self-tapping Screw, 5/16-18 x .75	24	731-04065	Steering Wheel Cap
2	710-0604A	Self-tapping Screw, 16-18 x .625	25	638-0021A	LH Axle Assembly, .75 Diameter
3	783-0726B	RH Pivot Support Bracket	26	638-0022A	RH Axle Assembly, .75 Diameter
4	783-0727A	LH Pivot Support Bracket	27	719-0525B	Cast Iron Pivot Bar w/ Fittings, .75
5	783-0728	Pivot Bar Bracket	28	712-0431	Flange Lock Nut, 3/8-16
6	710-0514	Hex Cap Screw, 3/8-16 x 1	29	714-0162	Cotter Pin
7	711-1408	RH Drag Link	30	726-0341	Push Cap, .750
8	711-1409A	LH Drag Link	31	736-0242	Bell Washer, .34 x .872
9	712-0240	Jam Nut, 7/16-20	32	736-0285	Flat Washer, .635 x 1.589 x .06
10	712-0241	Hex Nut, 3/8-24	33	736-0331	Bell Washer, .39 x 1.13 x .062
11	712-0431	Flange Lock Nut, 3/8-16	34	738-1011	Shoulder Screw, .5 x 2.2, 3/8-16
12	712-0459	Flange Lock Nut, 7/16-20	35	710-0643	Hex Bolt, 5/16-18 X 1
13	712-3004A	Flange Lock Nut, 5/16-18	36	634-0105A	Wheel Assembly Complete, 15 x 6 x 6
14	717-1550D	Steering Gear, 11/90 Ratio		634-0172	Rim Only w/ Plastic Bearing
15	717-1554	Steering Pinion Gear		734-0255	Air Valve (Not Shown)
16	723-0448A	Ball Joint, 7/16-20		734-1731	Tire Only, Square Shoulder
17	736-0169	Lock Washer, 3/8	37	734-2290A	Hub Cap
18	736-3084	Flat Washer, .51 x 1.12 x .06	38	783-0653E	Steering Support Bracket
19	738-1001A	Steering Shaft, .625 OD x 24.4	39	738-0143	Shoulder Screw, 3/8-16
20	741-0475	Plastic Bushing, .38 ID	40	710-04095	Hex Screw 3/8-16 x 1.0
21	741-0656	Hex Flange Bearing, 5/8	41	17962	Switch Plate
22	738-0372B	Shoulder Spacer, .38 ID	42	710-0224	AB Screw #10-16 x 0.5
23	631-04008	Steering Wheel: 3 Spoke			

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665
Yard-Man Yellow: 0674
Powder Black: 0637

Model Z814K



Model Z814K

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	712-3050	Lug Nut, 3/4-16	40	647-0031B	Brake Control Assembly
2	629-0949A	Reverse/Ground Wire Harness Adapter	41	647-0049	Drive Control Assembly
3	683-0251	Double Idler Bracket Assembly	42	683-0267C	Hydro Pedal Assembly
4	710-0176	Hex Cap Screw, 5/16-18 x 2.75	43	710-0650	Self-tapping Screw, 5/16-18 x .875
5	710-0216	Hex Cap Screw, 3/8-16 x .75	44	710-1260A	Self-tapping Screw, 5/16-18 x .75
6	710-0227	Screw, #8-18 x .5	45	711-0736	Ferrule, 1/4-20
7	710-0344	Hex Cap Screw, 3/8-16 x 1.5	46	711-1363	Pin, 3/8-16 x 2.43
8	710-0599	Self-tapping Screw, 1/4-20 x .50	47	732-0335	Compression Spring, .40 OD x 1.17
9	710-0604A	Self-tapping Screw, 5/16-18 x .625	48	732-0955	Extension Spring, .50 OD x 1.41
10	710-3011	Hex Cap Screw, 3/8-16 x 2.25	49	732-0963	Extension Spring, .50 OD x 6.37
11	711-0677	Ferrule, 5/16-18	50	735-0662	Drive Pedal Pad
12	711-0832	Ferrule, 3/8-24	51	735-3049	Brake Pedal Pad
13	712-0431	Flange Lock Nut, 3/8-16	52	736-0133	Flat Washer, .411 x 1.25 x 1.0
14	712-3004A	Flange Lock Nut, 5/16-18	53	736-0142	Flat Washer, .281 x .50 x .063
15	712-3017	Hex Nut, 3/8-16	54	736-0187	Flat Washer, .64 x 1.24 x .06
16	714-0104	Internal Cotter Pin	55	736-0204	Flat Washer, .344 x .062 x .03
17	714-0111	Cotter Pin	56	736-3004	Flat Washer, .406 x .875 x .105
18	725-0157	Cable Tie	57	738-0155	Shoulder Screw, .437 x 1.62
19	725-1644	Short Spring Switch	58	738-0507B	Shoulder Screw, .5 x .434
20	726-0154	Push-mount Cable Tie	59	741-0225	Hex Flange Bearing
21	726-0320	Insulator Nut Plate	60	741-3065B	Split Hex Flange Bearing
22	732-0716	Extension Spring, .59 x 4.0	61	747-1137	Cruise Control Rod
23	732-0429A	Extension Spring, .5 x 3.97	62	747-1138	Brake Lock Control Rod
24	732-3118	Extension Spring, 3/8 x 1.44	63	748-0413	Cruise Latch
25	736-0140	Flat Washer, .385 x .62 x .063	64	748-0415B	Spacer, 5/16 x 1.54
26	736-0169	Lock Washer, 3/8	65	783-0653F	Steering Support Bracket
27	736-3008	Flat Washer, .344 x .750 x .120	66	783-0663C	Drive Lockout Bracket
28	736-3010	Flat Washer, .407 x .812 x .135	67	783-0773	Brake Pedal
29	738-0372B	Shoulder Spacer, .38	68	783-0693	Transmikssion Axle Bracket
30	747-1119	Hydrostatic Control Rod	69	634-0132	Wheel Assy. Complete, 23 x 9.5 x 12
31	747-1121	Hydrostatic Bypass Rod		634-0194	Rim Only
32	747-1122	Hydrostatic Brake Rod		734-0255	Air Valve (Not Shown)
33	750-0535	Spacer, .376 x .625 x .22		734-1728	Tire Only, Square Shoulder
34	754-0349	Drive Belt	70	734-2290	Hub Cap
35	756-0116	V-idler Pulley, 3.06	71	736-0316	Flat Washer, .780 x 1.59 x .062
36	756-0981A	Flat Idler Pulley, 2.75	72	712-3026	Jam Nut, 3/4-16
37	783-0667A	Transmission Torque Bracket	73	710-1611B	Self-tapping Screw, 5/16-18 x .75
38	783-0745	Speed Control Bracket	74	756-0978A	Engine Pulley
39	783-0782	Switch Actuator Bracket	—	618-0379	Hydrostatic Transmission Assembly


NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665

Yard-Man Yellow: 0674

Powder Black: 0637

Model Z814K



Model Z814K

Ref. No.	Part No.	Description
1.	710-0604A	TT Screw 5/16-18 x 0.625"
2.	732-04035	Compression Spring
3.	738-1020	Shoulder Screw 0.625 x 0.5
4.	736-0407	Bell Washer
5.	712-0459	Flange Lock Nut
6.	736-0222	Lock Washer, 1/4
7.	725-1426	Solenoid: 12 V., 100 amp.
8.	710-0599	TT Screw 1/4-20 x 0.5"
9.	736-0329	Lock Washer, 1/4
10.	723-0444	Battery Strap
11.	712-0271	Hex Sems Nut 1/4-20
12.	712-3087	Wing Nut
13.	783-1033A	Hitch Plate
14.	725-1706	Battery: 12 V., 270 CCA
15.	738-1132	Shoulder Screw
16.	710-0703	Carriage Screw 1/4-20 x 0.75"
17.	712-3006	Hex Nut 1/4-20
18.	783-0349	Battery Tray
19.	683-0304C	Lower Frame Assembly
20.	712-0431	Flange Lock Nut 3/8-16
21.	710-3025	Hex Screw 5/16-18 x 0.625
22.	712-3004A	Flange Lock Nut 5/16-18
23.	756-0978A	Engine Pulley: Electric PTO
24.	683-0618	Clutch Bracket Assembly: 54" Deck
26.	710-1652	Hex Head Washer Screw
27.	783-0891B	Deck Stop
28.	748-0415B	Spacer
29.	783-0653E	Steering Support Bracket
30.	710-0859	Hex Screw 3/8-16 x 2.5"
31.	717-1774	Electric PTO Clutch
32.	736-0322	Flat Washer
33.	736-0171	Lock Washer
34.	710-3157	Hex Bolt 7/16-20 x 3.25"
—	629-0469B	Harness Assembly: Headlight
—	629-04048	Harness Assembly: PTO


NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part numbered 700-xxxx is painted Yard-Man Green, the part number to order would be 700-xxxx-0665.

Yard-Man Green: 0665

Yard-Man Yellow: 0674

Powder Black: 0637

Model Z814K



Model Z814K

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1.	12650	Bracket, Adjustment, Height	40.	717-1553B	Adjustment, Deck, Gear
2.	16606	Bracket, Hook, Retainer	41.	721-04041	Water Nozzle Adaptor
3.	618-0671	Spindle Assembly, Pulley, 5.39 Dia x .5625	43.	731-0335	Roller, Deck
4.	683-0254	Bracket Assembly, Deck, Hanger LH	44.	731-3005	Front Roller
5.	683-0459	Idlr Assembly, 54"	45.	731-3131A	Deflector, Chute
6.	683-0608	Bracket Assembly, Lift, 54"	46.	732-0306	Spring, Compression, .406 x .531 x 1.75
7.	683-0609	Bracket Assembly, LH-Front	47.	732-0459	Spring, Extension, .94 Dia x 6.74
8.	683-0610	Bracket Assembly, RH-Front	48.	732-0934	Spring, Extension, 1.15 Dia x 5.99
9.	683-0617	Stop Assembly, Chute	49.	732-3070	Torsion Spring .44 I.d. x 2.10
10.	703-2093	Baffle, RR, Inner	50.	734-3058B	Deck Wheel, 5" Dia.
11.	703-2392	Bracket	51.	736-0119	Lock Washer
12.	703-3511	Guard, Finger	52.	736-0134	Flat Washer, .812 ID x 1.38 OD x .1
13.	710-0216	Hex Screw 3/8-16 x 0.75	53.	736-0208	Flat Washer, .51 ID x 1.5 OD x .07
14.	710-0514	Hex Screw 3/8-16 x 1.0	54.	736-0760	Lock Washer
15.	710-0528	Hex Screw, 5/16-18 x 1.25	55.	736-0921	Washer, Lock, 1/2 , Regular Duty
16.	710-0602	Screw, Self-tapping, 5/16-18 x 1.000	56.	736-3039	Flat Washer .406 ID X 1.5 x 11ga
17.	710-0726	Screw, AB, 5/16-12 x 0.75	57.	736-3072	Washer, Flat .38 ID x.93 OD x.110
18.	710-0751	Hex Screw, 1/4-20 x .620	58.	737-04003	Water Nozzle: Deck Wash-Out System
19.	710-1644	Screw, Carriage, 3/8-16 x 5.00	59.	738-0295	Shoulder Screw, .750 x .47.12
20.	710-3011	Hex Screw, 3/8-16 x 2.25	60.	738-1229A	Shoulder Screw
21.	710-3073	Hex Screw, 5/16-18 x 2.25	61.	738-3056	Shoulder Screw, 1/2 Dia x 2.50 .
22.	710-3168	Bolt, Carriage, 3/8-16 x 1.0	62.	742-0677	Blade, 18.50"
23.	710-3178	Short Neck Carriage Bolt 3/8-16 x .75	63.	747-1116	Deck Release Handle Rod, .375 Dia
24.	711-0332	Pin, Clevis, .50 Dia x .78	64.	750-0151	Spacer .550 ID x .755 OD x 1.1
25.	711-1737	Pin, Roller, .5" Dia x 10.06 .	65.	750-0212	Spacer, .82 ID x 1.00 OD x .53
26.	711-1762	Pin, Hinge, Dia .375 x 14.06	66.	750-3213	Spacer, .405 x .75 x 3.875
27.	712-0229	Push Nut Retainer	67.	754-0642	Belt, V-Type, B Section
28.	712-0417A	Nut, Hex Flange, 5/8-18	68.	756-3105	Pulley, Idler, 5.0 Dia.
29.	712-0431	Nut, Flange Lock, 3/8-16	69.	783-04013A	Bracket, Stabilizing
30.	712-0641	Hex Nut M16	70.	783-04232	Deck: SD w/Water Nozzle Ftg.
31.	712-3004A	Nut, Flange Lock, 5/16-18, Gr5	71.	783-1453	Bracket, Mounting, 54" Roller
32.	712-3010	Nut, Hex, 5/16-18, Gr5	72.	783-1454	Bracket, Roller, Front
33.	712-3022	Nut, Hex Lock, 1/2-13	73.	783-1455	Bracket, Idler
34.	712-3027	Nut, 1/4-20, Hexflg, Lock	74.	783-1470	Cover, Spindle RH
35.	714-0145	Pin, Click, .092 x 1.64	75.	783-1471	Cover, Spindle LH
36.	714-0470	Pin, Cotter, 1/8 x 1.25	76.	783-1482	RH Skirt
37.	714-3004	Pin, Cotter, 3/32 x 1.25	77.	783-1483	LH Skirt
38.	715-0108	Pin, Sprg, 1/4 Dia x 1.00	78.	783-1484	LH Extension Skirt
39.	715-0246	Pin, Spring, 3/16 x 1.25			