
REVISION 3 PART NO. 17088 Printed in U.S.A. Price .35¢

parts list

HOMELITE®

VI Super 2 VI Super 2 SL





VI SUPER 2, VI SUPER 2 SL


ACCESSORIES

GASKET- Oil pump body	69596
KIT- Spark arrestor (for A-69253-1 Muffler)	A-69586-B
Includes: SCREW- Self tapping	
(#6 x 1/4) (3)	80328
ROPE- Starter #4 (250 ft)	68848
SAFE*T*TIP®	
(standard)	A-70776-A
Includes:	
SCREW (8-32 x .437)	93695
TUBING- Rubber (10 ft.)	70309- 9 9
TUBING- Rubber (10 ft.)	70310-99
CARRY CASE- Black	94216
KtT- Sprocket bar repair	A-70239-C
Includes:	
BEARING- Guide Bar	70737
RIVET- Flaticks, hd.	96623


TOOLS

PULLER- Magneto rotor	A-24747-A
Includes	
BOLT- 5/16 - 18 x 1 3/4	80288
NUT- Hex 5/16 - 18 (2)	81196
WRENCH- Spanner (clutch)	A-93791
Includes	
PIN	23717-A
WRENCH- Flat (for guide bar nut) (Opt.)	24814
DRIVER- Check valve (for HDC-67 carb.)	24972
PLIERS- Tru-Arc	17198






NO	.DESCRIPTION	PART NO	QTY.	NQ.	.DESCRIPTION	PAR1	F NO.	QTY.
1	SCREW- Pan hd (8-32 x 3/8)	80677	3	23	ISOLATOR- Vibration		70485-A	3
2	HANDLE- Throttle (see note 1)	70588-24	۹ آ	24	SPACER- laplator		70433	3
	HANDLE- Throtile (see note 1)	70569-4	1	25	SCREW- Pan washer hd (10-32)	x 5/81	82239	i
3	TRIGGER	70619	Í	26	HANDLE BAR		A-70604	•
4	STOP- Throttle safety	70593	1	27	COVER- Air filter		70571	1
5	LEVER- Throttle safety	70594	1	28	SCREW- Cep hex soc			
6	SPRING- Tarsion	70691	1		(10-32 x 1 3/4)		82310	1
7	SCREW- Pan hd (#10-32 x 5/8)	82239	1	29	BRACKET- Isolator mtg		70558-24	4 1
8	COVER- Handle	70826	1	30	SCREW- Hex hd			
9	ROD- Throttle	A-70614	1		[10-32 x 1 3/16]		80841	2
10	SPRING- Throttle rod	69249	1	31	SRACE- Handle		70664-1	1
11	LEVER- Throtile	69107	1	32	SCREW- Pan hd			
12	ROD- Throitie	70812	1		[10-92 x 1 3/4"]		82317	1
13	SCREW- Cap hex soc hd			33	WASHER- Flat (10)		B400B	1
	(10-32 x 1 3/4) (see note 2)	8231 0	i	34	NUT- Guide ber (1/4-28)		81065-2	1
14	NUT- Hex (10-32)	81206	2	35	WASHER- Flat		69309-A	1
15	WASHER	95813	4	36	PLATE- Guide ber		69360-1	1
16	BUSHING	95814	1	37	HOUSING- Engine			
17	BUSKING	95815	1		(see fig. 2 for breakdown)	-	4-70682-C	1
	SCREW- Mach pen hd	95869	1					
19	GUARD- Hend	95718	5	MAT	E 1: Units prior to Lat #1090 and	lahata B	raka walta r	
20	WASHER- Flat	70632	ſ	140	E I. Billis prior to Edit 1030 Ere	CHEM DI	14NB 417145 1	anty.
	WABHER- legistor	7044û-A	8	NOT	FE 2: For units with steel hand gui	ard 70802	-1 require :	10728
22	RING- Isolator	70432-A	6		believille washer and 70746	apacer, s	nd screw 6	2321.




VI SUPER 2, VI SUPER 2 SL FIGURE 2


NO	DESCRIPTION	PART NO.	QTY.	NO.	DESCRIPTION	PART NO.	QTY.
1	HOUBING- Engine	A-70682-C	 1	44	HOUSING- Rewind Marier	A-70663	1
	Includes:				Includes:		
2	PLATE- Instructions	70835	1	45	FILTER- Fuel tank valve	69443	1
3	SWITCH- Stop (grounding)	A-63938	1	46			
-	Includes:				(10-92 x 5/8)	80572	4
4	PLATE- Dn-Off	70834	1	47		61206	1
5	NUT- Hex	72084-A1		48		69217	1
6	SCREW- Pan hd, 10-24 x 1/2	98620	4	49	ROPE- Starter (#4, 34" long)	A-93874-A	. 1
7	MUFFLER	A-94061-B	i	10	Includes:		
•	Includes:	W-2400 I-P	'	60	WASHER- Nylon	93862	1
8	CAP- Mulfler	A-95428	1	51		69158-A	-
9	\$CREW- (10-24 x 1 3/4)	82320	1	٠.	PULLEY- Starter (alternate)	94562-A	•
	SPARK ARRESTOR	A-94139	i	52	WASHER- Flat	63606-1	
	Includes:	W-34 193	'	63		84085-1	-
10	SPACER	93989	1	54	NUT- Hex	81117	ť
11		D-83991	1	56	WASHER- Look	B3002	ì
12	SCREEN- Spark arrestor			56		60002	'
13	SPACER	83980	١	56		4 00744	1
	SCREW- #4 x .250 (note 6)	82342	Э		(Solid State)	A-96714	1
14	TERMINAL- Spark plug (solid state)				ROTOR & STARTER PAWL	4 40007 B	
	(serviced with Item #15)				(Point ignition—	A-69297-B	1
15	TERMINAL- Spark plug (point ignitter		1		Includes:	4 TROSE D	
16	SPARK PLUG— Champion DJ-7J	8-81868	1	57	KIT- Starter pawl (see note 4)	A-70285-C	
17	See Figure 3			58	CAP- Oil	A-70893-B	1
18	LEAD- Ground (Solid State)	A-94721	Ţ		lackydes:		
18	LEAD- High tension (see note 1)	89328	1	69	GASKET- Fuel filler cap		
20	LEAD- Ground (point ignition)	A-95051	1		(see note 3)	94838-A	
21	SCREW- Hex w/washer (8-32 x 3/4)	B2248	2	60	TANK- OII	A-70583-A	1
22	CORE- Coil (point ignition)	89324	1		Includes:		
23	COIL- Ignition (point (gnition)	69323	1	61	FILTER- Oil	A-68593	7
	RETAINER- Coif (not shown)			82	TUBING- Rubber 6"	70308-24	4 1
	(point ignition)	69326	1	63	LINE- Pressure	A-69358-B	1
24	MODULE: Ignition (Solid State)				Includes:		
	(note 8)	94711	1	64	CONNECTOR- Oil fins	69659-B	1
26	POINT SET- Breaker (point ignition)	A-89338	1	65	VALVE- Check (Duckbill)	89451	1
	Includes:			68	WASHER- Flat (Point Ignition)	84025	2
28	LEAD- Electrical (point ignition)	70249	1		WASHER- Lock (Point ignition)	83060	2
27	SEAL- Lead (point ignition)	69247	i	•		*****	
28	SCREW- FII. hd.						
	(6-32 x 3/8) (point ignition)	86026	2				
29	CLUTCH "S" (see note 2)	A-70351-A	ī	NO	E 1: For solid state ignition out wir	● to 8 1/2".	
30	BEARING- Clutch	68512	i	NOT	E 2: Crankshalts willhout threaded	clutch and regul	re re-
91	SPROCKET & DRUM 3/8" 6-100th	A-70221-G	i		laining ring 93972.	2.0.0	
32	WASHER- Thrust (clutch)	85286	i				
33	NUT- Locking 5/18-24 (see note 2)	81112	i	NOT	'E 3: Use 70826 Gesket in A-70883	and A-70884 ax	temal
34	TANK- Fuel	A-70582-A	i		thread caps. Use 89865 Gaaks	of for caps with in	terna)
35	FILTER- Fuel	96689	ť		ih reads.		
			-		T 4. 6	# 7 1 1	
37	TUBING: Rubber 9 1/2"	70310-38	Ţ	NO.	E 4: Replacement starter pawi kit, it		
38	VALVE- Check (Duckbill)	69451	1		sized pin. Patnt, stemp or men		
39	CAP- Fuel (red)	A-70894-B	1		pin can be installed lightly only		
	Includes:				is removed, the entire rotor easi	swoih wnau be teb	HOM.
40	GASKET- Filler cap (see note 3)	84838-A	1	NOT	E 5: Units with separate shield req	uires index \$13 c	ichtv.
41	GRIP- Starter rops	70211	1		All new mullier cap A-95428 in		
42	WASHER- Fig1	84025	1		to cap.		
43	DECAL (VI Super 2)	70800	1				
	DECAL (VI Super 2SL)	70798	1	NOT	Έ 8: Module 94711 includes items 1	6 and 19.	

VI SUPER 2, VI SUPER 2 SL



NÓ	.DESCRIPTION	PART NO.	QTY.	NO	DESCRIPTION	PART NO.	OTY.
1	CRANKCASE & CYLINDER	•		18	PIBTON & PIN	A-70224-A	
	(Solid State) V(Super 2	A-95072	1	-	Includes		
	CRANKCASE & CYLINDER			16	PISTON RING	70205	1
	(Point Ignation)	A-70228	1	20	RING- Piston retaining	65261	2
	CRANKCASE & CYLINDER			21	SEAL	94838	2
	(Solid State) VI Buper 2SL	A-95073	1	22	SPACER- Seal	69407	2 2 2 2
	CRANKCASE & CYLINDER			23	BEARING- Needle	12630	5
	(Point Ignition	A-70897	1	24	WASHER- Thrust	69093-B	2
	Includes			25	CRANKSHAFT- (Solid State	A-96384	1
2	PIN- Roll (VI Super 2SL only)	70783	2		GRANKSHAFT- (Point (grifton)	A-95385	1
3	SCREW- Tapping pan	• • • • •			Includes		
	(VI Super 2SL only)	93932	2		NUT (not shown)	81112	ſ
á	PLATE- Relaining	•		26	KEY- Magneto (see insert)	69250	1
	(VI Super 2St. only)	70724	1	27	SCREW- Adjusting fill hd		
5	SCREW- Pan hd			•	(8-32 K T)	80220-2	1
	(6-32 x 3/8)	80571	3	26	PIN- Adjusting	89254-1/	4 1
В	COVER- Oil pump	89224-10		29	GASKET- Intake manufold	69148	1
7	SPRING- Oil pump	69447	1	30	MANIFOLD- Intake	A-88373-A	ſ
B	GASKET- Oil pump	69244-1	2	31	GASKET- Carburetor	65016	1
9	PLUNGER- Oil pump	A-12356-B	4	32	CARBURETOR- HDC 87	A-96621	1
ō	BODY- Oil pump	69343-1	ſ	33	CUP- Air tilter	70057	1
ň	BALL- Chack valve	80051	1	34	WASHER- Lock #10	83008-1	2
2	SPR(NG- Check valve	6657D	1	35	SCREW- Hex hd		
3	FITTING- Oil line	70204	2	••	(10-32 x 2 1/4)	80481	2
4	FITTING- Tube	69833	2	38	FILTER ELEMENT- AIR	70566	ī
5	LINE- OII	70161	ī	37	RETAINER- Air filter	70556	1
6	BOLT- Quide ber	88195	1			10000	
7	SCREW- Sems hex hd ,		•				
•	(8-32 x 1)	88044	a				





CARBURETOR A-96621 HDC-67

Repair Kit (includes 1-15) Qasket/Diaphragm kit (includes 11-15) Check valve repair kit (#16) Inlet Needle (#8) Hamelite Division of Textron Inc.

14401 CAROWINDS BOULEVARD CHARLOTTE, NORTH CAROLINA 28217

