


# 125 B

**Spare parts**

<b>Parts List No.</b> 545103429		<b>Husqvarna</b> PARTS LIST	<b>MODEL</b> HVA 125B (US)
<b>Date</b> 5/13/08	<b>Replaces</b> 545103429 - 11/20/07		<b>NOTE</b> : Illustration may differ from actual model due to design changes.




**⚠ WARNING**  
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by Qualified Service Personnel.

Ref.	Part No.	Description	Ref.	Part No.	Description
1.	545081817	Kit - Rope	26.	545081841	Kit - Fuel line grommet (Incl. 25,28)
2.	545043204	Handle - Starter	27.	530150350	Assy - Fuel cap with retainer
3.	530015814	Screw	28.	530095646	Assy - Fuel pickup
4.	545081822	Kit - Cruise Control (Incl. 5,6,7)	29.	545108901	Assy - Fuel tank (Incl. 25,26,27,28)
5.	530015147	Washer - Wave	30.	530015814	Screw - Fuel tank
6.	545111501	Ratchet - Cruise Control	31.	545140401	Foot - Rear Impact
7.	530015814	Screw	32.	530015814	Screw
8.	545140301	Foot - Front Impact	33.	545132801	Scroll - Flywheel
9.	545157901	Assy. - Muffler Guard	34.	530015814	Screw
10.	545108701	Assy - Blower Knob	35.	530015810	Screw
11.	545111301	Wire - Linkage	36.	545088801	Assy - Flywheel
12.	545111601	Trigger - Throttle	37.	530015828	Washer
13.	545131701	Wire - Handle Ground	38.	530016134	Nut - Flywheel
14.	545131301	Impeller	39.	545108802	Cover - Motor housing
15.	530015127	Washer	40.	545112801	Screw
16.	530015197	Nut - Blower Tube Knob	41.	545140801	Hub
17.	545111101	Spring - Vac Door	42.	545081818	Kit - Starter (Incl. 40,41)
18.	545111202	Cover - Vac Door	43.	530042095	Spring - Starter
19.	530015814	Screw	44.	545111801	Housing - Starter Cover
20.	545113002	Assy - Outer scroll (Incl. 17,18)	45.	530015810	Screw
21.	545147101	Nut - Impeller	<b>Not Shown</b>		
22.	545164501	Washer - Impeller	545154658	Manual - Operators	
23.	530016445	Screw			
24.	545110002	Scroll - Inner			
25.	530047721	Bulb - Purge			

✓ = New Part Number For This IPL


★ = Refer to the Service Reference Indicated for more information.(Located at the END of the IPL)

<b>Parts List No.</b> 545103429		<b>Husqvarna</b> PARTS LIST	<b>MODEL</b> HVA 125B (US)
<b>Date</b> 5/13/08	<b>Replaces</b> 545103429 - 11/20/07		<b>NOTE</b> : Illustration may differ from actual model due to design changes.



**⚠ WARNING**

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by Qualified Service Personnel.




Ref.	Part No.	Description	Ref.	Part No.	Description
1.	545111901	Assy - Muffler (Incl. 2,3,4,5)	23.	545108101	Module - Ignition
2.	545081813	Gasket - Muffler (kit)	24.	530016456	Screw
3.	545081810	Kit - Spark Screen (Incl. 5)	25.	545081814	Kit - Piston (Incl. 26,27)
4.	530058982	Bolt - Muffler	26.	530019283	Ring - Piston
5.	530015241	Screw	27.	530015162	Retainer - Piston pin
6.	545049301	Switch	28.	545081816	Kit - Crankshaft
7.	545128201	Protector - Switch	29.	545013401	Bearing
8.	952030249	Accy - Spark Plug (RCJ6-Y)	30.	545081815	Kit - Crankshaft seal
9.	545132601	Cylinder - Chrome	31.	545081813	Seal - Cylinder (kit)
10.	545132501	Boot - Carb.	32.	545068301	Cap - Bearing
11.	530016187	Screw	33.	530015940	Screw
12.	545133301	Plate - Carb.	34.	530015897	Screw
13.	545081813	Gasket - Carb. (kit)	35.	545081813	Kit - Gasket (Incl. 2,13,16,31)
14.	545081811	Kit - Carb. (X5055) (Incl. 13,16)	36.	545081809	Kit - Decal
15.	530047721	Bulb - Purge (Incl. with #25 on page 1)			
16.	545081813	Gasket - Airbox (kit)			
17.	545109801	Base - Airbox			
18.	530016101	Nut - Carb screw			
19.	545112101	Filter - Air			
20.	545109601	Cover - Airbox			
21.	530059796	Assy - Airbox Knob			
22.	545108202	Assy - Leadwire			

✓ = New Part Number For This IPL

★ = Refer to the Service Reference Indicated for more information.(Located at the END of the IPL)

<b>Parts List No.</b> 545103429		<b>Husqvarna</b> PARTS LIST	<b>MODEL</b> HVA 125B (US)
<b>Date</b> 5/13/08	<b>Replaces</b> 545103429 - 11/20/07		<b>NOTE :</b> Illustration may differ from actual model due to design changes.



**⚠ WARNING**

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by Qualified Service Personnel.

Ref.	Part No.	Description
1.	545140201	Assy - Tube - Upper Blower w/barrier
2.	545118001	Tube - Lower Blower
3.	545119501	Flare - Lower Blower tube

✓ = New Part Number For This IPL

★ = Refer to the Service Reference Indicated for more information.(Located at the END of the IPL)