

# 125L (USA, Canada)

**Spare parts**

**Ersatzteile**


**Pièces détachées**

**Reserve onderdelen**

**Repuestos**

**Reservdelar**

<b>Parts List No.</b> 545014390		 <b>Husqvarna</b> ® PARTS LIST	<b>MODEL</b> 125L SST (US/CAN)
<b>Date</b> 01/26/06	<b>NEW</b>		<b>NOTE :</b> Illustration may differ from actual model due to design changes.




**⚠ WARNING**  
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by Qualified Service Personnel.

Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530150561	Assy-Cable/Wire Harness	19.	530015814	Screw
2.	545062001	Housing-Throttle (RH)	20.	530015771	Screw
3.	530016448	Screw	21.	530057554	Bracket-Shield
4.	530016449	Screw	22.	530016014	Screw
5.	530016454	Spring-Trigger	23.	530016301	Screw
6.	545066001	Trigger	24.	530150294	Assy-Dust cup
7.	530059804	Lockout-Throttle	25.	530096295	Assy-Gearbox
8.	545045601	Spring-Lockout	26.	5373383-02	Assy-T25 Cutting Head
9.	545067001	Housing-Throttle (LH)			
10.	545030601	Kit-Switch			
11.	530015820	Bolt			
12.	545042201	Handle-Assist			
13.	545030701	Kit-Driveshaft SST (Incl. decal)			
14.	530059185	Clamp-Handle			
15.	530016152	Wingnut			
16.	545007507	Flex shaft			
17.	545030901	Kit-Shield (Incl. 18,19,20)			
18.	530052286	Limiter-Line			
				<b>Not Shown</b>	
				545058716	Manual
				545059001	Decal-Warning

✓ = New Part Number For This IPL

★ = Refer to the Service Reference Indicated for more information.(Located at the END of the IPL)

<b>Parts List No.</b> 545014390		<b>Husqvarna</b> ® PARTS LIST	<b>MODEL</b> 125L SST (US/CAN)
<b>Date</b> 01/26/06	<b>NEW</b>		<b>Page:</b> 2
<b>NOTE :</b> Illustration may differ from actual model due to design changes.			



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530150253	Filter	25.	545003801	Screw	48.	530403094	Nut
2.	530016101	Nut-Carb. Screw	26.	545029602	Starter Hsg. w/eyelet	49.	530016456	Screw
3.	530057845	Air Box	27.	545029801	Kit-Starter Spring	50.	545017501	Assy-Fan Housing
4.	530057844	Lever - Choke	28.	545029701	Kit-Starter Pulley	51.	530150039	Assy-Clutch Drum
5.	545050402	Kit-Carb. Gasket (Incl 7,61)	29.	530016468	Screw	52.	545050405	Kit-Clutch Assy.
6.	530035596	Adaptor-Carb.	30.	530150567	Assy-Starter Hsg.(Incl. 23,24,26,27,28,29)	53.	530057852	Spacer
7.	545030101	Kit-Gasket (foam)	31.	530059780	Isolator-Tank	54.	530039242	Flywheel
8.	530016400	Bolt	32.	530058982	Bolt-Muffler	55.	545049801	Crankcase-Machined
9.	545001001	Cylinder	33.	530015496	Screw	56.	545013401	Bearing
10.	952030201	Plug-Spark (RCJ-8Y)	34.	530150440	Shield-Heat	57.	545030001	Kit-Crankshaft
11.	545050403	Kit-Crankshaft seal	35.	530016449	Screw	58.	530015162	Retainer-Piston Pin
12.	530016475	Washer-Starter	36.	530059784	Guard-Muffler	59.	530019283	Ring-Piston
13.	530016450	Spring-Starter Cup	37.	545030501	Kit-Spark Arrestor (Incl. 33)	60.	545030301	Kit-Piston (Incl. 58,59)
14.	530150568	Assy-Starter Cup	38.	530057847	Assy-Muffler	61.	545030101	Kit-Gasket (adaptor seal)
15.	530059800	Coupling-Starter	39.	530057848	Gasket-Paper Metal	62.	530015897	Screw
16.	530095646	Assy-Fuel Filter	40.	530015897	Screw	63.	545030401	Kit-Carb. (Incl. 4,5,64)
17.	545030201	Kit-Fuel Line	41.	545046701	Module	64.	545030101	Kit-Gasket (air box)
18.	530150350	Assy-Cap w/ret.(Incl. 19)	42.	530039227	Assy-Leadwire	65.	530057846	Cover-Air Box
19.	530019293	O-ring - Fuel Cap	43.	530016456	Screw	66.	530059796	Assy-Knob
20.	530057853	Assy-Fuel Tank (Incl. 16,17,18,19)	44.	530016030	Washer	67.	545030101	Kit-Gasket (Incl. 5,7,11,19,39,61,64)
21.	530057851	Shroud-Rear	45.	530094189	Washer-Clutch			
22.	530016448	Screw	46.	530016469	Screw			
23.	545029901	Kit-Rope	47.	530016470	Screw			
24.	530150318	Handle-Starter						
							530058709	Bulb-Purge

✓ = New Part Number For This IPL

★ = Refer to the Service Reference Indicated for more information.(Located at the END of the IPL)