







1.1995 Spare parts Ersatzteile Pièces détachées Reserve onderdelen Repuestos Reservdelar NUDEL NUMBER 200

| PART NUMBER SQUARE N | OTE PART NUMBER SQUARE NOTE | PART NUMBER SQUARE NOTE | PART NUMBER SQUARE NOTE |
|---|---|--|-------------------------|
| 501 48 54-01 D 501 78 97-01 E 501 78 98-01 E 501 79 01-01 E 501 79 04-01 E 501 79 07-01 J 501 79 08-01 J 501 89 11-01 E 501 93 13-01 J 501 94 03-01 A | 531 00 29-31 C 531 00 29-32 C 531 00 29-32 C 531 00 29-32 C 531 00 29-33 C 531 00 29-34 C 531 00 29-35 I 531 00 29-36 I 531 00 29-37 I 531 00 29-38 I 531 00 29-39 I 531 00 29-34 I | 531 00 30-83 A 531 00 30-84 A 531 00 30-85 A 531 00 30-85 A 531 00 30-86 A 531 00 30-87 A 531 00 30-88 A 531 00 30-89 A 531 00 30-90 A 531 00 30-91 A 531 00 30-92 A | |
| 501 94 04-01 A 501 94 06-01 A 501 94 07-01 A 501 94 08-01 A 501 94 09-01 A 501 94 10-01 A 501 94 11-01 A 501 94 14-01 A 501 94 19-01 A 501 94 26-01 K | 531 00 29-41 I 531 00 29-42 E 531 00 29-43 E 531 00 29-44 E 531 00 29-45 E 531 00 29-46 E 531 00 29-47 E 531 00 29-48 E 531 00 29-49 J 531 00 29-50 J | 531 00 30-93 A 531 00 30-94 A 531 00 30-95 A 531 00 30-95 A 531 00 30-96 A 723 53 35-55 A 724 33 28-51 A 734 11 56-01 A 738 21 01-01 A 738 21 01-04 A | |
| 501 94 28-01 K 502 12 85-01 A 503 02 02-01 G 503 20 12-01 A 503 20 12-02 A 503 20 51-01 K 503 21 48-01 D 503 21 83-14 C 503 21 83-18 DF 503 21 83-19 C | 531 00 29-51 J 531 00 29-52 J 531 00 29-53 J 531 00 29-54 J 531 00 29-55 J 531 00 29-56 J 531 00 29-57 J 531 00 29-58 J 531 00 29-59 J 531 00 29-59 J 531 00 29-60 J | | |
| 503 21 83-20 H 503 21 83-26 F 503 21 83-31 A 503 21 83-39 J 503 22 02-01 G 503 22 20-01 I 503 22 23-03 A 503 23 50-11 D 503 25 01-02 G 503 25 31-01 G | 531 00 29-61 H 531 00 29-62 A 531 00 29-63 A 531 00 29-64 A 531 00 29-65 A 531 00 29-70 A 531 00 29-71 A 531 00 29-72 A 531 00 29-73 A 531 00 29-75 A | | |
| 503 26 05-03 H 503 27 11-01 G 505 52 01-13 B 505 52 01-25 B 505 52 01-27 B 531 00 25-66 B 531 00 25-67 J 531 00 29-00 B 531 00 29-08 H 531 00 29-09 H | 531 00 29-77 A 531 00 29-78 A 531 00 29-79 K 531 00 29-80 B 531 00 29-81 B 531 00 29-82 B 531 00 29-83 B 531 00 29-83 B 531 00 29-84 B 531 00 29-85 B 531 00 29-85 B | | |
| 531 00 29-10 H 531 00 29-11 H 531 00 29-12 H 531 00 29-12 F 531 00 29-13 F 531 00 29-14 F 531 00 29-15 F 531 00 29-16 F 531 00 29-17 F 531 00 29-18 G 531 00 29-19 G | 531 00 29-87 B 531 00 29-88 B 531 00 29-89 B 531 00 29-90 B 531 00 29-90 B 531 00 29-91 B 531 00 29-92 B 531 00 29-93 B 531 00 29-94 B 531 00 29-95 B 531 00 29-95 B 531 00 29-96 B | | |
| 531 00 29-20 G 531 00 29-21 D 531 00 29-22 D 531 00 29-23 D 531 00 29-23 D 531 00 29-24 D 531 00 29-25 C 531 00 29-26 C 531 00 29-27 C 531 00 29-28 BC 531 00 29-29 C | 531 00 29-97 B 531 00 29-98 B 531 00 29-99 B 531 00 30-75 A 531 00 30-76 A 531 00 30-77 A 531 00 30-78 A 531 00 30-78 A 531 00 30-79 A 531 00 30-80 A 531 00 30-81 A | | |
| 531 00 29-30 C | 531 00 30-82 A | : | |





