


26 RLC



1. 1988

Spare parts

Pièces détachées

PARTS LIST NO. 530 06 75-17 - 11/7/88		HUSQVARNA PARTS LIST	Trimmer Model: 26 RLC
Page No. 3	REPLACES NONE	Note: Illustrations may differ from actual models due to design changes	

Key No.	Part No.	Description	Key No.	Part No.	Description
1	530 01 57-73	Screw	40	530 01 57-87	Retaining Ring
2	530 02 75-29	Air Filter Cover	41	530 01 91-58	Crankshaft Seal
3	530 02 75-30	Air Filter	42	530 03 21-02	Outer Bearing
4	530 01 57-66	Screw	43	530 01 57-89	Crankshaft Retaining Ring
5	530 02 75-28	Spacer	44	530 01 57-17	Screw
6	530 01 52-54	Wave Washer	45	530 02 77-81	Muffler Guard
7	530 02 75-26	Choke Shutter	46	530 06 92-57	Muffler Kit
8	530 02 75-27	Air Filter Plate	47	530 02 49-03	Muffler Attachment Spring
9	530 06 92-47	Fuel Line Kit	48	530 01 22-47	Cylinder
10	530 01 08-97	Fuel Pick-up Ass'y.	49	530 03 00-77	Spark Plug
11	530 03 52-59	Carburetor	50	530 01 52-39	Screw
12	* 530 01 91-56	Carburetor Gasket	51	530 03 91-34	Ignition Module Kit
13	530 01 08-07	Fuel Cap Ass'y.	52	530 01 57-76	Screw
14	530 01 57-75	Screw	53	530 03 91-36	Flywheel Ass'y.
15	530 02 75-49	Throttle Cable Ass'y.	54	530 02 75-72	Flywheel Counterweight
16	530 02 91-88	Shroud & Tank Ass'y.	55	530 02 91-89	Fan Housing
17	* 530 01 91-54	Crankcase/Shroud Gasket	56	530 06 92-91	Starter Pulley Kit (Incl. #75)
18	530 02 75-93	Reed			Starter Spring
19	530 02 75-94	Reed Stop	57	530 02 75-31	Starter Handle
20	530 01 09-60	Connecting Rod Ass'y. (Incl. Bearings)	58	530 02 75-69	Rope Kit
21	530 01 09-34	Crankshaft Ass'y.	59	530 06 92-32	Pulley Housing Ass'y.
22	530 01 51-26	Flywheel Key	60	530 01 41-14	Clutch Washer
23	530 01 57-72	Screw	61	530 09 41-89	Clutch Ass'y. Kit
24	530 01 57-80	Screw	62	530 06 92-54	Washer
25	530 02 75-46	Kill Switch Insulator	63	530 01 57-96	Nut
26	530 02 75-47	Lead Wire	64	530 00 17-33	Clutch Housing
27	530 01 57-71	Screw	65	530 01 41-15	Screw
28	530 01 40-16	Crankcase Ass'y. (Incl. #39,40,41, & 42)	66	530 01 57-67	Spacer
29	530 02 75-45	Kill Switch Ramp	67	530 02 75-11	Screw
30	530 02 79-58	Kill Switch Button	68	530 01 57-70	Screw
31	530 02 79-59	Kill Switch Spring	69	530 01 57-69	Screw
32	530 01 40-15	Crankcase & Crankshaft Ass'y (#38,39,40,41,42,& 43)	70	530 01 54-96	Retainer
33	530 01 52-41	Screw	71	530 02 75-23	Locknut
34	530 01 51-62	Piston Pin Retainer	72	530 01 57-68	Engine Gasket Kit (*Indicates Contents)
35	530 02 73-69	Piston Ring	73	530 06 92-76	Spark Arrestor Kit
36	* 530 01 91-61	Cylinder Gasket	74	952 70 16-12	Screw
37	530 06 92-40	Piston Kit (Incl. #34,35 & pin)	75	530 01 58-23	
38	530 01 57-88	Spacer			
39	530 03 21-03	Inner Bearing			
			Not Shown		
				530 02 91-90 530 02 92-67	Instruction Decal Shroud Decal

Key No.	Part No.	Description	Key No.	Part No.	Description
1	530 03 50-14	* + Metering Diaphragm	11	530 03 50-31	+ Metering Lever
2	530 03 51-51	* + Metering Diaphragm Gasket	12	530 03 51-88	+ Metering Lever Spring
3	530 03 51-47	* + Circuit Plate Gasket	13	530 03 51-06	+ Inlet Needle Valve
4	530 03 51-42	Hi Speed Needle	14	530 03 51-78	+ Inlet Screen
5	530 03 50-36	Hi Speed Needle Spring	15	530 03 51-66	* + Pump Diaphragm
6	530 03 51-41	Idle Needle	16	530 03 51-64	* + Pump Gasket
7	530 03 50-23	Idle Needle Spring	17	530 03 52-60	Carb. Kwik Repair Kit (+ Indicates Contents)
8	530 03 52-03	Idle Speed Screw	18	530 03 51-85	Carb. Gasket/Diaphragm Kit (*Indicates Contents)
9	530 03 52-08	Idle Speed Spring			
10	530 03 50-28	+ Metering Pin			

Key No.	Part No.	Description	Key No.	Part No.	Description
1	530 02 75-95	Grip	15	530 09 45-43	Dust Cup
2	530 01 57-68	Nut	16	530 09 45-51	Drive Shaft
3	530 09 46-41	Drive Shaft Housing	17	530 03 11-11	Hex Wrench (5/32)
4	530 01 09-57	Handle Ass'y.	18	530 03 01-02	Shaft Lubrication
5	530 01 51-97	Nut			
6	530 01 57-74	Screw			
7	530 01 09-59	Throttle Housing Ass'y.			
8	530 06 92-52	"T" Handle Kit			
9	530 06 92-82	Shield Kit Ass'y. (Incl. #10,11,12 & 14)			
10	530 01 53-37	Screw			
11	530 09 45-70	Line Limiter	Decals		
12	530 01 52-17	Locknut	A	530 02 74-30	Shaft Warning Decal
13	530 09 36-53	Shield Bracket			
14	530 09 22-43	Screw	Not Shown	530 06 75-16	Operator's Manual

PARTS LIST NO.
530 06 75-17 - 11/7/88


HUSQVARNA PARTS LIST

Trimmer Model:
26 RLC

Page No. 2


REPLACES
NONE

Note: Illustrations may differ from actual models due to design changes



PARTS LIST NO. 530 06 75-17 - 11/7/88	HUSQVARNA PARTS LIST	Trimmer Model: 26 RLC
REPLACES NONE	<i>Note: Illustrations may differ from actual models due to design changes</i>	

Carburetor Assembly Part Number 530-035259



PARTS LIST NO.
530 06 75-17 - 11/7/88


HUSQVARNA PARTS LIST

Trimmer Model:
28 RLC

REPLACES
NONE

Note: Illustrations may differ from actual models due to design changes

- | | | |
|---|--------------|---------------------|
| 1 | 952 70 16-04 | Cutting Head Ass'y. |
| 2 | 530 09 45-62 | Hub Ass'y. |
| 3 | 530 09 45-25 | Spring |
| 4 | 530 09 45-23 | Spool Post |
| 5 | 530 01 55-42 | Screw |
| 6 | 952 70 16-06 | Spool w/Line |
| 7 | 530 09 45-22 | Release Button |
| 8 | 530 09 45-21 | Cover |



Lubrication

18